

R&S® SMA100B

RF Signal Generator

User Manual



This document describes the R&S®SMA100B models, stock no. 1419.8888.02/.04 and its options:

- R&S®SMAB-B1H
- R&S®SMAB-B28
- R&S®SMAB-B29
- R&S®SMAB-B32/-B34/-B35/-B37/-B39
- R&S®SMAB-B80/-B85
- R&S®SMAB-B81/-B82
- R&S®SMAB-B86
- R&S®SMAB-B92/-B93
- R&S®SMAB-B103/-B106/-B112/-B120/-B131/-B140(N)/-B150(N)/-B167(N)
- R&S®SMAB-B709/-B710(N)/-B711(N)
- R&S®SMAB-K22/-K23/-K24/-K27
- R&S®SMAB-K25
- R&S®SMAB-K31/-K33
- R&S®SMAB-K40
- R&S®SMAB-K703
- R&S®SMAB-K704
- R&S®SMAB-K720/-K721
- R&S®SMAB-K722
- R&S®SMAB-K723
- R&S®SMAB-K724

This manual describes firmware version FW 4.60.112.xx and later of the R&S®SMA100B.

© 2019 Rohde & Schwarz GmbH & Co. KG

Mühlhofstr. 15, 81671 München, Germany

Phone: +49 89 41 29 - 0

Fax: +49 89 41 29 12 164

Email: info@rohde-schwarz.com

Internet: www.rohde-schwarz.com

Subject to change – Data without tolerance limits is not binding.

R&S® is a registered trademark of Rohde & Schwarz GmbH & Co. KG.

Trade names are trademarks of the owners.

1178.3834.02 | Version 06 | R&S®SMA100B

Throughout this manual, products from Rohde & Schwarz are indicated without the ® symbol, e.g. R&S®SMA100B is indicated as R&S SMAB. Linux® is abbreviated as Linux.

Contents

1	Preface	17
1.1	Key Features	17
1.2	About this Manual	17
1.3	Documentation Overview	18
1.3.1	Getting Started Manual.....	19
1.3.2	User Manuals and Help.....	19
1.3.3	Service Manual.....	19
1.3.4	Instrument Security Procedures.....	19
1.3.5	Basic Safety Instructions.....	19
1.3.6	Data Sheets and Brochures.....	19
1.3.7	Release Notes and Open Source Acknowledgment (OSA).....	20
1.3.8	Application Notes, Application Cards, White Papers, etc.....	20
2	Safety Information	21
3	Getting Started	22
3.1	Preparing for Use	22
3.1.1	Putting into Operation.....	22
3.1.1.1	EMI Suppression.....	23
3.1.1.2	Unpacking and Checking the Instrument.....	23
3.1.1.3	Accessory List.....	24
3.1.1.4	Placing or Mounting the Instrument.....	24
3.1.1.5	Connecting AC Power.....	25
3.1.1.6	Turning the Instrument On and Off.....	26
3.1.1.7	Functional Check.....	27
3.1.1.8	Checking the Supplied Options and Licenses.....	28
3.1.2	Connecting USB Devices.....	28
3.1.3	Setting Up a Network (LAN) Connection.....	29
3.1.3.1	Connecting the Instrument to the Network.....	29
3.1.3.2	Using Computer Names (Hostnames).....	30
3.1.3.3	Assigning the IP Address.....	31
3.2	Instrument Tour	32
3.2.1	Front Panel Tour.....	33

3.2.1.1	Touchscreen.....	34
3.2.1.2	Utility Keys.....	35
3.2.1.3	On/Standby.....	35
3.2.1.4	Function Keys.....	35
3.2.1.5	Keypad.....	36
3.2.1.6	Navigation Controls.....	36
	Rotary Knob.....	36
	Editing Keys.....	36
	Navigation Keys.....	37
3.2.1.7	Display Keys.....	37
3.2.1.8	USB Connector.....	38
3.2.1.9	SD card slot.....	38
3.2.1.10	Sensor.....	38
3.2.1.11	RF 50 Ω.....	39
3.2.1.12	Pulse Signal Connectors.....	40
3.2.1.13	LF Modulation Connectors.....	40
3.2.1.14	Clock Synthesizer Connectors.....	40
3.2.2	Rear Panel Tour.....	40
3.2.2.1	Connectors.....	42
3.3	Trying Out the Instrument.....	44
3.3.1	Generating an Unmodulated Carrier.....	44
3.3.2	Generating an RF Frequency Sweep Signal.....	47
3.3.3	Saving and Recalling Settings.....	49
3.4	Instrument Control.....	51
3.4.1	Possible Ways to Operate the Instrument.....	52
3.4.2	Means of Manual Interaction.....	52
3.4.3	Understanding the Display Information.....	53
3.4.3.1	Status Bar.....	53
3.4.3.2	Tile Diagram.....	53
3.4.3.3	Taskbar.....	54
3.4.3.4	Additional Display Characteristics.....	55
3.4.4	Accessing the Functionality.....	56
3.4.5	Entering Data.....	57

3.4.5.1	Entering Numeric Parameters.....	58
3.4.5.2	Entering Alphanumeric Parameters.....	58
3.4.5.3	Undo and Redo Actions.....	58
3.4.6	Getting Information and Help.....	58
3.4.7	Remote Control.....	60
3.4.8	Remote Operation over VNC.....	61
4	RF Signal Configuration.....	62
4.1	Activating RF Signal Output.....	63
4.2	How to Set the Frequency and Level.....	63
4.3	RF Frequency Settings.....	65
4.4	RF Level Settings.....	67
4.5	RF Phase Settings.....	72
5	Analog Modulations.....	74
5.1	Required Options.....	74
5.2	Modulation Types and Signal Sources.....	74
5.3	Activating Analog Modulations.....	76
5.4	Modulation Settings.....	77
5.4.1	Pulse Modulation.....	77
5.4.2	FM, PhiM and AM Modulation Settings.....	78
5.4.3	Pulse Generator.....	85
5.4.3.1	Pulse Generator > General Settings.....	86
5.4.3.2	Pulse Generator > Pulse Train Settings.....	90
5.4.3.3	Import/Export List Files.....	94
5.4.4	Pulse Graph.....	97
5.4.5	Pulse External / Trigger Settings.....	98
5.4.6	FM, PhiM and AM Modulation Sources.....	99
5.4.6.1	Source > LF Generator Settings.....	100
5.4.6.2	Source > External Settings.....	104
5.4.6.3	Source > Noise Generator Settings.....	105
5.4.7	LF Signal Output Settings.....	106
5.4.8	Overview.....	108
5.5	How to Generate an Amplitude Modulated Signal.....	110
5.6	How to Generate a Pulse Modulated Signal.....	110

5.7	How to Generate a Pulse Train Modulated Signal.....	111
6	Avionic Standards.....	113
6.1	Required Options.....	113
6.2	About the Avionics Options.....	113
6.2.1	VHF Omni Directional Radio Range (VOR).....	114
6.2.2	Instrument Landing System (ILS).....	115
6.2.3	Automatic Direction Finder (ADF).....	118
6.3	VOR Configuration and Settings.....	119
6.3.1	General Settings.....	119
6.3.2	Signal Settings.....	122
6.3.3	Position Settings.....	124
6.3.4	COM/ID Settings.....	125
6.4	ILS Configuration and Settings.....	127
6.4.1	General Settings.....	127
6.4.2	ILS Glide Slope Settings.....	130
6.4.2.1	General Settings.....	130
6.4.2.2	Signal Settings.....	133
6.4.2.3	Amplitude Settings.....	134
6.4.3	ILS Localizer Settings.....	137
6.4.3.1	General Settings	137
6.4.3.2	Signal Settings.....	139
6.4.3.3	Amplitude Settings.....	141
6.4.3.4	COM/ID Settings.....	144
6.4.4	ILS Marker Beacons Settings.....	146
6.4.4.1	General Settings.....	147
6.4.4.2	Signal Settings.....	148
6.4.4.3	COM/ID Settings.....	149
6.5	ADF Configuration and Settings.....	151
6.5.1	General Settings.....	152
6.5.2	COM/ID Settings.....	154
7	List and Sweep Mode.....	157
7.1	Signal Generation and Triggering in the Sweep and List Modes.....	159
7.2	About Sweep Mode.....	166

7.2.1	Correlating Parameters in Sweep Mode.....	167
7.2.2	Sweep Signal Shapes.....	169
7.3	About List Mode.....	170
7.4	Significant Parameters and Functions.....	171
7.5	Sweep Mode Settings.....	172
7.5.1	General Sweep Settings.....	173
7.5.2	Frequency Range Settings.....	178
7.5.3	Level Range Settings.....	180
7.5.4	Output Settings.....	182
7.5.5	Edit Marker Settings.....	183
7.6	List Mode Settings.....	185
7.6.1	General Settings.....	186
7.6.2	List Mode Data Settings.....	188
7.6.3	Import/Export Settings.....	189
7.7	List Editor.....	191
7.8	How to Generate a Signal in List or Sweep Mode.....	195
8	Improving Level Performance.....	197
8.1	Attenuator.....	197
8.1.1	Attenuator Settings.....	198
8.1.2	Reverse Power Protection.....	200
8.2	Automatic Level Control (ALC).....	200
8.2.1	ALC Settings.....	201
8.3	User Correction.....	202
8.3.1	User Correction Settings.....	205
8.3.2	List Editor.....	206
8.3.3	Fill with Sensor.....	210
8.3.4	Import/Export List Files.....	211
8.4	Using Power Sensors.....	214
8.4.1	Connecting R&S NRP Power Sensors to the R&S SMA100B.....	214
8.4.2	NRP Sensor Mapping.....	215
8.4.3	NRP Power Viewer.....	217
8.4.3.1	About.....	217
8.4.3.2	NRP Power Viewer Settings.....	219

8.4.4	NRP-Z Power Analysis.....	225
8.4.4.1	About.....	225
8.4.4.2	Accessing the NRP-Z Power Analysis Functionality.....	227
8.4.4.3	Required Options.....	229
8.4.4.4	Test Setup Example.....	229
8.4.4.5	NRP-Z Traces/Markers Settings.....	230
	Traces Settings.....	231
	Markers Settings.....	233
8.4.4.6	NRP-Z Configure Settings.....	234
	Configure Measurement Settings.....	234
	Configure Sensors Settings.....	238
	Configure Diagram.....	242
	Configure Time Mode Settings.....	243
	Trace Settings.....	244
	Pulse Data Notifications Settings.....	246
	Trigger Settings.....	251
	Gate Mode Settings.....	253
	Next Window List.....	255
8.4.4.7	Creating Screenshots of Power Analysis Settings	259
	Save (Power Analysis) Settings.....	259
	How to Save a Hardcopy of the Power Analysis Window.....	265
8.4.4.8	How to Setup a Frequency Sweep Measurement.....	266
8.4.4.9	How to Setup a Power Sweep Measurement.....	267
8.4.4.10	How to Setup a Pulse Measurement.....	268
8.4.4.11	How to Configure the Power Analysis Diagram.....	269
8.5	How to Calibrate the Power Level with an R&S NRP Power Sensor.....	269
9	Reference Oscillator.....	273
9.1	Required Options.....	273
9.2	Using the Reference Frequency for Instruments Synchronization.....	273
9.3	Reference Frequency Settings.....	276
9.4	Reference Output Settings.....	280
9.5	Adjustment Settings.....	281
10	Clock Synthesis.....	283

11	File and Data Management.....	287
11.1	About the File System.....	287
11.2	Restoring the (Default) Instrument Configuration.....	290
11.2.1	Preset, Set to Default and Factory Preset Settings.....	292
11.2.2	How to Identify Parameters Which Are Not in a Preset State.....	293
11.2.3	How to Recall User Settings Automatically after Preset.....	293
11.2.4	Reference.....	294
11.3	Protecting Data.....	295
11.4	Saving and Recalling Instrument Settings.....	296
11.4.1	Save/Recall Settings.....	296
11.4.2	How to Save and Recall Instrument Settings.....	299
11.5	Accessing Files with User Data.....	300
11.5.1	File Select Settings.....	300
11.6	Exporting Remote Command Lists.....	302
11.7	Loading, Importing and Exporting Lists.....	303
11.8	Using the File Manager.....	303
11.8.1	File Manager Settings.....	304
11.8.2	Map Network Share Settings.....	305
11.8.3	How to Display All Saved Files.....	307
11.8.4	How to Map a Network Folder.....	307
11.9	How to Transfer Files from and to the Instrument.....	310
11.9.1	Removing File System Protection.....	310
11.9.2	Accessing the File System of the R&S SMA100B Via ftp.....	312
11.9.3	Accessing the R&S SMA100B File System Via SMB (Samba).....	313
11.9.4	Using a USB Storage Device for File Transfer.....	315
11.9.5	Using a File Server for Test Files Exchange.....	315
11.10	Creating Screenshots of Current Settings.....	316
11.10.1	Hardcopy Settings.....	316
11.10.2	How to Save a Hardcopy of the Display.....	320
12	General Instrument Functions.....	322
12.1	Customizing the User Interface.....	322
12.1.1	Display and Keyboard Settings.....	323
12.1.2	Display Update Settings.....	324

12.1.3	Defining the RF Signal State On Power On	325
12.1.4	How to Set the Initial Instrument Settings.....	326
12.1.4.1	Setting the Keyboard Language.....	326
12.1.4.2	Setting the Screen Saver.....	326
12.2	Organizing Frequently Used Settings as Favorites.....	327
12.2.1	Using the User Menu for Fast Adjustments.....	328
12.2.2	Define User Key Actions Settings.....	330
12.2.3	Assigning Actions to the [★ (User)] Key.....	331
12.3	Managing Licenses and License Keys.....	333
12.3.1	Manage License Keys Settings.....	333
12.3.2	How to Move a Portable License.....	335
12.4	Using the Security Settings.....	337
12.4.1	Protection Level Settings.....	338
12.4.2	Setting Security Parameters.....	339
12.4.2.1	Update Policy Security Settings.....	339
12.4.2.2	Disk & Memory Security Settings.....	340
12.4.2.3	Manual Operation Security Settings.....	342
12.4.3	Configuring LAN Services.....	345
12.4.4	Password Management.....	347
12.5	Undoing or Restoring Actions.....	349
12.6	Shutting Down and Rebooting the Instrument.....	350
13	Network Operation and Remote Control.....	351
13.1	Overview of Remote Access Modes.....	351
13.2	Remote Control Interfaces and Protocols.....	353
13.2.1	LAN Interface.....	354
13.2.1.1	VISA Resource Strings.....	354
13.2.1.2	HiSLIP Protocol.....	356
13.2.1.3	VXI-11 Protocol.....	356
13.2.1.4	Socket Communication.....	356
13.2.2	USB Interface.....	357
13.2.2.1	USB Resource String.....	357
13.2.3	GPIB Interface (IEC/IEEE Bus Interface).....	358
13.2.4	LXI Browser Interface.....	358

13.3 Remote Control Programs and Libraries.....	359
13.3.1 VISA Library.....	359
13.3.2 Possible Setups and Access Functions.....	360
13.4 Remote Access Settings.....	362
13.4.1 Network Settings.....	363
13.4.2 VISA Resource Strings.....	366
13.4.3 GPIB Address Settings.....	367
13.4.4 RS232 Settings.....	367
13.4.5 Instrument Emulations Settings.....	368
13.4.6 Remote Connections Settings.....	369
13.4.6.1 Active Connections.....	369
13.4.6.2 Closed Connections.....	370
13.4.7 QR Code.....	371
13.5 LXI Settings.....	372
13.5.1 LXI Status Settings.....	372
13.5.2 LXI Browser Settings.....	374
13.5.2.1 LAN Configuration.....	375
IP Configuration.....	375
Advanced Config.....	376
Ping Client.....	376
SCPI Remote Trace.....	377
Data Sheet.....	378
13.6 How to Find the VISA Resource String.....	379
13.7 How to Change the GPIB Instrument Address.....	380
13.8 How to Set Up a Remote Control Connection.....	380
13.8.1 Establishing a Remote Control Connection over the LXI Browser Interface.....	381
13.8.2 Establishing a Remote Control Connection over LAN Using VXI-11 Protocol.....	382
13.8.3 Setting Up a Remote Control Connection over LAN Using Socket Communication...	387
13.8.4 Setting Up a Remote Control Connection over GPIB.....	388
13.8.5 Setting Up a Remote Control Connection over USB.....	389
13.9 Tracing SCPI Commands and Messages Exchanged via the LXI Web Browser Interface.....	389
13.10 How to Return to Manual Operation.....	390
13.11 Automating Tasks with Remote Command Scripts.....	391

13.11.1	Show SCPI Command.....	393
13.11.2	Displaying an SCPI List.....	394
13.11.3	SCPI Recording Export Settings.....	394
13.12	How to Find Out the SCPI Command Corresponding to the Manual Operation via Show SCPI Command.....	396
13.13	How to Find Out the SCPI Command Corresponding to the Manual Operation Using the Online Help.....	396
13.14	How to Record / Create SCPI Lists.....	397
13.15	How to Convert and Save SCPI Lists.....	400
13.16	How to Set Up Remote Operation via VNC.....	401
13.16.1	Setting Up a Remote Operation from a Desktop System.....	401
13.16.1.1	Using a Web Browser.....	401
13.16.1.2	Using a VNC Client Software.....	402
13.16.2	Setting Up a Remote Operation from a Smart Device.....	404
13.16.2.1	Using a VNC App.....	405
13.16.2.2	Using a Web Browser with HTML5.....	405
13.16.2.3	Special Mode QR Code	406
13.17	References.....	407
13.17.1	LXI Functionality.....	407
13.17.2	Code Generator Templates.....	407
13.17.3	Remote Control States	409
14	Remote Control Commands.....	411
14.1	Conventions used in SCPI Command Descriptions.....	411
14.2	Programming Examples.....	412
14.3	Common Commands.....	412
14.4	Preset Commands.....	417
14.5	MMEMory Subsystem.....	418
14.5.1	File Naming Conventions.....	419
14.5.2	Accessing Files in the Default or in a Specified Directory.....	420
14.5.3	Programming Examples.....	421
14.5.4	Remote Control Commands.....	423
14.6	CALibration Subsystem.....	428
14.7	CSYNthesis Subsystem.....	431
14.8	DIAGnostic Subsystem.....	436

14.9	DISPlay Subsystem	438
14.10	FORMat Subsystem	443
14.11	HCOPY Subsystem	444
14.11.1	Hard Copy Settings.....	445
14.11.2	Automatic Naming.....	447
14.12	KBOard Subsystem	449
14.13	OUTPut Subsystem	450
14.14	Power Sensor Measurement Subsystems	454
14.14.1	CALCulate Subsystem.....	455
14.14.2	DISPlay Subsystem.....	459
14.14.3	INITiate Command.....	460
14.14.4	SENSE SWEep Subsystem.....	460
14.14.5	TRACe Subsystem.....	493
14.15	SENSE, READ, INITiate and SLISt Subsystems	503
14.16	SOURce Subsystem	516
14.16.1	Analog Modulation Subsystems.....	517
14.16.1.1	SOURce:MODulation Subsystem.....	517
14.16.1.2	SOURce:AM Subsystem.....	518
14.16.1.3	SOURce:FM Subsystem.....	524
14.16.1.4	SOURce:PM Subsystem.....	529
14.16.1.5	SOURce:PULM Subsystem.....	533
	Pulse Modulation Settings.....	534
	Pulse Train Settings.....	539
	Pulse Train Data Exchange.....	542
14.16.2	Avionic Standards Subsystems.....	544
14.16.2.1	Programming Examples.....	545
14.16.2.2	General Commands.....	549
14.16.2.3	SOURce:ADF Subsystem.....	552
14.16.2.4	SOURce:ILS Subsystem.....	555
14.16.2.5	SOURce:VOR Subsystem.....	578
14.16.3	SOURce:CORRection Subsystem.....	586
14.16.3.1	Correction Settings.....	589
14.16.3.2	Correction Data Exchange.....	592

14.16.4	SOURce:FREQuency Subsystem.....	594
14.16.5	SOURce:INPut Subsystem.....	602
14.16.6	SOURce:LFOutput Subsystem.....	603
14.16.6.1	LF Generator Settings.....	605
14.16.6.2	LF Sweep Settings.....	613
14.16.7	SOURce:LIST Subsystem.....	616
14.16.7.1	List Mode Settings.....	619
14.16.7.2	List Mode File Operation.....	624
14.16.7.3	List Mode Data Exchange.....	626
14.16.8	SOURce:NOISe Subsystem.....	629
14.16.8.1	Noise Generator.....	629
14.16.9	SOURce:PGEN Subsystem.....	630
14.16.10	SOURce:PHASe Subsystem.....	632
14.16.11	SOURce:POWer Subsystem.....	633
14.16.12	SOURce:ROSCillator Subsystem.....	642
14.16.13	SOURce:SWEep Subsystem.....	647
14.17	SYSTem Subsystem.....	657
14.18	STATus Subsystem.....	682
14.19	TEST Subsystem.....	686
14.20	TRIGger Subsystem.....	687
14.21	UNIT Subsystem.....	690
15	Maintenance.....	691
15.1	Cleaning.....	691
15.2	Storing and Packing.....	692
15.3	Performing Maintenance Tasks.....	692
15.3.1	Date and Time Settings.....	694
15.3.2	Check Front Panel.....	696
15.3.2.1	Check Front Panel Settings.....	696
15.3.2.2	How to Test the Front Panel.....	697
15.3.3	Internal Adjustment Settings.....	699
15.3.4	FPGA/uC Update Settings.....	702
15.3.5	Requesting Instrument Configuration and Specifications.....	703
15.3.5.1	Hardware Configuration Settings.....	703

15.3.5.2	Versions/Options Settings.....	705
15.3.5.3	Requesting the Data Sheet.....	706
16	Troubleshooting and Error Messages.....	707
16.1	Error Messages.....	707
16.1.1	Volatile Messages.....	707
16.1.2	Permanent Messages.....	707
16.2	SCPI-Error Messages.....	708
16.3	Device-Specific Error Messages.....	708
16.4	Querying Error Messages.....	710
16.5	Resolving Network Connection Failures.....	712
16.6	Collecting Information for Technical Support.....	713
	Annex.....	715
A	Reference Information for Remote Control.....	715
A.1	Additional Basics on Remote Control.....	715
A.1.1	Messages.....	715
A.1.2	LAN Interface Messages.....	716
A.1.3	SCPI Command Structure.....	716
A.1.3.1	Syntax for Common Commands.....	717
A.1.3.2	Syntax for Device-Specific Commands.....	717
	Long and short form.....	718
	Numeric Suffixes.....	718
	Optional Mnemonics.....	718
A.1.3.3	SCPI Parameters.....	719
	Numeric Values.....	719
	Special Numeric Values.....	720
	Boolean Parameters.....	720
	Text Parameters.....	721
	Character Strings.....	721
	Block Data.....	721
A.1.3.4	Overview of Syntax Elements.....	721
A.1.3.5	Structure of a Command Line.....	723
A.1.3.6	Responses to Queries.....	723

A.1.4	Command Sequence and Synchronization.....	724
A.1.4.1	Preventing Overlapping Execution.....	724
A.1.4.2	Examples to Command Sequence and Synchronization.....	726
A.1.5	Status Reporting System.....	727
A.1.5.1	Hierarchy of the Status Registers.....	728
A.1.5.2	Structure of a SCPI Status Register.....	729
A.1.5.3	Status Byte (STB) and Service Request Enable Register (SRE).....	731
A.1.5.4	Event Status Register (ESR) and Event Status Enable Register (ESE).....	732
A.1.5.5	Questionable Status Register (STATus:QUESTionable).....	733
A.1.5.6	Operation Status Register (STATus:OPERation).....	733
A.1.5.7	Application of the Status Reporting System.....	733
	Service Request.....	734
	Serial Poll.....	734
	Query of an instrument status.....	734
	Error Queue.....	735
A.1.5.8	Reset Values of the Status Reporting System.....	735
A.1.6	General Programming Recommendations.....	736
A.2	Telnet program examples.....	736
B	Hardware Interfaces.....	742
B.1	GPIB-Bus Interface.....	742
C	Extensions for User Files.....	744
D	Morse Code Settings.....	745
	Glossary: List of the Often Used Terms and Abbreviations.....	746
	List of Commands.....	750
	Index.....	766

1 Preface

The R&S SMA100B is a new high-performance signal generator developed to meet demanding customer requirements. Offering excellent signal characteristic and straightforward and intuitive operation, the signal generator makes signal generation fast and easy.

1.1 Key Features

Outstanding key features of the R&S SMA100B are:

- Frequency range from 8 kHz to up to 67 GHz (overrange 72 GHz)
- Excellent signal quality
- Excellent single sideband (SSB) phase noise
- Nearly no wideband noise
- Very high output power
- Low harmonics
- Unique pulse train generation
- High-stability reference oscillator
- Intuitive operation via touchscreen with the tile diagram as key element

For more information, see data sheet.

1.2 About this Manual

This user manual describes general instrument functions, the manual operation of the instrument and remote control.

The main focus of this manual is on the signal generation capabilities of the instrument and the tasks required to achieve them. The following topics are included:

- **Welcome to the R&S SMA100B**
Introduction to and getting familiar with the instrument, including introduction to the signal generation principles.
- **Getting Started**
Information that you have received as a printed book together with your instrument
- **Configuration of the RF Signal**
Descriptions of the individual operation modes, including configuration settings and task descriptions
- **File and Data Management**
Description of general functions to handle data files and work with the file system of the instrument
- **System and General Instrument Configuration**
Description of the general instrument settings and functions

- **Network and Remote Control Operation**
Information on setting up the instrument in a network and operating it remotely.
- **Remote Commands**
Remote commands required to configure and perform measurements in a remote environment, sorted by tasks.
Remote commands required to set up the environment and to perform common tasks on the instrument, sorted by tasks.
Programming examples demonstrate the use of many commands and can usually be executed directly for test purposes.
- **Maintenance**
Information on tasks required to maintain the operability of the instrument
- **Troubleshooting and Error Messages**
Hints and tips on how to handle errors
- **Appendix**
Extensive reference information on remote control, hardware interfaces, etc.
- **Glossary**
List of often used terms and abbreviations
- **List of Commands**
Alphabetical list of all remote commands described in the manual
- **Index**

Contents and scope

This help system describes the full functionality of an R&S SMA100B. Depending on your model and the installed options, some of the functions may not be available on your instrument.

Notes on screenshots

When describing the functions of the product, we use sample screenshots. These screenshots are meant to illustrate as much as possible of the provided functions and possible interdependencies between parameters. The shown values may not represent realistic usage scenarios.

The screenshots usually show a fully equipped product, that is: with all options installed. Thus, some functions shown in the screenshots may not be available in your particular product configuration.

1.3 Documentation Overview

This section provides an overview of the R&S SMA100B user documentation. Unless specified otherwise, you find the documents on the R&S SMA100B product page at:

www.rohde-schwarz.com/manual/sma100b

1.3.1 Getting Started Manual

Introduces the R&S SMA100B and describes how to set up and start working with the product. Includes basic operations, typical measurement examples, and general information, e.g. safety instructions, etc. A printed version is delivered with the instrument.

1.3.2 User Manuals and Help

Contains the description of all instrument modes and functions. It also provides an introduction to remote control, a complete description of the remote control commands with programming examples, and information on maintenance, instrument interfaces and error messages. Includes the contents of the getting started manual.

The contents of the user manuals are available as help in the R&S SMA100B. The help offers quick, context-sensitive access to the complete information.

All user manuals are also available for download or for immediate display on the Internet.

1.3.3 Service Manual

Describes the performance test for checking the rated specifications, module replacement and repair, firmware update, troubleshooting and fault elimination, and contains mechanical drawings and spare part lists.

The service manual is available for registered users on the global Rohde & Schwarz information system (GLORIS, <https://gloris.rohde-schwarz.com>).

1.3.4 Instrument Security Procedures

Deals with security issues when working with the R&S SMA100B in secure areas. It is available for download on the Internet.

1.3.5 Basic Safety Instructions

Contains safety instructions, operating conditions and further important information. The printed document is delivered with the instrument.

1.3.6 Data Sheets and Brochures

The data sheet contains the technical specifications of the R&S SMA100B. It also lists the options and their order numbers and optional accessories.

The brochure provides an overview of the instrument and deals with the specific characteristics.

See www.rohde-schwarz.com/brochure-datasheet/sma100b

1.3.7 Release Notes and Open Source Acknowledgment (OSA)

The release notes list new features, improvements and known issues of the current firmware version, and describe the firmware installation.

The open source acknowledgment document provides verbatim license texts of the used open source software.

See www.rohde-schwarz.com/firmware/sma100b

1.3.8 Application Notes, Application Cards, White Papers, etc.

These documents deal with special applications or background information on particular topics.

See www.rohde-schwarz.com/application/sma100b

2 Safety Information

The product documentation helps you use the R&S SMA100B safely and efficiently. Follow the instructions provided here and in the printed "Basic Safety Instructions". Keep the product documentation nearby and offer it to other users.

Intended use

The R&S SMA100B is intended for the development, production and verification of electronic components and devices in industrial, administrative, and laboratory environments. Use the R&S SMA100B only for its designated purpose. Observe the operating conditions and performance limits stated in the data sheet.

Where do I find safety information?

Safety information is part of the product documentation. It warns you about the potential dangers and gives instructions how to prevent personal injuries or damage caused by dangerous situations. Safety information is provided as follows:

- The printed "Basic Safety Instructions" provide safety information in many languages and are delivered with the R&S SMA100B.
- Throughout the documentation, safety instructions are provided when you need to take care during setup or operation.

3 Getting Started

3.1 Preparing for Use

- [Putting into Operation](#)..... 22
- [Connecting USB Devices](#).....28
- [Setting Up a Network \(LAN\) Connection](#).....29

3.1.1 Putting into Operation

This section describes the basic steps to be taken when setting up the R&S SMA100B for the first time.

WARNING

Risk of injury due to disregarding safety information

Observe the information on appropriate operating conditions provided in the data sheet to prevent personal injury or damage to the instrument. Read and observe the basic safety instructions provided with the instrument, in addition to the safety instructions in the following sections. In particular:

- Do not open the instrument casing.
-

NOTICE

Risk of instrument damage due to inappropriate operating conditions

Specific operating conditions are required to ensure accurate measurements and to avoid damage to the instrument. Observe the information on appropriate operating conditions provided in the basic safety instructions and the instrument's data sheet.

NOTICE

Instrument damage caused by electrostatic discharge

Electrostatic discharge (ESD) can damage the electronic components of the instrument and the device under test (DUT). Electrostatic discharge is most likely to occur when you connect or disconnect a DUT or test fixture to the instrument's test ports. To prevent electrostatic discharge, use a wrist strap and cord and connect yourself to the ground, or use a conductive floor mat and heel strap combination.

NOTICE**Risk of instrument damage due to inappropriate operating conditions**

An unsuitable operating site or test setup can damage the instrument and connected devices. Before switching on the instrument, observe the information on appropriate operating conditions provided in the data sheet. In particular, ensure the following:

- All fan openings are unobstructed and the airflow perforations are unimpeded. A minimum distance of 10 cm to other objects is recommended.
- The instrument is dry and shows no sign of condensation.
- The instrument is positioned as described in the following sections.
- The ambient temperature does not exceed the range specified in the data sheet.
- Signal levels at the input connectors are all within the specified ranges.
- Signal outputs are connected correctly and are not overloaded.

3.1.1.1 EMI Suppression

Electromagnetic interference (EMI) may affect the measurement results.

To suppress generated Electromagnetic Interference (EMI),

- Use suitable shielded cables of high quality. For example use double-shielded RF, BNC and LAN cables (CAT6 STP).
Note: USB cables are of varying and often poor quality. Therefore, check the quality of each individual USB cable as described in the service manual.
- Always terminate open cable ends.

Note the EMC classification in the data sheet.

3.1.1.2 Unpacking and Checking the Instrument

Unpack the R&S SMA100B carefully and check the contents of the package.

- Check if all items listed on the delivery note, including this getting started manual, are included in the delivery.
- Check the R&S SMA100B for any damage.
If the contents are damaged, immediately contact the carrier who delivered the package.

**Packing material**

Retain the original packing material. If the instrument needs to be transported or shipped later, you can use the material to protect the control elements and connectors.

⚠ WARNING**Risk of injury during transportation**

The carrying handles at the front and side of the casing are designed to lift or carry the instrument. Do not apply excessive force to the handles. If a handle is ripped off, the falling instrument can cause injury.

3.1.1.3 Accessory List

The instrument comes with the following accessories:

- Power cable
- Getting Started printed manual

3.1.1.4 Placing or Mounting the Instrument

The R&S SMA100B is designed for use under laboratory conditions, either on a bench top or in a rack using the standard rackmount kit.


Bench top operation

If the R&S SMA100B is operated on a bench top, the surface must be flat. The instrument can be used in horizontal position, standing on its feet, or with the support feet on the bottom extended.

⚠ WARNING**Risk of injury if feet are folded out**

The feet can fold in if they are not folded out completely or if the instrument is shifted. Collapsing feet can cause injury or damage the instrument.

- Fold the feet completely in or out to ensure stability of the instrument. Never shift the instrument when the feet are folded out.
- When the feet are folded out, do not work under the instrument or place anything underneath.
- The feet can break if they are overloaded. The overall load on the folded-out feet must not exceed 500 N.




⚠ WARNING**Risk of injury when stacking instruments**

A stack of instruments can tilt over and cause injury if not stacked correctly. Furthermore, the instruments at the bottom of the stack can be damaged due to the load imposed by the instruments on top.

Observe the following instructions when stacking instruments:

- Never stack more than three instruments. If you need to stack more than three instruments, install them in a rack.
- The overall load imposed on the lowest instrument must not exceed 500 N.
- It is best if all instruments have the same dimensions (width and length). If you need to stack smaller instruments on the top, the overall load imposed on the lowest instrument must not exceed 250 N.
- If the instruments have foldable feet, fold them in completely.

**Mounting in a rack**

The R&S SMA100B can be installed in a rack using a rack adapter kit (Order No. see data sheet). The installation instructions are part of the adapter kit.

NOTICE**Risk of instrument damage due to insufficient airflow in a rack**

If you mount several instruments in a rack, you need an efficient ventilation concept to ensure that the instruments do not overheat. Insufficient airflow for a longer period can disturb the operation and even cause damage.

3.1.1.5 Connecting AC Power

The R&S SMA100B is equipped with an AC power supply connector, that can be operated with different AC power voltages. Once it is connected, the instrument automatically adjusts to the given voltage. Refer to the data sheet for the requirements of voltage and frequency. There is no need to set the voltage manually or change fuses.

The **AC supply and power switch** is at the rear of the unit.

To connect the AC supply

- ▶ Connect the R&S SMA100B to the AC power source using the supplied power cable.

Note: Since the instrument is designed in compliance with standard EN 61010-1 safety class I, it must only be connected to an outlet that has a ground contact.

Characteristics of the AC power supply:

- 100 V to 240 V AC
- 50 Hz to 60 Hz; 400 Hz
- 3.5 to 1.6 A, 2HU height unit (R&S SMAB-B92)
- 7.3 to 4.6 A, 3HU height unit (R&S SMAB-B92)

3.1.1.6 Turning the Instrument On and Off

To turn on the R&S SMA100B

1. **Connect the instrument to the AC supply.**
2. Turn on the main AC power switch at the rear panel of the R&S SMA100B (position "I" (on)).

The instrument is supplied with AC power.



Warm-up time for OCXO

When the instrument is switched on, the OCXO requires an extended warm-up time (see data sheet).

To start the R&S SMA100B

Starting the R&S SMA100B requires that it is **connected** and **turned on**.

- ▶ At the front panel, press the [On/Standby] key briefly.

The instrument boots the operating system and starts the instrument firmware.

After booting, the instrument is in the state before the last power off (standby or ready), indicated by the color of the [On/Standby] key's LEDs:

- Green: the R&S SMA100B is running and ready for operation.
All modules are power-supplied.
- Orange: the R&S SMA100B is in standby mode (main AC power switch is in position "I").

The standby power mode keeps the power switch circuits and the oven-controlled crystal oscillator OCXO active. In this state, it is safe to switch off the AC power and disconnect the instrument from the power supply.

To switch between standby and ready state, briefly press the [On/Standby] key.

If a previous session was terminated regularly, the instrument uses the last setup with the relevant instrument settings.

- ▶ To set up a new configuration, press the [Preset] key to return the instrument to its defined reset/preset state.

To shut down and turn off the R&S SMA100B

NOTICE

Risk of losing data

If you switch off the running instrument using the rear panel switch or by disconnecting the power cord, the instrument loses its current settings. Furthermore, program data can be lost.

Press the On/Standby key first to shut down the application properly.

1. Press the [On/Standby] key.

The current setup is saved, the operating system shuts down and sets the instrument to standby state.

The [On/Standby] LED must be orange.

2. Turn off the main AC power switch at the rear panel of the R&S SMA100B (position "0" (off)).

The instrument is no longer supplied with AC power.



Turning off the AC power

You can leave the AC power on permanently. Switching off is required only if the instrument must be disconnected from all power supplies.

3.1.1.7 Functional Check

When the instrument is switched on, it automatically monitors the main functions.

A detected fault is indicated by an "Error" message displayed in the "Info" line of the instrument together with a brief error description. For an in-depth identification of the error, tap on the "Info" indication. In response, a description of the errors is displayed. For more information, refer to the "Troubleshooting and Error Messages" section in the user manual.

Apart from the automatic monitoring, the R&S SMA100B provides internal adjustments to check correct functioning. See the corresponding sections under "Maintenance" in the user manual.

3.1.1.8 Checking the Supplied Options and Licenses

The instrument can be equipped with both, hardware and firmware options. To check whether the installed options correspond to the options indicated on the delivery note, proceed as follows:

1. Press the [Setup] key.
2. Select "Instrument Assembly > Hardware Config" and "Software / Options".
A list with hardware and firmware information is displayed.
3. Check the availability of the hardware options as indicated in the delivery note.
For an overview of the available options, refer to the data sheet.

See also [Chapter 15.3.5, "Requesting Instrument Configuration and Specifications"](#), on page 703.

3.1.2 Connecting USB Devices

The USB interfaces of the R&S SMA100B allow you to connect USB devices, including USB hubs directly to the instrument. Due to the large number of available USB devices, there is almost no limit to the expansions that are possible with the R&S SMA100B.

The following list shows various USB devices that can be useful:

- Memory stick for easy transfer of data to/from a computer (for example firmware updates)
- Keyboard or mouse to simplify the entry of data, comments, filenames, etc.
- Power sensors of the R&S NRP families

All USB devices can be connected to or disconnected from the instrument during operation.

Connecting a USB storage device

When a USB storage device like a memory stick, a CD-ROM drive, or a hard disk is connected, it is detected automatically. The device is made available as a new drive (/usb). The name of the drive is manufacturer-dependent.

Connecting a keyboard

A keyboard is detected automatically when it is connected. The default keyboard layout is English – US.

Use the "Setup > User Interface > USB Keyboard Settings" dialog to configure the keyboard properties (see [Chapter 12.1.4.1, "Setting the Keyboard Language"](#), on page 326).

Connecting a mouse

A mouse is detected automatically when it is connected.

3.1.3 Setting Up a Network (LAN) Connection

The R&S SMA100B is equipped with a network interface and can be connected to an Ethernet LAN (local area network). Provided the appropriate rights have been assigned by the network administrator, the interface can be used, for example:

- To transfer data between a controller and the instrument, for example to run a remote control program.
See [Chapter 13, "Network Operation and Remote Control"](#), on page 351.
- To access or operate the instrument from a remote computer using the Ultr@VNC program (or a similar tool, like another VNC client or any Web browser supporting Java).
- To transfer data from a remote computer and back, for example using network folders.
- To use power sensors with network capability, e.g. the R&S NRP LAN power sensors.

This section describes how to configure the LAN interface.



Accessing operating system

No access to the operating system is required for normal operation.
All necessary system settings can be made in the "Setup" dialog.

3.1.3.1 Connecting the Instrument to the Network

There are two methods to establish a LAN connection to the instrument:

- A non-dedicated network (Ethernet) connection from the instrument to an existing network
- A dedicated network connection (Point-to-point connection) between the instrument and a single computer

For addressing, both the instrument and the computer require an IP address. The address information is usually assigned to the devices automatically, depending on the network capabilities.

If the IP address is not assigned automatically, see [Chapter 3.1.3.3, "Assigning the IP Address"](#), on page 31 for information on how to assign the address manually.

To set up a network (LAN) connection

NOTICE

Risk of network failure

Consult your network administrator before performing the following tasks:

- Connecting the instrument to the network
- Configuring the network
- Changing IP addresses

Errors can affect the entire network.

- ▶ Connect the instrument to the network or to a single PC.

If the instrument is connected to the LAN, the operating system automatically detects the network connection and activates the required drivers.

By default, the instrument is configured to use DHCP (dynamic host configuration protocol) configuration and to obtain the whole address information automatically.

When connected, the R&S SMA100B displays the address information on the screen.

System Config
IP: 10.113.0.19
GPIB Address: 28
FW: 4.00.040



Risk of network connection failure

Network cables and cable connectors of poor quality, or failures in the autonegotiation process, can cause network connection failures.

If the network connection to the instrument fails, check the network infrastructure and contact your network administrator.

For details, see section "Troubleshooting and Error Messages".

3.1.3.2 Using Computer Names (Hostnames)

In a LAN that uses a DNS server, each PC or instrument connected in the LAN can be accessed via an unambiguous computer name (*hostname*) instead of the IP address. The DNS server translates the hostname to the IP address. It is especially useful when a DHCP server is used, as a new IP address can be assigned each time the instrument is restarted.

Each instrument is delivered with an assigned computer name, that remains permanent as long as it is not explicitly changed.

The default computer name follows the syntax <INST>-<Serial Number> (previous syntax: rs<inst><Serial Number>), where:

- <INST> is the short name of your instrument, as stated on the front panel.
- <Serial Number> is the individual serial number of the instrument.
You can find the serial number at the rear panel of instrument. It is the third part of the device ID printed on the barcode sticker .



Example:

The default hostname of an R&S SMA100B with a serial number 102030 is SMA100B-102030.

To query and change a computer name

1. Press the [Setup] key.
2. Select "Remote Access > Network".
The computer name is displayed under "Hostname".
3. Press the [Setup] key.
4. Select "Security > Protection".
5. Enable the "Protection Level 1".
The default password is *123456*.
The parameter "Hostname" in the "Network" tab is now enabled for configuration.
6. Change the "Hostname".

3.1.3.3 Assigning the IP Address

Depending on the network capacities, the TCP/IP address information for the instrument can be obtained in different ways.

- If the network supports DHCP (dynamic host configuration protocol), the address information is assigned automatically.
- If the network does not support DHCP, the instrument tries to obtain the IP address via Zeroconf (APIPA) protocol. If this attempt does not succeed or if the instrument is set to use alternate TCP/IP configuration, the addresses must be set manually.

Since the dynamic TCP/IP configuration assigns the address information automatically, it is safe to establish a physical connection to the LAN without any previous instrument configuration.

NOTICE**Risk of network failure**

Consult your network administrator before performing the following tasks:

- Connecting the instrument to the network
- Configuring the network
- Changing IP addresses

Errors can affect the entire network.

To assign the IP address manually on the instrument**Use computer names to identify the instrument**

In networks using a DHCP server, we recommend that you address the instrument by its unambiguous computer name, see [Chapter 3.1.3.2, "Using Computer Names \(Host-names\)"](#), on page 30.

1. Press the [Setup] key.
2. Select "Remote Access > Network".
3. Select "Address Mode > Static".
4. Select the "IP Address".
5. Enter the IP address, for example *192.168.0.1*.

The IP address consists of four number blocks separated by dots. Every block contains 3 numbers in maximum.

6. Select the "Subnet Mask" and enter the subnet mask, for example *255.255.255.0*.

The subnet mask consists of four number blocks separated by dots. Every block contains 3 numbers in maximum.

To assign the IP address manually on the computer

- ▶ Obtain the necessary information from your network administrator. If you use more than one LAN connector, you need separate address information for each connector.

For information on how to perform the configurations, refer to the documentation of the operating system the computer uses.

3.2 Instrument Tour

The following topics help you to get familiar with the instrument and perform the first steps:

- [Chapter 3.2.1, "Front Panel Tour"](#), on page 33

- Chapter 3.2.2, "Rear Panel Tour", on page 40

This section explains the control elements and the connectors of the R&S SMA100B with the aid of the front and rear views. For specifications of the interfaces, refer to the data sheet.

3.2.1 Front Panel Tour

This section provides an overview of the control elements at the front panel of the R&S SMA100B. Most of the connectors are at the rear panel and are described in Chapter 3.2.2, "Rear Panel Tour", on page 40.



Figure 3-1: Front panel view of the R&S SMA100B RF Signal Generator with height unit 2HU (option R&S SMAB-B92)

- 1 = Touchscreen
- 2 = Utility keys
- 3 = [On/Standby]
- 4 = Function keys
- 5 = Keypad
- 6 = Navigation controls
- 7 = Display keys
- 8 = USB connector
- 9 = SD card slot
- 10 = Sensor connector
- 11 = RF output connector




Figure 3-2: Front panel view of the R&S SMA100B RF Signal Generator with height unit 3HU (option R&S SMAB-B93)

NOTICE**Risk of touchscreen damage**

Inappropriate tools or excessive force can damage the touchscreen.

Observe the following instructions when operating the touchscreen:

- Never touch the screen with ball point pens or other sharp objects, use your fingers instead.
As an alternative, you can use a stylus pen with a smooth soft tip.
- Never apply excessive force to the screen. Touch it gently.
- Never scratch the screen surface, for example with a finger nail.
- Never rub the screen surface strongly, for example with a dust cloth.
For instructions on cleaning the screen, see [Chapter 15.1, "Cleaning"](#), on page 691.

3.2.1.2 Utility Keys

The utility keys set the R&S SMA100B to a defined state, and provide access to basic settings and information on assistance.

Table 3-1: Utility keys

Utility Key	Assigned functions
[Preset]	Sets the instrument to a defined state
[Local]	Switches from remote control to local (manual) control
[Setup]	Accesses the general instrument settings
[Help]	Displays context-sensitive help text

3.2.1.3 On/Standby

The [On/Standby] key starts up and shuts down the instrument, and switches between the standby and the ready state.

- In the ready state, On/Standby key lights green. The instrument is ready for operation.
- In the standby state, the On/Standby key lights orange. The standby power mode keeps the power switch circuits and the oven-controlled crystal oscillator OCXO active. In this state, it is safe to switch off the AC power and disconnect the instrument from the power supply.

3.2.1.4 Function Keys

Function keys provide access to the most common generator settings and functions. You can find a detailed description of the corresponding functions in the user manual.

Table 3-2: Function keys

Function key	Assigned functions
[Freq]	Activates frequency entry.
[Level]	Activates level entry.
[Mod on/off]	Switches the modulation on and off.
[RF on/off]	Switches the RF output on and off.

3.2.1.5 Keypad

The keypad enables you to enter alphanumeric parameters, including the corresponding units. It contains the following keys:

Table 3-3: Keys on the keypad

Type of key	Description
Alphanumeric keys	Enter numbers and (special) characters in edit dialog boxes.
Decimal point	Inserts a decimal point "." at the cursor position.
Sign key	Changes the sign of a numeric parameter. In the case of an alphanumeric parameter, inserts a "-" at the cursor position.
Unit keys (G/n dB μ V, M/ μ μ V, k/m mV and x1 dB(m))	These keys add the selected unit to the entered numeric value and complete the entry. In the case of level entries (e.g. in dB) or dimensionless values, all units have the value "1" as multiplying factor. Thus, they have the same function as an [Enter] key.

3.2.1.6 Navigation Controls

The navigation controls include a rotary knob, navigation keys, and the display keys. They allow you to navigate within the display or within dialog boxes.

Rotary Knob

The rotary knob has several functions:

- Increments (clockwise direction) or decrements (counterclockwise direction) the instrument parameter at a defined step width in the case of a numeric entry.
- Moves the selection, e.g. to a function block in the block diagram
- Shifts the selection bar within focused areas (e.g. lists).
- Acts like the [Enter] key, when it is pressed.

Editing Keys

Editing keys enable you to confirm an entry, delete individual characters, or exit the current operation.

Table 3-4: Editing keys

Type of key	Description
[Esc] key	<p>Closes all kinds of dialog boxes, if the edit mode is not active. Quits the edit mode, if the edit mode is active. In dialog boxes that contain a "Cancel" button it activates that button.</p> <p>For "Edit" dialog boxes the following mechanism is used:</p> <ul style="list-style-type: none"> • If data entry has been started, it retains the original value and closes the dialog box. • If data entry has not been started or has been completed, it closes the dialog box.
[Enter] key	<p>Has the same effect as pressing the rotary knob</p> <ul style="list-style-type: none"> • Concludes the entry of dimensionless entries. The new value is accepted. • With other entries, this key can be used instead of the default unit key. • In a dialog box, selects the default or focused element. • Calls the next dialog level. • Confirms and closes open input windows.
[Backspace] key	Deletes the character to the left of the cursor in editing mode.

Navigation Keys

As an alternative to the rotary knob or the touchscreen, you can use the navigation keys to navigate through dialog boxes, diagrams, or tables.

Table 3-5: Navigation keys

Type of key	Description
[Up/Down] Key	<p>The [Up] and the [Down] key does the following:</p> <ul style="list-style-type: none"> • In a numeric edit dialog box, increase or decrease the instrument parameter. • In a list, scroll forward and backward through the list entries. • In a table, move the selection bar vertically. • In windows or dialog boxes with vertical scrollbar, move the scrollbar.
[Left/Right] Key	<p>The [Left] and the [Right] key does the following:</p> <ul style="list-style-type: none"> • In an alphanumeric edit dialog box, move the cursor. • In a list, scroll forward and backward through the list entries. • In a table, move the selection bar horizontally. • In windows or dialog boxes with horizontal scrollbar, move the scrollbar.

3.2.1.7 Display Keys

The display keys arrange different windows on the display.

Table 3-6: Display keys

Display key	Assigned functions
[Home]	Returns to the initial feature screen.
[Next window]	Toggles between the entry fields in the taskbar.
[On/Off]	<ul style="list-style-type: none"> • Switches highlighted elements or a function block on and off. • Switches between two or more settings, e.g. items of selection lists. At the end of a list, the cursor is set on the first entry again.

Display key	Assigned functions
[Undo]	Reverts the last operation.
[★ (User)]	Adds a parameter to the user menu for quick access.

3.2.1.8 USB Connector

USB (universal serial bus) interfaces of type A (host USB).

- Connection of peripherals such as mouse or keyboard
- Connection of memory stick for file transmission
- Firmware update



Further USB interface type A (host USB) and a USB interface type B (USB In) are available on the rear panel.

3.2.1.9 SD card slot

Slot for removable mass storage (option R&S SMAB-B85).

To prevent from unauthorized removal, the SD card holder includes wholes that provide the opportunity of sealing the SD card. We recommend that you seal the SD card crosswise.

3.2.1.10 Sensor

Connector for R&S NRP sensors.

The R&S SMA100B supports the use of R&S NRP power sensors in various ways including the use as a power viewer.

A power sensor is connected to the R&S SMA100B by inserting the male connector. To disconnect, pull the connector by its sleeve. You cannot disconnect the sensor simply by pulling at the cable or the rear part of the connector.



The female connector allows the mechanical connection of 6-pole and 8-pole male connectors.

It mates with the interface cables R&S NRP-ZK8 and R&S NRP-ZK6, used for connecting R&S NRPxx power sensors, and also with the six-pole push-pull plugs of the R&S NRP-Zxx series.

However, the signal pair of the common time base clock assigned to the two pins in the center of the male connectors is not available. These pins are used by Rohde & Schwarz power meters to synchronize several power sensors.

Further information on connecting and using power sensors, see [Chapter 8.4.1, "Connecting R&S NRP Power Sensors to the R&S SMA100B"](#), on page 214, [Chapter 8.4.3, "NRP Power Viewer"](#), on page 217, [Chapter 8.4.2, "NRP Sensor Mapping"](#),

on page 215, [Chapter 8.4.4, "NRP-Z Power Analysis"](#), on page 225 and [Chapter 8.3, "User Correction"](#), on page 202.

3.2.1.11 RF 50 Ω

Output of the RF signal.

NOTICE

Maximum input levels

Do not overload the RF output.

The instrument is equipped with a reverse power protection that prevents the RF output against back feed, see [Chapter 8.1.2, "Reverse Power Protection"](#), on page 200. Nevertheless, the maximum permissible reverse power is specified in the data sheet.

The connector type depends on the installed frequency option.

Table 3-7: Overview of RF connector types depending on the frequency range

Required option	Connector type
RF: R&S SMAB-B103	N female
RF: R&S SMAB-B106	N female
RF: R&S SMAB-B112	Test port adapter, PC 3.5 mm female
RF: R&S SMAB-B120	Test port adapter, PC 3.5 mm female
RF: R&S SMAB-B131	Test port adapter, PC 3.5 mm female
RF: R&S SMAB-B140(N)	Test port adapter, PC 3.5 mm female
RF: R&S SMAB-B150(N)	PC 1.85 mm female
RF: R&S SMAB-B167(N)	PC 1.85 mm female

NOTICE

Risk of RF connector and cable damage

If you tighten the connectors too strongly, you can damage the cables and connectors. If you do not tighten the connectors enough, the measurement results can be inaccurate.

Always use an appropriate torque wrench suitable for this type of connector and apply the torque specified in the application note [1MA99](#).

The application notes are available on the Internet and provide additional information on care and handling of RF connectors.

Rohde & Schwarz offers appropriate torque wrenches for various connectors. For ordering information, see the R&S SMA100B data sheet or product brochure.

3.2.1.12 Pulse Signal Connectors

Pulse Sync

Output signal for synchronizing the pulse generator signal. The synchronization signal is generated at the beginning of each pulse. For double-pulse generation, the synchronization signal is generated at the beginning of the first pulse.

Pulse Video

Output of the internal pulse generator signal or the looped through pulse signal from Pulse Ext connector (video signal).

See [Chapter 5.4.1, "Pulse Modulation"](#), on page 77.

Pulse Ext

Input for an external pulse modulation signal or an external trigger/gate signal for the pulse generator.

3.2.1.13 LF Modulation Connectors

LF

Output for internal LF generator signal.

See also data sheet and user manual, section "Analog Modulation".

Ext

Input for external analog modulation signals.

See [Chapter 5, "Analog Modulations"](#), on page 74.

3.2.1.14 Clock Synthesizer Connectors

Clk Syn/Clk Syn N

Connectors for output of the clock synthesizer signal, or the inverted signal.

3.2.2 Rear Panel Tour

This section provides an overview of the connectors at the rear panel of the instrument. For technical data of the connectors, refer to the data sheet.




Figure 3-4: Rear panel view of the R&S SMA100B RF Signal Generator with height unit 2HU (option R&S SMAB-B92)

- 1 = IEC 625/IEEE 488 connector
- 2 = USB In connector (type micro-B)
- 3 = LAN connector
- 4 = USB connector (type A)
- 5 = V/GHz X-Axis and Z-Axis output connectors (BNC)
- 6 = Stop input and output connector (BNC)
- 7 = Marker User1 output connector (BNC)
- 8 = Ref In 1GHz and Ref Out 1GHz connectors (SMA)
- 9 = Ref In and Ref Out connectors (BNC)
- 10 = EFC input connector (BNC)
- 11 = Inst Trig input connector (BNC)
- 12 = Signal Valid output connector (BNC)
- 13 = Clk Syn and Clk Syn N output connectors (SMA)
- 14 = Pulse Sync, Pulse Video and Pulse Ext connectors (BNC)
- 15 = LF output connector (BNC)
- 16 = Ext 1/2 input connectors (BNC)
- 17 = AC power supply connection and main power switch
- 18 = RF output connector
- 19 = Serial number (six digits in the string 1419.8888.02-<serial number>-<checksum>)




Figure 3-5: Rear panel view of the R&S SMA100B RF Signal Generator with height unit 3HU (option R&S SMAB-B93)

- 1 = IEC 625/IEEE 488 connector
- 2 = USB In connector (type micro-B)
- 3 = LAN connector
- 4 = USB connector (type A)
- 5 = V/GHz X-Axis and Z-Axis output connectors (BNC)
- 6 = Stop input and output connector (BNC)
- 7 = Marker User1 output connector (BNC)
- 8 = Ref In 1GHz and Ref Out 1GHz connectors (SMA)
- 9 = Ref In and Ref Out connectors (BNC)
- 10 = EFC input connector (BNC)

- 11 = Inst Trig input connector (BNC)
- 12 = Signal Valid output connector (BNC)
- 13 = Clk Syn and Clk Syn N output connectors (SMA)
- 14 = Pulse Sync, Pulse Video and Pulse Ext connectors (BNC)
- 15 = LF output connector (BNC)
- 16 = Ext 1/2 input connectors (BNC)
- 17 = AC power supply connection and main power switch
- 18 = RF output connector
- 19 = Serial number (six digits in the string 1419.8888.02-<serial number>-<checksum>)

3.2.2.1 Connectors

IEC 625/IEEE 488

Option: R&S SMAB-B86

GPIB-bus interface for remote control of the instrument.

The IEC 625 interface is in compliance with IEEE488 and SCPI. A computer for remote control can be connected via this interface. To set up the connection, we recommend that you use a shielded cable.

Note: To avoid electromagnetic interference (EMI) caused by open lines, always terminate any connected IEC-bus cable with an instrument or a controller.

See also [Chapter B.1, "GPIB-Bus Interface"](#), on page 742 and [Chapter 13, "Network Operation and Remote Control"](#), on page 351.

USB/USB In

- Female USB type A connector, to connect devices like a keyboard, a mouse, a memory stick, or the R&S NRP-Z3/Z4 cable for the R&S NRP power sensors
- Female USB In connector (USB type B), for example for remote control.
Option: R&S SMAB-B86

See also [Chapter 3.1.2, "Connecting USB Devices"](#), on page 28.

LAN

The LAN interface can be used to connect the R&S SMA100B to a local network for remote control, remote operation, and data transfer.

For details, see [Chapter 3.1.3, "Setting Up a Network \(LAN\) Connection"](#), on page 29.

V/GHz X-Axis

Output of a voltage ramp:

- "V / GHz": the voltage is proportional to the frequency.
- "X-Axis": output of a voltage ramp for the X deflection of an oscilloscope or an XY recorder.

Z-Axis

Output of a voltage pulse, e.g. for the combined blanking and marker generation of network analyzers.

Stop

Input and output for stopping the sweep in all modes.

This connector is bidirectional. Used as:

- "Input": enables you to stop a sweep triggered by an external network analyzer.
- "Output": enables the R&S SMA100B to stop the sweep of an external network analyzer.

Marker User1

Output signal for marker or trigger signal.

Signal Valid

Output signal that marks the valid signal times (valid level and frequency) for all analog modulations.

Alternatively, you can use this connector to synchronize pulse signals by activating the "Pulse Sync" in the dialog [Chapter 5.4.3, "Pulse Generator"](#), on page 85.

Inst Trig

Input for external trigger of sweeps and list mode.

For detailed information on the sweep modes and the triggering, see [Chapter 7.1, "Signal Generation and Triggering in the Sweep and List Modes"](#), on page 159.

EFC

Input connector for an EFC (external frequency control) signal for electronic tuning of the internal reference frequency.

See [Chapter 9, "Reference Oscillator"](#), on page 273.

Ref In/Ref Out

Input/output for external reference signal.

Incl. dedicated connectors for the 1GHz reference signal.

See [Chapter 9, "Reference Oscillator"](#), on page 273.

Clk Syn/Clk Syn N

Connectors for output of the clock synthesizer signal, or the inverted signal.

Pulse Ext

Input for an external pulse modulation signal or an external trigger/gate signal for the pulse generator.

Pulse Video

Output of the internal pulse generator signal or the looped through pulse signal from Pulse Ext connector (video signal).

See [Chapter 5.4.1, "Pulse Modulation"](#), on page 77.

Pulse Sync

Output signal for synchronizing the pulse generator signal. The synchronization signal is generated at the beginning of each pulse. For double-pulse generation, the synchronization signal is generated at the beginning of the first pulse.

LF

Output for internal LF generator signal.

See also data sheet and user manual, section "Analog Modulation".

Ext 1/2

Inputs for external analog modulation signal, and an external detector voltage.

See [Chapter 5, "Analog Modulations"](#), on page 74.

AC supply and power switch

The AC power supply connector and the main power switch are located in a unit on the rear panel of the instrument.

Main power switch function:

- Position 1: The instrument is in operation.
- Position 0: The entire instrument is disconnected from the AC power supply.

For details, refer to [Chapter 3.1.1.6, "Turning the Instrument On and Off"](#), on page 26.

RF

Rear panel connector for the RF signal. This connector is for use of the instrument in a 19" rack.

3.3 Trying Out the Instrument

This chapter introduces the first steps with the R&S SMA100B. It shows how to operate and configure the instrument using simple examples. The complete description of the functionality and its usage is given in the R&S SMA100B user manual. Basic instrument operation is described in [Chapter 3.4, "Instrument Control"](#), on page 51.

Prerequisites

The instrument is set up, connected to the power supply, and started up as described in [Chapter 3.1, "Preparing for Use"](#), on page 22.

The first signal generation tasks explain how to generate an unmodulated signal, to configure the RF signal output, and how you can vary the RF frequency and level in sweep mode.

The instrument is manually operated via the touchscreen. Try out the following:


- [Generating an Unmodulated Carrier](#)..... 44
- [Generating an RF Frequency Sweep Signal](#)..... 47
- [Saving and Recalling Settings](#)..... 49

3.3.1 Generating an Unmodulated Carrier

We start to generate a simple unmodulated signal. In this example, the R&S SMA100B can be in its minimal configuration.


1. On the R&S SMA100B front panel, press the [Preset] key to set a defined initial instrument state.

2. Set the frequency:
 - a) In the "Status Bar", tap the "Frequency" field.
 - b) On the on-screen keypad, enter "6" and press the "GHz" key.



The on-screen key pad closes and the frequency value is displayed.

3. To set the signal level, tap the "Level" field and enter the level in the same way.
4. To activate RF signal output, select "Level" > "RF On" in the tile diagram.



The blue colored "RF On" icon indicates that the RF output is activated.

The R&S SMA100B provides the 6 GHz signal at the RF A connector at the front panel.




Figure 3-6: Generating an unmodulated signal

Alternative ways to access the instrument functions

To fulfill the same task, you can also use the front panel keys or the setting parameters provided in the frequency and level dialogs.

Try out the settings dialogs

- In the "Frequency" tile, select "Frequency...".
 - In the "RF Frequency" tab, tap the "Frequency" field.
 - Set the frequency via the on-screen keypad.
- Access the "RF Level" dialog via the "Level" tile.
 - In the "RF Level" tab, select "Amplitude".
 - Set the amplitude (level) via the on-screen keypad.
- Select "RF State > On" to activate the RF signal generation.

See [Chapter 4, "RF Signal Configuration"](#), on page 62.

Try out the front panel keys

- Use the [Freq], [Level], and [RF on/off] key on the front panel.



Connect RF of the R&S SMA100B to a signal analyzer, for example R&S®FSW, to display the generated signal.

For the required settings of the signal analyzer, refer to its user manual or its online help.


3.3.2 Generating an RF Frequency Sweep Signal

The "Sweep" operating mode allows you to generate an RF signal with periodically varying frequencies or amplitudes.

This example deals with an RF signal with varying frequency and constant level. To configure the sweep, you need to determine a defined start and end frequency with constant time intervals between the frequency steps.

The sweep function does not require specific options.

1. On the front panel, press the [Preset] key to set a defined initial instrument state.
2. Set the signal output level, if required, e.g. set "Level > -25 dBm".
3. In the tile diagram, select "Sweep" > "Frequency Sweep".
4. In the "General" tab:



- a) Select "Mode > Auto" to run the sweep continuously.
 - b) Select "Shape > Sawtooth" to set the waveform shape of the sweep signal.
 - c) Select "Spacing > Linear", to determine the calculation method for the frequency shift of a step.
 - d) Set "Dwell Time > 15.0 ms", to determine the time interval of the sweep steps.
5. Select the "Frequency Range" tab.

Start Frequency 200.000 000 000 MHz	Stop Frequency 600.000 000 000 MHz
Center Frequency 400.000 000 000 MHz	Span 400.000 000 000 MHz
Spacing Linear	Step Linear 10.000 000 000 MHz

- a) Set "Start Freq > 200 MHz" and "Stop Freq > 600 MHz" to determine the frequency sweep range.
 - b) Set the step width "Step Lin > 10.0 MHz" to determine the width for a frequency step.
6. In the "General" tab, activate the frequency sweep with "State > On".
 7. Close the sweep dialog.
(Alternatively, tap the "Home" button to minimize the dialog. The R&S SMA100B indicates the "Sweep" dialog as active dialog in the task bar.)
 8. To activate the RF signal output, select "Level" > "RF On".

The screenshot shows the instrument's status bar and configuration panels. The status bar at the top displays the current frequency as **500.000 000 000 MHz** and the level as **-25.00 dBm**. Below the status bar, there are several configuration panels:

- Modulation:** configure AM, FM, Phase and Pulse Modulation. Mod Off.
- Frequency:** Ref Out: 10 MHz. Int Ref.
- Level:** Limit: 30.00 dBm. **RF On** (highlighted in orange).
- System Config:** IP: 10.124.0.207, GPIB Address: 28, FW: 4.15.148.
- Sweep:** Freq Sweep: Mode - Auto, Start: 200.0 MHz, Stop: 600.0 MHz.
- Clk Syn / Pow Sens:** configure Clock Synthesis and Power Sensor Applications. Clock Syn Off.

Figure 3-7: Generating a frequency sweep signal

The frequency field in the status bar indicates the continuously changing frequency, i.e. the running sweep.


3.3.3 Saving and Recalling Settings

To restore the results of our measurements later, we save the instrument settings in a file.

To save the instrument settings in a file

We assume, a test configuration as described in [Chapter 3.3.2, "Generating an RF Frequency Sweep Signal"](#), on page 47.

1. Press the [Setup] key on the front panel.
2. In the "Setup" menu, select "Settings > Save/Recall".
3. In the "Save/Recall" dialog, select "Operation Mode > Save".



4. Tap the "Filename", use the on-screen keyboard, and enter *MyTestSignal*.
5. Tap the "Save" button.


The file `MyTestSignal.savrc1.txt` is stored in the default directory `/var/user/`.

To load saved instrument settings

You can restore the settings to the instrument at any time using the settings file.

1. Press the [Preset] button to restore the default instrument settings so you can check that the stored user settings are restored afterwards.
2. Press the [Setup] key on the front panel.
3. In the "Setup" menu, select "Settings > Save/Recall".

- In the "Save/Recall" dialog, select "Operation Mode > Recall".
Navigate to the directory the file is saved in and select the `MyTestSignal` file.



- Tap the "Recall" button.

All instrument settings are restored and the display resembles [Chapter 3.3.2, "Generating an RF Frequency Sweep Signal"](#), on page 47, which shows the instrument display right before the settings were saved.





How to display all parameters with values different to their preset values


When you load a file to your instrument, you do not have enough information on the changed settings. In such case, it is useful to visualize all parameters that have been changed from their default state.


Try out the following:


- Touch and hold a spot in the tile diagram for at least 1 second to access the context-sensitive menu.
- Select "Mark All Parameters Changed from Preset".


-  **Mark All Parameters Changed from Preset**

-  **Start SCPI Recording**




-  **Undo**

-  **Redo**

-  **Help**

-  **Key Emulation**

- All changed parameters are highlighted.

	Frequency 410.000 000 000 MHz		Level -25.00 dBm
SCPI(3)	Modulation	Frequency	Level
Frequency Sweep	<i>configure AM, FM, Phase and Pulse Modulation</i>	Ref Out: 10 MHz	Limit: 30.00 dBm
	Mod Off	Int Ref	RF On
	System Config	Sweep	Clk Syn / Pow Sens
	IP: 10.124.0.207 GPIB Address: 28 FW: 4.15.148	Freq Sweep: Mode - Auto Start: 200.0 MHz Stop: 600.0 MHz	<i>configure Clock Synthesis and Power Sensor Applications</i>
 Info			Clock Syn Off

See also [Chapter 11, "File and Data Management"](#), on page 287.

3.4 Instrument Control

This chapter provides an overview on how to work with the R&S SMA100B.

It covers the following topics:

• Possible Ways to Operate the Instrument.....	52
• Means of Manual Interaction.....	52
• Understanding the Display Information.....	53
• Accessing the Functionality.....	56
• Entering Data.....	57
• Getting Information and Help.....	58
• Remote Control.....	60
• Remote Operation over VNC.....	61

3.4.1 Possible Ways to Operate the Instrument

There are three ways to operate the R&S SMA100B:

- Manual operation:
Use the touchscreen, hard keys and rotary knob, or an optional mouse and/or keyboard.
The description under [Chapter 3.4, "Instrument Control"](#), on page 51 shows how to operate the instrument manually.
- Remote control:
Create programs to automatize repeating settings, tests and measurements. The instrument is connected to a computer running the program.
This way of operation is described in [Chapter 13, "Network Operation and Remote Control"](#), on page 351.
- Remote operation from a computer:
Remote monitoring and control of the instrument from a connected computer is based on the common cross-platform technology VNC (Virtual Network Computing). On the remote computer, any standard web browser (supporting Java) or a dedicated VNC client (like Ultr@VNC) can be used. See also [Chapter 3.4.8, "Remote Operation over VNC"](#), on page 61.

3.4.2 Means of Manual Interaction

For the manual interaction with the R&S SMA100B, you have several methods that you can use as an alternative to perform a task:

- Touchscreen:
Touchscreen operation is the most direct way to interact. Almost all control elements and actions on the screen are based on the standard operating system concept. You can tap any user interface element to set parameters in dialog boxes, enter data, scroll within a dialog etc., as if you work with a mouse pointer.
Tapping the screen works like clicking mouse buttons:
 - Touch quickly = click: Selects a parameter or provokes an action.
 - Touch and hold = right-click: Opens a context-sensitive menu.
 - Touch and swipe = drag: Scrolls through the contents of a display element larger than the screen, e.g. a list or a table.
- Function keys and rotary knob:
The front panel provides nearly all functions and controls to operate the instrument in the classic way, without touchscreen.

- Optional mouse and/or keyboard:
These devices work like known from PCs. The navigation keys on the front panel correspond to the keys on the keyboard.

This manual describes the manual interaction with the instrument via the touchscreen. It mentions the alternative methods using the keys on the instrument or the on-screen keypads if it deviates from the standard operating procedures. The usage of the touchscreen and navigation keys is described in [Chapter 3.4.4, "Accessing the Functionality"](#), on page 56.

Throughout the manual, the term "select" refers to any of the described methods, i.e. using a finger on the touchscreen, a mouse pointer in the display, or a key on the instrument or on a keyboard.

3.4.3 Understanding the Display Information

The home screen of the R&S SMA100B displays all main settings and generator states, divided into three main operation areas.




Figure 3-8: Home screen

- 1 = Taskbar/softkey bar with "Home" and "System Config" key
- 2 = Status bar
- 3 = Tile diagram

- [Status Bar](#)..... 53
- [Tile Diagram](#)..... 53
- [Taskbar](#)..... 54
- [Additional Display Characteristics](#)..... 55

3.4.3.1 Status Bar

The status bar at the top of the screen indicates the RF frequency and the level of the output signal provided to the DUT. You can set both parameters directly here.

3.4.3.2 Tile Diagram

The tile diagram is the main entry to the settings of the R&S SMA100B.





Tile	Access to:
"Modulation"	<ul style="list-style-type: none"> • Analog and stereo¹⁾, and pulse¹⁾ modulation settings • Built in LF generator
"System Config"	<ul style="list-style-type: none"> • "Save/Recall": settings for saving and loading instrument configurations • "Remote access": Network and emulation settings. • "Setup": general system configuration
"Sweep"	<ul style="list-style-type: none"> • Frequency and level sweeps • List mode
"Frequency"	<ul style="list-style-type: none"> • RF frequency and phase • Reference frequency
"Level"	<ul style="list-style-type: none"> • RF level • Attenuator • Automatic level control • User correction
"Clk Syn / Pow Sens"	<ul style="list-style-type: none"> • Clock synthesis¹⁾ • Power sensors
¹⁾ requires additional options	


3.4.3.3 Taskbar

The "Taskbar" shows a home and an info button, and assigns a labeled button whenever you open a dialog. If more dialogs are open than the taskbar can display, touch and swipe the taskbar to scroll up and down.

The buttons shown in the following example represent the variants.

Table 3-8: Example of buttons in the taskbar

	"Home" button Returns to the home screen.
	"User Menu" Lists parameters that can be defined for quick access.
	Shows the current remote access connections when the instrument is remotely controlled. Tip: An indicator in the "System Config" tile shows the current remote control status.
	R&S NRP power sensors Shows a connected external power sensor. The button displays the current readings when the sensor is active.



Active dialogs

Indicates the dialog name of each active dialog in a separate button.



"Info" key

Provides access to status and error messages.

Note: The warning symbol signifies a permanent error message.

3.4.3.4 Additional Display Characteristics

The following section provides a short insight on the indication of the screen in general, and significant elements that you see under specific operating modes, in dialogs or settings.

- **Appearance of active elements**
 - *Active* elements like On/Off switches, state buttons have a **blue** background.
 - *Selected* elements are framed or highlighted **orange**.
 - *Inactive* elements are **gray**.
- **On-Screen keypads**


As additional means of interacting with the instrument without having to connect an external keyboard, either a numerical or alphanumerical on-screen keypad appears when you activate an entry field (see [Chapter 3.4.5, "Entering Data"](#), on page 57).
- **Info line**

The "Info line" shows brief status information and error messages. It appears when an event generates a message.
- **Key parameters indicated in tab labels**

Most dialogs are divided into tabs with logically grouped parameters. The tab label expresses the content and can also contain status indicators or the set value of a key parameter.
- **Scroll bar handle**

An arrow icon that appears when you touch a scroll bar helps you to scroll in a dialog or list.
If no scrollbar handle appears, you can touch and swipe an element to scroll up and down.
- **Context-sensitive menus**

Within the entire screen display, including single parameters, you can access context-sensitive menus that provide some additional functions.



3.4.4 Accessing the Functionality

All functionalities are provided in dialog boxes as known from computer programs. You can control the instrument intuitively with the touchscreen. This section provides an overview of the accessing methods.

The instrument's functions and settings can be accessed by selecting one of the following elements:

- System and function keys on the front panel of the instrument
- Taskbar/softkeys on the touchscreen
- Context-sensitive menus for specific elements on the touchscreen
- Elements on the status bar in the touchscreen
- Displayed setting on the touchscreen, that means block diagram and all settings available in dialogs.

To open a dialog box

- ▶ Perform one of the following actions:
 - Tap the required tile, and then the menu entry.
 - Tap the minimized view (button) on the taskbar.

Some of the utility keys access a dedicated dialog, too.

To minimize a dialog box

1. To return to the home screen, tap the "Home" button.

2. To switch to another dialog, press the [Next Window] button.

To close a dialog box

To close a dialog box, you have the same controls as you know from computers or devices with touchscreen.

- ▶ Perform one of the following actions:
 - Tap the "Close" icon in the upper right corner.
 - Press the [Esc] key on the front panel.
 - Drag and drop a minimized dialog from the taskbar to the tile diagram.

To select an option in a dialog box

- ▶ Tap the required option.

3.4.5 Entering Data

Some parameters have their own key on the front panel.

For data input in dialog boxes, the instrument provides on-screen keypads for entering numeric and alphanumeric values. Thus, you can always set the parameters via the touchscreen, the front panel, or an external keyboard.

Correcting an entry

1. Using the arrow keys, move the cursor to the right of the entry you want to delete.
2. Press the [Backspace] key.
3. Deletes the entry to the left of the cursor.
4. Enter your correction.

Completing the entry

- ▶ Press the [Enter] key or the rotary knob.

Aborting the entry

- ▶ Press the [Esc] key.
The dialog box closes without changing the settings.

3.4.5.1 Entering Numeric Parameters

To enter values with the on-screen keypad

For numeric settings, the instrument displays the numeric keypad. The units specified correspond to the units of the parameter.

1. Enter the numeric value.
2. Tap the unit button to complete the entry.
The unit is added to the entry.
3. If the parameter does not require a unit, confirm the entered value by pressing "Enter".

To enter values by using the front panel controls

1. Change the currently used parameter value by using the rotary knob or the [Up/Down] keys.
2. If the parameter does not require a unit, confirm the entered value by pressing the [Enter] key or any of the unit keys.
The instrument highlights the editing line to confirm the entry.

If you edit numeric data in tables, the entry field must be in edit mode: Press [Enter], or the rotary knob to activate the edit mode.

3.4.5.2 Entering Alphanumeric Parameters

If a field requires alphanumeric input, you can use the on-screen keyboard to enter letters and (special) characters.

3.4.5.3 Undo and Redo Actions

Accessed via the context-sensitive menus, "Undo" allows you to restore one or more actions on the instrument. Depending on the available memory, the "Undo" steps can restore all actions.



"Redo" restores a previously undone action.

3.4.6 Getting Information and Help

In some dialog boxes, graphics are included to explain the way a setting works.


For further information, you can use the following sources:

- Tooltips give the value range of the parameter.
- The context help provides functional description on a setting.
- The general help explains a dialog box, provides instructions, and general information.

To display context help

- ▶ To access a help topic, perform one of the following:
 - a) Tap and hold the parameter for which you need information and tap "Help" in the context menu.
 - b) Tap the parameter and press the [Help] key.

The "Help" dialog opens. You can browse the help for further information.



Contents of the help dialog box

The help dialog box covers two main areas:

- "Contents" - contains a table of help contents
- "Topic" - contains a specific help topic

The help system also provides an "Index" and a "Find" area, and "Zoom" functions that are accessed via the corresponding buttons.

To open general help

- ▶ Press the yellow [Help] key on the front panel.
If a dialog box is opened, the help topic for the current tab is shown. Otherwise the "Contents" page appears.

Navigating in the table of contents and in the help topics

1. To move through the displayed contents entries, tap on an entry and scroll or use a connected mouse or the [Up/Down] keys.
Entries with a plus sign contain further entries.
2. To display a help topic, tap on the topic name or double click on the topic name or press the [Enter] key.
3. To follow a cross-reference, tap on the link text.
4. To return to the previous page, select "Back".
This function scrolls back all steps you have performed before.
5. Use the "scroll bars" to shift the visible section of content shown.
6. To maximize the "Topics" area, tap the "Hide Contents Tree" button to hide the contents tree.

Using the index

1. Select the "Index" button.
2. Enter the first characters of the topic you are interested in.
The entries starting with these characters are displayed.
3. Tap on the index entry.
The corresponding help topic is displayed.

3.4.7 Remote Control

In addition to working with the R&S SMA100B interactively, located directly at the instrument, it is also possible to operate and control it from a remote PC.

The R&S SMA100B supports various methods for remote control:

- Connecting the instrument to a (LAN) network (see [Chapter 3.1.3, "Setting Up a Network \(LAN\) Connection"](#), on page 29)
- Using the LXI browser interface in a LAN network
- Connecting a PC via the IEC-bus (IEEE 488) interface
- Remote control via the USB interface



For remote control over LAN or USB, you can use the R&S VISA (Virtual Instrument Software Architecture) library provided for download at the Rohde & Schwarz website <http://www.rohde-schwarz.com/rsvisa>.

How to configure the remote control interfaces is described in [Chapter 13, "Network Operation and Remote Control"](#), on page 351.

3.4.8 Remote Operation over VNC

The VNC is an application which can be used to access and control the instrument from a remote computer through a LAN connection. While the instrument is in operation, the instrument screen contents are displayed on the remote computer, and VNC provides access to all applications, files, and network resources of the instrument. Thus, remote operation of the instrument is possible.



Instrument control from a remote computer

To access the basic utility functions of the R&S SMA100B, perform a right mouse click on the block diagram and select "Key Emulation".

A key panel to the right of the block diagram gives access to the utility functions provided by the front panel keys.

The VNC is an add-on program, included in operating system Linux/Unix, and available as a free-of-charge download on the internet.

For more information, refer to [Chapter 13.16, "How to Set Up Remote Operation via VNC"](#), on page 401.

4 RF Signal Configuration

The R&S SMA100B signal generator generates RF signals with outstanding spectral purity within the frequency range from 8 kHz up to 20 GHz and with adjustable signal level over a wide range.

In addition to these real-time CW signals, you can generate RF signals from predefined lists and sweep signals that vary according to the frequency or amplitude curves.

You can also apply versatile analog modulation types with definable characteristics.

The variably adjustable output level due to the built-in attenuator, allows you to vary the RF signal level over the full level range. There are different methods to improve signal performance and to optimize the signal quality for the particular application, or to increase the accuracy and reliability of the generated RF signal.

The R&S SMA100B supports R&S NRP power sensors, e.g. to monitor the output level of the generator or to determine the level correction values for user correction lists.

Signal modes and characteristics

The R&S SMA100B generates unmodulated or analog modulated RF signals. You can output the signal in fixed mode or as a signal having periodically varying frequencies or amplitudes.

Signal modes for RF signal generation:

- Unmodulated signal
Generates an unmodulated continuous wave (CW) of constant frequency and amplitude.
For information on the signal frequency and level settings and an example on how to configure a simple CW signal, see:
 - [Chapter 4.3, "RF Frequency Settings"](#), on page 65
 - [Chapter 4.4, "RF Level Settings"](#), on page 67
 - [Chapter 3.3.1, "Generating an Unmodulated Carrier"](#), on page 44
- Analog modulated signal
Modulates the signal with an analog signal and generates amplitude, phase, frequency and pulse modulation.
See [Chapter 5, "Analog Modulations"](#), on page 74.

The R&S SMA100B allows you to provide the RF signal with constant or varying frequencies and/or amplitudes at the output:

- Constant frequency and level (CW/Fixed mode)
The RF output signal has the set frequency and level.
- Varying frequency and/or level
 - Sweep mode
An RF or LF frequency and RF level sweep signal, processed continuously, step-by-step or individually and with selectable trigger modes. You can only run one sweep at a time.
 - List mode

The RF signal is based on a list of predefined frequency and level values pairs and step widths.

See [Chapter 7, "List and Sweep Mode"](#), on page 157.

4.1 Activating RF Signal Output

Per default, the RF output signal is deactivated.

To activate the RF output

1. Configure the RF signal as required.
Set, for example, the frequency and level values.
2. Activate the RF output in one of the following ways:
 - a) Select "Level > RF ON > On"
 - b) Press the [RF on/off] key at the front panel.
3. In the "Level" tile, observe the color of the "RF On" icon.
The blue color indicates that the RF output is activated.

RF State/RF ON	63
RF output impedance	63

RF State/RF ON

Activates or deactivates the RF output.

Acts as the [RF on/off] key.

Remote command:

`:OUTPut<hw>[:STATe]` on page 451

RF output impedance

You can query the impedance of the RF output.

Remote command:

`:OUTPut<hw>:IMPedance?` on page 452

4.2 How to Set the Frequency and Level

The simplest form of the RF signal is a continuous wave (CW) of constant frequency and amplitude. The RF signal is defined by its frequency, level and phase.

- ▶ Use one of the following:
 - "Status Bar > Frequency and Level"
 - "Frequency panel > Frequency"
 - "Level panel > Level"
 - "Frequency panel > Frequency > Phase"

- On the front panel, press the [Freq] or the [Level] key.

Current frequency and level values are indicated in the "Status bar" so that you can see them at a glance. Values displayed in the status bar and in the "Frequency/Level" dialogs can deviate from each other.

See "RF frequency and level display with a downstream instrument" on page 64.

RF frequency and level display with a downstream instrument

If your test setup includes a downstream instrument, you can enter the parameter of the downstream instrument in the frequency or level settings dialog of the R&S SMA100B. Examples of downstream instruments are mixers, frequency multipliers, amplifiers or attenuators and of their corresponding major parameters offset, multiplier, amplitude. The R&S SMA100B generates the signal without the downstream parameters, but considers all additional parameters concerning the frequency and level.

Example parameters that affect the frequency and level:

- Frequency offset
- Multiplication factor
- User correction

Any of these cases are indicated by a dedicated icon, displayed in the "Frequency" or "Level" tile, depending on the affected parameter.

Figure 4-1 illustrates the calculation of the "Frequency" and "Level" values, displayed in the status bar.




Figure 4-1: Frequency and Level display vs frequency and level at the RF output

f_{RF} , $Level_{RF}$	= Frequency and level ("Status bar > Frequency and Level") at the output of the downstream instrument, see also Calculation of f_{RF} and $Level_{RF}$
$f_{RF\ Out}$, $Level_{RF\ Out}$	= Frequency and level at the output connector [RF] ("RF > RF Frequency > Frequency" and "RF > RF Level > Amplitude")
$n*f$	= Multiplication factor ("RF > RF Frequency > Multiplier")
Δf	= Frequency offset ("RF > RF Frequency > Offset")
$\Delta Level$	= Power offset ("RF > RF Level > Offset")

Calculation of f_{RF} and $Level_{RF}$

- $f_{RF} = n * f_{RF\ Out} + \Delta f$
- $Level_{RF} = Level_{RF\ Out} + \Delta Level$

4.3 RF Frequency Settings

Access:

1. Select "Frequency" > "RF Frequency".

RF Frequency	Phase		
Frequency	3.000 000 000 000 GHz	Main PLL Bandwidth	Narrow
Offset	10.000 000 000 MHz	Multiplier	2.000
User Variation			
Variation Active <i>is Off</i>	<input type="checkbox"/>	Variation Step	1.000 000 000 MHz

2. Observe the information on the home screen, "Frequency" tile.

Frequency	
Offset:	10.000 MHz
Multiplier:	2.000
Ref Out:	10 MHz
Δ Phase:	180.00 deg
Int Ref	Freq Offs

The "Frequency" tile indicates the reference frequency, current frequency offset and multiplier values, and phase offset value.

In the "RF Frequency" dialog, you can configure:

- RF frequency, incl. an offset or multiplication factor of a downstream instrument
- The step size for varying the frequency with the rotary knob.

The remote commands required to define the settings are described in [Chapter 14.16.4, "SOURCE:FREQUENCY Subsystem"](#), on page 594.

Settings

Frequency.....	66
Main PLL Bandwidth.....	66
Offset.....	66
Multiplier.....	66
User Variation.....	67
L Variation Active.....	67
L Variation Step.....	67

Frequency

Sets the RF frequency.

This frequency is output at the RF connector. It does not consider an [Offset](#) or multiplication factor ([Multiplier](#)).

See "[RF frequency and level display with a downstream instrument](#)" on page 64.

Note: Suppressed values in the status bar

For security concerns or certain operating modes, you can hide the frequency and level display in the status bar.

- *********

The display has been disabled for security reasons.

See:

- [Annotation Frequency](#)
- [Annotation Amplitude](#)

- 

The display is disabled when list mode is running, see [Chapter 7, "List and Sweep Mode"](#), on page 157.

Remote command:

[\[:SOURce<hw>\]:FREQuency\[:CW|FIXed\]](#) on page 596

Main PLL Bandwidth

Selects the PLL (Phase Locked Loop) bandwidth of the **main synthesizer**.

"Normal" Default main PLL bandwidth.
The instrument provides the maximum modulation bandwidth and FM/PhiM deviation.

"Narrow" Sets the narrow PLL bandwidth.

Remote command:

[\[:SOURce<hw>\]:FREQuency:PLL:MODE](#) on page 601

Offset

Sets the frequency offset.

This value represents the frequency shift of a downstream instrument, like for example a mixer.

The "Frequency" value displayed in the status bar is the resulting frequency, as it is at the output of the downstream instrument. The frequency at the R&S SMA100B RF output is not changed.

See "[RF frequency and level display with a downstream instrument](#)" on page 64.

Remote command:

[\[:SOURce<hw>\]:FREQuency:OFFSet](#) on page 598

Multiplier

Sets the multiplication factor for the RF frequency.

This value represents the multiplication factor of a downstream instrument, as for example a multiplier.

The "Frequency" value displayed in the status bar is the resulting frequency, as it is at the output of the downstream instrument. The frequency at the R&S SMA100B RF output is not changed.

See ["RF frequency and level display with a downstream instrument"](#) on page 64.

Remote command:

`[:SOURce<hw>] :FREQuency:MUlTIplier` on page 598

User Variation

Defines and activates a user-defined step width for varying the RF frequency or RF level with the rotary knob.

If disabled, the step width varies in steps of one unit at the cursor position.

Variation Active ← User Variation

Activates the set user-defined step width.

Remote command:

`[:SOURce<hw>] :FREQuency:STEP:MODE` on page 600

`[:SOURce<hw>] :POWer:STEP:MODE` on page 639

Variation Step ← User Variation

Sets the user-defined step width.

Remote command:


`[:SOURce<hw>] :FREQuency:STEP [:INCRement]` on page 600

`[:SOURce<hw>] :POWer:STEP [:INCRement]` on page 639

4.4 RF Level Settings


Access:

1. Select "Level" > "RF Level".




In the "RF Level" dialog, you can configure the offset-free level, the level limit, and the step width for varying the level with the rotary knob.

2. Select "User Variation" to set the step width to be used when setting the RF level using the rotary knob.



3. Observe the information on the home screen, "Level" tile.



The "Level" tile indicates the level limit, the user correction status and current correction value, current setting characteristics incl. mode.

The remote commands required to define the settings are described in [Chapter 14.16.11, "SOURce:POWer Subsystem"](#), on page 633.

Settings

RF State/RF ON..... 69
 Amplitude..... 69
 Limit 70
 Offset 70
 Setting Characteristics 70
 Mode 71
 Harmonic Filter 71
 Level Range 71
 Readjust..... 72
 User Variation..... 72
 L Variation Active..... 72
 L Variation Step..... 72

RF State/RF ON

Activates or deactivates the RF output.

Acts as the [RF on/off] key.

Remote command:

:OUTPut<hw> [:STATe] on page 451

Amplitude

Sets the level of the RF signal.

The value is offset-free and corresponds to the level at the RF connector.

See "[RF frequency and level display with a downstream instrument](#)" on page 64.

Note: Suppressed values in the status bar

For security concerns or certain operating modes, you can hide the frequency and level display in the status bar.

- *********

The display has been disabled for security reasons.

See:

- [Annotation Frequency](#)
- [Annotation Amplitude](#)

- 

The display is disabled when list mode is running, see [Chapter 7, "List and Sweep Mode"](#), on page 157.

Remote command:

`[:SOURce<hw>] :POWer :POWer` on page 638

Note: The SCPI command `[:SOURce<hw>] :POWer [:LEVel] [:IMMediate] [:AMPLitude]` sets the level of the "Level" display.

This means, the level containing offset.

Limit

Sets an upper limit for the RF output power.

You can use this value to protect your DUT from damage due to high input power. If you enter an RF level above this value, the instrument limits the output power to this specified value, and generates the warning message:

"Pep value greater than the defined limit." However, the level indication in the status bar is not affected.

The setting is not affected by an instrument preset ([Preset] key or *RST) and the "Save/Recall" function. It is reset only by factory preset.

Remote command:

`[:SOURce<hw>] :POWer :LIMit [:AMPLitude]` on page 636

Offset

Sets a level offset.

This value represents the level shift of a downstream instrument, like, for example, an attenuator or an amplifier.

The "Level" value displayed in the status bar is the resulting level, as it is at the output of the downstream instrument. The level at the R&S SMA100B RF output is not changed.

See "[RF frequency and level display with a downstream instrument](#)" on page 64.

Remote command:

`[:SOURce<hw>] :POWer [:LEVel] [:IMMediate] :OFFSet` on page 639

Setting Characteristics

Selects additional quality characteristics to optimize the behavior of the RF signal level for the corresponding application.

- | | |
|-----------------|--|
| "Auto" | <p>Sets the RF output level automatically according to the selected mode.</p> <p>In this mode, the instrument provides the highest dynamic range and fastest setting times, as specified in the data sheet.</p> <p>The RF signal is shortly blanked when the step attenuator is switching.</p> |
| "Uninterrupted" | <p>Suppresses blanking at level transitions. Frequency transitions can lead to an RF level blanking due to hardware specific switching points.</p> <p>This mode reduces the dynamic range of the instrument. The step attenuator is fixed.</p> |

"Strictly Monotone"

Executes signal level changes monotonically increasing or decreasing.

The setting makes sure that increasing the level value exclusively results in an increased output level, and vice versa.

All electronic switches, which might affect the monotonicity are fixed. The operation mode is useful for applications using level searching algorithms which rely on a strictly monotonous behavior.

"Constant-VSWR"

Suppresses output impedance variations at the RF output connector, due to changed level settings.

"High Dyn. Uninterrupted"

R&S SMAB-K724

Provides a linear output power that is uninterrupted over a wide dynamic range.

"User"

Indicates that a setting has been modified in the expert mode. The expert mode is a protected function, that requires protection level 2 password.

Remote command:

[\[:SOURce<hw>\]:POWer:LBEHaviour](#) on page 636

Mode

Allows you to optimize the RF output signal for applications, where improved harmonic distortion or improved wideband noise is required.

"Normal"

Generates an RF output signal with high signal to noise ratio as well as low distortion, according to the data sheet.

"Low Noise"

Optimizes the signal to noise ratio.

"Low Distortion"

Reduces distortion (harmonics) of the RF signal to a minimum.

Remote command:

[\[:SOURce<hw>\]:POWer:LMODe](#) on page 636

Harmonic Filter

Activates low harmonic filter or enables its automatic switching.

"On"

Ensures best low harmonics performance but decreases the level range.

"Auto"

Applies an automatically selected harmonic filter that fits to the current level setting.

Remote command:

[:OUTPut<hw>:FILTer:MODE](#) on page 452

Level Range

Shows the interruption-free range of the level that you can use in the currently selected mode.

Remote command:

[:SOURce<hw>] :POWer:RANGe:LOWer? on page 641

[:SOURce<hw>] :POWer:RANGe:UPPer? on page 641

Readjust

Recalculates and adjusts the internal switch positions of the RF chain according to the current level.

Remote command:

[:SOURce<hw>] :POWer:ALC:SONCe on page 634

User Variation

Defines and activates a user-defined step width for varying the RF frequency or RF level with the rotary knob.

If disabled, the step width varies in steps of one unit at the cursor position.

Variation Active ← User Variation

Activates the set user-defined step width.

Remote command:

[:SOURce<hw>] :FREQuency:STEP:MODE on page 600

[:SOURce<hw>] :POWer:STEP:MODE on page 639

Variation Step ← User Variation

Sets the user-defined step width.

Remote command:

[:SOURce<hw>] :FREQuency:STEP [:INCRe ment] on page 600

[:SOURce<hw>] :POWer:STEP [:INCRe ment] on page 639

4.5 RF Phase Settings

The phase in sinusoidal signals defines the initial angle at its origin.

Access:


1. Select "Frequency" > "Phase".



In the "Phase" tab, you can determine the delta phase value and reset the phase to this reference.

2. Observe the information on the home screen, "Frequency" tile.

The "Frequency" tile indicates used reference frequency, current frequency offset and multiplier values, and the delta phase value.



The remote commands required to define the settings are described in [Chapter 14.16.10, "SOURCE:PHASe Subsystem"](#), on page 632.

Settings

Delta Phase	73
Reset Delta Phase Display	73

Delta Phase

Sets the phase of the RF signal.

The current phase of the signal is used as the reference.

Remote command:

[:SOURCE<hw>] : PHASe on page 632

Reset Delta Phase Display

Adopts the selected "Delta Phase" value as the current value, and resets delta phase to 0 degrees.

Remote command:

[:SOURCE<hw>] : PHASe:REFERENCE on page 632

5 Analog Modulations

The R&S SMA100B supports AM (amplitude modulation), FM (frequency modulation), Φ M (phase modulation (PhiM)), and also PULM (pulse modulation). It generates low frequency signals (LF) as sine, triangle, trapezoidal or square (pulse) waveform, that can be output and further processed by a downstream instrument.

5.1 Required Options

R&S SMA100B base unit equipped with the following options:

- Option frequency (R&S SMAB-B10x)
- Option pulse modulator (R&S SMAB-K22)
- Option pulse generator (R&S SMAB-K23)
(supports generation of single and double pulse signals)
- Option multi-function generator (R&S SMAB-K24)
- Option pulse train generator (R&S SMAB-K27)
(requires R&S SMAB-K23)
- Option AM/FM/PhiM, up to 6 GHz (R&S SMAB-K720)
- Option Scan AM (R&S SMAB-K720 and R&S SMAB-K721)

For more information, see data sheet.

5.2 Modulation Types and Signal Sources

Radio transmitters do not transmit an audio signal directly. Instead, they modulate the audio signal onto a continuous wave (CW) carrier with much higher frequency.

A CW carrier has a sinusoidal waveform with constant amplitude and constant frequency. Modulating a signal onto the carrier means varying a property of the carrier according to the modulating signal. The three basic modulation types FM, AM and PhiM for example, vary one property of the carrier proportional to the instantaneous amplitude of the modulating signal.

Signal sources

If fully equipped, the R&S SMA100B modulates signals from the following sources:

- **Internal modulation source**
 - *Two LF generators*
Each of the LF generators provides a modulation signal with sine, pulse, triangle or trapezoid shape.
 - *Noise generator*
The noise generator supplies white noise with selectable bandwidth and distribution.

- *High-performance pulse generator*
Generates single and double pulse, or pulse train signals.
- **External modulation source**
 - Amplitude, frequency or phase modulation signals are input at the Ext connector.
 - Pulse modulation signals, at the Pulse Ext connector.

Signal output

You can perform AM, FM and PhiM with the signal of any of the provided sources. Moreover, you can combine two modulation signals and generate a two-tone signal. Regardless of the signal source, the generated signal can be output for further processing in a downstream instrument.

Current configuration is indicated in the "Analog Modulations > Overview" dialog; the output signal routing can be changed, too.

Input and output connectors

Direction	Modulation	Connector	Required option
Output	Pulse modulation from internal signal Loop through of pulse signal from Pulse Ext	Pulse Video	R&S SMAB-K22/-K23
	All analog modulations Marks the valid level and frequency	Signal Valid	
	Pulse generator	Pulse Sync	
	LF generator	LF	
Input	AM, FM, PhiM	Ext **)	R&S SMAB-K720
	Pulse modulation from external source ^{*)} Or External trigger or gate signal ^{*)}	Pulse Ext ^{*)}	R&S SMAB-K22

- ^{*)} External trigger signal and external signal for the pulse modulation cannot be used simultaneously, because these signals are expected at the same connector Pulse Ext. Signal polarity and impedance are the same for both signals.
- ^{**)} The external modulation signal must have a voltage of $U_S = 1 \text{ V}$ ($U_{EFF} = 0.707 \text{ V}$) to achieve the displayed modulation depth and range.
Note that the input voltage does not exceed 1 V, otherwise modulation distortions can occur.

For more information, see data sheet.

Interactions and characteristics

- FM and PhiM modulations exclude each other and cannot be performed simultaneously.
- In sweep mode, LF frequency sweep is possible.

- The settings of the modulation signal affect all analog modulations that use an internal modulation source.
- You can feed an external LF signal in each of the two paths.
- Using exponential amplitude modulation with an external source, sets the coupling of the corresponding input automatically to DC.
See also [Chapter 5.4.6.2, "Source > External Settings"](#), on page 104.
- If you use Scan AM with an external modulation input signal, the voltage range is adjusted to +/- 6 V (usually +/-1 V). Therefore, we recommend that you do not use the external modulation signal for FM or PhiM in parallel, since the voltage will affect the modulations.
- The amplitude modulation types linear and exponential derive the carrier signal either linear in percent / volt, or as complex exponential in dB / volt.
- Scan AM provides the scan mode, i.e. an amplitude modulation depth with an extended dynamic range that automatically uses the exponential amplitude modulation type.
- For pulse modulated signals, you can select between fast or smoothed transitions, see ["Transition Type"](#) on page 78.
This setting is available over the entire frequency range for all instruments with frequency options up to 6 GHz. For higher frequency options, the frequency range for the smoothed setting is limited.

For more information, see data sheet.

5.3 Activating Analog Modulations

- ▶ Use one of the following:
 - Select "Modulation > Amplitude Modulation/Frequency Modulation/Phase Modulation > State > ON".
 - Select "Modulation > MOD ON".
 - Press the [Mod on/off] key.

[Mod on/off]

Activate one or more analog modulations and press the [Mod on/off] key to toggle the state of them all.

Pressing the key again restores the status that was active before the last switch-off.

Remote command:

`[:SOURce<hw>] :MODulation [:ALL] [:STATe]` on page 517

5.4 Modulation Settings

Access:

- ▶ Select "Modulation" > "Modulation Sources".

The "Modulation" dialog contains all functions and settings to configure the analog modulations, the LF signal sources for performing a modulation, and the LF signal output.

The remote commands required to define these settings are described in:


- [Chapter 14.16.1.2, "SOURce:AM Subsystem"](#), on page 518
- [Chapter 14.16.1.3, "SOURce:FM Subsystem"](#), on page 524
- [Chapter 14.16.1.4, "SOURce:PM Subsystem"](#), on page 529
- [Chapter 14.16.1.5, "SOURce:PULM Subsystem"](#), on page 533
- [Chapter 14.16.6, "SOURce:LFOOutput Subsystem"](#), on page 603

5.4.1 Pulse Modulation

Option: see [Chapter 5.1, "Required Options"](#), on page 74.

Access:

- ▶ Select "Modulation" > "Pulse Modulation".



The "Pulse Modulation" dialog contains all parameters required to configure the pulse modulator and the pulse generator. It also displays the pulse signal graphically.

For an overview of the supported signals sources and related connectors, see [Chapter 5.2, "Modulation Types and Signal Sources"](#), on page 74.

The remote commands required to define these settings are described in [Chapter 14.16.1.5, "SOURce:PULM Subsystem"](#), on page 533.

Settings:

State.....	78
Source.....	78
Transition Type.....	78

State

Activates pulse modulation and triggers the following automatic settings:

- Pulse generator is activated.
The signal is output at the Pulse Video connector.
To deactivate the signal output, set "Pulse Generator" > [Pulse Output State](#) > "Off".

Remote command:

[: SOURce<hw>] : PULM: STATE on page 537

Source

Selects between the internal "Pulse Generator" or an "External" pulse signal for the modulation.

"Pulse Generator"

Selects the internal generator.

See [Pulse Generator](#).

"External"

Modulation source is fed to the input connector.

See "[Signal sources](#)" on page 74.

Remote command:

[: SOURce<hw>] : PULM: SOURce on page 537

Transition Type

Selects between "Fast" or "Smoothed" slew rate (slope).

"Fast"

Enables fast transitions with shortest rise and fall times.

"Smoothed"

Flattens the slew rate, resulting in longer rise / fall times. Use this mode if you are working with devices that are sensitive to steep slopes.

Note: The R&S SMA100B supports this functionality up to a certain frequency, depending on the installed frequency options, see also "[Interactions and characteristics](#)" on page 75.

For more information, see data sheet.

Remote command:


[: SOURce<hw>] : PULM: TTYPe on page 538

5.4.2 FM, PhiM and AM Modulation Settings

Option: R&S SMAB-K720

Access:

- ▶ Select "Modulation" > "Amplitude Modulation/Frequency Modulation/Phase Modulation".



The "FM", "ΦM" and "AM" tabs contain the parameters per modulation type.

Source

State.....80

Source.....80

FM settings.....80

- └ Deviation.....80
- └ Deviation Mode.....81
- └ Total Deviation.....81
- └ Ratio Path2/Path1.....81
- └ Mode.....81

PhiM settings.....82

- └ Deviation.....82
- └ Deviation Mode.....82
- └ Total Deviation.....82
- └ Ratio Path2/Path1.....82
- └ Mode.....83

AM settings.....83

- └ Mode.....84
- └ Type.....84
- └ Depth.....84
- └ Sensitivity.....84

L Deviation Mode.....	84
L Total Depth.....	85
L Ratio Path2/Path1.....	85

State

Activates a modulation.

Note: Some modulations exclude each other and cannot be performed simultaneously. For more information, see data sheet.

Remote command:

[:SOURce<hw>] :AM<ch> :STATe on page 520

[:SOURce<hw>] :FM<ch> :STATe on page 526

[:SOURce<hw>] :PM<ch> :STATe on page 531

Source

Selects the LF signal source.

You can vary the signal sources for each of the modulations.

"LF Generator 1/2"

Selects one or both of the internally generated LF signals.

See [Chapter 5.4.6.1, "Source > LF Generator Settings"](#), on page 100.

"External 1/2" Selects an externally supplied LF signal.

"Noise Generator"

Selects the internally generated noise signal.

See [Chapter 5.4.6.3, "Source > Noise Generator Settings"](#), on page 105.

Remote command:

[:SOURce<hw>] :AM<ch> :SOURce on page 520

[:SOURce<hw>] :FM<ch> :SOURce on page 527

[:SOURce<hw>] :PM<ch> :SOURce on page 531

FM settings

The following settings are dedicated to FM.

Deviation ← FM settings

Sets the frequency modulation deviation in Hz.

The maximal deviation depends on the RF frequency and the selected modulation mode (see data sheet).

Maximal possible deviation is selected automatically, if one of the following applies:

- The selected deviation is too high for the particular frequency
- The selected frequency is outside of the range where deviation is possible.

A warning message indicates this situation, too.

Remote command:

[:SOURce<hw>] :FM<ch> [:DEViation] on page 526

Deviation Mode ← FM settings

Enables you to couple the LF signal of both paths and determines the mode for fixing the total deviation.

The total deviation is the sum of both paths. When the sum is exceeded, the R&S SMA100B reports a settings conflict, but does not change the settings.

- | | |
|---------------|--|
| "Uncoupled" | Enables you to adjust the deviation for each path independently. |
| "Fixed Total" | Couples the deviation of both paths in per Hz. If you change the deviation of any path, the R&S SMA100B automatically adjusts the value of the other path. The sum always results in the set Total Deviation . |
| "Fixed Ratio" | Couples the deviation ratio of both paths. If you change the deviation of any path, the R&S SMA100B adjusts the value of the other path. |

Remote command:

`[:SOURce<hw>] :FM:DEVIation:MODE` on page 527

Total Deviation ← FM settings

Sets the sum of the signal deviation for path 1 and path 2 in Hz when using combined sources in [Deviation Mode > Fixed Total](#).

[Deviation](#) of both paths always sum up to the value of the total deviation.

Behavior when changing any depth settings:

- Changing the total deviation adjusts the deviation of both paths proportionally.
- Changing the deviation of one path adjusts the deviation of the other path. The sum always results in the set total deviation.

Remote command:

`[:SOURce<hw>] :FM:DEVIation:SUM` on page 528

Ratio Path2/Path1 ← FM settings

Sets the deviation ratio (path2 to path1) in percent.

Example:

If the deviation in path1 is 10 kHz and the ratio is 50%, the deviation in path 2 is automatically set to 5 kHz.

Remote command:

`[:SOURce<hw>] :FM:RATio` on page 528

Mode ← FM settings

Selects the mode of the frequency modulation.

"High Bandwidth"

The maximum range for modulation bandwidth is available.

"Low Noise"

Phase modulation with phase noise and spurious characteristics close to CW mode. The range for modulation bandwidth and FM deviation is reduced (see data sheet).

To reduce the phase noise further, set the [Main PLL Bandwidth](#) = "Narrow"

Remote command:

`[:SOURce<hw>] :FM:MODE` on page 528

PhiM settings

The following settings are dedicated to PhiM.

Deviation ← PhiM settings

Sets the phase modulation deviation in radians or degrees.

The maximal deviation depends on the RF frequency and the selected modulation mode (see data sheet).

Maximal possible deviation is selected automatically, if one of the following applies:

- The selected deviation is too high for the particular frequency
- The selected frequency is outside of the range where deviation is possible.

A warning message indicates this situation, too.

Remote command:

`[:SOURce] :PM<ch> [:DEVIation]` on page 533

Deviation Mode ← PhiM settings

Enables you to couple the LF signal of both paths and determines the mode for fixing the total deviation.

The deviation sum 2 rad at a maximum. When the sum is exceeded, the R&S SMA100B adjusts the settings automatically.

- | | |
|---------------|--|
| "Uncoupled" | Enables you to adjust the deviation for each path independently. |
| "Fixed Total" | Couples the deviation of both paths. If you change the deviation of any path, the R&S SMA100B automatically adjusts the value of the other path. The sum always results in the set Total Deviation . |
| "Fixed Ratio" | Couples the deviation ratio of both paths. If you change the deviation of any path, the R&S SMA100B adjusts the value of the other path. |

Remote command:

`[:SOURce<hw>] :PM:DEVIation:MODE` on page 532

Total Deviation ← PhiM settings

In [Deviation Mode = Fixed Total](#), sets the sum of the signal deviation for path 1 and path 2.

[Deviation](#) of both paths always sum up to the value of the total deviation.

Behavior when changing any depth settings:

- Changing the total deviation adjusts the deviations of both paths proportionally.
- Changing the deviation of one path adjusts the deviation of the other path. The sum always results in the set total deviation.

Remote command:

`[:SOURce<hw>] :PM:DEVIation:SUM` on page 532

Ratio Path2/Path1 ← PhiM settings

Sets the deviation ratio (path2 to path1) in per cent.

Example:

If the deviation in path1 is 10 rad and the ratio is 50%, the deviation in path 2 is automatically set to 5 rad.

Remote command:

[:SOURce<hw>] :PM:RATio on page 533

Mode ← PhiM settings

Selects the mode of the phase modulation.

"High Bandwidth"

The maximum range for modulation bandwidth and PhiM deviation is available.

However, phase noise increases at low frequencies, and the range of PhiM deviation is limited. This mode is suitable if you process high frequencies.

"High Deviation"

The maximum range for PhiM deviation is available.

Phase noise is improved for low frequencies compared to the default mode. The range for modulation frequency is limited (see data sheet). This mode is suitable for low modulation frequencies and/or high PhiM deviation.

"Low Noise"

Frequency modulation with phase noise and spurious characteristics close to CW mode. The range for modulation bandwidth and FM deviation is reduced (see data sheet).

Remote command:

[:SOURce<hw>] :PM:MODE on page 532

AM settings

The following settings are dedicated to AM.

Sources	<input checked="" type="radio"/> FM	<input type="radio"/> ΦM	<input checked="" type="radio"/> AM	<input type="radio"/> Output	Overview	✕
Mode	Normal		Type	Linear		
Path 1			Path 2			
State	<input checked="" type="checkbox"/>		State	<input checked="" type="checkbox"/>		
Source	LF Generator 1		Source	External 1		
Depth	30.00 %		Sensitivity	30.0 %/V		
Deviation Mode	Fixed Ratio		Ratio Path 2 / Path 1	100.00 %		

Mode ← AM settings

Selects the mode to derive the carrier signal for amplitude modulation.

- "Normal" Performs the standard amplitude modulation with a single sinusoidal carrier signal.
- "Scan" (Option: R&S SMAB-K721)
Performs amplitude modulation with a higher dynamic range. The R&S SMA100B provides a special exponential amplitude modulation system optimized for highest dynamic range. You can use the scan mode to emulate level behaviors of transmitter/receiver systems with rotating antennas. Selecting "Mode > Scan" sets the modulation type to "Exponential".
Note: Using exponential AM with an external source affects other operating modes as described in ["Interactions and characteristics"](#) on page 75.

Remote command:

`[:SOURce<hw>] :AM:MODE` on page 522

Type ← AM settings

Selects the type of the amplitude modulation for both paths.

Using exponential AM with an external source affects the coupling mode and the external modulation input, see ["Interactions and characteristics"](#) on page 75.

- "Linear" Sets linear amplitude modulation with depths specified in percent / volt.
- "Exponential" Sets the exponential AM type with depths in dB / volt.

Remote command:

`[:SOURce<hw>] :AM:TYPE` on page 524

Depth ← AM settings

Determines the depth of the modulation signal in percent.

For "Type = Exponential", the unit of "AM Depth" changes to dB.

The depth is limited by the maximum peak envelope power (PEP).

Remote command:

`[:SOURce<hw>] :AM<ch>:DEPTH:LINear` on page 521

`[:SOURce<hw>] :AM<ch>:DEPTH:EXponential` on page 522

Sensitivity ← AM settings

Sets the input sensitivity of the external modulation signal.

Remote command:

`[:SOURce<hw>] :AM<ch>:SENSitivity[:LINear]` on page 524

`[:SOURce<hw>] :AM<ch>:SENSitivity:EXponential` on page 523

Deviation Mode ← AM settings

Enables you to couple the LF signal of both paths and determines the mode for fixing the total deviation.

The deviation sum of both paths is 100% in total. When the sum is exceeded, the R&S SMA100B reports a settings conflict, but does not change the settings.

- "Uncoupled" Enables you to adjust the deviation depth for each path independently.
- "Fixed Total" Couples the deviation depth of both paths in per cent. If you change the depth of any path, the R&S SMA100B automatically adjusts the value of the other path. The sum always results in the set [Total Depth](#).
- "Fixed Ratio" Couples the deviation ratio of both paths. If you change the depth of any path, the R&S SMA100B adjusts the value of the other path.

Remote command:

`[:SOURce<hw>] :AM:DEVIation:MODE` on page 523

Total Depth ← AM settings

Sets the sum of the signal [Depth](#) for path 1 and path 2 in per cent when using combined sources and [Deviation Mode > Fixed Total](#).

Using external LF signals, the R&S SMA100B indicates the [Sensitivity](#) per Volts for the input signal.

Provided both signal paths are turned on, the depth of both paths always sum up to the value of the total depth.

Behavior when changing any depth settings:

- Changing the total depth adjusts the depths of both paths proportionally.
- Changing the depth of one path adjusts the depth of the other path. The sum always results in the set total depth.

Remote command:

`[:SOURce<hw>] :AM:DEPTh:SUM` on page 522

Ratio Path2/Path1 ← AM settings

Sets the deviation ratio of the signal depth for path 2 to path 1 in per cent when using combined sources.

Using external LF signals, the R&S SMA100B indicates the [Sensitivity](#) per Volts for the input signal.

In conjunction with the deviation mode, you can set the depth of both paths independently or coupled.

- [Deviation Mode > Uncoupled](#)
Enables you to set the [Depth](#) or [Sensitivity](#) of both paths independently.
- [Deviation Mode > Fixed Ratio](#)
Couples the ratio of the two paths as follows.
 - Changing the ratio path2/path1 adjusts the depth of both path2. The depth of path1 remains the same
 - Changing the depth of one path adjusts the depth of the other accordingly. The ratio path2/path1 remains the same.

Remote command:


`[:SOURce<hw>] :AM:RATio` on page 523

5.4.3 Pulse Generator

Option: see [Chapter 5.1, "Required Options"](#), on page 74.

Access:

- ▶ Select "Modulation" > "Pulse Modulation > Pulse Generator".



The "Pulse Generator" tab contains the settings for creating the pulse modulation signal internally.

- [Pulse Generator > General Settings](#)..... 86
- [Pulse Generator > Pulse Train Settings](#)..... 90
- [Import/Export List Files](#)..... 94

5.4.3.1 Pulse Generator > General Settings

Access:

- ▶ Select "Modulation" > "Pulse Modulation > Pulse Generator".

Settings

- [Pulse Mode](#)..... 87
- [Trigger Mode](#)..... 87
- [Pulse Period](#)..... 89
- [Pulse Width](#)..... 89
- [Double Pulse Width](#)..... 90
- [Pulse Delay](#)..... 90
- [Double Pulse Delay](#)..... 90
- [Pulse Output State](#)..... 90

Show Connector.....	90
Pulse Output Polarity.....	90
Execute Single Trigger.....	90

Pulse Mode

Sets the operating mode of the pulse generator. Depending on the selection, the instrument displays the associated parameters.

"Single"	Generates a single pulse in one pulse period.
"Double"	Generates two pulses in one pulse period.
"Train"	Option: R&S SMAB-K27 Generates a user-defined pulse train. See Chapter 5.4.3.2, "Pulse Generator > Pulse Train Settings" , on page 90.

Remote command:

[: SOURce<hw>] : PULM:MODE on page 535

Trigger Mode


Selects between continuous triggering or triggering initiated by a trigger event from an external signal.

See also ["Input and output connectors"](#) on page 75.

"Auto"	Generates the internal modulation signal continuously.
"Single"	The pulse generator is triggered by an internal trigger event, initiated with Execute Single Trigger . The pulse signal is generated once.
"Ext Single"	Generates a single pulse signal, triggered by an external signal.


"Ext Triggered" Generates the pulse signal each time an external trigger event occurs.

Example: Generation of single pulse signal ("Pulse Mode = Single") using "Trigger Mode = Ext Triggered"



- 1 = External trigger signal input with "Trigger Input Polarity = Normal" (the positive slope is active)
- 2 = Sync signal
- 3 = Pulse signal
- Δt = Trigger delay between the trigger and the sync signal start; see data sheet
- delay = "Pulse Delay = 100 ns"
- PW = "Pulse Width = 100 ns"

Example: Generation of double pulse signal ("Pulse Mode = Double") using "Trigger Mode = Ext Triggered"




- 1 = External trigger signal input with "Trigger Input Polarity = Normal" (the positive slope is active)
- 2 = Sync signal

- 3 = Pulse signal
- a = Trigger signal during double pulse generation is without effect
- Δt = Trigger delay between the trigger and the sync signal start; see data sheet
- delay = "Double Pulse Delay = 200 ns"; the first pulse starts without a delay
- PW = "Double Pulse Width = 100 ns"

"Ext Gated" Generates the signal triggered by an external gate signal.

Example: Generation of single pulse signal ("Pulse Mode = Single") using "Trigger Mode = Ext Gated"



- 1 = External trigger signal input with "Trigger Input Polarity = Normal" (the positive slope is active)
- 2 = Sync signal
- 3 = Pulse signal
- Δt = Trigger delay between the trigger and the sync signal start; see data sheet
- delay = "Pulse Delay = 100 ns"
- PW = "Pulse Width = 100 ns"
- period = "Pulse Period = 300 ns" (time between the pulse start of two consecutive pulses)
- a = Gate active duration (pulses are generated during the gate active part)

Remote command:

[\[:SOURCE<hw>\]:PULM:TRIGger:MODE](#) on page 535

Pulse Period

Sets the repetition rate of the generated pulse signal.

Remote command:

[\[:SOURCE<hw>\]:PULM:PERiod](#) on page 536

Pulse Width

Sets the pulse duration of the generated pulse signal.

Note: The pulse width must be at least 20 ns less than the set pulse period.

Remote command:

[\[:SOURCE<hw>\]:PULM:WIDTH](#) on page 536

Double Pulse Width

Sets the width of the second pulse.

Remote command:

`[:SOURce<hw>] :PULM:DOUBle:WIDTh` on page 537

Pulse Delay

Sets the pulse delay. The pulse delay determines the time that elapses after a trigger event before pulse modulation starts. The pulse delay is not effective for double pulse generation.

Remote command:

`[:SOURce<hw>] :PULM:DELay` on page 536

Double Pulse Delay

Sets the delay from the start of the first pulse to the start of the second pulse.

Remote command:

`[:SOURce<hw>] :PULM:DOUBle:DELay` on page 537

Pulse Output State

Activates the output of the pulse modulation signal.

Remote command:

`[:SOURce<hw>] :PGENerator:OUTPut [:STATe]` on page 631

**Show Connector**

Accesses a dialog that displays the physical location of the selected connector on the front/rear panel of the instrument.

Pulse Output Polarity

Sets the polarity of the pulse output signal.

Remote command:

`[:SOURce<hw>] :PGENerator:OUTPut:POLarity` on page 631

Execute Single Trigger

If "Trigger Mode = Single", initiates a single pulse sequence manually.

Remote command:


`[:SOURce] :PULM [:INTernal] [:TRAIIn] :TRIGger:IMMediate` on page 536

5.4.3.2 Pulse Generator > Pulse Train Settings

Option: see [Chapter 5.1, "Required Options"](#), on page 74.

Access:

1. Select "Modulation" > "Pulse Modulation > Pulse Generator" > "**Pulse Mode = Train**".



2. Select "Pulse Train Data".
3. Select an existing file or select "New" to create one.
4. Define the filename.
Select "Edit Pulse Train Data", if the file is empty or to control and change the values.
5. In the "Edit Pulse Train Data" dialog, enter the pulse on/off times and pulse repetition values.
6. Select "Save".

A pulse train is a sequence of pulses with user-defined repetition, and pulse on and off times. Once defined, pulse train settings can be saved in a file. The filename is user-definable; the file extension (*.pulstrn) is assigned automatically. When a file is selected, the filename is indicated.

Possible ways to configure a pulse train

You can configure a pulse train in the following ways:

- **Internally**
 - Use the built-in editor table editor, see in the "Pulse Generator > Pulse Train" dialog.
Once defined, pulse train settings can be saved in a file. For example, to exchange configuration between instruments or to modify the file content with an external program and reload them again.
The filename is user-definable; the file extension is *.pulstrn.
 - Using the corresponding remote-control commands.

Note that you have to create a pulse train file first.

- **Externally**

Create a pulse train sequence as a CSV file with Microsoft Excel, with a Notepad or a similar tool, save it with the predefined extension. Transfer the file to and load it into the instrument.

Pulse train ASCII file format

Files describing pulse trains are simple files in text or comma-separated value (CSV) file format. The filename is user-definable; the file extension is `*.csv` or `*.txt`.

The file contains a list of pulse definition values, one row per pulse; a new line indicator separates the pulses. Pulses are defined with their pulse on time, pulse off time given in us and number of repetitions.

Example: Pulse train file content (*.txt file)

```
0.0001,0.0005,2
0.00025,0.0005,1
0.0001,0.0003,3
```

For file handling, use the standard functions in the "File Manager", see [Chapter 11.8, "Using the File Manager"](#), on page 303.

Settings

Pulse Train Data.....	92
Edit Pulse Train Data.....	93
Data handling keys	93
L Go To.....	93
L Edit.....	93
L Save As/Save.....	93
Fill.....	93

Pulse Train Data

Accesses the standard "File Select" function of the instrument. The provided navigation possibilities in the dialog are self-explanatory.

Pulse train files are files with predefined file extension `*.pulstrn`. When a file is selected, the dialog indicates the filename.

You can create the file internally in the table editor or externally.

- To select an existing file, select "Select List > navigate to the file *.pulstrn > Select"
- Use the general editor function to create internally new file or to edit an existing one.
- Use the standard file manager function to load externally created files to the instrument.

Remote command:

`[:SOURce<hw>] :PULM:TRAI:n:CATalog?` on page 540

`[:SOURce<hw>] :PULM:TRAI:n:SElect` on page 542

`[:SOURce<hw>] :PULM:TRAI:n:DElete` on page 540

Edit Pulse Train Data

Accesses the build-in table editor to define a new pulse train file or edit an existing one.

"On-Time, μ s/Off-Time, μ s"

Sets the pulse on and pulse off time.

"Count"

Sets the number of repetitions of an "On-/ Off-Time" value pair.

Pulses with "Count = 0" are ignored.

Use this method to skip value pairs temporarily, without deleting them from the table.

Remote command:

[:SOURce<hw>] :PULM:TRAI:n:ONTime on page 541


[:SOURce<hw>] :PULM:TRAI:n:OFFTime on page 541

[:SOURce<hw>] :PULM:TRAI:n:REPetition on page 541

[:SOURce<hw>] :PULM:TRAI:n:DELeTe on page 540

Data handling keys

Standard functions for file and data handling.



Note: Save a list only after filling both columns (frequency and level), otherwise the entries are lost.

Go To ← Data handling keys

Selects a row for editing.

Edit ← Data handling keys

Enables you to insert, or delete a row or ranges within a list, and provides access to a dialog for automatic filling.

See " [Fill...](#) " on page 93.

Save As/Save ← Data handling keys

Saves the list in a file with user-defined name and predefined file extension. To save a copy or create a file, use the "Save as" function.

Fill...

Provides parameters for filling a table automatically with user-defined values.

From 0	Range 1
Column To Fill Frequency/Hz	
Start Value 2.000 000 000 000 GHz	End Value 2.000 000 000 000 GHz
Increment Value 200.000 000 000 MHz	
<input checked="" type="checkbox"/> Fill	

To fill the table, select "Fill".

Note: Once you enter a value or fill a column, the editor automatically adds preset values in the other columns. This functionality protects against data loss, otherwise incomplete rows will be lost when saving. You can simply override these values.

"From / Range"

Defines the start line and number of lines to be filled.

"Column To Fill"

Selects, if the column is filled up with frequencies in Hz, levels in dBm or dwell times in s.

"Start Value / End Value"

Sets the start value for frequency, level or dwell time. The end value is read only and depends on the increment value and the range.

"Increment Value"

Determines the step size.

"Fill"

Fills the column specified in "Column To fill".

5.4.3.3 Import/Export List Files

Access:

- Select one of the following:
 - "Sweep" > "List mode".
 - "Level" > "User Correction".
 - "Modulation > Pulse Modulation > Pulse Generator > Pulse Mode = Train".

2. Select "Import/Export".




Figure 5-1: Im-/Export dialog (example with UCOR settings)

The "Import/Export" dialog contains all functions and settings to import externally created list data or to export it accordingly. You can process and store a list in the formats *.txt (ASCII), or *.csv (plain text with identical sequence of fields). The table separators and the decimal floating point numbers are customizable.

Settings

Mode	95
ASCII File Settings.....	95
Select (ASCII) Source/Select (ASCII) Destination.....	96
Select Source/Select ASCII Destination.....	96
Import / Export.....	96

Mode

Selects import or export of a data list file. The provided parameters vary according to the selected mode.

Remote command:

- [:SOURce<hw>] :LIST:DEXChange:MODE on page 628
- [:SOURce<hw>] :CORRection:DEXChange:MODE on page 594
- [:SOURce<hw>] :PULM:TRAIIn:DEXChange:MODE on page 542

ASCII File Settings

Defines the format and the separators of the associated data file.

- "Extension" Selects *.csv or *.txt format.
- "Decimal Point" Sets "Point" (dot) or "Comma" as the decimal separator used in the ASCII data with floating-point numerals.

"Column Separator"

Sets the separator between the columns in an ASCII table.
Available are: "Tab", "Semicolon", "Comma" or "Space".

Remote command:

[:SOURce<hw>] :LIST:DEXChange:AFILe:EXTension on page 627
 [:SOURce<hw>] :LIST:DEXChange:AFILe:SEParator:DECimal on page 628
 [:SOURce<hw>] :LIST:DEXChange:AFILe:SEParator:COLumn on page 628
 [:SOURce<hw>] :CORRection:DEXChange:AFILe:EXTension on page 592
 [:SOURce<hw>] :CORRection:DEXChange:AFILe:SEParator:DECimal
 on page 593
 [:SOURce<hw>] :CORRection:DEXChange:AFILe:SEParator:COLumn
 on page 593
 [:SOURce<hw>] :PULM:TRAIIn:DEXChange:AFILe:EXTension on page 543
 [:SOURce<hw>] :PULM:TRAIIn:DEXChange:AFILe:SEParator:DECimal
 on page 543
 [:SOURce<hw>] :PULM:TRAIIn:DEXChange:AFILe:SEParator:COLumn
 on page 543

Select (ASCII) Source/Select (ASCII) Destination

In "Mode > Import", access the file select dialog that provides standard file handling functions.

Where:

- "Select ASCII Source": defines the file to be loaded (imported)
- "Select ASCII Destination": selects the filename under that the loaded file is saved

Remote command:

[:SOURce<hw>] :LIST:DEXChange:AFILe:CATalog? on page 627
 [:SOURce<hw>] :LIST:DEXChange:AFILe:SELeCt on page 627
 [:SOURce<hw>] :CORRection:DEXChange:AFILe:CATalog? on page 592
 [:SOURce<hw>] :CORRection:DEXChange:AFILe:SELeCt on page 593
 [:SOURce<hw>] :PULM:TRAIIn:DEXChange:AFILe:CATalog? on page 543
 [:SOURce<hw>] :PULM:TRAIIn:DEXChange:AFILe:SELeCt on page 544

Select Source/Select ASCII Destination

In "Mode > Export", access the file select dialog that provides standard file handling functions.

Where:

- "Select Source": selects the file to be exported
- "Select ASCII Destination": defines the filename and the file path for the exported file

Remote command:

[:SOURce<hw>] :LIST:DEXChange:SELeCt on page 628
 [:SOURce<hw>] :CORRection:DEXChange:SELeCt on page 594
 [:SOURce<hw>] :PULM:TRAIIn:DEXChange:SELeCt on page 544

Import / Export

Imports or exports the selected data list file, depending on the current mode.

Remote command:

[:SOURce<hw>] :LIST:DEXChange:EXECute on page 627

[:SOURce<hw>] :CORRection:DEXChange:EXECute on page 593

[:SOURce<hw>] :PULM:TRAIIn:DEXChange:EXECute on page 544


5.4.4 Pulse Graph

Option: see [Chapter 5.1, "Required Options"](#), on page 74.

Access:

- ▶ Select "Modulation" > "Pulse Modulation > Pulse Graph".

The pulse graph is the graphical representation of the current pulse signal.



The height of the bars corresponds to the selected amplitude of the pulse signal.

File Name

Indicates the name of the pulse train data file.

To create or select a file, see ["Pulse Train Data"](#) on page 92.

Remote command:

[:SOURce<hw>] :PULM:TRAIIn:SELEct on page 542

Zooming

You can zoom into the diagram to visualize the graph in more detail:


- "Zoom Position": Sets the focus on the time axis where to enlarge the graph.
- "Zoom In": Enlarges the graph at the selected position.

- "Zoom Out" for the reverse operation.

5.4.5 Pulse External / Trigger Settings

Access:

- ▶ Select "Modulation" > "Pulse Modulation > Pulse External / Trigger".



The dialog specifies some characteristics of the Pulse Ext connector. This connector is common for the pulse generator and the pulse modulator. For an overview, see ["Input and output connectors"](#) on page 75.

Settings

Polarity	98
Impedance	98
Threshold	99
Show Connector	99

Polarity

Sets the polarity of the active slope of a pulse input signal, that is the external pulse modulation signal.

Remote command:

`[:SOURce<hw>] :PULM:POLarity` on page 538

Impedance

Sets the input impedance.

Remote command:

`[:SOURce<hw>] :PULM:IMPedance` on page 538

Threshold

Sets the high/low threshold in volts for the signal at the [Pulse Ext] connector.

Remote command:

[\[:SOURce<hw>\]:PULM:THReshold](#) on page 539

**Show Connector**

Accesses a dialog that displays the physical location of the selected connector on the front/rear panel of the instrument.

5.4.6 FM, PhiM and AM Modulation Sources

Access:

- ▶ Select "Modulation > Modulation Sources".


In the "Sources" tab, you can configure an LF modulation signal for performing analog modulations. It includes the setting parameters of the internal LF-and multi-function generators, the noise generator, and an external signal source.

- [Source > LF Generator Settings](#)..... 100
- [Source > External Settings](#)..... 104
- [Source > Noise Generator Settings](#)..... 105

5.4.6.1 Source > LF Generator Settings

Access:

- ▶ Select "Modulation" > "Modulation Sources > LF Generator".



The internal LF signal can be the modulation signal source for any of the analog modulations. The LF signal applies to all modulations which use the internal modulation signal. Therefore, any modification of the LF signal immediately affects all currently active modulations.

Settings

State (LF frequency sweep)..... 100

Shape..... 101

Frequency..... 102

Period..... 102

Pulse Width..... 102

Pulse Duty Cycle..... 103

Triangle Rise..... 103

Trapezoid Rise / Fall..... 103

Trapezoid High..... 103

State (LF frequency sweep)

Status of the LF frequency sweep signal.

You find this parameter in two dialogs:

- "LF Frequency Sweep" turns on/off the signal generation.
See [Sweep Mode Settings](#) for access.

- "Analog Modulation Sources" displays the current state (read-only). If it is turned on, this dialog provides the varying sweep frequency, see [Current Frequency](#).

Note: Active sweep mode deactivates other sweeps or lists and vice versa.

Remote command:


`[:SOURce<hw>] :LFOutput:FREQUENCY:MODE` on page 607

Shape

Selects the waveform shape of the LF signal.


The "Triangle" and "Trapezoid" waveforms require option R&S SMAB-K24.

"Sine"




1 = Period

"Square"




1 = Period
2 = Width

"Pulse"




1 = Pulse period
2 = Pulse width
3 = Delay

"Triangle"

1 = Triangle period

2 = Triangle rise

"Trapezoid"

1 = Trapezoid period

2 = Trapezoid rise

3 = Trapezoid fall

4 = Trapezoid high

Remote command:

[:SOURce<hw>]:LFOutput<ch>:SHAPE on page 610

Frequency

Sets the frequency of the LF generator for sine signals.

Set the signal shape with the parameter [Shape](#).

Remote command:

[:SOURce]:LFOutput<ch>:FREQUENCY on page 606

PeriodSets the repetition rate of the generated LF signal for triangle, trapezoid or pulse shapes, see [Shape](#).The period of sine signals is calculated from the selected [Frequency](#)

Remote command:

[:SOURce<hw>]:LFOutput<ch>:SHAPE:TRAPeZe:PERiod on page 611

[:SOURce<hw>]:LFOutput<ch>:SHAPE:TRIangle:PERiod on page 612

[:SOURce<hw>]:LFOutput<ch>:SHAPE:PULSe:PERiod on page 610

Pulse Width

Sets the pulse duration of the generated pulse signal.

Remote command:

[:SOURce<hw>] :LFOutput<ch>:SHAPE:PULSe:WIDTh on page 611

Pulse Duty Cycle

Sets the ratio between the pulse duration and the pulse period in percent.

Remote command:

[:SOURce<hw>] :LFOutput<ch>:SHAPE:PULSe:DCYCLe on page 610

Triangle Rise

Sets the time required for the triangle signal to change from low level to high level.

Remote command:

[:SOURce<hw>] :LFOutput<ch>:SHAPE:TRIangle:RISE on page 612

Trapezoid Rise / Fall

Sets the time required for the trapezoid signal to change from low level to high level, and vice versa.

Remote command:

[:SOURce<hw>] :LFOutput<ch>:SHAPE:TRAPeZe:RISE on page 612

[:SOURce<hw>] :LFOutput<ch>:SHAPE:TRAPeZe:FALL on page 611

Trapezoid High

Sets how long the trapezoid signal is at high level.

Remote command:

[:SOURce<hw>] :LFOutput<ch>:SHAPE:TRAPeZe:HIGH on page 611

5.4.6.2 Source > External Settings

Access:

- ▶ Select "Modulation" > "Modulation Sources > External".

External 1	External 2	LF Generator
Coupling(AC/DC) AC	Coupling(AC/DC) DC	External
Impedance High	Impedance 50 Ω	
Bandwidth 10 MHz	Bandwidth 10 MHz	
Show Connector ...	Show Connector ...	
		Noise Generator

The "External" settings section contains all parameters required to configure the signal of an externally supplied LF signal.

Settings

Coupling (AC/DC)	104
Impedance	104
Bandwidth	105
Show Connector	105

Coupling (AC/DC)

Selects the coupling mode (AC or DC) for the external signal.

- "AC" Disconnects the DC voltage component and uses only the AC component of the modulation signal.
- "DC" Uses the modulation signal with both components, AC and DC. For active external exponential AM, sets the coupling of the corresponding input automatically to DC.

Remote command:

[:SOURce<hw>] : INPut:MODext:COUPling<ch> on page 602

Impedance

Sets the impedance for the externally supplied signal.

Remote command:

[:SOURce<hw>] :INPut:MODext:IMPedance<ch> on page 603

Bandwidth

Displays the maximum bandwidth of the external LF signal.

Remote command:

[:SOURce] :LFOutput<ch>:BANDwidth? on page 606




Show Connector

Accesses a dialog that displays the physical location of the selected connector on the front/rear panel of the instrument.

5.4.6.3 Source > Noise Generator Settings

Access:

- ▶ Select "Modulation" > "Modulation Sources > Noise Generator".



The "Noise Generator" settings contain all parameters to configure the signal of the internal noise generator.

Settings

Distribution..... 105
 Bandwidth..... 105

Distribution

Selects the distribution of the noise power density.

"Gauss" Generates the noise power according to a Gaussian distribution.

"Equal" Generates an evenly distributed noise.

Remote command:

[:SOURce<hw>] :NOISe:DISTriBution on page 630

Bandwidth

Sets the noise bandwidth as distinct value.

You can set the bandwidth between 100 kHz and 10 MHz in 100 KHz steps.

Remote command:


[:SOURce<hw>] :NOISe: BANDwidth | BWIDth on page 629

[:SOURce<hw>] :NOISe: BWIDth: STATe on page 629

5.4.7 LF Signal Output Settings

Access:

- ▶ Select "Modulation" > "LF Output".



In the "LF Output" tab, you can configure the signal at the LF outputs, determine the output voltage or add a DC offset. Activate both paths to output the sum signal of the two sources.

Settings:

State.....	107
Source.....	107
Show Connector.....	107
Output Voltage.....	107
DC-Offset.....	107
Load Impedance.....	107
Noise Level.....	108
L Noise Density.....	108
L Noise Level.....	108

State

Activates the output of the LF signal.

Remote command:

[\[:SOURce\]:LFOutput<ch>\[:STATe\]](#) on page 608

Source

Select the sources for the signal output at the LF connector. If you activate path 1 *and* 2, those sources are added.

Use the "Show Connector" function to find out where this connector is located.

"LF Generator 1/2"

Selects one of internally generated LF signals.

"AM"

Option: R&S SMAB-K720

Selects the AM signal.

"FM/PhiM"

Option: R&S SMAB-K720

Selects the signal also used by the frequency or phase modulations.

"Noise Generator"

Selects the internally generated noise signal.

"External 1/2"

Selects one of the externally supplied LF signals.

Remote command:

[\[:SOURce\]:LFOutput<ch>:SOURce](#) on page 609

**Show Connector**

Accesses a dialog that displays the physical location of the selected connector on the front/rear panel of the instrument.

Output Voltage

Sets the voltage (peak) of the selected LF output source.

Remote command:

[\[:SOURce\]:LFOutput<ch>:INTernal:VOLTage](#) on page 608

DC-Offset

Adds a DC offset to the LF output signal.

Remote command:

[\[:SOURce\]:LFOutput:OFFSet](#) on page 609

Load Impedance

Sets the specification of the load impedance interconnected to the LF generator output.

This parameter is available in case of activated R&S SML0x emulations only, see "Remote Access Settings" > "Instrument Emulations" > "Language" on page 368.

These signal generators come with an LF generator source impedance of 10 Ohm which is not available with the R&S SMA100B.

The set LF generator load impedance enables the R&S SMA100B to emulate the 10 Ohm LF generator source impedance of these generators by a corresponding increase of the open circuit LF generator output voltage.

The load impedance setting is not affected by an instrument preset ([Preset] key or *RST), restart or the "Save/Recall" function. It is reset to the default value of 1 MOhm by a factory preset only.


Remote command:

n.a.

Noise Level

Access:

- Select "Modulation" > "Output > Noise Level".



Noise Density ← Noise Level

Indicates the level of the noise signal for a bandwidth of 1 Hz (relative).

Remote command:

`[:SOURce<hw>] :NOISe:LEVel:RELative?` on page 630

Noise Level ← Noise Level

Indicates the level of the noise signal per Hz within the total bandwidth (absolute).

Remote command:


`[:SOURce<hw>] :NOISe:LEVel [:ABSolute] ?` on page 630

5.4.8 Overview

Option: AM and FM/PM require R&S SMAB-K720

Access:

- ▶ Select "Modulation" > "Modulation Sources > Overview".



- Blue color = Active output signal (AM and FM)
- Gray color = Inactive output signal (LF Out)
- Miniature graph = Indicates an active source
- Connectors = Indicate a connector (e.g. external signal) is involved in the path of the signal

The "Overview" tab is an interactive diagram that indicates the active modulations and the signal being output.

Here you can:

- Select the output signal ("LF Out") in one or two paths; the setting acts as the parameter "LF Output Source"
- Select the source for each modulation and modulation path; the setting acts as the parameter "Source"
- Activate modulation in one or two paths; the setting acts as the parameter "State"
To generate a two-tone signal composed form the two paths of the same modulation type, activate both paths.
- The "FM" box allows switching to "PhiM", but those modulations are mutually exclusive.

LFOut

Label for the LF output settings in the overview.

Remote command:

n.a.

AM

Label for the amplitude modulation settings in the overview.

Remote command:

n.a.

FM/PhiM

Selects the modulation signal to be assigned to the output. You can assign the frequency or phase modulated signal.

Remote command:

n.a.

5.5 How to Generate an Amplitude Modulated Signal

The following examples use the internal LF generator.

To set the frequency and level of the RF signal

1. Press [Preset] to start from a defined state.
2. In the status bar, set "Frequency = 2 GHz".
3. Set "Level = -20 dBm".

To configure the modulation signal (LF generator)

1. Select "Modulation" > "Modulation Source".
2. In the "Sources" tab, select "Shape > Sine".
3. Set "Frequency = 20 kHz".

The period is calculated automatically and indicates "Period = 50.00 µs".

To configure the amplitude modulation settings

1. In "Modulation" dialog, select the "AM" tab.
2. Set "Source = LF Generator1"
3. Set "Depth = 30%"
4. Select "State = I" to activate the modulation.
5. Set "Level > RF ON" to enable signal output.

5.6 How to Generate a Pulse Modulated Signal

The following example uses the internal pulse generator.

To set the frequency and level of the RF signal

1. Press [Preset].
2. In the status bar, set "Frequency = 4 GHz".
3. Set "Level = -25 dBm".

To configure the pulse generator

1. Select "Modulation" > "Pulse Generator".
2. Select "Pulse Mode = Double".
3. Set "Pulse Period = 10 us".
4. Set "Pulse Width = 2 us".
5. Set "Double Pulse Width = 1.2 us".
6. Set "Double Pulse Delay = 4.5 us".
7. Activate "Pulse Output State".
8. Set "Trigger Mode = Auto".

In the "Pulse Graph" tab, you can view the generated pulse signal graphically.

To enable pulse modulation

1. Select the "Pulse Modulation" tab.
2. Set "State = I" to activate pulse modulation.
3. Set "Level > RF ON" to enable signal output.

5.7 How to Generate a Pulse Train Modulated Signal

The following example uses the internal pulse generator.

To set the frequency and level of the RF signal

1. Press [Preset].
2. In the status bar, set "Frequency = 6 GHz".
3. Set "Level = -25 dBm".

To configure the pulse generator

1. Select "Modulation" > "Pulse Generator".
2. Select "Pulse Mode = Train".
3. Select "Pulse Train Data".
Accesses the standard function for file handling.

4. Select an existing file or select "New" to create one.
5. Define the filename.
Select "Edit Pulse Train Data", if the file is empty or to control and change the values.
6. In the "Edit Pulse Train Data" dialog, enter the pulse on/off times and pulse repetition values.
For example:
 - "On-Time = 500 us", "OFF-Time = 2 ms", "Count = 2"
 - "On-Time = 100 us", "OFF-Time = 2.5 ms", "Count = 1"
 - "On-Time = 10 us", "OFF-Time = 50 us", "Count = 10"
7. "Save" the file and close the dialog.
The instrument returns to the /var/user/ where it has saved the file.
8. Select the file in the directory.
9. Confirm with "Select".
10. In the "Pulse Generator" dialog, select "Pulse Output State = On".
11. Set "Trigger Mode = Auto".

In the "Pulse Graph" tab, you can view the generated pulse signal graphically.

To enable pulse train modulation

1. Select the "Pulse Modulation" tab.
2. Set "State = I".
3. Set "Level > RF ON" to enable signal output.

6 Avionic Standards

The R&S SMA100B supports avionic standards VOR, ILS and ADF.

Contents

• Required Options	113
• About the Avionics Options	113
• VOR Configuration and Settings	119
• ILS Configuration and Settings	127
• ADF Configuration and Settings	151

6.1 Required Options

The R&S SMA100B base unit equipped with the following options:

- Option frequency (R&S SMAB-B10x)
- Option signal generation for VOR, ILS and ADF (R&S SMAB-K25)

6.2 About the Avionics Options

The following topics summarize some background information on the related avionics standards. The provided overview information is intended as explanation of the used terms and does not aim to be comprehensive.

Brief overview of the avionics standards

- **Landing systems:** ILS (Instrument Landing System), MLS (Microwave Landing System)
Landing systems are ground-based approach systems that provide precision guidance to an aircraft approaching and (blind) landing on a runway.
- **Radio/Flight navigation systems:** VOR (VHF Omnidirectional Radio), DME (Distance measuring equipment), TACAN (Tactical Air Navigation), ADF (Automatic Direction Finder)
The radio navigation systems are aircraft systems that support the pilots to determine the aircraft positions and stay on course. These systems are more and more obsolete. However, due to security reasons, these flight navigation systems are still in use.
- **Radar systems:** RSR (En Route Surveillance Radar), ASR (Airport Surveillance Radar), PAR (Precision Approach Radar), ASDE (Airport Surface Detection Equipment), SSR (Secondary Surveillance Radar)
Radar systems are divided into two groups, primary (RSR, ASR, PAR and ASDE) and secondary (SSR). The radar systems are used in air traffic control to mainly detect and measure the position of aircraft, i.e. its range and bearing.

6.2.1 VHF Omni Directional Radio Range (VOR)

Very high frequency (VHF) omnidirectional radio range (VOR) is used for radio navigation and helps aircraft to determine their position and stay on course.

A VOR system consists of a ground transmission station and a VOR receiver on the board of the aircraft.

The transmitter stations operate at VHF frequencies of 108 MHz to 118 MHz (see [Table 6-1](#)), with the code identification (COM/ID) transmitting on a modulation tone of 1.020 kHz. It emits two types of signals:

- An omnidirectional reference signal (REF) that can consist of two parts:
 - 30 Hz frequency modulated (FM) sine wave on subcarrier 9.96 kHz from amplitude modulation (AM) carrier
 - 1020 Hz AM modulated sine wave morse code
- A directional positioning signal, variable (VAR): 30 Hz AM modulated sine waves with variable phase shift

The position of the aircraft is determined by measuring azimuth as the difference in phase of those two signals. The magnetic north is defined as the reference point, for which both signals are exactly in phase.

VOR ICAO Frequencies

The individual values in [Table 6-1](#) cells are:

- **Chan.** = ICAO channel number
- **VOR Freq.** = VOR Interrogation frequency (MHz)

Table 6-1: VOR ICAO standard frequencies (MHz) and channels

Chan.	VOR Freq.	Chan.	VOR Freq.	Chan.	VOR Freq.	Chan.	VOR Freq.	Chan.	VOR Freq.	Chan.	VOR Freq.
17X	108.00	45X	110.80	75X	112.80	89X	114.20	103X	115.60	117X	117.00
17Y	108.05	45Y	110.85	75Y	112.85	89Y	114.25	103Y	115.65	117Y	117.05
19X	108.20	47X	111.00	76X	112.90	90X	114.30	104X	115.70	118X	117.10
19Y	108.25	47Y	111.05	76Y	112.95	90Y	114.35	104Y	115.75	118Y	117.15
21X	108.40	49X	111.20	77X	113.00	91X	114.40	105X	115.80	119X	117.20
21Y	108.45	49Y	111.25	77Y	113.05	91Y	114.45	105Y	115.85	119Y	117.25
23X	108.60	51X	111.40	78X	113.10	92X	114.50	106X	115.90	120X	117.30
23Y	108.65	51Y	111.45	78Y	113.15	92Y	114.55	106Y	115.95	120Y	117.35
25X	108.80	53X	111.60	79X	113.20	93X	114.60	107X	116.00	121X	117.40
25Y	108.85	53Y	111.65	79Y	113.25	93Y	114.65	107Y	116.05	121Y	117.45
27X	109.00	55X	111.80	80X	113.30	94X	114.70	108X	116.10	122X	117.50
27Y	109.05	55Y	111.85	80Y	113.35	94Y	114.75	108Y	116.15	122Y	117.55
29X	109.20	57X	112.00	81X	113.40	95X	114.80	109X	116.20	123X	117.60
29Y	109.25	57Y	112.05	81Y	113.45	95Y	114.85	109Y	116.25	123Y	117.65
31X	109.40	58X	112.10	82X	113.50	96X	114.90	110X	116.30	124X	117.70
31Y	109.45	58Y	112.15	82Y	113.55	96Y	114.95	110Y	116.35	124Y	117.75

Chan.	VOR Freq.	Chan.	VOR Freq.	Chan.	VOR Freq.	Chan.	VOR Freq.	Chan.	VOR Freq.	Chan.	VOR Freq.
33X	109.60	59X	112.20	83X	113.60	97X	115.00	111X	116.40	125X	117.80
33Y	109.65	59Y	112.25	83Y	113.65	97Y	115.05	111Y	116.45	125Y	117.85
35X	109.80	70X	112.30	84X	113.70	98X	115.10	112X	116.50	126X	117.90
35Y	109.85	70Y	112.35	84Y	113.75	98Y	115.15	112Y	116.55	126Y	117.95
37X	110.00	71X	112.40	85X	113.80	99X	115.20	113X	116.60		
37Y	110.05	71Y	112.45	85Y	113.85	99Y	115.25	113Y	116.65		
39X	110.20	72X	112.50	86X	113.90	100X	115.30	114X	116.75		
39Y	110.25	72Y	112.55	86Y	113.95	100Y	115.35	114Y	116.75		
41X	110.40	73X	112.60	87Y	114.00	101X	115.40	115X	116.80		
41Y	110.45	73Y	112.65	87Y	114.05	101Y	115.45	115Y	116.85		
43X	110.60	74X	112.70	88X	114.10	102X	115.50	116X	116.90		
43Y	110.65	74Y	112.75	88Y	114.15	102Y	115.55	116Y	116.95		

Related Settings

For VOR settings at the R&S SMA100B, see [Chapter 6.3, "VOR Configuration and Settings"](#), on page 119.

6.2.2 Instrument Landing System (ILS)

The instrument landing system is used during the landing approach and monitors the correct approach path to the runway.




Figure 6-1: Approach navigation using instrument landing system (ILS) [1MA193]

An ILS system consists of three independent subsystems:

- A glide slope for vertical guidance.
- A localizer for horizontal guidance.
- (optional) marker beacons

Glide Slope


The glide slope transmitter is located near the end of the runway (nearest to the start of the aircraft approach).

Typically, vertically aligned antennas transmit two intersecting main beams on top of one another at carrier frequencies between 329 MHz and 335 MHz (see [Table 6-2](#)). The top beam is usually modulated at 90 Hz and the beam below at 150 Hz [[1MA193](#)].

The information on position is provided after demodulation of the beam signals by evaluating the difference in depth of modulation (DDM). The following scenarios are possible:

- Predominance of the 90 Hz beam: the aircraft is too high and must descend
- Predominance of the 150 Hz beam: the aircraft is too low and needs to climb
- The signal strength from both beams is equal: the aircraft is in the center, on the right course.

If there is a predominance of the 90 Hz beam, then the aircraft is too high and must descend. A predominant 150 Hz means that the aircraft is too low and needs to climb.




Localizer

The localizer transmitter is located near the end of the runway (nearest to the start of the aircraft approach). Typically, horizontally aligned antennas transmit two intersecting main beams beside one another at carrier frequencies between 108 MHz and 112 MHz (see [Table 6-2](#)). As seen from the approaching aircraft coming in for a landing, the left beam is usually modulated at 90 Hz and the right beam at 150 Hz [[1MA193](#)].

The information on position is provided after demodulation of the beam signals by evaluating the difference in depth of modulation (DDM). The following scenarios are possible:

- Predominance of the 90 Hz beam: the aircraft is too far to the left and must turn to the right
- Predominance of the 150 Hz beam: the aircraft is too far to the right and must turn to the left
- The signal strength from both beams is equal: the aircraft is in the center, on the right course.



ILS ICAO Frequencies

The individual values in [Table 6-2](#) are:

- **Chan.** = ICAO channel number
- **LOC Freq.** = ILS localizer frequency (MHz)
- **GS Freq.** = ILS glide slope frequency (MHz)

Table 6-2: ILS glide slope and localizer ICAO standard frequencies (MHz) and channels

Chan.	LOC Freq.	GS Freq.	Chan.	LOC Freq.	GS Freq.	Chan.	LOC Freq.	GS Freq.
18X	108.10	334.70	32X	109.50	332.60	46X	110.90	330.80
18Y	108.15	334.55	32Y	109.55	332.45	46Y	110.95	330.65
20X	108.30	334.10	34X	109.70	333.20	48X	111.10	331.70
20Y	108.35	333.95	34Y	109.75	333.05	48Y	111.15	331.55
22X	108.50	329.90	36X	109.90	333.80	50X	111.30	332.30
22Y	108.55	329.75	36Y	109.95	333.65	50Y	111.35	332.15
24X	108.70	330.50	38X	110.10	334.40	52X	111.50	332.90
24Y	108.75	330.35	38Y	110.15	334.25	52Y	111.55	332.75
26X	108.90	329.30	40X	110.30	335.00	54X	111.70	333.50
26Y	108.95	329.15	40Y	110.35	334.85	54Y	111.75	333.35
28X	109.10	331.40	42X	110.50	329.60	56X	111.90	331.10
28Y	109.15	331.25	42Y	110.55	329.45	56Y	111.95	330.95
30X	109.30	332.00	44X	110.70	330.20			
30Y	109.35	331.85	44Y	110.75	330.05			

Marker Beacons

Marker beacon receivers are used for a rough distance measurement. They are available only for some ILS installations [[1MA193](#)].




Figure 6-2: Marker beacon placement and distance to runway

Marker beacon receivers decode audio and provide signaling output to identify one of three marker beacons installed near the runway. They transmit a narrow beam width at 75 MHz carrier frequency in a vertical direction. Each of them has a different distinct modulation code to allow the receiver to identify which one it is flying over [1MA193].

Both visual (color of the marker beacon) and audio tone identification is supported for determining which marker has been flown over. The audio/visual pairing of marker beacons is as follows:

- Outer marker flashes BLUE in the cockpit at 400 Hz (“relaxed” tone).
- Middle marker flashes AMBER in the cockpit at 1300 Hz (“hurried” tone).
- Inner marker flashes WHITE in the cockpit at 3000 Hz (“urgent” tone).

Related Settings

For ILS settings at the R&S SMA100B, see the following sections:

- [Chapter 6.4.2, "ILS Glide Slope Settings"](#), on page 130
- [Chapter 6.4.3, "ILS Localizer Settings"](#), on page 137
- [Chapter 6.4.4, "ILS Marker Beacons Settings"](#), on page 146

6.2.3 Automatic Direction Finder (ADF)

ADF receivers provide the relative bearing of a basic ground-based Non-Directional Beacon (NDB) to the fore/aft axis of the aircraft. The beacon signal is generated by a directional antenna assembly in the aircraft.

The ADF determines the direction to the NDB station relative to the aircraft and is used for instrument approaches (autopilot). It provides additional information to other navigation equipment, e.g. VOR.

Related Settings

For ADF settings at the R&S SMA100B, see [Chapter 6.5, "ADF Configuration and Settings"](#), on page 151.

6.3 VOR Configuration and Settings

Option: R&S SMAB-K25

Access:

- ▶ Select "Modulation > Avionic Standards > VOR".

The remote commands required to define VOR settings are described in [Chapter 14.16.2.5, "SOURCE:VOR Subsystem"](#), on page 578.


Settings

- [General Settings](#)..... 119
- [Signal Settings](#)..... 122
- [Position Settings](#)..... 124
- [COM/ID Settings](#)..... 125

6.3.1 General Settings

Access:

- ▶ Select "VOR > General"



This dialog comprises general settings of the VOR standard, the default and the "Save/Recall" settings.

By default, a VOR modulation signal is set on an RF carrier with a frequency of 108 MHz or ICAO channel 17X. The 9.96 kHz subcarrier signal is frequency modulated with a 30.00 Hz reference signal. The COM/ID signal has 1.02 kHz frequency, the variable phase signal 30.00 Hz frequency.

If enabled, the avionic standard modulation is displayed in the "Modulation" tile as follows:

- "Avionic: VOR" for enabled VOR modulation
- "Avionic ILS: Glide Slope/Localizer/Marker Bcn" for enabled ILS glide slope/localizer/marker beacons modulation
- "Avionic: ADF" for enabled ADF modulation

Changing a parameter in the avionic standards causes an instant signal change in the R&S SMA100B. There is no extra measurement cycle to calculate the RMS value of the baseband signal to set the correct RF level.

If the avionics standard is activated for the first time, or after every subsequent on/off sequence, the measurement cycle will take place to determine the correct RF level. Every subsequent parameter change in the avionic standard is performed without another measurement cycle to provide a continuous signal output.

Settings

State.....	120
Set To Default.....	120
Save/Recall.....	121
Carrier Frequency Mode.....	121
Carrier Frequency.....	121
ICAO Channel.....	121
EXT AM.....	122

State

Activates the avionic standard.

Activation of the standard deactivates a previously active avionic standard. The "VOR/ILS > Carrier Frequency" setting is applied automatically to the RF [Frequency](#) and displayed in the status bar.

Remote command:

[<subsystem>:STATE](#) on page 551

Set To Default

Calls the default settings. The values of the main parameters are listed in the following table.

Standard	Parameter	Value
VOR/ILS/ADF	State	Not affected by "Set to default"
VOR	Carrier Frequency Mode	User Defined
	Carrier Frequency	108.000000 MHz
ILS	ILS Component	Glide Slope (GS)
	ILS GS > Carrier Frequency Mode	User Defined

Standard	Parameter	Value
	ILS GS > Carrier Frequency	334.700000 MHz
ADF	Carrier Frequency	190.000 kHz

Remote command:

`<subsystem>:PRESet` on page 550

Save/Recall

Accesses the "Save/Recall" dialog, that is the standard instrument function for saving and recalling the complete dialog-related settings in a file. The provided navigation possibilities in the dialog are self-explanatory.

The filename and the directory, in which the settings are stored, are user-definable; the file extension is however predefined.

Remote command:

`<subsystem>:SETTing:CATalog` on page 550

`<subsystem>:SETTing:DELeTe` on page 550

`<subsystem>:SETTing:LOAD` on page 550

`<subsystem>:SETTing:STORe` on page 551

Carrier Frequency Mode

Sets the mode for the carrier frequency of the signal.

"User Defined" Activates user-defined variation of the carrier frequency.

"ICAO" Activates variation in predefined steps according to standard VOR transmitting frequencies (see [Table 6-1](#)). The start value can be selected in the field "ICAO Channel".

Remote command:

`[:SOURce<hw>] :VOR:FREQuency:MODE` on page 583

Carrier Frequency

Requires "Carrier Frequency Mode > User Defined".

Sets the carrier frequency of the signal.

Remote command:

`[:SOURce<hw>] :VOR:FREQuency` on page 583

ICAO Channel

Requires "Carrier Frequency Mode > ICAO".

Sets the ICAO channel and the corresponding transmitting frequency.

If avionic standard modulation is activated and you change the "RF Frequency", the frequency value of the closest ICAO channel is applied automatically. The "ICAO Channel" is also updated.

For an overview of the VOR ICAO channel frequencies, see [Table 6-1](#).

Remote command:

`[:SOURce<hw>] :VOR:ICAO:CHANnel` on page 583

EXT AM

Enables/disables additional modulation from an external source. The external signal is input via the Ext connector.

"OFF" Selects the internal modulation source for the avionic standard modulation.

"EXT (MOD AM)" Selects the external source. The external signal is added to the internal signal. Switching off the internal source is not possible. The external signal is input via the Ext connector. The sensitivity is 10 mV per percent modulation depth.

Note: There can be an overmodulation as a function of the level of the external signal without a corresponding caution message being generated. To avoid an overmodulation, the peak value of the external signal is to be delimited corresponding to the sum of the modulation depths of the remaining VOR signal components.


Remote command:

[:SOURce<hw>] :VOR:SOURce on page 578

6.3.2 Signal Settings

Access:

- ▶ Select "VOR > Signal".



This dialog provides access to signal settings of the VOR modulation signal.

Settings

Mode..... 123
 VAR/REF Frequency..... 123
 VAR Depth..... 123

Subcarrier Frequency.....	123
Subcarrier Depth	123
REF Deviation.....	124

Mode

Selects the operating mode for the VOR modulation signal.

"Norm"	VOR modulation is active.
"Var"	Amplitude modulation of the output signal with the VAR signal component (30Hz signal content) of the VOR signal. The modulation depth corresponds to the value set under VAR Depth .
"Subcarrier"	Amplitude modulation of the output signal with the unmodulated FM carrier (9960Hz) of the VOR signal. The modulation depth corresponds to the value set under Subcarrier Depth .
"Subcarrier + FM"	Amplitude modulation of the output signal with the frequency-modulated FM carrier (9960Hz) of the VOR signal. The frequency deviation corresponds to the value set under REF Deviation , the modulation depth corresponds to the value set under "Subcarrier Depth".

Remote command:

`[:SOURCE<hw>] :VOR:MODE` on page 584

VAR/REF Frequency

Sets the frequency of the VAR signal and the REF signal. As the two signals must have the same frequency, the setting is valid for both signals.

Remote command:

`[:SOURCE<hw>] :VOR:VAR:FREQUENCY` on page 586

VAR Depth

Sets the AM modulation depth of the 30Hz VAR signal.

Note: The sum of "Subcarrier depth", "VAR depth" and "COM/ID > Depth" must be smaller than 100 %.

Remote command:

`[:SOURCE<hw>] :VOR:VAR[:DEPTH]` on page 586

Subcarrier Frequency

Sets the frequency of the FM carrier.

Remote command:

`[:SOURCE<hw>] :VOR:SUBCarrier[:FREQUENCY]` on page 585

Subcarrier Depth

Sets the AM modulation depth of the FM carrier.

Note: The sum of "Subcarrier depth", "VAR depth" and "COM/ID > Depth" must be smaller than 100 %.

Remote command:

`[:SOURCE<hw>] :VOR:SUBCarrier:DEPTH` on page 585

REF Deviation

Sets the frequency deviation of the reference signal on the FM carrier.


Remote command:

[\[:SOURce<hw>\]:VOR:REFerence\[:DEViation\]](#) on page 585

6.3.3 Position Settings

Access:

- ▶ Select "VOR > Position".



This dialog provides access to position settings related to the VOR modulation signal.

Settings

[Bearing Angle](#)..... 124
[Direction](#)..... 124

Bearing Angle

Sets the phase angle between the 30 Hz VAR signal and the 30 Hz reference signal. The orientation of the angle depends on the set [Direction](#).

Remote command:

[\[:SOURce<hw>\]:VOR\[:BANGLE\]](#) on page 579

Direction

Sets the reference position of the phase information.

The angle set under "Bearing Angle" corresponds to the angle between the geographic north and the connection line from beacon to airplane.

"From" Selection of the beacon as a reference position.

"To" Selection of the airplane position as a reference position.

Remote command:

[:SOURce<hw>] :VOR [:BANGLE] :DIRection on page 579

6.3.4 COM/ID Settings

Access:

- ▶ Select "VOR > COM/ID"

VOR		ILS <i>Glide Slope</i>	ADF	
COM/ID State <input type="checkbox"/>				General
Code	MUC	Period	9.000 s	Signal
Frequency	1.020 00 kHz	Depth	10.0 %	Position
Time Schema	Standard			COM I/D
Dot Length	100.0 ms			

This dialog comprises COM/ID signal settings related to the VOR signal.

Settings

COM/ID State.....	125
Code.....	126
Period.....	126
Frequency.....	126
Depth.....	126
Time Schema.....	126
Dot Length.....	126
Dash Length.....	126
Symbol Space	127
Letter Space	127

COM/ID State

Enables/disables the COM/ID signal.

See also [Chapter D, "Morse Code Settings"](#), on page 745.

Remote command:

[:SOURce<hw>] :VOR:COMid [:STATe] on page 582

Code

Sets the coding of the COM/ID signal by the international short name of the airport (e.g. MUC for the Munich airport).

The COM/ID tone is sent according to the selected code, see [Chapter D, "Morse Code Settings"](#), on page 745.

If no coding is set, the COM/ID tone is sent uncoded (key down).

Remote command:

`[:SOURce<hw>] :VOR:COMid:CODE` on page 580

Period

Sets the period of the COM/ID signal.

Remote command:

`[:SOURce<hw>] :VOR:COMid:PERiod` on page 581

Frequency

Sets the frequency of the COM/ID signal.

Remote command:

`[:SOURce<hw>] :VOR:COMid:FREQuency` on page 581

Depth

Sets the AM modulation depth of the COM/ID signal.

Note: The sum of [Subcarrier Depth](#) , [VAR Depth](#) and [COM/ID > Depth](#) must be smaller than 100 %.

Remote command:

`[:SOURce<hw>] :VOR:COMid:DEPTH` on page 580

Time Schema

Sets the time schema of the Morse code for the COM/ID signal.

- "Standard"
The set dot length determines the length of the dash, the symbol space and letter space of the Morse code.
- "User"
You can set each length value separately.

Remote command:

`[:SOURce<hw>] :VOR:COMid:TSCHEMA` on page 582

Dot Length

Sets the length of a Morse code dot.

If "Time Schema > Standard", the dot length value determines also the length of the dash (= 3 times the dot length), symbol space (= dot length) and letter space (= 3 times the dot length).

Remote command:

`[:SOURce<hw>] :VOR:COMid:DOT` on page 580

Dash Length

Requires "Time Schema > User".

Sets the length of a Morse code dash.

Remote command:

[\[:SOURCE<hw>\]:VOR:COMid:DASH](#) on page 580

Symbol Space

Requires "Time Schema > User".

Sets the length of the Morse code symbol space.

Remote command:

[\[:SOURCE<hw>\]:VOR:COMid:SYMBOL](#) on page 582

Letter Space

Requires "Time Schema > User".

Sets the length of a Morse code letter space.

Remote command:

[\[:SOURCE<hw>\]:VOR:COMid:LETTER](#) on page 581

6.4 ILS Configuration and Settings

Option: R&S SMAB-K25

Access:

- ▶ Select "Modulation > Avionic Standards > ILS".

The remote commands required to define ILS settings are described in [Chapter 14.16.2.4, "SOURCE:ILS Subsystem"](#), on page 555.

Settings


- [General Settings](#)..... 127
- [ILS Glide Slope Settings](#)..... 130
- [ILS Localizer Settings](#)..... 137
- [ILS Marker Beacons Settings](#)..... 146

6.4.1 General Settings

This chapter comprises general settings, which are common for all ILS components.

Access:

- ▶ Select "ILS > General".



This dialog comprises general settings of the ILS standard, the default and the "Save/Recall" settings.

By default, an ILS glide slope modulation signal on an RF carrier with a frequency of 344.7 MHz or ICAO channel 18X. The dual-tone LF signal with frequencies 90 Hz and 150 Hz and a balanced modulation at SDM of 80 %.

If enabled, the avionic standard modulation is displayed in the "Modulation" tile as follows:

- "Avionic: VOR" for enabled VOR modulation
- "Avionic ILS: Glide Slope/Localizer/Marker Bcn" for enabled ILS glide slope/localizer/marker beacons modulation
- "Avionic: ADF" for enabled ADF modulation

Changing a parameter in the avionic standards causes an instant signal change in the R&S SMA100B. There is no extra measurement cycle to calculate the RMS value of the baseband signal to set the correct RF level.

If the avionics standard is activated for the first time, or after every subsequent on/off sequence, the measurement cycle will take place to determine the correct RF level. Every subsequent parameter change in the avionic standard is performed without another measurement cycle to provide a continuous signal output.

Settings

State.....	129
Set To Default.....	129
Save/Recall.....	129
ILS Component.....	129

State

Activates the avionic standard.

Activation of the standard deactivates a previously active avionic standard. The "VOR/ILS > Carrier Frequency" setting is applied automatically to the RF [Frequency](#) and displayed in the status bar.

Remote command:

[<subsystem>:STATe](#) on page 551

Set To Default

Calls the default settings. The values of the main parameters are listed in the following table.

Standard	Parameter	Value
VOR/ILS/ADF	State	Not affected by "Set to default"
VOR	Carrier Frequency Mode	User Defined
	Carrier Frequency	108.000000 MHz
ILS	ILS Component	Glide Slope (GS)
	ILS GS > Carrier Frequency Mode	User Defined
	ILS GS > Carrier Frequency	334.700000 MHz
ADF	Carrier Frequency	190.000 kHz

Remote command:

[<subsystem>:PRESet](#) on page 550

Save/Recall

Accesses the "Save/Recall" dialog, that is the standard instrument function for saving and recalling the complete dialog-related settings in a file. The provided navigation possibilities in the dialog are self-explanatory.

The filename and the directory, in which the settings are stored, are user-definable; the file extension is however predefined.

Remote command:

[<subsystem>:SETTing:CATalog](#) on page 550

[<subsystem>:SETTing:DELeTe](#) on page 550

[<subsystem>:SETTing:LOAD](#) on page 550

[<subsystem>:SETTing:STORe](#) on page 551

ILS Component

Sets the ILS component.

- "Glide slope" Enables the glide slope.
 "Localizer" Enables the localizer.
 "Marker Beacons" Enables the marker beacons.

Remote command:

[:SOURce<hw>] : ILS : TYPE on page 557

6.4.2 ILS Glide Slope Settings

Access:

1. Select "ILS > General".
2. Select "ILS Component > Glide Slope".

Settings


- [General Settings](#)..... 130
- [Signal Settings](#)..... 133
- [Amplitude Settings](#)..... 134

6.4.2.1 General Settings

Access:

1. Select "ILS Component > Glide Slope", see [Chapter 6.4.2, "ILS Glide Slope Settings"](#), on page 130.

2. Select "ILS > General".



This dialog comprises carrier frequency settings related to the ILS glide slope component of the ILS signal.

Settings

Carrier Frequency Mode..... 131
 Carrier Frequency..... 131
 ICAO Channel..... 132
 Sync with Glide Slope/ Sync with Localizer..... 132
 EXT AM..... 132

Carrier Frequency Mode

Sets the mode for the carrier frequency of the signal.

Select "Carrier Frequency Mode > ICAO" to set a standard ILS frequency channel. If you want to couple carrier frequencies of ILS glide slope and localizer components, enable [Sync with Glide Slope/ Sync with Localizer](#).

"User Defined" Activates user-defined variation of the carrier frequency.

"ICAO" Activates variation in predefined steps according to standard ILS transmitting frequencies (see [Table 6-2](#)).

Remote command:

[: SOURce<hw>] : ILS [: GS | GSLope] : FREQuency:MODE on page 560

Carrier Frequency

Requires "Carrier Frequency Mode > User Defined".

Sets the carrier frequency of the signal.

Remote command:

[:SOURce<hw>] : ILS [:GS | GSLope] : FREQuency on page 560

ICAO Channel

Requires "Carrier Frequency Mode > ICAO".

Sets the ICAO channel and the corresponding transmitting frequency.

If avionic standard modulation is activated and you change the "RF Frequency", the frequency value of the closest ICAO channel is applied automatically. The "ICAO Channel" is also updated.

For an overview of the ILS ICAO channel frequencies, see [Table 6-2](#).

Remote command:

[:SOURce<hw>] : ILS [:GS | GSLope] : ICAO:CHANnel on page 561

Sync with Glide Slope/ Sync with Localizer

Activates synchronization of the ILS glide slope with the ILS localizer carrier frequency or vice versa.

If "Carrier Frequency Mode > User", the ILS glide slope carrier frequency is applied to the ILS localizer carrier frequency or vice versa.

If "Carrier Frequency Mode > ICAO", the ILS glide slope ICAO channel is applied to the ILS localizer ICAO channel or vice versa. The ILS glide slope/localizer frequency of the ICAO channel ([Table 6-2](#)) is set automatically.

Remote command:

<subsystem>:FREQuency:SYNChronize:STATe on page 551

EXT AM

Enables/disables additional modulation from an external source. The external signal is input via the Ext connector.

"OFF" Selects the internal modulation source for the avionic standard modulation.

"EXT (MOD AM)" Selects the external source. The external signal is added to the internal signal. Switching off the internal source is not possible. The external signal is input via the Ext connector. The sensitivity is 10 mV per percent modulation depth.

Note: There can be an overmodulation as a function of the level of the external signal without a corresponding caution message being generated. To avoid an overmodulation, the peak value of the external signal is to be delimited corresponding to the sum of the modulation depths of the remaining VOR signal components.


Remote command:

[:SOURce<hw>] : ILS [:GS | GSLope] : SOURce on page 563

6.4.2.2 Signal Settings

Access:

1. Select "ILS Component > Glide Slope", see Chapter 6.4.2, "ILS Glide Slope Settings", on page 130.
2. Select "ILS > Signal".



This dialog comprises modulation signal settings related to the ILS glide slope component of the ILS signal.

Settings

Operating Mode.....	133
DDM Polarity.....	134
Up Frequency.....	134
Down Frequency.....	134
Up/Down Phase.....	134

Operating Mode

Selects the operating mode for the ILS glide slope modulation signal.

- "Norm" ILS glide slope modulation is active.
- "90 Hz" Amplitude modulation of the output signal with the upper lobe signal component (90 Hz signal content) of the ILS glide slope signal.
The modulation depth of the 90 Hz signal results from the settings of the parameters [Sum of Depth](#) and [DDM Depth](#) according to:
 - "Fly > Down"
 $AM(90\text{ Hz}) = 0.5 \times (SDM + DDM \times 100\%)$
 - "Fly > Up"
 $AM(90\text{ Hz}) = 0.5 \times (SDM - DDM \times 100\%)$

- "150 Hz" Amplitude modulation of the output signal with the lower lobe signal component (150 Hz signal content) of the ILS glide slope signal.
- The modulation depth of the 150 Hz signal results from the settings of parameters [Sum of Depth](#) and [DDM Depth](#) according to:
- "Fly > Down"

$$AM(150\text{ Hz}) = 0.5 \times (\text{SDM} + \text{DDM} \times 100\%)$$
 - "Fly > Up"

$$AM(150\text{ Hz}) = 0.5 \times (\text{SDM} - \text{DDM} \times 100\%)$$

Remote command:

[\[:SOURCE<hw>\]:ILS\[:GS|GSLope\]:MODE](#) on page 561

DDM Polarity

Defines the polarity for DDM calculation (see ["DDM Depth"](#) on page 136).

Remote command:

[\[:SOURCE<hw>\]:ILS\[:GS|GSLope\]:DDM:POLarity](#) on page 559

Up Frequency

Sets the modulation frequency of the upper antenna lobe.

Remote command:

[\[:SOURCE<hw>\]:ILS\[:GS|GSLope\]:ULObE\[:FREQuency\]](#) on page 563

Down Frequency

Sets the modulation frequency of the lower antenna lobe.

Remote command:

[\[:SOURCE<hw>\]:ILS\[:GS|GSLope\]:LLObE\[:FREQuency\]](#) on page 561

Up/Down Phase

Sets the phase between the modulation signals of the upper and lower antenna lobe.

The zero crossing of the lower lobe (150Hz) signal serves as a reference. The angle refers to the period of the signal of the lower antenna lobe.

Remote command:

[\[:SOURCE<hw>\]:ILS\[:GS|GSLope\]:PHASe](#) on page 562

6.4.2.3 Amplitude Settings

Access:

1. Select "ILS Component > Glide Slope", see [Chapter 6.4.2, "ILS Glide Slope Settings"](#), on page 130.

2. Select "ILS > Amplitude".

VOR		ILS Glide Slope		ADF		✕	
Fly Mode						General	
Up							
Sum of Depth			DDM - SDM Coupling			Signal	
80.0 %			Fixed DDM				
DDM Step						Amplitude	
Decimal							
DDM Current			DDM Depth				
0.0 µA			0.000 0				
DDM Logarithmic			DDM Percent				
0.000 0 dB			0.00 %				

This dialog comprises amplitude settings related to the ILS glide slope component of the ILS signal.

Settings

Sum of Depth.....	135
FlyMode.....	135
DDM Step.....	136
DDM Current.....	136
DDM Depth.....	136
DDM Logarithmic.....	136
DDM Percent.....	136
DDM - SDM Coupling.....	137

Sum of Depth

Sets the arithmetic sum of the modulation depths of the upper lobe (90 Hz) and lower lobe (150 Hz) ILS glide slope signal contents.

The RMS modulation depth of the sum signal depends on the phase setting of both modulation tones.

Remote command:

[:SOURce<hw>] : ILS [:GS | GSLope] : SDM on page 562

FlyMode

Selects the simulation mode for the ILS glide slope modulation signal. A change of the setting automatically changes the sign of the DDM value.

This setting simulates the direction in which the pilot has to correct the course.

"Up" The 150 Hz modulation signal is predominant, the DDM value is negative (the airplane is too low, it must climb).

"Down" The 90 Hz modulation signal is predominant, the DDM value is positive (the airplane is too high, it must descend).

Remote command:

[\[:SOURce<hw>\]:ILS\[:GS|GSLope\]:DDM:DIRection](#) on page 558

DDM Step

Selects the variation of the DDM values.

"Decimal" Decimal variation according to the current cursor position.

"Predefined" Variation in predefined steps according to the standardized DDM values.

Remote command:

[\[:SOURce<hw>\]:ILS\[:GS|GSLope\]:DDM:STEP](#) on page 559

DDM Current

Sets the current of the ILS indicating the instrument corresponding to the DDM value. The instrument current is calculated according to:

$$\text{DDM Current } \mu\text{A} = \text{DDM Depth } [\%] \times 857,125 \mu\text{A}$$

A variation of the instrument current automatically leads to a variation of the DDM value and the DDM value in dB.

Remote command:

[\[:SOURce<hw>\]:ILS\[:GS|GSLope\]:DDM:CURRent](#) on page 557

DDM Depth

Sets the difference in depth of modulation between the upper lobe (90 Hz) and the lower lobe (150 Hz) tone of the ILS glide slope modulation signal.

The DDM value is calculated with the formula:

- "DDM Polarity > 90 Hz - 150 Hz":
DDM = [AM (90 Hz) - AM (150 Hz)] / 100%
- "DDM Polarity > 150 Hz - 90 Hz":
DDM = [AM (150 Hz) - AM (90 Hz)] / 100%

A variation of the DDM value automatically leads to a variation of the value of the instrument current and the DDM value in dB.

Remote command:

[\[:SOURce<hw>\]:ILS\[:GS|GSLope\]:DDM\[:DEPTh\]](#) on page 559

DDM Logarithmic

Sets the DDM value in dB. The dB value is calculated according to:

$$\text{DDM dB} = 20 \times \text{LOG} [(SDM+DDM \times 100\%) / (SDM-DDM \times 100\%)]$$

A variation of the value automatically leads to a variation of the DDM value and the instrument current.

Remote command:

[\[:SOURce<hw>\]:ILS\[:GS|GSLope\]:DDM:LOGarithmic](#) on page 558

DDM Percent

Sets the difference in depth of modulation between the upper lobe (90 Hz) and the lower lobe (150 Hz) tone of the ILS glide slope modulation signal.

The DDM value in percent is calculated as follows:

- "DDM Polarity > 90 Hz - 150 Hz":
DDM = [AM (90 Hz) - AM (150 Hz)]
- "DDM Polarity > 150 Hz - 90 Hz":
DDM = [AM (150 Hz) - AM (90 Hz)]

A variation of the DDM value automatically leads to a variation of the value of the instrument current and the DDM value in dB.

Remote command:

[:SOURce<hw>] : ILS [:GS | GSLope] : DDM : PCT on page 558

DDM - SDM Coupling

Selects if the DDM value is fixed or is changed with a change of sum of modulation depths (SDM, see below).

"Fixed DDM" The absolute DDM value stays constant, if the SDM is changed.

"Coupled to SDM"

The absolute DDM value changes, if the SDM is changed. The DDM value expressed in dB stays constant.

Remote command:

[:SOURce<hw>] : ILS [:GS | GSLope] : DDM : COUPling on page 557

6.4.3 ILS Localizer Settings

Access:

1. Select "ILS > General".
2. Select "ILS Component > Localizer".

Settings


- [General Settings](#) 137
- [Signal Settings](#)..... 139
- [Amplitude Settings](#)..... 141
- [COM/ID Settings](#)..... 144

6.4.3.1 General Settings

Access:

1. Select "ILS Component > Localizer", see [Chapter 6.4.3, "ILS Localizer Settings"](#), on page 137.

2. Select "ILS > General".



This dialog comprises carrier frequency settings related to the ILS localizer component of the ILS signal.

Settings

Carrier Frequency Mode.....	138
Carrier Frequency.....	138
ICAO Channel.....	139
Sync with Glide Slope/ Sync with Localizer.....	139
EXT AM.....	139

Carrier Frequency Mode

Sets the mode for the carrier frequency of the signal.

"User Defined" Activates user-defined variation of the carrier frequency.

"ICAO" Activates variation in predefined steps according to standard ILS transmitting frequencies (see [Table 6-2](#)).
Select the [ICAO Channel](#) to set a standard ILS frequency channel. If you want to couple carrier frequencies of ILS glide slope and localizer components, enable [General Settings](#) .

Remote command:

`[:SOURce<hw>] :ILS:LOCalizer:FREquency:MODE` on page 570

Carrier Frequency

Requires "Carrier Frequency Mode > User Defined".

Sets the carrier frequency of the signal.

Remote command:

`[:SOURce<hw>] :ILS:LOCalizer:FREquency` on page 569

ICAO Channel

Requires "Carrier Frequency Mode > ICAO".

Sets the ICAO channel and the corresponding transmitting frequency.

If avionic standard modulation is activated and you change the "RF Frequency", the frequency value of the closest ICAO channel is applied automatically. The "ICAO Channel" is also updated.

For an overview of the ILS ICAO channel frequencies, see [Table 6-2](#).

Remote command:

`[:SOURce<hw>] : ILS : LOCalizer : ICAO : CHANnel` on page 570

Sync with Glide Slope/ Sync with Localizer

Activates synchronization of the ILS glide slope with the ILS localizer carrier frequency or vice versa.

If "Carrier Frequency Mode > User", the ILS glide slope carrier frequency is applied to the ILS localizer carrier frequency or vice versa.

If "Carrier Frequency Mode > ICAO", the ILS glide slope ICAO channel is applied to the ILS localizer ICAO channel or vice versa. The ILS glide slope/localizer frequency of the ICAO channel ([Table 6-2](#)) is set automatically.

Remote command:

`<subsystem> : FREQuency : SYNChronize : STATe` on page 551

EXT AM

Enables/disables additional modulation from an external source. The external signal is input via the Ext connector.

"OFF" Selects the internal modulation source for the avionic standard modulation.

"EXT (MOD AM)" Selects the external source. The external signal is added to the internal signal. Switching off the internal source is not possible. The external signal is input via the Ext connector. The sensitivity is 10 mV per percent modulation depth.

Note: There can be an overmodulation as a function of the level of the external signal without a corresponding caution message being generated. To avoid an overmodulation, the peak value of the external signal is to be delimited corresponding to the sum of the modulation depths of the remaining VOR signal components.

Remote command:

`[:SOURce<hw>] : ILS : LOCalizer : SOURce` on page 573

6.4.3.2 Signal Settings

Access:

1. Select "ILS Component > Localizer", see [Chapter 6.4.3, "ILS Localizer Settings"](#), on page 137.

2. Select "ILS > Signal".

VOR		ILS Localizer		ADF		X	
Operating Mode		DDM Polarity		General			
Norm		90 Hz - 150 Hz					
Left Frequency		Right Frequency		Signal			
90.00 Hz		150.00 Hz					
Left/Right Phase				Amplitude			
0.00 deg							
				COM I/D			

This dialog comprises audio signal and modulation settings related to the ILS localizer component of the ILS signal.

Settings

Operating Mode.....	140
DDM polarity.....	141
Left Frequency.....	141
Right Frequency.....	141
Left/Right Phase.....	141

Operating Mode

Selects the operating mode for the ILS localizer modulation signal.

"Norm"	ILS localizer modulation is active.
"90 Hz"	<p>Amplitude modulation of the output signal with the left lobe (90 Hz) signal component of the ILS localizer signal.</p> <p>The modulation depth of the 90 Hz signal results from the settings of parameters Sum of Depth and DDM Depth according to:</p> <ul style="list-style-type: none"> "Fly > Right" $AM(90\text{ Hz}) = 0.5 \times (SDM + DDM \times 100\%)$ "Fly > Left" $AM(90\text{ Hz}) = 0.5 \times (SDM - DDM \times 100\%)$
"150 Hz"	<p>Amplitude modulation of the output signal with the right lobe (150 Hz) signal component of the ILS localizer signal.</p> <p>The modulation depth of the 150 Hz signal results from the settings of parameters Sum of Depth and DDM Depth according to:</p> <ul style="list-style-type: none"> "Fly" = "Right" $AM(150\text{ Hz}) = 0.5 \times (SDM + DDM \times 100\%)$ "Fly" = "Left" $AM(150\text{ Hz}) = 0.5 \times (SDM - DDM \times 100\%)$

Remote command:

`[:SOURce<hw>] : ILS : LOCalizer : MODE` on page 571

DDM polarity

Defines the polarity for DDM calculation (see "DDM Depth" on page 143).

Remote command:

`[:SOURce<hw>] : ILS : LOCalizer : DDM : POLarity` on page 568

Left Frequency

Sets the modulation frequency of the antenna lobe arranged at the left viewed from the air plane.

Remote command:

`[:SOURce<hw>] : ILS : LOCalizer : LLOBe [: FREQuency]` on page 571

Right Frequency

Sets the modulation frequency of the antenna lobe arranged at the right viewed from the air plane.

Remote command:

`[:SOURce<hw>] : ILS : LOCalizer : RLOBe [: FREQuency]` on page 572

Left/Right Phase

Sets the phase between the modulation signals of the left and right antenna lobe. The zero crossing of the right lobe (150 Hz) signal serves as a reference. The angle refers to the period of the signal of the right antenna lobe.

Remote command:

`[:SOURce<hw>] : ILS : LOCalizer : PHASe` on page 571

6.4.3.3 Amplitude Settings

Access:

1. Select "ILS Component > Localizer", see [Chapter 6.4.3, "ILS Localizer Settings"](#), on page 137.

2. Select "ILS > Amplitude".

VOR		ILS Localizer		ADF		✕	
Fly Mode						General	
Left							
Sum of Depth			DDM - SDM Coupling			Signal	
40.0 %			Fixed DDM				
DDM Step						Amplitude	
Decimal							
DDM Current			DDM Depth			COM I/D	
0.0 µA			0.000 0				
DDM Logarithmic			DDM Percent				
0.000 0 dB			0.00 %				

This dialog comprises amplitude settings related to the ILS localizer component of the ILS signal.

Settings

FlyMode.....	142
Sum of Depth.....	142
DDM - SDM Coupling.....	143
DDM Step.....	143
DDM Current.....	143
DDM Depth.....	143
DDM Logarithmic.....	144
DDM Percent.....	144

FlyMode

Selects the simulation mode for the ILS localizer modulation signal. A change of the setting automatically changes the sign of the DDM value.

This setting simulates the direction in which the pilot has to correct the course.

"Left"	The 150 Hz modulation signal is predominant, the DDM value is negative (the airplane is too far to the right, it must turn to the left).
"Right"	The 90 Hz modulation signal is predominant, the DDM value is positive (the airplane is too far to the left, it must turn to the right).

Remote command:

`[:SOURce<hw>] :ILS:LOCalizer:DDM:DIRection` on page 567

Sum of Depth

Sets the arithmetic sum of the modulation depths of the left lobe (90 Hz) and right lobe (150 Hz) ILS localizer signal contents.

The RMS modulation depth of the sum signal depends on the phase setting of both modulation tones.

The "Sum of Depth" and "COM/ID > Depth" must be smaller than 100 %.

Remote command:

[\[:SOURce<hw>\]:ILS:LOCalizer:SDM](#) on page 572

DDM - SDM Coupling

Selects if the DDM value is fixed or is changed with a change of sum of modulation depths (SDM, see below).

"Fixed DDM" The absolute DDM value stays constant, if the SDM is changed.

"Coupled to SDM" The absolute DDM value changes, if the SDM is changed. The DDM value expressed in dB stays constant.

Remote command:

[\[:SOURce<hw>\]:ILS:LOCalizer:DDM:COUPling](#) on page 566

DDM Step

Selects the variation step of the DDM values.

"Decimal" Decimal variation according to the current cursor position.

"Predifined" Variation in predefined steps according to the standardized DDM values.

Remote command:

[\[:SOURce<hw>\]:ILS:LOCalizer:DDM:STEP](#) on page 569

DDM Current

Sets the current of the ILS indicating instrument corresponding to the DDM value. The instrument current is calculated according to:

$$\text{DDM } \mu\text{A} = \text{DDM} \times 967.75 \mu\text{A}$$

A variation of the instrument current automatically leads to a variation of the DDM value and the DDM value in dB.

Remote command:

[\[:SOURce<hw>\]:ILS:LOCalizer:DDM:CURRent](#) on page 567

DDM Depth

Sets the difference in depth of modulation (DDM) between the signal of the left lobe (90 Hz) and the right lobe (150 Hz) of the ILS localizer modulation signal.

The DDM value in percent is calculated as follows:

- "DDM Polarity > 90 Hz - 150 Hz" (default setting):
DDM = [AM (90 Hz) - AM (150 Hz)] / 100 %
- "DDM Polarity > 150 Hz - 90 Hz":
DDM = [AM (150 Hz) - AM (90 Hz)] / 100 %

A variation of the DDM value automatically leads to a variation of the DDM value in dB and the value of the instrument current.

Remote command:

[\[:SOURce<hw>\]:ILS:LOCalizer:DDM\[:DEPTh\]](#) on page 569

DDM Logarithmic

Sets the DDM value in dB. The dB value is calculated according to:

$$\text{DDM dB} = 20 \times \text{LOG} [(\text{SDM} + \text{DDM} \times 100 \%) / (\text{SDM} - \text{DDM} \times 100 \%)]$$

A variation of the value automatically leads to a variation of the DDM value and the instrument current.

Remote command:

`[:SOURce<hw>] :ILS:LOCalizer:DDM:LOGarithmic` on page 568

DDM Percent

Sets the difference in depth of modulation between the signal of the left lobe (90 Hz) and the right lobe (150 Hz).

The DDM value in percent is calculated by the following formulas:

- "DDM Polarity > 90 Hz - 150 Hz" (default setting):
DDM = [AM(90 Hz) - AM (150 Hz)]
- "DDM Polarity > 150 Hz - 90 Hz":
DDM = [AM(150 Hz) - AM (90 Hz)]

A variation of the DDM value automatically leads to a variation of the DDM value in dB and the value of the instrument current.


Remote command:

`[:SOURce<hw>] :ILS:LOCalizer:DDM:PCT` on page 568

6.4.3.4 COM/ID Settings

Access:

1. Select "ILS Component > Localizer", see [Chapter 6.4.3, "ILS Localizer Settings"](#), on page 137.
2. Select "ILS > COM/ID".



This dialog comprises COM/ID settings related to the ILS localizer component of the ILS signal.

Settings

COM/ID State.....	145
Code.....	145
Frequency.....	145
Period.....	145
Depth.....	145
Time Schema.....	146
Dot Length.....	146
Dash Length.....	146
Symbol Space.....	146
Letter Space.....	146

COM/ID State

Enables/disables the COM/ID signal.

See also [Chapter D, "Morse Code Settings"](#), on page 745.

Remote command:

`[:SOURCE<hw>] : ILS : LOCALizer : COMid [: STATE]` on page 566

Code

Sets the coding of the COM/ID signal by the international short name of the airport (e.g. MUC for the Munich airport).

The COM/ID tone is sent according to the selected code, see [Chapter D, "Morse Code Settings"](#), on page 745.

If no coding is set, the COM/ID tone is sent uncoded (key down).

Remote command:

`[:SOURCE<hw>] : ILS : LOCALizer : COMid : CODE` on page 563

Frequency

Sets the frequency of the COM/ID signal.

Remote command:

`[:SOURCE<hw>] : ILS : LOCALizer : COMid : FREQuency` on page 565

Period

Sets the period of the COM/ID signal.

Remote command:

`[:SOURCE<hw>] : ILS : LOCALizer : COMid : PERiod` on page 565

Depth

Sets the AM modulation depth of the COM/ID signal.

Note: The sum of [Sum of Depth](#) and $\text{COM/ID} > \text{Depth}$ must be smaller than 100 %.

Remote command:

`[:SOURCE<hw>] : ILS : LOCALizer : COMid : DEPT h` on page 564

Time Schema

Sets the time schema of the Morse code for the COM/ID signal.

- "Standard"
The set dot length determines the length of the dash, the symbol space and letter space of the Morse code.
- "User"
You can set each length value separately.

Remote command:

[\[:SOURCE<hw>\]:ILS:LOCALizer:COMid:TSCHEMA](#) on page 566

Dot Length

Sets the length of a Morse code dot.

If "Time Schema > Standard", the dot length value determines also the length of the dash (= 3 times the dot length), symbol space (= dot length) and letter space (= 3 times the dot length).

Remote command:

[\[:SOURCE<hw>\]:ILS:LOCALizer:COMid:DOT](#) on page 564

Dash Length

Requires "Time Schema > User".

Sets the length of a Morse code dash.

Remote command:

[\[:SOURCE<hw>\]:ILS:LOCALizer:COMid:DASH](#) on page 564

Symbol Space

Requires "Time Schema > User".

Sets the length of the Morse code symbol space.

Remote command:

[\[:SOURCE<hw>\]:ILS:LOCALizer:COMid:SYMBOL](#) on page 565

Letter Space

Requires "Time Schema > User".

Sets the length of a Morse code letter space.

Remote command:

[\[:SOURCE<hw>\]:ILS:LOCALizer:COMid:LETTER](#) on page 565

6.4.4 ILS Marker Beacons Settings

Access:

1. Select "ILS > General".
2. Select "ILS Component > Marker Beacons".


Settings

- [General Settings](#)..... 147
- [Signal Settings](#)..... 148
- [COM/ID Settings](#)..... 149

6.4.4.1 General Settings

Access:

1. Select "ILS Component > Marker Beacons", see [Chapter 6.4.4, "ILS Marker Beacons Settings"](#), on page 146.
2. Select "ILS > General".



This dialog comprises carrier frequency and signal settings related to the ILS marker beacons component of the ILS signal.

Settings

- [Carrier Frequency Mode](#)..... 147
- [Carrier Frequency](#)..... 147

Carrier Frequency Mode

Sets the mode for the carrier frequency of the signal.

"User Defined" Activates user-defined variation of the carrier frequency.

"Predefined" Activates variation of the carrier frequency by integer 25 kHz steps.

Remote command:

[\[:SOURce<hw>\] \[:ILS\] :MBEacon:FREQUENCY:MODE](#) on page 576

Carrier Frequency

Requires "Carrier Frequency Mode > User Defined".

Sets the carrier frequency of the signal.


Remote command:

[:SOURce<hw>] [:ILS] :MBEacon:FREQuency on page 576

6.4.4.2 Signal Settings

Access:

1. Select "ILS Component > Marker Beacons", see [Chapter 6.4.4, "ILS Marker Beacons Settings"](#), on page 146.
2. Select "ILS > Signal".



This dialog comprises signal settings related to the ILS marker beacons component of the ILS signal.

Settings

Marker Frequency.....	148
Marker Depth.....	148
Pulsed Marker.....	148

Marker Frequency

Sets the modulation frequency of the marker signal.

Remote command:

[:SOURce<hw>] [:ILS] :MBEacon:MARKer:FREQuency on page 577

Marker Depth

Sets the modulation depth of the marker signal.

Remote command:

[:SOURce<hw>] [:ILS] :MBEacon [:MARKer] :DEPTh on page 577

Pulsed Marker

Activates the modulation of a pulsed marker signal (morse coding).

"ON" Modulation of pulsed marker signals (morse coding). The duty cycle, i.e. the marker on- and off-times, depend on the marker signal frequency (Table 6-3).

Table 6-3: Morse coding for ILS marker beacons marker signals

Marker signal	On	Off	Rate	Duty cycle
Outer Marker (400 Hz)	375 ms	125 ms	2 dots/s	75 %
Middle Marker (1300 Hz)	First: 375 ms Second: 83 ms	First: 125 ms Second: 83 ms	1.5 dots/s	68.8 %
Inner Marker (3000 Hz)	83 ms	83 ms	6 dots/s	50 %

"OFF" Modulation of a continuous non-coded marker signal.

Remote command:

[:SOURce<hw>] [:ILS] :MBEacon [:MARKer] :PULSed on page 577

6.4.4.3 COM/ID Settings

Access:

1. Select "ILS Component > Marker Beacons", see [Chapter 6.4.4, "ILS Marker Beacons Settings"](#), on page 146.
2. Select "ILS > COM/ID".

The screenshot shows a software interface for configuring ILS Marker Beacons. At the top, there are three tabs: 'VOR', 'ILS Marker Beacons' (which is selected and highlighted in blue), and 'ADF'. To the right of these tabs is a close button (X). Below the tabs, the 'COM/ID State' is shown as an unchecked checkbox. To the right of this is a 'General' tab. Below the 'COM/ID State' checkbox, there are several settings arranged in a grid-like fashion. The 'Code' is set to 'MUC'. The 'Period' is set to '9.000 s'. The 'Frequency' is set to '1.020 00 kHz'. The 'Depth' is set to '5.0 %'. The 'Time Schema' is set to 'Standard'. The 'Dot Length' is set to '100.0 ms'. On the right side of the dialog, there are three tabs: 'General', 'Signal', and 'COM I/D'. The 'COM I/D' tab is currently selected and highlighted in orange.

This dialog provides access to general, signal and COM/ID settings of the marker beacons component of the ILS signal.

Settings

COM/ID State.....	150
Code.....	150
Period.....	150
Frequency.....	150
Depth.....	150
Time Schema.....	150
Dot Length.....	151
Dash Length.....	151
Symbol Space.....	151
Letter Space.....	151

COM/ID State

Enables/disables the COM/ID signal.

See also [Chapter D, "Morse Code Settings"](#), on page 745.

Remote command:

`[:SOURce<hw>] [:ILS] :MBEacon:COMid[:STATe]` on page 576

Code

Sets the coding of the COM/ID signal by the international short name of the airport (e.g. MUC for the Munich airport).

The COM/ID tone is sent according to the selected code, see [Chapter D, "Morse Code Settings"](#), on page 745.

If no coding is set, the COM/ID tone is sent uncoded (key down).

Remote command:

`[:SOURce<hw>] [:ILS] :MBEacon:COMid:CODE` on page 573

Period

Sets the period of the COM/ID signal.

Remote command:

`[:SOURce<hw>] [:ILS] :MBEacon:COMid:PERiod` on page 575

Frequency

Sets the frequency of the COM/ID signal.

Remote command:

`[:SOURce<hw>] [:ILS] :MBEacon:COMid:FREQuency` on page 574

Depth

Sets the AM modulation depth of the COM/ID signal.

Remote command:

`[:SOURce<hw>] [:ILS] :MBEacon:COMid:DEPTH` on page 574

Time Schema

Sets the time schema of the Morse code for the COM/ID signal.

- "Standard"

The set dot length determines the length of the dash, the symbol space and letter space of the Morse code.

- "User"
You can set each length value separately.

Remote command:

`[:SOURce<hw>] [:ILS] :MBEacon:COMid:TSCHEMA` on page 576

Dot Length

Sets the length of a Morse code dot.

If "Time Schema > Standard", the dot length value determines also the length of the dash (= 3 times the dot length), symbol space (= dot length) and letter space (= 3 times the dot length).

Remote command:

`[:SOURce<hw>] [:ILS] :MBEacon:COMid:DOT` on page 574

Dash Length

Requires "Time Schema > User".

Sets the length of a Morse code dash.

Remote command:

`[:SOURce<hw>] [:ILS] :MBEacon:COMid:DASH` on page 573

Symbol Space

Requires "Time Schema > User".

Sets the length of the Morse code symbol space.

Remote command:

`[:SOURce<hw>] [:ILS] :MBEacon:COMid:SYMBOL` on page 575

Letter Space

Requires "Time Schema > User".

Sets the length of a Morse code letter space.

Remote command:

`[:SOURce<hw>] [:ILS] :MBEacon:COMid:LETTER` on page 575

6.5 ADF Configuration and Settings

Option: R&S SMAB-K25

Access:

- ▶ Select "Modulation > Avionic Standards > ADF".

The remote commands required to define ADF settings are described in [Chapter 14.16.2.3, "SOURce:ADF Subsystem"](#), on page 552.


Settings

- [General Settings](#)..... 152
- [COM/ID Settings](#)..... 154

6.5.1 General Settings

Access:

- ▶ Select "ADF > General".



This dialog comprises general settings of the ADF standard, the default and the "Save/Recall" settings.

By default, an ADF signal modulation is set on an RF carrier with a frequency of 190 kHz. The COM/ID signal has 1.02 kHz frequency.

If enabled, the avionic standard modulation is displayed in the "Modulation" tile as follows:

- "Avionic: VOR" for enabled VOR modulation
- "Avionic ILS: Glide Slope/Localizer/Marker Bcn" for enabled ILS glide slope/localizer/marker beacons modulation
- "Avionic: ADF" for enabled ADF modulation



ADF state and carrier frequency range

If the R&S SMA100B carrier frequency is outside the specified ADF frequency range from 190 to 1750 kHz, a settings conflict is displayed. Activating the ADF is not possible. Change the carrier frequency to a value within the specified frequency range.

Changing a parameter in the avionic standards causes an instant signal change in the R&S SMA100B. There is no extra measurement cycle to calculate the RMS value of the baseband signal to set the correct RF level.

If the avionics standard is activated for the first time, or after every subsequent on/off sequence, the measurement cycle will take place to determine the correct RF level. Every subsequent parameter change in the avionic standard is performed without another measurement cycle to provide a continuous signal output.

Settings

State.....	153
Set To Default.....	153
Save/Recall.....	153

State

Activates the avionic standard.

Activation of the standard deactivates a previously active avionic standard. The "VOR/ILS > Carrier Frequency" setting is applied automatically to the RF [Frequency](#) and displayed in the status bar.

Remote command:

`<subsystem>:STATe` on page 551

Set To Default

Calls the default settings. The values of the main parameters are listed in the following table.

Standard	Parameter	Value
VOR/ILS/ADF	State	Not affected by "Set to default"
VOR	Carrier Frequency Mode	User Defined
	Carrier Frequency	108.000000 MHz
ILS	ILS Component	Glide Slope (GS)
	ILS GS > Carrier Frequency Mode	User Defined
	ILS GS > Carrier Frequency	334.700000 MHz
ADF	Carrier Frequency	190.000 kHz

Remote command:

`<subsystem>:PRESet` on page 550

Save/Recall

Accesses the "Save/Recall" dialog, that is the standard instrument function for saving and recalling the complete dialog-related settings in a file. The provided navigation possibilities in the dialog are self-explanatory.

The filename and the directory, in which the settings are stored, are user-definable; the file extension is however predefined.

Remote command:

`<subsystem>:SETTing:CATalog` on page 550

`<subsystem>:SETTing:DELeTe` on page 550

`<subsystem>:SETTing:LOAD` on page 550

`<subsystem>:SETTing:STORe` on page 551

6.5.2 COM/ID Settings

Access:

- ▶ Select "ADF > COM/ID".

COM/ID State		General
Code	MUC	COM I/D
Period	9.000 s	
Frequency	1.020 00 kHz	
Depth	95.0 %	
Time Schema	Standard	
Dot Length	100.0 ms	

This dialog comprises COM/ID signal settings related to the ADF signal.

Settings

COM/ID State.....	154
Code.....	154
Period.....	155
Frequency.....	155
Depth.....	155
Time Schema.....	155
Dot Length.....	155
Dash Length	155
Symbol Space	155
Letter Space	156

COM/ID State

Enables/disables the COM/ID signal.

Remote command:

[:SOURce<hw>] :ADF:COMid [:STATe] on page 555

Code

Sets the coding of the COM/ID signal by the international short name of the airport (e.g. MUC for the Munich airport).

The COM/ID tone is sent according to the selected code, see [Chapter D, "Morse Code Settings"](#), on page 745.

If no coding is set, the COM/ID tone is sent uncoded (key down).

If no coding is set, the COM/ID tone is sent uncoded (key down).

Remote command:

[:SOURce<hw>] :ADF:COMid:CODE on page 552

Period

Sets the period of the COM/ID signal.

Remote command:

[:SOURce<hw>] :ADF:COMid:PERiod on page 554

Frequency

Sets the frequency of the COM/ID signal.

Remote command:

[:SOURce<hw>] :ADF:COMid:FREQuency on page 553

Depth

Sets the AM modulation depth of the COM/ID signal.

Remote command:

[:SOURce<hw>] :ADF:COMid:DEPT h on page 553

Time Schema

Sets the time schema of the Morse code for the COM/ID signal.

- "Standard"
The set dot length determines the length of the dash, the symbol space and letter space of the Morse code.
- "User"
You can set each length value separately.

Remote command:

[:SOURce<hw>] :ADF:COMid:TSCHEMA on page 555

Dot Length

Sets the length of a Morse code dot.

If "Time Schema > Standard", the dot length value determines also the length of the dash (= 3 times the dot length), symbol space (= dot length) and letter space (= 3 times the dot length).

Remote command:

[:SOURce<hw>] :ADF:COMid:DOT on page 553

Dash Length

Requires "Time Schema > User".

Sets the length of a Morse code dash.

Remote command:

[:SOURce<hw>] :ADF:COMid:DASH on page 552

Symbol Space

Requires "Time Schema > User".

Sets the length of the Morse code symbol space.

Remote command:

[\[:SOURCE<hw>\]:ADF:COMid:SYMBOL](#) on page 554

Letter Space

Requires "Time Schema > User".

Sets the length of a Morse code letter space.

Remote command:

[\[:SOURCE<hw>\]:ADF:COMid:LETTER](#) on page 554

7 List and Sweep Mode

The operating modes "List" and "Sweep" allow you to generate an RF signal having periodically varying frequencies or amplitudes.

A signal generated with varying parameters scans a certain range of varying values of a parameter, with defined start and end points, and can be repeated cyclically.

The R&S SMA100B supports two basic methods:

- **Sweep** mode

The instrument generates an RF signal which varies its frequency or level values in discrete steps between the start and end values. The values change according to a specific shape like sawtooth or triangle. The spacing is linear or logarithmic.




Figure 7-1: Schematic representation of a signal generated in sweep mode

The main application field of the "Sweep" mode is to determine the frequency response a DUT.

- **List** mode

The instrument generates a varying output signal, based on a previously saved list with frequency, amplitude and step width values. While in sweep mode the frequency **or** the level values change, in list mode you can vary **both parameters simultaneously**. The frequency and level values do not need to have ascending or descending order, they can vary arbitrarily.

You can use a global dwell time, which means that the time interval is constant for all steps of the list, or different dwell times for each value pair.

[Figure 7-2](#) represents the frequency and power value pairs, in this case with the dwell time set the same for all steps (global dwell time).




Figure 7-2: Schematic representation of a signal generated in list mode (global dwell time)

The list mode is especially useful in high-speed measurements with fast changing frequency and level settings.



Note that the shown diagrams represent the behaviour in theory. In real signal generation, the instruments usually have a blank time when the frequency or level changes.

Interactions and characteristics of list and sweep mode

- Activating the list mode automatically deactivates all RF and LF sweeps and vice versa.
- In list processing mode, the frequency and level display in the status bar is disabled.



- The sweep modes only work with a *global* dwell time, that means the time intervals are constant during signal generation.
- If you want to hold a running sweep at a specific frequency or level value, enter the value in the status bar. The sweep stops immediately.
- We recommend that you switch off the display update for optimum sweep performance, especially with short dwell times
See [Chapter 12.1.2, "Display Update Settings"](#), on page 324.

7.1 Signal Generation and Triggering in the Sweep and List Modes

In both operating modes "List" and "Sweep", triggering and signal generation follow the same principle. The instrument generates the signal continuously (that means triggered automatically) or in individual steps (controlled manually by an internal or external trigger signal).

The instrument expects the trigger signal at the Inst Trig connector.



If the dwell time in sweep or list mode is too short or external trigger signals come too fast, the signal generation delays. As the delay increases, the R&S SMA100B signals an overrun, or even stops sweep or list mode signal generation, if the delay gets too long.

The instrument displays corresponding error messages.

The figures in this section give an overview on the signal generation in the sweep and list modes and the appropriate triggering. The figures show the signal state after activating the mode and the generation of the signal when a trigger event occurs. For each mode, the relevant parameters and settings are briefly explained.

Each "Sweep" and "List" mode dialog provides also a "Reset" function that sets the signal to the initial value or the beginning of the list. Depending on the selected trigger mode, the signal generation proceeds accordingly.



The naming of the selection parameters in manual control (GUI) sometimes deviates from the naming in the remote-control commands. In addition, the value names of the selection parameters used in the signal generator partly differ from the SCPI syntax. The instrument accepts all value names.

The correlation between the manual control and the corresponding remote control commands, including the SCPI conform syntax are explained for each mode (see the cross-reference tables).

See also the following programming examples on the sweep and list modes in remote control:

- [Example "Setup an RF frequency or power sweep"](#) on page 647
 - [Example "Setup an LF sweep"](#) on page 603
 - [Example "Create an RF list and activate the list mode"](#) on page 616
-

Auto mode (Sweep/List)




Figure 7-3: Auto mode (Sweep/List)

- The instrument generates the signal continuously.
- Trigger mode "Auto" is prerequisite (default). It causes the continuous generation of the sweep signal.
- Starts signal generation immediately with "State = On".
- Switches automatically to the next step when the **Dwell time** has elapsed.
- Stops signal generation with "State = Off".

Table 7-1: Cross-reference between manual and remote control in Auto mode (Sweep/List)

Manual control mode: "Auto"	Remote commands Rohde & Schwarz proprietary and [SCPI conform] value name
RF frequency sweep	:TRIGger<hw>:FSweep:SOURce AUTO [IMMediate] :SOURce<hw>:SWEep:FREQuency:MODE AUTO
RF level sweep	:TRIGger<hw>:PSweep:SOURce AUTO [IMMediate] :SOURce<hw>:SWEep:POWer:MODE AUTO
LF frequency sweep	:TRIGger<hw>:LFFSweep:SOURce AUTO [IMMediate] :SOURce<hw>:LFOutput<ch>:SWEep:FREQuency:MODE AUTO
List	:SOURce<hw>:LIST:MODE AUTO :SOURce<hw>:LIST:TRIGger:SOURce AUTO

Single / Extern Single mode (Sweep/List)




Figure 7-4: Single / Extern Single mode (sweep / list)



In single mode, you can specify, that the signal returns to the start value when a sweep cycle has been completed.

See "[The Retrace function](#)" on page 166 for details.

- The instrument generates a single sweep cycle.
- Trigger mode "Manual". A trigger event initiates one sweep from the start value to the end value.
- "State = On" sets the signal to the start value: the sweep start frequency, the sweep start power or the frequency-power value pair of the selected index in the list.
- Starts signal generation with a trigger event.
- Switches automatically to the next step when the [Dwell time](#) has elapsed.
- Stops signal generation at the set end value and waits for the subsequent trigger event.
- Trigger sources:
 - The "Execute Single Sweep" function.
 - The corresponding remote control command.
 - An externally applied trigger signal.
- "State = Off" stops the signal generation in sweep or list mode.

Table 7-2: Cross-reference between manual and remote control in Single / Extern Single modes (Sweep/List)

Manual control mode: "Single / Extern Single"	Remote commands Rohde & Schwarz proprietary and [SCPI conform] value name
RF frequency sweep	:TRIGger<hw>:FSWEEP:SOURce SINGLE [BUS] "Single" or :TRIGger<hw>:FSWEEP:SOURce EXTERNAL [EXTERNAL] "Extern Single" :SOURce<hw>:SWEep:FREQuency:MODE AUTO
RF level sweep	:TRIGger<hw>:PSWEEP:SOURce SINGLE [BUS] for "Single" or :TRIGger<hw>:PSWEEP:SOURce EXTERNAL [EXTERNAL] for "Extern Single" :SOURce<hw>:SWEep:POWer:MODE AUTO
LF frequency sweep	:TRIGger<hw>:LFFSWEEP:SOURce SINGLE [BUS] "Single" or :TRIGger<hw>:LFFSWEEP:SOURce EXTERNAL [EXTERNAL] "Extern Single" :SOURce<hw>:LFOuTput<ch>:SWEep:FREQuency:MODE AUTO
List	:SOURce<hw>:LIST:TRIGger:SOURce SINGLE "Single" or :SOURce<hw>:LIST:TRIGger:SOURce EXTERNAL "Extern Single" :SOURce<hw>:LIST:MODE AUTO

Step / Extern Step mode (Sweep/List)




Figure 7-5: Step / Extern Step mode (sweep / list)

- The instrument generates the signal step-by-step.
- Starts signal generation with "State = On".
- Switches to the next step with a manual action.
If the end value is reached, signal generation starts again from the beginning.
- Stops signal generation with "State = Off".

- Trigger sources:
 - The rotary knob at the front panel.
 - The [Arrow] keys at the front panel.
 - The corresponding remote control commands.
 - An externally applied trigger signal.

To step through the sweep frequencies or levels:

- In manual mode:
 - Set the [Current Frequency](#) or [Current Level](#) values
 - Use the [Up] and [Down] keys or the rotary knob
- In remote control mode:
 - Use the commands `[:SOURce<hw>] :FREQuency:MANual` or `[:SOURce<hw>] :POWer:MANual` with the UP or DOWN parameter



Steps that would exceed the sweep range are ignored.

Table 7-3: Cross-reference between manual and remote control in Step / Extern Step modes (Sweep/List)

Manual control mode: "Step / Extern Step"	Remote commands Rohde & Schwarz proprietary and [SCPI conform] value name
RF frequency sweep	:TRIGger<hw>:FSweep:SOURce SINGLE [BUS] "Step" or :TRIGger<hw>:FSweep:SOURce EXTernal [EXTernal] for "Extern Step" :SOURce<hw>:SWEep:FREQuency:MODE STEP
RF level sweep	:TRIGger<hw>:PSweep:SOURce SINGLE [BUS] "Step" or :TRIGger<hw>:PSweep:SOURce EXTernal [EXTenal] "Extern Step" :SOURce<hw>:SWEep:POWer:MODE STEP
LF frequency sweep	:TRIGger<hw>:LFFSweep:SOURce SINGLE [BUS] "Step" or :TRIGger<hw>:LFFSweep:SOURce EXTernal [EXTenal] "Extern Step" :SOURce<hw>:LFOutput<ch>:SWEep:FREQuency:MODE STEP
List	:SOURce<hw>:LIST:TRIGger:SOURce SINGLE "Step" or :SOURce<hw>:LIST:TRIGger:SOURce EXTernal "Extern Step" :SOURce<hw>:LIST:MODE STEP

Extern Start/Stop mode (sweep)




Figure 7-6: Extern Start/Stop mode (sweep)

- The instrument generates the signal continuously.
- Trigger mode "Auto" and "Sweep > State = On" are prerequisite.
- State "On" sets the signal to the start value, that is one of the following:
 - Sweep start frequency
 - Sweep start power
 - Frequency-power value pair of the selected index in the list
- Starts signal generation with a trigger event.
- Switches automatically to the next sweep step when the Dwell time has elapsed. If the end value is reached, signal generation continues with the next sweep cycle.
- Stops signal generation with the next external trigger event.
- Starts the signal generation again with the next trigger event, beginning at the start value.
- "State = Off" stops the signal generation in sweep or list mode.
- Trigger source: An externally applied trigger signal.

Table 7-4: Cross-reference between manual and remote control in Extern Start/Stop modes (sweep)

Manual control mode: "Extern Start/Stop"	Remote commands Rohde & Schwarz proprietary and [SCPI conform] value name
RF frequency sweep	:TRIGger<hw>:FSweep:SOURce EAUTO [-] :SOURce<hw>:SWEep:FREQuency:MODE AUTO
RF level sweep	:TRIGger<hw>:PSweep:SOURce EAUTO [-] :SOURce<hw>:SWEep:POWer:MODE AUTO
LF frequency sweep	:TRIGger<hw>:LFFSweep:SOURce EAUTO [-] :SOURce<hw>:LFOutput<ch>:SWEep:FREQuency:MODE AUTO

Manual mode (Sweep/List)



The **manual** mode only applies to remote control. It is not visible in the graphical user interface of the instrument and is described here for completeness.





Figure 7-7: Manual mode in remote control (sweep / list)

- The instrument generates the signal in steps.
- Starts signal generation with "State = On".
- Switches to the next step with a user defined setting via remote control. You can arbitrarily select a value within the range of the start and stop values by setting the frequency, power or index using the corresponding remote control command. There is no ascending or descending order.
- Stops signal generation with "State = Off".

Table 7-5: Remote control commands in manual mode (Sweep/List)

Remote control mode:	Remote commands
Manual	Rohde & Schwarz proprietary and [SCPI conform] value name
RF frequency sweep	:SOURce<hw>:FREQuency:MANUal <Manual>
RF level sweep	:SOURce<hw>:POWer:MANUal <Manual>
LF frequency sweep	:SOURce<hw>:LFOUtpuT:FREQuency:MANUal <Manual>
List	:SOURce<hw>:LIST:INDex <Index>

The Retrace function



Retrace is a function especially designed for "Single" sweep modes, when the sweep signal follows a sawtooth shape. Working in this mode, the instrument performs a single sweep cycle when a trigger event occurs. The signal generation stops at the set end point (stop frequency or stop level), and waits for the next trigger event.

In this state, the upper value of the signal remains at the output until the next cycle starts. In particular, if you generate a level sweep signal, the high amplitude of the signal is output for a certain time. To protect the DUT from overload, the retrace function immediately resets the signal value to the start value at the end of a sweep cycle. It returns to the start level or start frequency until the next trigger is applied.

You can use the "Retrace" function if "Sweep > Mode = Single/External Single" and "Shape = Sawtooth", see:

- "Shape" on page 176
- "Mode" on page 175

7.2 About Sweep Mode

In sweep mode, the signal generator scans the sweep range gradually from one point to another, using a defined step size and following a triangle or sawtooth shape. This mode also enables you to change direction, that means, it is possible to step backwards.

See [Chapter 7.2.2, "Sweep Signal Shapes"](#), on page 169.

Configuration and operation of sweep mode signals

- The R&S SMA100B generates a sweep signal by varying one of the following parameters: the *RF frequency*, the *LF frequency* or the *RF level*.
- In all sweep modes, you can perform a complete sweep cycle once, repeat the cycle continuously or step through it gradually.
- The instrument generates the sweep signal according to the sweep settings.
- The "Reset Sweep" function, provided in the sweep settings dialogs enables you to reset the sweep to its initial value and restart it.



Impact of changing the sweep mode during performance

If you change the sweep mode during the execution, the signal generator stops the sweep and starts with the next trigger event at the initial value.

7.2.1 Correlating Parameters in Sweep Mode

A sweep signal is a periodic signal that changes its frequency or level from a starting value to an ending value in a defined time.

The R&S SMA100B provides various possibilities to configure a sweep signal. For example, you can determine the sweep range by the start and end values, or based on the start value and span. In any case, related parameters are adjusted accordingly.

The formulas below show how the sweep parameters correlate and the corresponding calculation basis, by the frequency and offset settings. Apart from "Center Frequency", "Span" and "Step_lin", the values apply accordingly to the level settings.

Table 7-6: Variables that are used in the following formulas

Variable	Description
Sweep range	Defined frequency or level value range
f_{CENTer}	Defined center frequency
f_{SPAN}	Defined extend of the sweep range
f_{OFFSet}	Frequency offset
f_{START}	Start frequency of the sweep range
f_{STOP}	End frequency of the sweep range
f_1	Current sweep frequency
f_2	Next, subsequent sweep frequency
step_lin	Step size in linear scaling
step_log	Step size in logarithmic scaling
POINTS	Number of steps within the sweep range

Sweep range

The sweep range is defined by a start and an end value. How the remaining parameters correlate is shown below.

Offset = 0

Sweep Range = f_{START} to f_{STOP}

$$f_{\text{CENTer}} = (f_{\text{START}} + f_{\text{STOP}})/2$$

$$f_{\text{SPAN}} = (f_{\text{STOP}} - f_{\text{START}})$$

Where:

$$f_{\text{START}} = f_{\text{CENTer}} - (f_{\text{SPAN}}/2)$$

$$f_{\text{STOP}} = f_{\text{CENTer}} + (f_{\text{SPAN}}/2)$$

Offset≠0

A defined offset also affects the sweep range and the center frequency. Therefore, the set frequencies are only absolute values, if the Offset = 0. Offset ≠ 0 shifts the frequencies with the offset value:

Sweep Range = $f_{\text{START}} + f_{\text{OFFSet}}$ to $f_{\text{STOP}} + f_{\text{OFFSet}}$

$$f_{\text{CENTer}} = f_{\text{CENTer}} + f_{\text{OFFSet}}$$

$$f_{\text{SPAN}} = f_{\text{SPAN}} + f_{\text{OFFSet}}$$

The value range of the instrument is calculated as follows:

$$RF_{\text{min}} + f_{\text{OFFSet}} \text{ to } RF_{\text{max}} + f_{\text{OFFSet}}$$



It is possible to set $f_{\text{START}} > f_{\text{STOP}}$ and $f_{\text{START}} < f_{\text{STOP}}$, so that even a negative value is permitted for the "Span".

If you change the start and/or stop frequency, the span and center frequency change accordingly, and vice versa.

Sweep steps

In the following, you see how the sweep steps are calculated depending on the defined spacing mode. The formulas show a frequency sweep, but apply to the level settings in the same way.

The step size is added to the current value, to get the subsequent sweep step.

With **linear** scaling, the next frequency is calculated according to:

$$f_2 = f_1 + \text{step_lin}$$

In the **logarithmic** scaling, the step size is determined in per cent, as a constant fraction of the current frequency.

Successive frequencies are calculated as follows:

- For $f_{\text{START}} < f_{\text{STOP}}$

$$f_2 = f_1 * (1 + \text{step_log}/100)$$

If $f_2 > f_{STOP}$, then $f_2 = f_{STOP}$

- For $f_{START} > f_{STOP}$
 $f_2 = f_1 / (1 + \text{step_log}/100)$
 If $f_2 < f_{STOP}$, then $f_2 = f_{STOP}$

With "Shape = Triangle", the frequency values on the slope from f_{STOP} to f_{START} are the same as on the slope from f_{START} to f_{STOP} .

If you specify the number of steps within the sweep range, the step size is adjusted according to the following correlation:

- For **linear** sweeps and $f_{START} < f_{STOP}$
 $\text{POINTS}_{\text{frequency}} = ((f_{START} - f_{STOP})/\text{step_lin}) + 1 = (f_{SPAN}/\text{step_lin}) + 1$
- For **logarithmic** sweeps and $f_{START} < f_{STOP}$
 $\text{POINTS}_{\text{frequency}} = ((\log f_{STOP} - \log f_{START})/\log \text{step_log}) + 1$

If step_log changes, the value of POINTs is adjusted. The f_{START} and f_{STOP} values are retained.

7.2.2 Sweep Signal Shapes

The R&S SMA100B supports the following sweep shapes:

- Sawtooth
 The sweep sequence resembles a sawtooth. One sweep runs from start to stop frequency, or level value respectively. Each subsequent sweep starts again at the start value.




Figure 7-8: Sweep signal sawtooth shape

1 = Start value
 2 = Stop value
 3 = Step size

- Triangle
 The sweep sequence resembles a triangle. One sweep runs from start to stop value frequency and back. Each subsequent sweep starts at the start value.




Figure 7-9: Sweep signal triangle shape

- 1 = Start value
- 2 = Stop value
- 3 = Step size

The current frequency or level of an RF frequency, level or LF frequency sweep is determined by the shape (e.g. sawtooth or triangle) and the spacing (linear or logarithmic), and the step size.

7.3 About List Mode

The list mode is used to generate the RF signal based on a set of predefined frequency and amplitude value pairs, with individual step times. You can define the values arbitrarily, in any order and varying step sizes, within the entire configurable value range of the instrument.

Configuration and operation of list mode signals

The parameters configuring the RF signal are defined in a list (table) and stored in a file.

Creating and handling lists

List files can be created in the following ways:

- **Internally**
Use the build-in table editor with columns for the frequency-level values pairs and the dwell time.
Define the values manually (row by row) or automatically, based on value range and step size.
(See [Chapter 7.7, "List Editor"](#), on page 191)
Lists are saved as files with user-definable filename and the predefined file extension *.lsw. To load a saved file, use the "File Manager".
(See [Chapter 11.8, "Using the File Manager"](#), on page 303)
- Lists can be exported, too. For example, to exchange configuration between instruments or to modify the file content with an external program and reload them again.

- **Externally**

Create a list file as a CSV file with Microsoft Excel, with a Notepad or a similar tool and save it with the predefined extension. Transfer the file to and load it into the instrument.

Dwell time mode

You can choose whether you want to use different dwell times or a fixed value for all steps in the list mode:

- "From List"
This mode uses the values from the data table.
See [Edit List Mode Data](#)
- "Global"
This mode processes the list with a fixed time interval you can set with [Global Dwell Time](#).

List processing mode

See:

- ["Live list processing mode"](#) on page 172

7.4 Significant Parameters and Functions

This section provides some basic parameters, settings and functions that affect the operating modes CW, list and sweep, that means at all frequency and level transitions of the RF signal.

Dwell time

Dwell time is the length of time that elapses from the beginning until the end of a step in list or sweep mode.




Figure 7-10: Dwell Time vs. settling time

- 1 = "Dwell Time" (as set with the parameter)
- 2 = Settling time
- 3 = Dwell time (effective)

However, the time the instrument requires for the signal to settle reduces the set dwell time:

$$t_{\text{dwell(effective)}} = t_{\text{dwell}} - t_{\text{settling}}$$



If the dwell time in sweep or list mode is too short or external trigger signals come too fast, the signal generation delays. As the delay increases, the R&S SMA100B signals an overrun, or even stops sweep or list mode signal generation, if the delay gets too long.

The instrument displays corresponding error messages.

Hardware adjustments

The first time a list (new or modified) is processed, the instrument automatically calculates the necessary hardware settings. It can be performed during list processing, but delays the first cycle, especially with short dwell times.

With long dwell times, you can perform this calculation while the list is being processed; the entered dwell times are observed. With short dwell times, calculation of the hardware settings increases the dwell time for the initial processing cycle; the entered value is only observed from the second processing cycle onwards. In this case, a message indicates that there is a deviation between the current and set dwell times. After the first cycle, you do not need to perform additional calculations. The current dwell times do not deviate from the set dwell times.

Blanking

The instrument applies *blanking*, which temporarily turns off the RF signal when the frequency or level changes, until the signal has settled to a stable state.

Temporary blanking applies to all operating modes.

Live list processing mode

The R&S SMA100B generates the signal directly from the value pairs in the database, and adjusts the hardware settings accordingly. The current instrument state and thus any change during the signal generation directly affects the RF signal. The temporary memory is not used.

You can conveniently modify parameters like modulation settings during run-time. Learning list mode data is not required. Impacts like temperature drift are also considered immediately.

This mode is optimized for **maximum signal quality**, and is useful if dwell times higher than 2 ms are sufficient.

7.5 Sweep Mode Settings

This section lists the settings of **all** available sweep modes.

Access:

1. Select "Sweep" > "RF Frequency Sweep"
2. Select "Sweep" > "RF Level Sweep"
3. Select "Sweep" > "LF Frequency Sweep"

The remote commands required to define these settings are described in:

- [Chapter 14.16.4, "SOURce:FREQuency Subsystem"](#), on page 594
- [Chapter 14.16.13, "SOURce:SWEep Subsystem"](#), on page 647
- [Chapter 14.16.6, "SOURce:LFOuTput Subsystem"](#), on page 603


Settings

- [General Sweep Settings](#)..... 173
- [Frequency Range Settings](#).....178
- [Level Range Settings](#)..... 180
- [Output Settings](#)..... 182
- [Edit Marker Settings](#)..... 183

7.5.1 General Sweep Settings

Access:

- ▶ Select for example "Sweep" > "RF Frequency Sweep".



Settings

Sweep Type	174
State (RF frequency sweep).....	174
State (RF level sweep).....	174
State (LF frequency sweep).....	174
Current Frequency.....	175
Current Level.....	175
Mode.....	175
Retrace.....	176
Shape.....	176
Spacing.....	177
Sweep Time	177
Dwell Time	177
Trigger Slope.....	178
Reset Sweep	178
Execute Single Sweep	178

Sweep Type

Selects the kind of the frequency sweep.

- | | |
|--------|---|
| "Step" | Increases or decreases the frequency at each step.
To determine the frequency intervals, see Spacing . |
| "Ramp" | Provides a synthesized continuous analog frequency sweep with the set Sweep Time . |

Remote command:

[\[:SOURce<hw>\]:SWEep:GENeration](#) on page 650

State (RF frequency sweep)

Activates RF frequency sweep signal generation.

Note: Active sweep mode deactivates other sweeps or lists and vice versa.

Remote command:

[\[:SOURce<hw>\]:FREQuency:MODE](#) on page 595

State (RF level sweep)

Activates RF level sweep signal generation.

Note: Active sweep mode deactivates other sweeps or lists and vice versa.

Remote command:

[\[:SOURce<hw>\]:POWer:MODE](#) on page 637

State (LF frequency sweep)

Status of the LF frequency sweep signal.

You find this parameter in two dialogs:

- "LF Frequency Sweep" turns on/off the signal generation.
See [Sweep Mode Settings](#) for access.
- "Analog Modulation Sources" displays the current state (read-only). If it is turned on, this dialog provides the varying sweep frequency, see [Current Frequency](#).

Note: Active sweep mode deactivates other sweeps or lists and vice versa.

Remote command:

`[:SOURce<hw>] :LFOutput:FREQuency:MODE` on page 607

Current Frequency

In "RF/LF Frequency Sweep" mode, displays the current frequency.

In **Mode** = "Step", the parameter is editable and you can enter the next frequency step.

Remote command:

`[:SOURce<hw>] :FREQuency:MANual` on page 597

`[:SOURce<hw>] :LFOutput:FREQuency:MANual` on page 607

Current Level

Applies to "RF Level Sweep" mode.

Displays the current level value.

In **Mode** = "Step", the parameter is editable and you can enter the next level step.

Remote command:

`[:SOURce<hw>] :POWer:MANual` on page 637

Mode

Selects the sweep mode.

For detailed information on the sweep modes and the triggering, see [Chapter 7.1, "Signal Generation and Triggering in the Sweep and List Modes"](#), on page 159.

"Auto" Generates a continuously repeating sweep signal directly after activating the sweep mode.
The sweep steps are performed automatically, controlled by the dwell time.

"Single / Extern Single" Generates a single sweep cycle after a trigger event.
The sweep steps within the cycle are performed automatically, controlled by the dwell time. If one cycle is completed, the instrument waits for the next trigger event.

"Step / Extern Step" Generates the sweep signal step-by-step, manually triggered.

"Extern Start/Stop" Generates a continuously repeating sweep signal that is started, stopped, and restarted by subsequent external trigger events.
The sweep steps are performed automatically, controlled by the dwell time.

Remote command:

`[:SOURce<hw>] :SWEep [:FREQuency] :MODE` on page 652

`[:SOURce<hw>] :SWEep:POWer:MODE` on page 650

`[:SOURce<hw>] :LFOutput:SWEep [:FREQuency] :MODE` on page 613

`:TRIGger<hw> [:SWEep] :SOURce` on page 688

`:TRIGger<hw>:FSWEEP:SOURce` on page 688

`:TRIGger<hw>:PSWEEP:SOURce` on page 688

`:TRIGger<hw>:LFFSWEEP:SOURce` on page 688

Retrace

For "Shape = Sawtooth" and "Mode = Single/External Single", enables changing the signal to the start value while it is waiting for the next trigger event. It returns to the start level or start frequency until the next trigger is applied.

Remote command:

`[:SOURce<hw>] :SWEep [:FREQuency] :RETRace` on page 654

`[:SOURce<hw>] :SWEep:POWer:RETRace` on page 654

`[:SOURce<hw>] :LFOutput:SWEep [:FREQuency] :RETRace` on page 614

Shape

Selects the waveform shape of the sweep signal.

"Sawtooth" The sweep runs from start to stop frequency. The subsequent sweep starts at the start value, i.e. the shape of the sweep sequence resembles a sawtooth.




Figure 7-11: Sweep signal sawtooth shape

1 = Start value

2 = Stop value

3 = Step width

"Triangle" The sweep runs from start to stop value and back, i.e. the shape of the sweep resembles a triangle. Each subsequent sweep starts at the start frequency.
The triangle shape is only available for [Sweep Type > Step](#).




Figure 7-12: Sweep signal triangle shape

1 = Start value
2 = Stop value
3 = Step width

Remote command:

[\[:SOURce<hw>\]:SWEep\[:FREQuency\]:SHApe](#) on page 653

[\[:SOURce<hw>\]:SWEep:POWer:SHApe](#) on page 653

[\[:SOURce<hw>\]:LFOutput:SWEep\[:FREQuency\]:SHApe](#) on page 615

Spacing

In "RF and LF Frequency Sweep" modes, selects the mode for the calculation of the frequency intervals, with which the current frequency at each step is increased or decreased.

Enter the step size with the parameter [Step Linear/Step Logarithmic](#).

This parameter is only available for [Sweep Type > Step](#).

"Linear" Takes the frequency value entered as absolute value in Hz.

"Logarithmic" Takes the value entered as a logarithmic value, i.e. as a constant fraction of the current frequency in %.

Remote command:

[\[:SOURce<hw>\]:SWEep\[:FREQuency\]:SPACing](#) on page 653

[\[:SOURce<hw>\]:LFOutput:SWEep\[:FREQuency\]:SPACing](#) on page 615

Sweep Time

Option: R&S SMAB-B28

For frequency sweep with "Spacing > Ramp", sets the duration of a ramp sweep step.

Remote command:

[\[:SOURce<hw>\]:SWEep\[:FREQuency\]:TIME](#) on page 655

Dwell Time

Defines the duration of the individual sweep steps.

Note: In case of considerable overrun conditions, the R&S SMA100B turns off the sweep mode.

See also [Chapter 7.4, "Significant Parameters and Functions"](#), on page 171.

Remote command:

[\[:SOURce<hw>\]:SWEep\[:FREQuency\]:DWELl](#) on page 652

[\[:SOURce<hw>\]:SWEep:POWEr:DWELl](#) on page 650

[\[:SOURce<hw>\]:LFOutput:SWEep\[:FREQuency\]:DWELl](#) on page 613

Trigger Slope

For "Mode = Extern Step/Single", selects the polarity of the active slope of an applied instrument trigger.

Trigger signal is expected at the Inst Trig connector.

"Positive" The rising edge of the trigger signal triggers the instrument.

"Negative" The falling edge of the trigger signal triggers the instrument.

Remote command:

[\[:SOURce\]:INPut:TRIGger:SLOPe](#) on page 603

Reset Sweep

Resets a sweep.

With the next trigger event, the sweep starts at the initial value.

Remote command:

[\[:SOURce<hw>\]:SWEep:RESet\[:ALL\]](#) on page 655

Execute Single Sweep

In "Mode = Single", starts a sweep manually.

Remote command:

[\[:SOURce<hw>\]:SWEep\[:FREQuency\]:EXECute](#) on page 654

[\[:SOURce<hw>\]:SWEep:POWEr:EXECute](#) on page 654

[\[:SOURce<hw>\]:LFOutput:SWEep\[:FREQuency\]:EXECute](#) on page 613

[:TRIGger<hw>\[:SWEep\]\[:IMMediate\]](#) on page 689

[:TRIGger<hw>:FSWEEP\[:IMMediate\]](#) on page 689

[:TRIGger<hw>:PSWEEP\[:IMMediate\]](#) on page 689

[:TRIGger<hw>:LFFSWEEP:IMMediate](#) on page 689

7.5.2 Frequency Range Settings

Access:

1. Select for example "Sweep" > "RF Frequency Sweep"
2. Select "Frequency Range".

Start Frequency 200.000 000 000 MHz	Stop Frequency 600.000 000 000 MHz
Center Frequency 400.000 000 000 MHz	Span 400.000 000 000 MHz
Spacing Linear	Step Linear 10.000 000 000 MHz

Settings

Start Frequency/Stop Frequency	179
Center Frequency	179
Span.....	179
Spacing.....	179
Step Linear/Step Logarithmic	180

Start Frequency/Stop Frequency

Defines the frequency sweep range by setting the start and end values.

See [Chapter 7.2.1, "Correlating Parameters in Sweep Mode"](#), on page 167.

Remote command:

[:SOURce<hw>] :FREQuency :STARt on page 599

[:SOURce<hw>] :FREQuency :STOP on page 599

[:SOURce<hw>] :LFOutput :FREQuency :STARt on page 608

[:SOURce<hw>] :LFOutput :FREQuency :STOP on page 608

Center Frequency

In "RF Frequency Sweep" mode, sets the RF center frequency.

See [Chapter 7.2.1, "Correlating Parameters in Sweep Mode"](#), on page 167.

Remote command:

[:SOURce<hw>] :FREQuency :CENTer on page 598

Span

In "RF Frequency Sweep" mode, sets the span of the frequency sweep range.

See [Chapter 7.2.1, "Correlating Parameters in Sweep Mode"](#), on page 167.

Remote command:

[:SOURce<hw>] :FREQuency :SPAN on page 599

Spacing

In "RF and LF Frequency Sweep" modes, selects the mode for the calculation of the frequency intervals, with which the current frequency at each step is increased or decreased.

Enter the step size with the parameter [Step Linear/Step Logarithmic](#) .

This parameter is only available for [Sweep Type > Step](#).

- "Linear" Takes the frequency value entered as absolute value in Hz.
- "Logarithmic" Takes the value entered as a logarithmic value, i.e. as a constant fraction of the current frequency in %.

Remote command:

`[:SOURce<hw>] :SWEep [:FREQuency] :SPACing` on page 653

`[:SOURce<hw>] :LFOutput :SWEep [:FREQuency] :SPACing` on page 615

Step Linear/Step Logarithmic

In "RF/LF Frequency Sweep" mode, sets the step width for the individual frequency sweep steps. The value is added at each sweep step to the current frequency.

Depending on the current [Spacing](#), you can enter either an absolute or logarithmic step width.

This parameter is only available for [Sweep Type > Step](#).

See [Chapter 7.2.1, "Correlating Parameters in Sweep Mode"](#), on page 167.

"Step Linear" The step width is a constant value in Hz.

"Step Logarithmic"

The step width is determined logarithmically in %, i.e. as a constant fraction of the current frequency.

Remote command:

`[:SOURce<hw>] :SWEep [:FREQuency] :STEP [:LINear]` on page 655

`[:SOURce<hw>] :SWEep [:FREQuency] :STEP :LOGarithmic` on page 655

`[:SOURce<hw>] :LFOutput :SWEep [:FREQuency] :STEP [:LINear]` on page 616

`[:SOURce<hw>] :LFOutput :SWEep [:FREQuency] :STEP :LOGarithmic`

on page 615

7.5.3 Level Range Settings

Access:

1. Select "Sweep" > "RF Level Sweep"
2. Select "Level Range".

General Auto		Level Range	X
Start Level	-30.00 dBm	Stop Level	-10.00 dBm
Spacing	Linear	Step	1.00 dB
Setting Characteristics	Auto		

Settings

Start Level / Stop Level	181
Spacing.....	181
Step	181
Setting Characteristics	181

Start Level / Stop Level

Defines the RF level sweep range by setting the start and end values.

See [Chapter 7.2.1, "Correlating Parameters in Sweep Mode"](#), on page 167.

Remote command:

`[:SOURce<hw>] :POWer:STARt` on page 638

`[:SOURce<hw>] :POWer:STOP` on page 638

Spacing

Indicates that the level step intervals are linearly (straight proportional) distributed, i.e. intervals are of equal size.

Set the step size with the parameter "Step".

Remote command:

n.a.

Step

Applies to "RF Level Sweep" mode.

Sets the step width for the RF level sweep steps logarithmically in dB.

Remote command:

`[:SOURce<hw>] :SWEep:POWer:STEP[:LOGarithmic]` on page 651

Setting Characteristics

Selects additional quality characteristics to optimize the behavior of the RF signal level for the corresponding application.

"Auto"	<p>Sets the RF output level automatically according to the selected mode.</p> <p>In this mode, the instrument provides the highest dynamic range and fastest setting times, as specified in the data sheet.</p> <p>The RF signal is shortly blanked when the step attenuator is switching.</p>
"Uninterrupted"	<p>Suppresses blanking at level transitions. Frequency transitions can lead to an RF level blanking due to hardware specific switching points.</p> <p>This mode reduces the dynamic range of the instrument. The step attenuator is fixed.</p>

"Strictly Monotone"

Executes signal level changes monotonically increasing or decreasing.

The setting makes sure that increasing the level value exclusively results in an increased output level, and vice versa.

All electronic switches, which might affect the monotonicity are fixed. The operation mode is useful for applications using level searching algorithms which rely on a strictly monotonous behavior.

"Constant-VSWR"

Suppresses output impedance variations at the RF output connector, due to changed level settings.

"High Dyn. Uninterrupted"

R&S SMAB-K724

Provides a linear output power that is uninterrupted over a wide dynamic range.

"User"

Indicates that a setting has been modified in the expert mode. The expert mode is a protected function, that requires protection level 2 password.

Remote command:


[\[:SOURce<hw>\]:POWer:LBEHaviour](#) on page 636

7.5.4 Output Settings

Option: R&S SMAB-B28

Access:

1. Select for example "Sweep" > "RF Frequency Sweep".
2. Select "Output".



Settings

V/GHz / X-Axis	182
Marker / User	183

V/GHz / X-Axis

Option: R&S SMAB-B28

Selects the mode the voltage is supplied depending on the frequency.

The R&S SMA100B supplies the signal at the V/GHz X-Axis connector.

"0,25 V/GHz" / Supplies the voltage proportional to the set frequency, derived from
 "0,5 V/GHz" / the selected setting.
 "1 V/GHz"

"X-Axis" Supplies a voltage range from 0 V to 10 V proportional to the fre-
 quency sweep range, set with [Start Frequency/Stop Frequency](#) .

Remote command:

[:OUTPut:FPRoportional:SCALe](#) on page 452

Marker / User

Option: R&S SMAB-B28

Selects the signal to be supplied at the Marker User1 connector.

"Marker" Assigns a marker signal to the output.
 To configure and assign the marker signals, see [Chapter 7.5.5, "Edit Marker Settings"](#), on page 183.

"User" Intended for future use.

Remote command:

[:OUTPut:USER:MARKer](#) on page 453

7.5.5 Edit Marker Settings

Option: R&S SMAB-B28

Access:

1. Select "Sweep" > "RF Frequency Sweep"
2. Select "Marker".

General	Frequency Range	Advanced	Edit Marker		✕
Frequency 1	2.100 000 000 000 GHz	<input checked="" type="checkbox"/>	Frequency 2	3.000 000 000 000 GHz	<input checked="" type="checkbox"/>
Frequency 3	4.500 000 000 000 GHz	<input checked="" type="checkbox"/>	Frequency 4	2.100 000 000 000 GHz	<input type="checkbox"/>
Frequency 5	2.100 000 000 000 GHz	<input type="checkbox"/>	Frequency 6	2.100 000 000 000 GHz	<input type="checkbox"/>
Frequency 7	2.100 000 000 000 GHz	<input type="checkbox"/>	Frequency 8	2.100 000 000 000 GHz	<input type="checkbox"/>
Frequency 9	2.100 000 000 000 GHz	<input type="checkbox"/>	Frequency 10	2.100 000 000 000 GHz	<input type="checkbox"/>
Marker Polarity			Active Marker		
Normal			3		

You can define up to 10 markers, and assign one of them to the output at a time. When the sweep run has reached the marker frequency, the R&S SMA100B activates the marker signal and supplies it at the Marker User1 connector. The duration of the active signal corresponds to the dwell time of a step.

Settings

Frequency x 184
 State 184
 Marker Polarity..... 185
 Active Marker 185

Frequency x

Sets the frequency that the selected marker indicates.

When the specified value is used, the polarity of the marker signal changes, as selected with the parameter .

Remote command:

```
[ :SOURce<hw> ] :SWEep [ :FREQuency ] :MARKer<ch>:FREQuency on page 656
```

State

Enables the selected marker.

A marker signal at the output connector marks the moment the specified frequency values is used.

Remote command:

```
[ :SOURce<hw> ] :SWEep [ :FREQuency ] :MARKer<ch>:FState on page 657
```

Marker Polarity

Sets the polarity of the marker signal.

The duration of the active signal is equal to the dwell time of a step.

Remote command:

`[:SOURce<hw>] :SWEep:MARKer:OUTPut:POLarity` on page 656

Active Marker

Boosts a specific marker signal so that it is output with higher voltage than all other markers.

Remote command:

`[:SOURce<hw>] :SWEep [:FREQuency] :MARKer:ACTive` on page 656

7.6 List Mode Settings

The "List Mode" dialog contains all the functions and settings for creating and handling lists with RF frequency/level pairs including the corresponding dwell times for generating the RF signal based on these values.

Access:

- ▶ Select "Sweep" > "List mode".

The dialog contains parameters for configuring the list mode processing, entering list mode data and transferring data files from or to the instrument.


The remote commands required to define these settings are described in [Chapter 14.16.7, "SOURce:LIST Subsystem"](#), on page 616.

- [General Settings](#)..... 186
- [List Mode Data Settings](#)..... 188
- [Import/Export Settings](#)..... 189

7.6.1 General Settings

Access:

- ▶ Select "Sweep" > "List mode".



In the "General" tab, you can configure the trigger and dwell time modes for list processing and activate signal generation.

Settings

State	186
Current Index	186
Mode.....	187
Dwell Time Mode.....	187
Global Dwell Time.....	187
Trigger Slope.....	187
Reset	188
Execute Single.....	188

State

Activates the list mode and processes the currently selected list.

Note: Active sweep mode deactivates other sweeps or lists and vice versa.

Remote command:

[:SOURce<hw>] :FREQUency:MODE on page 595

Current Index

Sets the list index for list processing in "Step" mode. In the other modes, the index indicates the current step.

Remote command:

[:SOURce<hw>] :LIST:INDEX on page 621

Mode

Selects the mode for list processing.

For detailed information on the sweep modes and the triggering, see [Chapter 7.1, "Signal Generation and Triggering in the Sweep and List Modes"](#), on page 159.

"Auto" Generates the signal by processing the frequency/level value pairs of the list from the beginning to the end.
The list steps are performed automatically, controlled by the dwell time. If you switch from any mode to "Auto", signal generation always starts at the top of the list.

"Single / Extern Single" Generates the signal by processing the frequency/level value pairs of the list once from the beginning to the end after a trigger event.
The list steps are performed automatically, controlled by the dwell time. If one cycle is completed, the instrument waits for the next trigger event.

"Step / Extern Step" Generates the signal by processing the frequency/level value pairs of the list step-by-step, manually triggered.

Remote command:

`[:SOURce<hw>] :LIST:TRIGger:SOURce` on page 623

`[:SOURce<hw>] :LIST:MODE` on page 622

Dwell Time Mode

Selects either variable dwell times or a fixed dwell time to perform signal generation in list mode.

"Global" Uses the same dwell time for all lists steps, set with [Global Dwell Time](#).

"From List" Uses the dwell times from the list.
You can define the dwell time for each frequency/level value pair individually, see [Chapter 7.7, "List Editor"](#), on page 191.

Remote command:

`[:SOURce<hw>] :LIST:DWELL:MODE` on page 619

Global Dwell Time

Sets the dwell time for [Dwell Time Mode](#) > "Global".

Note: In case of considerable overrun conditions, the R&S SMA100B turns off the list mode.

See also ["Dwell time"](#) on page 171.

Remote command:

`[:SOURce<hw>] :LIST:DWELL` on page 619

Trigger Slope

For "Mode = Extern Step/Single", selects the polarity of the active slope of an applied instrument trigger.

Trigger signal is expected at the Inst Trig connector.

"Positive" The rising edge of the trigger signal triggers the instrument.

"Negative" The falling edge of the trigger signal triggers the instrument.

Remote command:

`[:SOURce] : INPut : TRIGger : SLOPe` on page 603

Reset

Resets the list to the starting point.

Remote command:

`[:SOURce<hw>] : LIST : RESet` on page 626

Execute Single

Manually starts list processing in "Single" mode.


Remote command:

`[:SOURce<hw>] : LIST : TRIGger : EXECute` on page 623

7.6.2 List Mode Data Settings

Access:

1. Select "Sweep" > "List mode".
2. Select "List Mode Data".



This dialog contains the parameters required for creating and editing lists, activating the learning function and selecting the list processing mode.

Settings

List Mode Data	188
Edit List Mode Data	189
List Range from/to	189

List Mode Data

Accesses the standard "Select List" dialog for selecting, creating and editing a list file. The currently loaded file is indicated.

You can create data lists with the internal editor or import externally created files, see ["Creating and handling lists"](#) on page 170.

Remote command:

`[:SOURce<hw>] : LIST : CATalog?` on page 624

`[:SOURce<hw>] : LIST : SElect` on page 626

`[:SOURce<hw>] : LIST : DElete` on page 625

`[:SOURce<hw>] : LIST : DElete : ALL` on page 625

Edit List Mode Data

Opens the editor to insert and save data lists with RF frequency, power and dwell time values, see [Chapter 7.7, "List Editor"](#), on page 191.

You find this function also in standard file select dialog, accessed via [List Mode Data](#) .

List Range from/to

Defines an index range in the current list by setting the start and stop index.

The instrument generates the signal with the values of the selected index range and ignores all other list entries.

Remote command:


[:SOURce<hw>] :LIST:INDEX:START on page 621

[:SOURce<hw>] :LIST:INDEX:STOP on page 621

7.6.3 Import/Export Settings

Access:

1. Select "Sweep" > "List Mode".
2. Select "List Mode Data" > "Im-/Export".



The "Im-/Export" dialog provides the parameters for importing or exporting files with user data in standard ASCII *.txt or *.csv file format.

The table separators and the decimal floating point numbers are customizable.

Settings

Mode	190
ASCII File Settings.....	190
Select (ASCII) Source/Select (ASCII) Destination.....	190
Select Source/Select ASCII Destination.....	191
Import / Export.....	191

Mode

Selects import or export of a data list file. The provided parameters vary according to the selected mode.

Remote command:

[:SOURce<hw>] :LIST:DEXChange:MODE on page 628
 [:SOURce<hw>] :CORRection:DEXChange:MODE on page 594
 [:SOURce<hw>] :PULM:TRAIIn:DEXChange:MODE on page 542

ASCII File Settings

Defines the format and the separators of the associated data file.

"Extension" Selects *.csv or *.txt format.
 "Decimal Sets "Point" (dot) or "Comma" as the decimal separator used in the
 Point" ASCII data with floating-point numerals.
 "Column Separator"
 Sets the separator between the columns in an ASCII table.
 Available are: "Tab", "Semicolon", "Comma" or "Space".

Remote command:

[:SOURce<hw>] :LIST:DEXChange:AFIle:EXTeNsion on page 627
 [:SOURce<hw>] :LIST:DEXChange:AFIle:SEParator:DECimal on page 628
 [:SOURce<hw>] :LIST:DEXChange:AFIle:SEParator:COLumn on page 628
 [:SOURce<hw>] :CORRection:DEXChange:AFIle:EXTeNsion on page 592
 [:SOURce<hw>] :CORRection:DEXChange:AFIle:SEParator:DECimal
 on page 593
 [:SOURce<hw>] :CORRection:DEXChange:AFIle:SEParator:COLumn
 on page 593
 [:SOURce<hw>] :PULM:TRAIIn:DEXChange:AFIle:EXTeNsion on page 543
 [:SOURce<hw>] :PULM:TRAIIn:DEXChange:AFIle:SEParator:DECimal
 on page 543
 [:SOURce<hw>] :PULM:TRAIIn:DEXChange:AFIle:SEParator:COLumn
 on page 543

Select (ASCII) Source/Select (ASCII) Destination

In "Mode > Import", access the file select dialog that provides standard file handling functions.

Where:

- "Select ASCII Source": defines the file to be loaded (imported)
- "Select ASCII Destination": selects the filename under that the loaded file is saved

Remote command:

[:SOURce<hw>] :LIST:DEXChange:AFILe:CATalog? on page 627
 [:SOURce<hw>] :LIST:DEXChange:AFILe:SElect on page 627
 [:SOURce<hw>] :CORRection:DEXChange:AFILe:CATalog? on page 592
 [:SOURce<hw>] :CORRection:DEXChange:AFILe:SElect on page 593
 [:SOURce<hw>] :PULM:TRain:DEXChange:AFILe:CATalog? on page 543
 [:SOURce<hw>] :PULM:TRain:DEXChange:AFILe:SElect on page 544

Select Source/Select ASCII Destination

In "Mode > Export", access the file select dialog that provides standard file handling functions.

Where:

- "Select Source": selects the file to be exported
- "Select ASCII Destination": defines the filename and the file path for the exported file

Remote command:

[:SOURce<hw>] :LIST:DEXChange:SElect on page 628
 [:SOURce<hw>] :CORRection:DEXChange:SElect on page 594
 [:SOURce<hw>] :PULM:TRain:DEXChange:SElect on page 544

Import / Export

Imports or exports the selected data list file, depending on the current mode.

Remote command:

[:SOURce<hw>] :LIST:DEXChange:EXECute on page 627
 [:SOURce<hw>] :CORRection:DEXChange:EXECute on page 593
 [:SOURce<hw>] :PULM:TRain:DEXChange:EXECute on page 544

7.7 List Editor

The "User Correction" and "List Mode" dialogs provide a build-in list editor for defining the corresponding value pairs.

The table and navigation functions of the UCOR and list mode editors have the same structure and are therefore summarized below. The access is specified for both modes, the fields and functions are explained using the example of the list mode.

Access to "Edit List Mode Data":

- ▶ "Sweep" > "List Mode" > "List Mode Data" > "Edit List Mode Data"

	Frequency /Hz	Correction Value /dB
0	1 560 000 000.00	11.51
1	1 561 000 000.00	11.03
2	1 562 000 000.00	10.55
3	1 563 000 000.00	10.07
4	1 564 000 000.00	9.59
5	1 565 000 000.00	9.11
6	1 566 000 000.00	8.63
7	1 567 000 000.00	8.15
8	1 568 000 000.00	7.67
9	1 569 000 000.00	7.19
10	1 570 000 000.00	6.71
11	1 571 000 000.00	6.23

Go To Edit Fill with Sensor ... Save As ... Save

The editor for list mode data provides a table with RF frequency and power values and standard navigation functions.

Access to "Edit User Correction Data":

- ▶ "Level" > "User Correction" > "Edit User Cor. Data"

	Frequency /Hz	Power /dBm	Dwell Time /s
0	1 000 000 000.000	-20.00	0.010 000
1	1 500 000 000.000	-25.00	0.010 000
2	3 000 000.000	-10.00	0.050 000
3	2 000 000 000.000	-30.00	0.100 000
4			

Go To Edit Save As ... Save

The editor for user correction provides a table with RF frequency and power values, an extra column for defining variable dwell times, and standard navigation functions.



All columns in a row must contain values. Cells with missing values are therefore filled automatically, using the value of the previous row.

If you use **global dwell time in list mode**, consider also that the instrument uses the value set with [Global Dwell Time](#) for all list steps and not the values from the list.

Since the table and navigation functions can be assumed to be known, the following description contains a brief overview, shown by the example of the "List Data Editor". If a function relates to a particular dialog, it is explicitly stated.

Settings

Edit List Mode Data.....	193
Data handling keys	193
L Go To.....	193
L Edit.....	194
L Fill with Sensor.....	194
L Save As/Save.....	194
Fill.....	194

Edit List Mode Data

Table with values for list or user correction processing.

Note: Once you enter a value, the editor automatically adds preset values in the other columns. This functionality protects against data loss, otherwise incomplete rows will be lost when saving. You can simply override these values.

"Frequency /Hz"

Sets the frequency values.

Remote command:

[:SOURce<hw>] :LIST:FREQuency on page 620

[:SOURce<hw>] :CORRection:CSET:DATA:FREQuency on page 589

"Power /dBm" Sets the level values.

Remote command:

[:SOURce<hw>] :LIST:POWer on page 622

[:SOURce<hw>] :CORRection:CSET:DATA:POWer on page 589


"Dwell /s" In list mode, sets the dwell time values.

Remote command:

[:SOURce<hw>] :LIST:DWELL:LIST on page 620

Data handling keys

Standard functions for file and data handling.



Go To ← Data handling keys

Selects a row for editing.

Edit ← Data handling keys

Enables you to insert, or delete a row or ranges within a list, and provides access to a dialog for automatic filling, see " Fill... " on page 93.

Fill with Sensor ← Data handling keys

Opens a dialog to configure the automatic filling of user correction data with an R&S NRP power sensor. Available in UCOR mode only.


See [Chapter 8.3.3, "Fill with Sensor"](#), on page 210

Save As/Save ← Data handling keys

Stores the list in a file with user-defined name and predefined file extension. To save a copy or create a file, use the "Save as" function.

Fill...

Provides parameters for filling a table automatically with user-defined values.

From 0	Range 1
Column To Fill Frequency/Hz	
Start Value 2.000 000 000 000 GHz	End Value 2.000 000 000 000 GHz
Increment Value 200.000 000 000 MHz	
 Fill	

To fill the table, select "Fill".

Note: Once you enter a value or fill a column, the editor automatically adds preset values in the other columns. This functionality protects against data loss, otherwise incomplete rows will be lost when saving. You can simply override these values.

"From / Range"

Defines the start line and number of lines to be filled.

"Column To Fill"

Selects, if the column is filled up with frequencies in Hz, levels in dBm or dwell times in s.

"Start Value / End Value"

Sets the start value for frequency, level or dwell time. The end value is read only and depends on the increment value and the range.

"Increment Value"

Determines the step size.

"Fill"

Fills the column specified in "Column To fill".

7.8 How to Generate a Signal in List or Sweep Mode

This section shows you how to configure a varying RF output signal for both, the list and sweep modes.

To configure the frequency sweep signal

- ▶ For a step-by-step description, see [Chapter 3.3.2, "Generating an RF Frequency Sweep Signal"](#), on page 47.

Example: Fast changing frequency and level settings in list mode

The following example shows you how to generate an amplitude modulated RF signal based on list mode data.

General workflow

Since any change of the hardware settings or list entries can affect the RF signal characteristics directly, we recommend that you proceed as follows:

1. Configure the modulation settings.
Activate the RF signal.
2. Wait until the hardware settings have settled.
3. Create a list file.
4. Configure the list mode.
5. Activate list mode.

To configure amplitude modulation and switch RF on

1. Press [Preset] to start from an initial state.
2. Select "Modulation" > "Amplitude Modulation > On".
3. Select "Level" > "RF ON" to activate RF signal generation.

To create list mode data

1. Select "Sweep" > "List Mode".
2. In the "List Mode Data" tab, select "List Mode Data > New"
3. Enter the filename `ListMode_Test` for the data list and confirm with "Ok".
The instrument creates a file and stores it in the `/var/user/` directory.
4. Select "Edit List Mode Data".
5. Enter the first values "Frequency > 2", "Power > 0" and "Dwell > 2".
6. Enter further frequency, power and dwell time values in the same way.
7. Select "Save" and close the dialog.

To configure the list mode and start signal generation

1. In the "General" tab, select "List Mode > Auto".
2. Select "Dwell Time Mode > From List".
3. Switch state to "On".
4. Select "General > State > On".

The instrument continuously generates an amplitude-modulated RF signal whose frequency and level values change according to the dwell times, as defined in the list.

With active list mode, the generator displays no frequency and level values in the status bar, but you can check the following parameters.

- In the list mode dialog, the current index indicates the steps of the signal generation.
- In remote control mode, you can query:
 - The current state with `[:SOURce<hw>] :LIST:RUNNING?`
 - Current parameters with the commands `FREQ?`, `POW?` and `LIST:DWEL?`.

8 Improving Level Performance

To adapt the RF output signal to specific needs in your application, the R&S SMA100B offers different functions:

- **Attenuator**
The R&S SMA100B is equipped with a step attenuator that enables you to vary the amplitude of the RF signal in a wide range. It is characterized by low VSWR (voltage standing wave ratio) over the full level and frequency range, and provides highest level accuracy and noise suppression.
See ["About the attenuator"](#) on page 197.
- **Automatic Level Control (ALC)**
The automatic level control system ensures stable RF signals with highest absolute level accuracy over temperature and time.
See ["About ALC"](#) on page 200.
- **User correction (UCOR)**
The user correction function allows you to compensate frequency responses of external setups (e.g. losses of cables) and achieve a stable input signal over frequency directly at the DUT.
See ["About UCOR"](#) on page 203.
- **Power sensors**
The R&S SMA100B has excellent absolute level accuracy. Since a DUT is rarely connected directly to the generator, but with cables or other components, the reference level shifts from the RF output to the DUT. To calibrate this level with high accuracy, i.e. in the tenth dB range, you can connect an R&S NRP power sensor to the generator. The power sensor transmits its readings to the generator, which indicates these measurement results in the display. Thus you can adjust the RF output power of the generator until you reach the target level at the DUT.
See [Chapter 8.4, "Using Power Sensors"](#), on page 214

8.1 Attenuator

About the attenuator

The step attenuator is either an electronic or a mechanical device. Instruments with frequency options up to 20 GHz use an electronic step attenuator, providing fast and wear free level settings. Instruments capable to generate higher frequency signals use mechanical step attenuators. Depending on the frequency range and the installed high-power option, both types of step attenuators can be built in, and you can select the type to be used below 20 GHz.

To achieve a consistent level setting behavior for all frequencies, the mechanical step attenuator is used even for lower frequencies while the electronic one is disregarded.

According to the requirements of your application, you can select different attenuator characteristics.


The following are examples of test requirements and the corresponding configuration:

- Automatic configuration
Select standard operation mode ("Auto"), in which the generator adjusts the attenuation of the RF output signal automatically.
- DUT tests under low signal to noise conditions
Low output power is suitable to test the behavior of a DUT under low signal to noise conditions.
- Uninterrupted level settings with constant VSWR
A fix attenuation value is required for obtaining uninterrupted level settings with constant VSWR.
The configuration "RF Off Mode > Unchanged" ensures that constant VSWR is maintained if you turn the signal off and on again.
- Noise sensitive applications
The parameter "RF OFF Mode > Full Attenuation" sets maximum attenuation and thus suppresses noise when you turn off the RF signal.

8.1.1 Attenuator Settings

Access:

- ▶ Select "Level" > "Level > Attenuator".



In the "Attenuator" dialog, you can select the operating mode of the electronic step attenuator.

The remote commands required to define these settings are described in [Chapter 14.13, "OUTPut Subsystem"](#), on page 450 and [Chapter 14.16.11, "SOURce:POWer Subsystem"](#), on page 633.

Settings

Mode	199
Step Attenuator below 20 GHz.....	199
Level Range	199
RF OFF Mode	199

Mode

Determines the operating mode of the step attenuator.

- "Auto" Adjusts the attenuator settings automatically.
- "Fixed" Fixes the attenuator and amplifier paths for the current RF level and provides signal output with constant output VSWR. The resulting level range is indicated under "[Level Range](#)" on page 199.

Remote command:

`:OUTPut<hw>:AMODE` on page 451

Step Attenuator below 20 GHz

Selects the type of the step attenuator for frequencies up to 20 GHz.

This setting depends on the frequency range and the installed high power options, see "[About the attenuator](#)" on page 197.

- "Mechanical" Selects that the R&S SMA100B uses the mechanical step attenuator over the whole frequency range.
The mechanical attenuator is used even for lower frequencies to achieve a consistent level setting behavior for all frequencies. The electronic step attenuator is disregarded.
- "Electronic" Selects that the R&S SMA100B uses the electronic attenuator as long as the frequency is below 20 GHz, providing benefits regarding setting time and wear.

Remote command:

`[:SOURce<hw>] :POWer:ATTenuation:PATTenuator` on page 635

Level Range

Shows the interruption-free range of the level that you can use in the selected mode.

Remote command:

`:OUTPut<hw>:AFIXed:RANGe:LOWer?` on page 453

`:OUTPut<hw>:AFIXed:RANGe:UPPer?` on page 453

RF OFF Mode

Determines the state of the step attenuator, when the RF signal is switched off.

The setting is not affected by an instrument preset ([Preset] key or *RST) and the "Save/Recall" function. It is reset only by factory preset.

- "Unchanged" Freezes the setting of the step attenuator.
Use this mode if a constant VSWR (Voltage Standing Wave Ratio) is required.
- "Full Attenuation" Switches to the maximum attenuation.
Use this mode for applications that require a high level of noise suppression.

Remote command:

`[:SOURce<hw>] :POWer:ATTenuation:RFOff:MODE` on page 635

8.1.2 Reverse Power Protection

The R&S SMA100B is equipped with a reverse power protection circuit.

The reverse power protection is tripped when the power of signals reflected from the load or external signals applied to the RF output get too high. A relay opens and interrupts the internal connection to the RF output. This condition is indicated in the status bar by the "Overload" status message.

Overload

If an "Overload" status message is indicated in the status bar, perform the following:

- Remove the cause for the overload
- Press the [RF on/off] key to reset the overload protection

The RF input is activated when the overload protection is reset.

Remote command:

`:OUTPut<hw>:PROTection:TRIPped?` on page 454

`:OUTPut<hw>:PROTection:CLEar` on page 453

8.2 Automatic Level Control (ALC)

The R&S SMA100B is equipped with an automatic level control (ALC) unit to obtain best RF level accuracy.

About ALC

ALC is an adaptive control system to stabilize the RF output level. It continuously monitors the current level and adjusts it to keep a steady state over temperature and time.



ALC is active in almost all applications by default.

However, when **pulse modulation** with short pulses is used, the ALC uses table-based level settings with table values depending on the pulse width.

Also note that ALC can detect incorrect values in **multi-transmitter** test setups. If multiple generators are coupled, reverse power can affect the ALC readings, which can lead to an incorrect RF output power.

ALC States and their effects

The following description basically explains the ALC states and their principle of operation:

- "Auto"
Adjusts the output level to the operating conditions automatically. ALC is active in almost all operating modes.
- "On"
Activates the internal level control permanently, regardless of the operating conditions. This setting provides the highest level accuracy.
- "Off (Table)"

Deactivates internal level control loop. The instrument calculates every level setting using the attenuation values from the internal (ALC) table. Level attenuation between two table values is done with linear interpolation. This mode enables you to perform a strictly monotonic, but not quite as precise level adjustment.


- "Table & On"
Starts with the associated value of the internal level table and then activates the automatic level control. This mode achieves maximum level accuracy and fast setting times.
If pulse modulation is applied, this mode ensures fast level setting even with narrow pulses at low repetition rate.

The R&S SMA100B displays the level control setting as a status message in the info line.

8.2.1 ALC Settings

Access:

- ▶ Select "Level" > "Automatic Level Control".



In the "ALC" dialog, you can configure the settings for the automatic level control of the RF signal to achieve optimal accuracy.

The remote commands required to define these settings are described in [Chapter 14.16.11, "SOURCE:POWER Subsystem"](#), on page 633.

Settings

State	201
Detector Sensitivity	202

State

Selects the internal level control mode.

Find further details about the individual settings in ["ALC States and their effects"](#) on page 200. It covers an overview of the functionality and indicates what is to be considered.

- "Auto" Selects the most appropriate ALC mode automatically.
- "On" Activates ALC permanently.

"Off (Table)"

Controls the level using the attenuation values of the internal ALC table.

"Table & On"

Starts with the attenuation setting from the table and continues with automatic level control.

Remote command:

`[:SOURce<hw>] :POWer:ALC [:STATe]` on page 633

Detector Sensitivity

Determines the path of the internal level detector.

The level detector of the ALC has multiple paths distinguished by their sensitivity.

"Auto"

Selects the detector path automatically, according to the given level. This mode is the recommended operation mode.

"Fix"

Fixes the last set sensitivity setting.

Remote command:

`[:SOURce<hw>] :POWer:ALC:DSENsitivity` on page 634

8.3 User Correction

The R&S SMA100B supports a correction function to compensate external losses, caused, for example, by the RF cable, to achieve a precise target input level at the DUT.

The signal at the RF outputs of the R&S SMA100B is flat. However, the DUT is usually not connected directly to the outputs of the instrument but rather via connecting cables. Components like cables, power combiners, switches or mixers can affect the signal flatness at the DUT input.




Figure 8-1: Effect of external losses on the signal flatness at the DUT input

DUT = Device under test

Components = Designation of all components between the measurement equipment and the DUT, e.g. cables

1 = Flat signal at the outputs of the R&S SMA100B

2 = Signal received at the DUT, incl. the external losses

About UCOR

User correction (UCOR) is a method that determines the external level loss over a frequency range in advance, see [Figure 8-2](#).

The difference between the generator output level and the level at the DUT determines the correction value at the respective frequency. Alternatively, the attenuation characteristics over a certain frequency range of, for example, RF cables are also specified in the associated data sheet.




Figure 8-2: Understanding the principle of user correction

DUT	= Device under test
Components	= Designation of all components between the measurement equipment and the DUT, e.g. cables
PS	= Power sensor, e.g. R&S NRP, connected at the DUT's input and the USB connector of the R&S SMA100B
1	= Power sensor measures the level over a frequency range, where the collected values correspond to the losses caused by the components between the R&S SMA100B and the DUT
2	= Obtain the correction data by inverting the collected data; load the correction parameters in the R&S SMA100B
3	= In the R&S SMA100B, the RF signal is pre-processed with the correction values so that the signal at the outputs is the inverted version of the external losses
4	= Received at the DUT input, the pre-processed signal is flat

With active **UCOR**, the generator adds the correction value internally and thus increases the output level by exactly the amount of the loss between its output and the DUT. For frequencies which are not contained in the list, the level correction is calculated by interpolation of the closest correction values.

Possible ways for configuring the user correction values

You can configure correction values in the following ways:

- **Internally**

- Use the built-in table editor in the "UCOR > Edit User Correction Data" dialog. Once defined, user correction values can be saved in a file. Files with correction data can be exported, for example, to exchange configuration between instruments or to modify the file content with an external program and reload them again.
- Using the corresponding remote-control commands.

Note that you have to create a user correction file first.

- **Externally**
Create a file with correction values as a CSV file with Microsoft Excel, with a Notepad or a similar tool and save it with the predefined extension. Transfer the file to and load it into the instrument.

UCOR file format

Files containing correction data are simple files in text or comma-separated value (CSV) file format. The filename is user-definable; the file extension is *.ucor.

The file contains a list of correction values, one row per frequency and correction value pair; a new line indicator separates the correction values.

For file handling, use the standard functions in the "File Manager", see [Chapter 11.8, "Using the File Manager"](#), on page 303.

Collecting correction data

To fill the frequency and power values in the correction table, use one of the following options:

- **Manually**, row by row.
- Fill the table **automatically** with linearly interpolated values, calculated based on value range and step size.
- Acquire the real frequency response characteristics of the used component with the **R&S NRP power sensor**, see [Understanding the principle of user correction](#).

Using a power sensor for frequency response measurements

Consider the following when using R&S NRP power sensors to measure the correction values:

- Measure the level directly at the input of the DUT.
- Use the internal correction functions of an R&S NRP power sensor to increase the measurement accuracy.
- Use S-parameter to consider the impact of any two-port device like an adapter between the signal generator and the sensor input.



Interactions and characteristics

Activated user correction is effective in all operating modes.

The RF output level ($Level_{RF}$) is the sum of the level value and the correction for the particular frequency:


$$Level_{RF} = \text{"Status bar > Level"} + \text{"UCOR"}$$

Activated user correction is indicated by the status indication "Lev Ucor" in the "Level" tile.

8.3.1 User Correction Settings

Access:

1. Select "Level" > "User Correction".
2. If you already have created a file with user correction data:
 - a) Select "UCOR Data > navigate to the file *.uco > Select".
 - b) Proceed with [step 4](#).
3. If you need to create a file:
 - a) Select "UCOR Data > New".
 - b) Enter the filename `UCOR_Data` and confirm with "Ok".
 - c) Choose the file and confirm with "Select".
 - d) Select "Edit UCOR Data".
 - e) To fill the user correction data table, proceed as described in [Chapter 7.7, "List Editor"](#), on page 191.
4. Select "RF Level > RF State > On".
5. Select "User Cor. Data > State > On".



The "UCOR" dialog contains all settings for creating and handling files with user-defined level correction values.

The remote commands required to define these settings are described in [Chapter 14.16.3, "SOURCE:CORREction Subsystem"](#), on page 586.

Settings

State.....	206
User Correction.....	206
UCOR Data.....	206
Edit UCOR Data.....	206

State

Activates user correction.

The R&S SMA100B displays the status icon "Lev Ucor" in the "Level" panel.

Remote command:

[\[:SOURCE<hw>\]:CORRection\[:STATe\]](#) on page 591

User Correction

Indicates the corrected level value for a specific frequency point.

Remote command:

[\[:SOURCE<hw>\]:CORRection:VALue?](#) on page 590

UCOR Data

Accesses the standard "File Select" function of the instrument. The provided navigation possibilities in the dialog are self-explanatory.

Files with user correction values are files with predefined file extension *.uco. When a file is selected, the dialog indicates the filename.

You can create the file internally in the table editor or externally.

- To select an existing file, select "Select List > navigate to the file *.uco > Select"
- Use the general editor function to create internally new file or to edit an existing one.
- Use the standard file manager function to load externally created files to the instrument.

Remote command:

[\[:SOURCE\]:CORRection:CSET:CATalog?](#) on page 591

[\[:SOURCE<hw>\]:CORRection:CSET\[:SElect\]](#) on page 590

[\[:SOURCE\]:CORRection:CSET:DElete](#) on page 592

Edit UCOR Data

Opens the build-in table editor to define a new correction table or edit an existing one.

See also:

- [Chapter 7.7, "List Editor"](#), on page 191
- [" Fill... "](#) on page 93
- [Chapter 8.3.3, "Fill with Sensor"](#), on page 210

8.3.2 List Editor

The "User Correction" and "List Mode" dialogs provide a build-in list editor for defining the corresponding value pairs.

The table and navigation functions of the UCOR and list mode editors have the same structure and are therefore summarized below. The access is specified for both modes, the fields and functions are explained using the example of the list mode.

Access to "Edit List Mode Data":

- ▶ "Sweep" > "List Mode" > "List Mode Data" > "Edit List Mode Data"

	Frequency /Hz	Correction Value /dB
0	1 560 000 000.00	11.51
1	1 561 000 000.00	11.03
2	1 562 000 000.00	10.55
3	1 563 000 000.00	10.07
4	1 564 000 000.00	9.59
5	1 565 000 000.00	9.11
6	1 566 000 000.00	8.63
7	1 567 000 000.00	8.15
8	1 568 000 000.00	7.67
9	1 569 000 000.00	7.19
10	1 570 000 000.00	6.71
11	1 571 000 000.00	6.23

Go To Edit Fill with Sensor ... Save As ... Save

The editor for list mode data provides a table with RF frequency and power values and standard navigation functions.

Access to "Edit User Correction Data":

- ▶ "Level" > "User Correction" > "Edit User Cor. Data"

	Frequency /Hz	Power /dBm	Dwell Time /s
0	1 000 000 000.000	-20.00	0.010 000
1	1 500 000 000.000	-25.00	0.010 000
2	3 000 000.000	-10.00	0.050 000
3	2 000 000 000.000	-30.00	0.100 000
4			

Go To Edit Save As ... Save

The editor for user correction provides a table with RF frequency and power values, an extra column for defining variable dwell times, and standard navigation functions.



All columns in a row must contain values. Cells with missing values are therefore filled automatically, using the value of the previous row.

If you use **global dwell time in list mode**, consider also that the instrument uses the value set with **Global Dwell Time** for all list steps and not the values from the list.

Since the table and navigation functions can be assumed to be known, the following description contains a brief overview, shown by the example of the "List Data Editor". If a function relates to a particular dialog, it is explicitly stated.

Settings

Edit List Mode Data.....	208
Data handling keys	208
L Go To.....	208
L Edit.....	209
L Fill with Sensor.....	209
L Save As/Save.....	209
Fill.....	209

Edit List Mode Data

Table with values for list or user correction processing.

Note: Once you enter a value, the editor automatically adds preset values in the other columns. This functionality protects against data loss, otherwise incomplete rows will be lost when saving. You can simply override these values.

"Frequency /Hz"

Sets the frequency values.

Remote command:

[:SOURce<hw>] :LIST:FREQuency on page 620

[:SOURce<hw>] :CORRection:CSET:DATA:FREQuency on page 589

"Power /dBm" Sets the level values.

Remote command:

[:SOURce<hw>] :LIST:POWer on page 622

[:SOURce<hw>] :CORRection:CSET:DATA:POWer on page 589


"Dwell /s" In list mode, sets the dwell time values.

Remote command:

[:SOURce<hw>] :LIST:DWELL:LIST on page 620

Data handling keys

Standard functions for file and data handling.



Go To ← Data handling keys

Selects a row for editing.

Edit ← Data handling keys

Enables you to insert, or delete a row or ranges within a list, and provides access to a dialog for automatic filling, see " Fill... " on page 93.

Fill with Sensor ← Data handling keys

Opens a dialog to configure the automatic filling of user correction data with an R&S NRP power sensor. Available in UCOR mode only.


See [Chapter 8.3.3, "Fill with Sensor"](#), on page 210

Save As/Save ← Data handling keys

Stores the list in a file with user-defined name and predefined file extension. To save a copy or create a file, use the "Save as" function.

Fill...

Provides parameters for filling a table automatically with user-defined values.

From 0	Range 1
Column To Fill Frequency/Hz	
Start Value 2.000 000 000 000 GHz	End Value 2.000 000 000 000 GHz
Increment Value 200.000 000 000 MHz	
 Fill	

To fill the table, select "Fill".

Note: Once you enter a value or fill a column, the editor automatically adds preset values in the other columns. This functionality protects against data loss, otherwise incomplete rows will be lost when saving. You can simply override these values.

"From / Range"

Defines the start line and number of lines to be filled.

"Column To Fill"

Selects, if the column is filled up with frequencies in Hz, levels in dBm or dwell times in s.

"Start Value / End Value"

Sets the start value for frequency, level or dwell time. The end value is read only and depends on the increment value and the range.

"Increment Value"

Determines the step size.

"Fill"

Fills the column specified in "Column To fill".

8.3.3 Fill with Sensor

Access:

1. Select "Level" > "User Correction".
2. Select "UCOR Data > navigate to the file *.ucor > Select".
3. Select "Edit UCOR Data > Fill With Sensor...".

Sensor		List To Fill	
2: NRP18S S/N 100654		ucor	
Use SParameter	<input type="checkbox"/>	Include Zeroing	<input checked="" type="checkbox"/>
Execute			
Used		Settings for Measurement	
Modulation	Off (CW)	Amplitude	-30.00 dBm

This dialog contains parameters for filling a table automatically with sensor readings.



To fill the table, select "Execute".

For information on power sensors and how to use them, see [Chapter 8.5, "How to Calibrate the Power Level with an R&S NRP Power Sensor"](#), on page 269.

Settings

Fill User Correction Data with Sensor	210
Used SMAB Settings For Measurement	211

Fill User Correction Data with Sensor

- "Sensor"
Displays connected sensors for selection.
- "List To Fill"
Indicates the used list.
- "Use SParameter"
Indicates whether SParameter correction in the R&S NRP power sensor is used.
- "Include Zeroing"
Performs a zeroing procedure before acquiring the user correction data to improve precision.
No signal is applied to the sensor during zeroing. RF output is temporarily switched off during that time.

When unchecked, the zeroing procedure is skipped. However, the RF signal level might be blanked shortly. This setting is useful if blanking of RF is undesirable or the absence of power at the sensor cannot be guaranteed.

- "Execute"

The "Execute" button is only enabled if a sensor is detected and the user correction list contains at least one frequency value.

Remote command:

`[:SOURce<hw>] :CORRection:ZERoing:STATe` on page 591

`[:SOURce<hw>] :CORRection:CSET:DATA [:SENSor<ch>] [:POWER] :SONCe`
on page 590

Used SMAB Settings For Measurement

Displays the settings relevant for the measurement.

"Modulation" Indicates the modulation state

"Amplitude" Shows the currently set level.

Remote command:

n.a.

8.3.4 Import/Export List Files

Access:

1. Select one of the following:
 - "Sweep" > "List mode".
 - "Level" > "User Correction".
 - "Modulation > Pulse Modulation > Pulse Generator > Pulse Mode = Train".

2. Select "Import/Export".




Figure 8-3: Im-/Export dialog (example with UCOR settings)

The "Import/Export" dialog contains all functions and settings to import externally created list data or to export it accordingly. You can process and store a list in the formats *.txt (ASCII), or *.csv (plain text with identical sequence of fields). The table separators and the decimal floating point numbers are customizable.

Settings

Mode 212
 ASCII File Settings..... 212
 Select (ASCII) Source/Select (ASCII) Destination..... 213
 Select Source/Select ASCII Destination..... 213
 Import / Export..... 213

Mode

Selects import or export of a data list file. The provided parameters vary according to the selected mode.

Remote command:

- [:SOURce<hw>] :LIST:DEXChange:MODE on page 628
- [:SOURce<hw>] :CORRection:DEXChange:MODE on page 594
- [:SOURce<hw>] :PULM:TRAIIn:DEXChange:MODE on page 542

ASCII File Settings

Defines the format and the separators of the associated data file.

- "Extension" Selects *.csv or *.txt format.
- "Decimal Point" Sets "Point" (dot) or "Comma" as the decimal separator used in the ASCII data with floating-point numerals.

"Column Separator"

Sets the separator between the columns in an ASCII table.
Available are: "Tab", "Semicolon", "Comma" or "Space".

Remote command:

[\[:SOURce<hw>\]:LIST:DEXChange:AFILe:EXTension](#) on page 627
[\[:SOURce<hw>\]:LIST:DEXChange:AFILe:SEParator:DECimal](#) on page 628
[\[:SOURce<hw>\]:LIST:DEXChange:AFILe:SEParator:COLumn](#) on page 628
[\[:SOURce<hw>\]:CORRection:DEXChange:AFILe:EXTension](#) on page 592
[\[:SOURce<hw>\]:CORRection:DEXChange:AFILe:SEParator:DECimal](#)
on page 593
[\[:SOURce<hw>\]:CORRection:DEXChange:AFILe:SEParator:COLumn](#)
on page 593
[\[:SOURce<hw>\]:PULM:TRAIIn:DEXChange:AFILe:EXTension](#) on page 543
[\[:SOURce<hw>\]:PULM:TRAIIn:DEXChange:AFILe:SEParator:DECimal](#)
on page 543
[\[:SOURce<hw>\]:PULM:TRAIIn:DEXChange:AFILe:SEParator:COLumn](#)
on page 543

Select (ASCII) Source/Select (ASCII) Destination

In "Mode > Import", access the file select dialog that provides standard file handling functions.

Where:

- "Select ASCII Source": defines the file to be loaded (imported)
- "Select ASCII Destination": selects the filename under that the loaded file is saved

Remote command:

[\[:SOURce<hw>\]:LIST:DEXChange:AFILe:CATalog?](#) on page 627
[\[:SOURce<hw>\]:LIST:DEXChange:AFILe:SELeCt](#) on page 627
[\[:SOURce<hw>\]:CORRection:DEXChange:AFILe:CATalog?](#) on page 592
[\[:SOURce<hw>\]:CORRection:DEXChange:AFILe:SELeCt](#) on page 593
[\[:SOURce<hw>\]:PULM:TRAIIn:DEXChange:AFILe:CATalog?](#) on page 543
[\[:SOURce<hw>\]:PULM:TRAIIn:DEXChange:AFILe:SELeCt](#) on page 544

Select Source/Select ASCII Destination

In "Mode > Export", access the file select dialog that provides standard file handling functions.

Where:

- "Select Source": selects the file to be exported
- "Select ASCII Destination": defines the filename and the file path for the exported file

Remote command:

[\[:SOURce<hw>\]:LIST:DEXChange:SELeCt](#) on page 628
[\[:SOURce<hw>\]:CORRection:DEXChange:SELeCt](#) on page 594
[\[:SOURce<hw>\]:PULM:TRAIIn:DEXChange:SELeCt](#) on page 544

Import / Export

Imports or exports the selected data list file, depending on the current mode.

Remote command:

[:SOURce<hw>] :LIST:DEXChange:EXECute on page 627

[:SOURce<hw>] :CORRection:DEXChange:EXECute on page 593

[:SOURce<hw>] :PULM:TRAIIn:DEXChange:EXECute on page 544

8.4 Using Power Sensors

The R&S SMA100B works with most of the R&S NRP power sensors and thus supports various application tasks. Using power sensors, you can for example determine attenuation characteristics of downstream equipment or cables. You can use the measured values to compensate the losses with internal control functions or with an external control circuit in real time.

R&S NRP sensors are highly accurate standalone measuring devices, suitable for a wide range of applications. The devices communicate directly with the signal generator, calculate the average or peak power internally, include S-parameter correction and return the measurement results to the generator.

The R&S SMA100B works with any sensor of the R&S NRP series and can perform up to four power measurements simultaneously.



Check the firmware version of the R&S NRP sensors regularly. Update the firmware, if necessary.

For updates, see the Rohde & Schwarz website <http://www.rohde-schwarz.com> in section "Power Meters & Voltmeters".

• Connecting R&S NRP Power Sensors to the R&S SMA100B	214
• NRP Sensor Mapping	215
• NRP Power Viewer	217
• NRP-Z Power Analysis	225

8.4.1 Connecting R&S NRP Power Sensors to the R&S SMA100B

R&S NRP sensors are connected to the R&S SMA100B in the following ways:

- Connection to the Sensor connector
 - R&S NRP-ZK8 (eight-pole interface cable) for R&S NRPxx power sensors
 - R&S NRP-ZK6 (six-pole interface cable) for R&S NRPxx power sensors
 - No additional cable for R&S NRP-Zxx power sensors (cable is fixed on the sensor)
- Connection to the USB connector

Requires the following cables, depending on the used sensor type:

 - R&S NRP-ZKU (USB interface cable) for R&S NRPxx power sensors
 - R&S NRP-Z3 or R&S NRP-Z4 (USB adapter cables) for sensors of the R&S NRP-Zxx family

- Connection via R&S NRP-Z5 sensor hub
The R&S NRP-Z5 USB sensor hub (high-speed USB 2.0) can host up to 4 R&S NRP sensors. It provides simultaneous internal and external triggering of all connected sensors.
Requires additional cables, depending on the used output connector of the hub. Choose one of the following:
 - Short extension cable R&S NRP-Z2 for connection to the sensor connector. This six-pole connection provides the external trigger capability.
 - Standard USB cable (USB type A to USB type B) to any USB type A connector of the R&S SMA100B. This connection does not support external triggering.
- Connection via USB hub with external power supply unit
Requires the following cables, depending on the used sensor type:
 - R&S NRP-ZKU (USB interface cable) for R&S NRPxx power sensors
 - R&S NRP-Z3 or R&S NRP-Z4 (USB adapter cables) for sensors of the R&S NRP-Zxx family
- Connection via LAN for R&S NRPxxxSN/xxxTN/xxxAN power sensors
Using the Ethernet interface requires PoE (Power over Ethernet) to provide the electrical power.
To establish the connection, you can use:
 - A PoE Ethernet switch, e.g. R&S NRP-ZAP1 and an RJ-45 Ethernet cable.
 - A PoE injector and an RJ-45 Ethernet cable.

For details, see the description R&S®NRP®Series Power Sensors Getting Started.

Detection and mapping

The R&S SMA100B automatically detects a connected R&S NRP power sensor and indicates it in the "NRP Power Viewer" and "NRP Sensor Mapping" dialogs.

By default, detected sensors are indicated as follows:

- A sensor connected at the Sensor socket is assigned as "Sensor 1".
If no sensor is connected to this socket, channel 1 remains unassigned.
- Sensors 2 to 4 are assigned to the sensors at the USB connectors, according to their sequence of connection.

You can change the default mapping in the [NRP Sensor Mapping](#) dialog.



On connection, the R&S SMA100B immediately starts the measurement of a detected R&S NRP power sensor. If you perform an instrument preset ([Preset] key or *RST), the R&S SMA100B stops the measurements. The connection and the mapping of the power sensors remain, the measurements must be restarted.

8.4.2 NRP Sensor Mapping


The "NRP Sensor Mapping" lists all R&S NRP sensors detected by the instrument.

Any R&S NRP sensor that supports the USB legacy protocol and is connected to one of the USB interfaces, is detected automatically and added to the list. Vice versa, the R&S SMA100B removes a sensor from the list, when it is disconnected.

R&S NRP sensors that are connected via LAN or use the USBTMC protocol are not automatically detected. They are detected by the scan search function.

Access:

- ▶ Select "Clk Syn/Power Sens" > "NRP Sensor Mapping".

	Sensor Name	Protocol	Connector	Mapping
1	NRP18S-100654	Legacy		1
2				
3				
4				
5				

Scan

The dialog lists all detected R&S NRP sensors for selection and mapping. You can also browse the network for sensors.

The detected sensors are characterized by the used protocol and the corresponding connector icon. In the "Mapping" column, you can assign the sensor to one of the available sensor channels. The list can contain several entries but the R&S SMA100B can only use up to four sensors simultaneously.

The remote commands required to define these settings are described in [Chapter 14.15, "SENSe, READ, INITiate and SLISt Subsystems"](#), on page 503.

Settings

[Sensor Mapping List](#) 216

[Scan](#) 217

Sensor Mapping List

Displays a list of all sensor entries with information on the sensor name, the used protocol, the connector and the assigned mapping.

If a sensor is connected via LAN or uses the USBTMC protocol, its protocol is indicated as "Visa".

Remote command:

:SLIST[:LIST]? on page 506

:SLIST:ELEMent<ch>:MAPPING on page 506

:SLIST:SENSOR:MAP on page 507

Scan

Scans the network and the USB connections for sensors connected via the VISA communication protocol, i.e. sensors that are addressed via LAN or USBTMC.

Sensors communicating via the USB legacy protocol are detected automatically.

Remote command:

:SLIST:SCAN[:STATe] on page 506

8.4.3 NRP Power Viewer

The R&S SMA100B features the power viewer function for measuring or monitoring signals with R&S NRP power sensors.

8.4.3.1 About

The R&S SMA100B can perform up to four power measurements simultaneously.

Depending on the signal characteristic (CW, AM, pulsed, etc.) or the parameter to be measured (average, peak, etc...) a suitable R&S power sensor must be used.

About the measuring principle, averaging filter, filter length, and achieving stable results

A sensor measures the average or peak RF power of the source continuously. The measurement results are displayed in the "NRP Power Viewer" dialog.

The power viewer function uses **averaging filters** for getting a stable readout.

Measurement results could be interfered for instance by too much noise in your setup, by a bad suppression of harmonics or non harmonics or when you reach the sensitivity level of your power sensor.

Measurements are continuously repeated in a predefined time window. The measurement result is obtained by averaging the measured values for the last 2N time windows. This approach is referred to as a **two-step averaging process**.

The factor of 2 in the formula arises because the output signals from the microwave detector are chopped at the same rate as the time windows to suppress low-frequency noise. An independent measured value can only be obtained from two consecutive values.

The variable N in the formula indicates the **filter length**. The filter length then directly influences the measurement time. The filter length can be selected automatically or it can be manually set to a fixed value.

Depending on the R&S NRP power sensor type, the manual setting of the filter length varies in resolution:

- Resolution = 1 for the R&S NRPxx power sensor family
- Resolution = 2^n for R&S NRP-Zxx power sensors, with $n = 1$ to 16

Follow the following general recommendation to find out the **optimum filter length**:

- Always start a measurement in auto mode ("Filter > Auto").
Check if the measurement results are sufficient.
- If the power is not constant, select the filter length manually ("Filter > User").
Trigger the "Auto Once" function to search for the optimum filter length for the current measurement conditions.
The estimated value is indicated as filter length.
- If the target measurement accuracy value is known, select "Filter > Fixed Noise".
The averaging factor is selected automatically and so that the sensor's intrinsic noise (two standard deviations) does not exceed the specified noise content.
- Different sensor types achieve the same filtering result with different filter and time window lengths.

The time window length depends on the sensor type:

- For most sensors, it is fixed to 20 ms.
- For the R&S NRP-Z81 sensor, it is 10 μ s.
The R&S NRP-Z81 uses filter length that is 1000 times larger than the filter length for other sensors.

About zeroing

Activates the auto zero function.

Zeroing calibrates the external power sensor by adjusting its reading at zero signal power. For this purpose, the RF power source must be switched off or disconnected from the sensor. If a Rohde & Schwarz power sensor receives an input power during the zeroing process, it aborts zeroing and generates an error message. Zeroing takes a few seconds, depending on the sensor model. Refer to the documentation of your power sensor for more information.

Tips for zeroing

When to perform zeroing:

- During warm up after switching on or connecting the instrument
- After a substantial change of the ambient temperature
- After fastening the power sensor module to an RF connector at high temperature
- After several hours of operation
- When low-power signals are to be measured, e.g. less than 10 dB above the lower measurement limit.
- Switch off the RF power source for zeroing, but do not disconnect it from the power sensor. This proceeding keeps the thermal equilibrium, and the zeroing process also compensates the noise that superimposes the measured signal (e.g. from a broadband amplifier).

Related settings and functions

- Measurements-related settings, like results, filter, filter length:
[Chapter 8.4.3.2, "NRP Power Viewer Settings"](#), on page 219
- Software version of the connected power sensor:
`:SENSe<ch>[:POWER]:TYPE?` on page 515
- Acquisition of level correction data:
[Chapter 8.3, "User Correction"](#), on page 202

Additional information


See Rohde & Schwarz website <http://www.rohde-schwarz.com> in section "Power Meters & Voltmeters" for:

- R&S NRP power sensor manual.
- Information on the R&S NRP-Z5 sensor hub and the available accessories.
- Sensor software updates.


8.4.3.2 NRP Power Viewer Settings

Access:

- ▶ Select "Clk Syn/Power Sens" > "NRP Power Viewer".



The "Overview" tab shows the list of detected sensors, and provides a separate tab per sensor.



A sensor tab contains all parameters for configuring the sensor settings, like average or peak display, reference source, filter and level offset.

The remote commands required to define these settings are described in [Chapter 14.15, "SENSe, READ, INITiate and SLISt Subsystems"](#), on page 503, including the triggering of the measurement and the retrieval of measurement results.

See also [Chapter 8.5, "How to Calibrate the Power Level with an R&S NRP Power Sensor"](#), on page 269.

Settings

Sensor type and serial number.....	221
Level (Peak) / Level (Average)	221
Sensor Mapping.....	221
Sensor settings.....	221
L State	221
L Zero	221
L Display.....	221
L Permanent	221
L Display	222
L Use Frequency Of.....	222
L Frequency	222
L Level Offset State,Level Offset.....	222
L Filter.....	222
L Filter Length.....	223
L Noise/Signal Ratio.....	223
L Auto Once.....	223
L Timeout.....	223
L Default Aperture Time.....	224

L Aperture Time.....	224
L S-Parameter	224
L Enable Logging.....	224

Sensor type and serial number

Indicates the type and the serial number of a selected R&S NRP power sensor, and the channel the sensor is assigned to.

The displayed [Level \(Peak\)](#) / [Level \(Average\)](#) values correspond to the particular sensor.

Remote command:

`:SENSe<ch>[:POWer]:TYPE?` on page 515

`:SENSe<ch>[:POWer]:SNUMber?` on page 514

Level (Peak) / Level (Average)

Indicates the measured peak or average level value.

You can also change the unit for the results display: Watt, dBm or dBμV.

Note: Peak level measurements are provided if the power sensor supports this feature.

Remote command:

`:READ<ch>[:POWer]?` on page 507

`:SENSe<ch>:UNIT[:POWer]` on page 508

Sensor Mapping

Accesses the [NRP Sensor Mapping](#) dialog.

Sensor settings

One tab per sensor provides the corresponding settings.

State ← Sensor settings

Activates level measurement.

Remote command:

`:INITiate<hw>[:POWer]:CONTinuous` on page 460

To query the availability of a sensor at a given connector, use the command :

`SENSe<ch>[:POWer]:STATus[:DEvice]?` on page 515.

Zero ← Sensor settings

Activates the auto zeroing.

For details, see "[About zeroing](#)" on page 218.

Remote command:

`:SENSe<ch>[:POWer]:ZERO` on page 516

Display ← Sensor settings

Sets the display mode for power readings.

Permanent ← Display ← Sensor settings

Activates the permanent indication of the power measurement result on the left side of the home screen.

You can activate the permanent display for several sensors.

Remote command:

`:SENSe<ch>[:POWer]:DISPlay:PERManent:STATe` on page 510

Display ← Display ← Sensor settings

Sets the display of results on mean or peak power.

Remote command:

`:SENSe<ch>[:POWer]:DISPlay:PERManent:PRIority` on page 510

Use Frequency Of ← Sensor settings

Selects the source for measurement.

- | | |
|--------|---|
| "RF" | The R&S SMA100B transfers the RF frequency and level settings to the R&S power sensor automatically. Thus you achieve power readings of high accuracy, irrespective from the connected sensor type. |
| "User" | Sets a user defined frequency. |

Example:

If you have a frequency converting device between the generator and the DUT. If the frequency converter doubles the frequency, you can set twice the frequency in the R&S SMA100B. The R&S power sensor considers this RF frequency setting.

Set the parameter [Frequency](#) to the measurement's frequency.

Remote command:

`:SENSe<ch>[:POWer]:SOURce` on page 514

Frequency ← Sensor settings

Defines the frequency value if "Source > User" is used.

Remote command:

`:SENSe<ch>[:POWer]:FREQuency` on page 513

Level Offset State,Level Offset ← Sensor settings

Activates and defines a level offset which is considered in the power measurement result. The level offset value is always expressed in dB, irrespective of the display of the measurement result.

This function allows you to consider, for example, an attenuator in the signal path.

Remote command:

`:SENSe<ch>[:POWer]:OFFSet` on page 514

`:SENSe<ch>[:POWer]:OFFSet:STATe` on page 514

Filter ← Sensor settings

Selects the way the length of the used filter is defined.

See also "[About the measuring principle, averaging filter, filter length, and achieving stable results](#)" on page 217.

"Auto"	<p>Selects the filter length automatically and adjusts it to the measured value. The value is indicated with the parameter Filter Length.</p> <p>When high output power is applied, the filter length and therefore the measurement time can be short.</p> <p>When low output power is applied, the filter length and therefore the measurement time is increased which reduces the considered noise content in your measurement.</p>
"User"	<p>The filter length is defined manually, with the parameter Filter Length.</p> <p>As the filter length works as a multiplier for the time window, constant filter length results in a constant measurement time.</p> <p>Values 1 and 2N are allowed.</p>
"Fixed Noise"	<p>The averaging factor is taken automatically in accordance to the value Noise/Signal Ratio. Thus, the sensor's intrinsic noise (2 standard deviations) does not exceed the specified noise content.</p> <p>To avoid long measurement times when the power is too low, set a Timeout.</p> <p>Timeout is the maximum acceptable measurement time which limits the averaging factor and therefore leads to a more unstable readout.</p>

Remote command:

`:SENSe<ch>[:POWER]:FILTer:TYPE` on page 512

Filter Length ← **Sensor settings**

Sets or indicates the filter length, depending on the selected filter mode.

- "Filter > Auto" indicates the automatically adjusted filter length.
- "Filter > User" enables you to set the filter length manually.
- "Filter > Fixed Noise" hides the setting parameter.

Remote command:

`:SENSe<ch>[:POWER]:FILTer:LENGth:AUTO?` on page 510

`:SENSe<ch>[:POWER]:FILTer:LENGth[:USER]` on page 511

Noise/Signal Ratio ← **Sensor settings**

For [Filter > Fixed Noise](#), sets the noise content.

Remote command:

`:SENSe<ch>[:POWER]:FILTer:NSRatio` on page 511

Auto Once ← **Sensor settings**

Searches the optimum filter length for the current measurement conditions. The result is indicated with the parameter [Filter Length](#).

See also ["About the measuring principle, averaging filter, filter length, and achieving stable results"](#) on page 217.

Remote command:

`:SENSe<ch>[:POWER]:FILTer:SONCe` on page 512

Timeout ← **Sensor settings**

For "Filter > Fixed Noise", sets a time limit for the averaging process.

Remote command:

`:SENSe<ch>[:POWER]:FILTer:NSRatio:MTIME` on page 512

Default Aperture Time ← Sensor settings

The sensor default setting is sufficient. Disable this parameter to specify a user-defined aperture time per sensor, if, for example, the readings vary.

To obtain stable readings, set the [Aperture Time](#) exactly to one modulation period.

Remote command:

```
:SENSe<ch>[:POWer]:APERture:DEFault:STATe on page 508
```

Aperture Time ← Sensor settings

If "Use Default Aperture Time > Off", defines the acquisition time per sensor.

For example, to obtain a sufficient low average value, set the aperture time exactly to one modulation period.

Remote command:

```
:SENSe<ch>[:POWer]:APERture:TIME on page 509
```

S-Parameter ← Sensor settings

Lists the S-Parameter correction data files retrieved for the connected power sensor. To activate the correction data, select the corresponding file.

S-Parameter correction is used to mathematically shift the reference plane to the DUT by considering the S-parameters for any components connected upstream of the sensor.

The S-Parameter table can be changed with the S-Parameters tool, provided as part of the free R&S NRP Toolkit software. For more information, refer to the manual of the connected R&S NRP power sensor.

Remote command:

```
:SENSe<ch>[:POWer]:CORRection:SPDevice:STATe on page 509
```

```
:SENSe<ch>[:POWer]:CORRection:SPDevice:LIST? on page 510
```

```
:SENSe<ch>[:POWer]:CORRection:SPDevice:SELeCt on page 509
```

Enable Logging ← Sensor settings

Activates recording of R&S NRP power sensor readings in a log file.

There is 1 log file per sensor. The log files are created automatically and filled in continuously. They are text files with predefined filename `SensLog<n>.txt`, where `<n>` indicates the connected sensor. Log files are stored on the internal memory, in the directory `/var/user/SensorLogging`.

Each log file contains the measured value (2 readings when you work with peak sensors), the sensor type, and the measurement time (timestamp). Logged data is not overwritten. When a new measurement is started, the collected logging data is appended in the log file.

Check the used disc space regularly and remove log files to maintain storage capacity.

Note: The logging function is intended for measurements with long time intervals. It is suitable source for data reconstructions if the connection to the sensor was interrupted.

Remote command:

```
:SENSe<ch>[:POWer]:LOGGing:STATe on page 513
```

8.4.4 NRP-Z Power Analysis

With a connected R&S NRP-Z8x wideband power sensor, the R&S SMA100B enables the analysis of power measurements of DUTs. You can analyze the measured power under frequency, power and time aspects, while the instrument supports you with marker, graphic and reference value functions.

8.4.4.1 About

Characteristics and features of the NRP-Z power analysis function

The NRP-Z power analysis displays the measurement data graphically. The measurement diagram covers up to four traces you can manually or automatically assign to one or more connected power sensors. For evaluation of the readings, you can save a defined reference trace or even freeze a reading temporarily on the screen. Markers and mathematic functions enable you to compare particular values.

The NRP-Z power analysis supports three measurement modes:


- Power versus frequency (frequency response).
For this mode, all required generator settings are automatically configured except for the power level. The power level setting of the generator is used for the frequency sweep measurements.
The frequency sweep settings are transferred to the sensor to automatically calculate the correct measurement value for each frequency point.
- Power versus power (power sweep, AM/AM)
Power sweep measurements are executed using the frequency settings of the generator. Alternatively, the sensor can be adjusted to a frequency different from the generator, see [Use Separate Frequency- Power Analysis](#) .
This frequency is transmitted to the sensor to automatically calculate the correct measurement value.
- Power versus time (power measurement in the time domain R&S NRP-Z8x trace mode).
In the time mode, you can analyze the signal of the generator but also externally supplied signals. This mode requires an additional trigger event, with selectable level, hysteresis and drop time. Provided the sensor used supports the power measurement of pulse signals, you can also analyze pulse data in time domain.

Characteristics of pulse data



For R&S NRP-Z8x power sensors that support time domain analysis and automatic pulse analysis.

The power sensors enable pulse data analysis in measurement mode time. All important pulse parameters are measured after setting the threshold levels. The following graph shows most of these parameters:



The sensor calculates the pulse parameters from each measurement and delivers the results to the R&S SMA100B.

The indication state of the parameters also affects the save function. Storing the measurement diagram as hardcopy includes the parameters selected in this dialog.



A total of 6 parameters can be indicated at one time. Structured hierarchically, trace 1 features top priority and trace 4 is addressed with the lowest weighting. This means that only the first 6 checked parameters are indicated, starting with the settings of trace 1.

The pulse data is only visible for certain zoom levels of the diagram.

8.4.4.2 Accessing the NRP-Z Power Analysis Functionality

Access:

- ▶ Select "Clk Syn/Power Sens" > "NRP-Z Power Analysis".




Figure 8-4: Power analysis window

- 1 = Buttons for accessing the "NRP Power Viewer" settings
- 2 = Power analysis diagram
- 3 = Buttons for accessing the traces/marker dialogs
- 4 = Buttons for accessing the configuration dialogs with measurement and sensor parameters
- 5 = "Start" button to trigger/stop the measurement
- 6 = "Progress bar" indicated during measurement

The start screen of the NRP-Z power analysis contains the measurement diagram and labelled buttons indicating connected power sensors. These buttons and a configuration button provide access to the dialogs for setting up the measurement and sensor parameters, for configuring the diagram and for the trace display. You can start or stop your measurement directly. During the measurement, the R&S SMA100B shows the progress of the measurement in the progress bar at the bottom of the diagram.

Context-sensitive menu

A context sensitive menu also provides access to the configuration dialogs and some additional functions.

Access:

- ▶ Touch and hold a spot in the power analysis diagram for at least 1 second to access the context-sensitive menu.




Figure 8-5: Power analysis context-sensitive menu

In the context-sensitive menu you can access:

- "Start Continuous/Stop": Triggers / stops the power analysis measurement
Note: During a measurement in the frequency domain, or the power domain respectively, the displayed frequency/power value in the status bar (home screen) does not correspond to the value applied at the output. Therefore, the R&S SMA100B displays asterisks instead of the frequency or power value during the measurement and indicates the original value again when the measurement is completed or aborted.
- "Next Window (Hardkey)": Switches between the measurement views that are enabled in the following order:
 - "Standard View"
 - "Marker View"
 - "Pulse Data View"
 - "Full Screen"

At least one viewing mode has to be selected. For details on the different view modes, see ["Next Window List"](#) on page 255.

- "Configure...": opens a dialog for configuring the power analysis measurement. See [Chapter 8.4.4.6, "NRP-Z Configure Settings"](#), on page 234.
- "Trace/Markers...": opens a dialog for configuring the traces/marker. See [Chapter 8.4.4.5, "NRP-Z Traces/Markers Settings"](#), on page 230.
- "Save...(Power Analysis)": opens a dialog to save a hardcopy of the measurement. See [Chapter 8.4.4.7, "Creating Screenshots of Power Analysis Settings"](#), on page 259.

Power Analysis Diagram

Indicates the measurement results graphically, including configured markers, functions, etc.

Off / NRP-Zxx

Accesses the dialogs for configuring the traces and markers, see [Chapter 8.4.4.5, "NRP-Z Traces/Markers Settings"](#), on page 230

Configure...

Accesses the dialog for configuring the power analysis measurement, see [Chapter 8.4.4.6, "NRP-Z Configure Settings"](#), on page 234.

Start / Stop measurement

Starts and stops the power analysis measurement. Depending on the selected measurement mode, the label varies.

8.4.4.3 Required Options

The R&S SMA100B base unit equipped with the following options:

- Power Analysis (R&S SMAB-K28)

Requires an external R&S NRP power sensor that supports automatic pulse and time domain analysis, for example a sensor of the R&S NRP-Z8x series.

For more information, see data sheet.

8.4.4.4 Test Setup Example

As a power meter has no built-in selection, it is measuring all signal components from nearly DC to 40 GHz and higher. Therefore, the DUT's signal must be rather pure or subjected to external filtering (harmonics, spurious) before measured.

The test setup for the power analysis in the power versus frequency or power versus power is as follows:



Figure 8-6:

DUT = Device under test

PS = Power sensor, e.g. R&S NRP-Z8x, connected at the DUT's input and the USB connector of the R&S SMA100B


1. Connect the DUT RF input to the RF output of the instrument.
2. Connect the DUT RF output to the power sensor.
3. Connect the power sensor to the signal generator.
4. Select "Clk Syn/Power Sens" > "NRP-Z Power Analysis".
5. Select "Configure..." to open a dialog for setting up the measurement.
6. Select the power sensor, indicated at the bottom of the dialog to set the trace.

7. Select "Start Cont." to trigger the measurement.

8.4.4.5 NRP-Z Traces/Markers Settings

Access:

1. Select "Clk Syn/Power Sens" > "NRP-Z Power Analysis".
2. Select power sensor indication located at the bottom of the dialog.
3. To access the trace settings, select the respective "Trace x" tab.



The measurement data can be current (sensor trace) or stored trace data. You can store data either in a file (reference trace) or in a temporary memory (hold trace). Up to four traces can be indicated at one time. On connection, the sensors are automatically detected and assigned to a trace. By default, connected sensors are assigned to the traces in ascending order, that means sensor 1 to trace 1, sensor 2 to trace 2, etc. If the default trace is already used, the sensor has to be assigned manually in the trace dialog.

Using the reference and hold traces, you can compare traces. Assign a reference curve to one trace and your measured values to a second one, and switch on the display. With this feature you can compare results directly in the graph, or show the deviations in a graph by using the "[Mathematics - Trace Power Analysis](#)" on page 232 function.

Example

The current single measurement of sensor 2 which is assigned to trace 2 is used as reference trace.

1. Select "Trace 2" with "Indication" = "2 - NRP-Z81".
2. Select "Save To Ref".
3. Select "Trace 1" > "Indication > Ref".
4. Select "Diagram".

The R&S SMA100B indicates two identical traces.

5. Select "Start single".

Triggers a new measurement cycle with sensor 2. You can compare the resulting measurement trace with the former measurement, which is displayed as reference trace.

Traces Settings

Indication - Trace Power Analysis

Selects the source for the trace data.

The selection is indicated on the trace button in the measurement diagram.

"Off"	No source is selected, the trace is not indicated.
"2 - NRP-Zxx"	The current measurement results of the selected power sensor are the source for the trace data. The index at the beginning of the sensor name indicates the used connector, for example "2" indicates that the sensor is connected via a USB interface. The data is either continuously updated (continuous measurement) or represents a single measurement cycle (single measurement).
"Ref"	Selects the reference trace. The reference trace is a static trace that was stored in a file and can be recalled. It is possible to store one reference trace at a time.
"Hold"	Freezes the current trace data. The hold trace is a temporary trace that is available until the power analysis is finished. Freezing the trace of a sensor in one trace and displaying the measurement values of the same sensor in another trace allows fast comparison between measurements.

Remote command:

[:TRACe<ch>\[:POWer\]:SWEep:STATe](#) on page 501

[:TRACe<ch>\[:POWer\]:SWEep:COpy](#) on page 495

[:TRACe<ch>\[:POWer\]:SWEep:FEED](#) on page 496

Color - Trace Power Analysis

Selects the color of the trace.

Remote command:

[:TRACe<ch>\[:POWer\]:SWEep:COLor](#) on page 494

Save to Ref - Trace Power Analysis

Saves the selected trace as reference trace. Only one reference trace is available at a time.

Remote command:

[:TRACe<ch>\[:POWer\]:SWEep:COLor](#) on page 494

Define Reference - Trace Power Analysis

Opens a dialog for defining a linear reference curve.

Freq (X) / Pow (Y) ← Define Reference - Trace Power Analysis

For [Configure Measurement Settings](#) > "Frequency", determines the parameters of the frequency reference curve.

Remote command:

`:SENSe[:POWER]:SWEep:FREQuency:REFErence:DATA:XVALues` on page 471

`:SENSe[:POWER]:SWEep:FREQuency:REFErence:DATA:YVALues` on page 472

Pow (X) / Pow (Y) ← Define Reference - Trace Power Analysis

For [Configure Measurement Settings](#) > "Power", sets the x- and y-axis values of the points A and B.

Remote command:

`:SENSe[:POWER]:SWEep:POWEr:REFErence:DATA:XVALues` on page 484

`:SENSe[:POWER]:SWEep:POWEr:REFErence:DATA:YVALues` on page 484

Time (X) / Pow (Y) ← Define Reference - Trace Power Analysis

For [Configure Measurement Settings](#) > "Time", sets the time values for the x-axis and the corresponding y-axis power values.

Remote command:

`:SENSe[:POWER]:SWEep:TIME:REFErence:DATA:XVALues` on page 489

`:SENSe[:POWER]:SWEep:TIME:REFErence:DATA:YVALues` on page 489

Save To Ref ← Define Reference - Trace Power Analysis

Saves the selected trace as reference trace. One reference trace is available at a time.

Remote command:

`:SENSe[:POWER]:SWEep:FREQuency:REFErence:DATA:COPI` on page 471

`:SENSe[:POWER]:SWEep:POWEr:REFErence:DATA:COPI` on page 484

`:SENSe[:POWER]:SWEep:TIME:REFErence:DATA:COPI` on page 489

Mathematics - Trace Power Analysis

Activates the mathematic function.

The function enables you to determine the deviation of two test series, either of measurement traces, or also of traces that contain math results or stored reference curves. That means you can also assign a math result to an operand for further calculation. Various nested computation steps are possible.

The math operation follows the formula:

$$T\langle\text{ch}\rangle_{\text{result}} = T\langle\text{ch}\rangle_{\text{Operand1}} - T\langle\text{ch}\rangle_{\text{Operand2}}$$

How to proceed:

Determine $T\langle\text{ch}\rangle_{\text{Operand1}}$ in the entry field next to "Tx", and then select $T\langle\text{ch}\rangle_{\text{Operand2}}$ in the second entry field right to it.

The result (" $T\langle\text{ch}\rangle_{\text{result}}$ ") is assigned to the above selected "Trace". If switched on, the graph shows the resulting curve.

Note:

Depending on the type of trace, the instrument automatically sets the appropriate unit on the y-axis:

- "dBm" if it shows only measurement traces.

- "dB" for purely mathematical curves.
- "dB/dBm" ratio scale for mixed display, that means measurements and mathematical curves.

Example:

Example of a nested calculation.

- T1 shows the result of the subtraction of the trace ("Trace 1"), and the reference curve.
- Trace2 subtracts Ref from T1.

That illustrates the nested calculation, since T1 covers already a math operation.

Note: "(Ind.)" denotes the currently selected trace.

Remote command:

`:CALCulate[:POWer]:SWEep:FREQuency:MATH<ch>:STATe` on page 455

`:CALCulate[:POWer]:SWEep:FREQuency:MATH<ch>:SUBTRACT` on page 456

`:CALCulate[:POWer]:SWEep:POWer:MATH<ch>:STATe` on page 456

`:CALCulate[:POWer]:SWEep:POWer:MATH<ch>:SUBTRACT` on page 456

`:CALCulate[:POWer]:SWEep:TIME:MATH<ch>:STATe` on page 459

`:CALCulate[:POWer]:SWEep:TIME:MATH<ch>:SUBTRACT` on page 459

Markers Settings

Access:

1. Select "Clk Syn/Power Sens" > "NRP-Z Power Analysis".
2. Select power sensor indication located at the bottom of the dialog.
3. Select the "Markers" tab.

Trace 1	Trace 2	Trace 3	Trace 4	Markers	X
Trace				Marker 1 Visible	<input checked="" type="checkbox"/>
			1		
Trace				Marker 2 Visible	<input checked="" type="checkbox"/>
			2		
Trace				Marker 3 Visible	<input type="checkbox"/>
			1		
Trace				Marker 4 Visible	<input type="checkbox"/>
			1		

This dialog comprises the markers settings display on the respective trace diagram.

Marker x Visible - Power Analysis

Selects if the respective marker and the marker list are shown in the diagram.

Remote command:
n.a.

Trace - Power Analysis

Selects the trace the marker is assigned to.

Remote command:
n.a.

8.4.4.6 NRP-Z Configure Settings

The "Configure" dialog allows you to set measurement and sensor parameters.

• Configure Measurement Settings	234
• Configure Sensors Settings	238
• Configure Diagram	242
• Configure Time Mode Settings	243
• Trace Settings	244
• Pulse Data Notifications Settings	246
• Trigger Settings	251
• Gate Mode Settings	253
• Next Window List	255

Configure Measurement Settings

Access:

1. Select "Clk Syn/Power Sens" > "NRP-Z Power Analysis".
2. Select "Configure" > "Configure Measurement".

Configure Measurement	Configure Sensors	Configure Diagram	Configure Time Mode	Next Window List		X
Mode						Time
Min		-5.000 000 µs		Max		45.000 000 µs
Steps		1 000		Average		1
Spacing		Linear		Execution		Continuous
All Trigger Events		Wired AND				

The measurement section provides the parameters for configuring the measurement either in frequency, power or time domain. Depending on the measurement domain, the settings vary.

Mode - Power Analysis

Selects the measurement mode.

- | | |
|-------------|---|
| "Frequency" | Power versus frequency measurement (frequency response). |
| "Power" | Power versus power measurement (power sweep, AM/AM). |
| "Time" | Power versus time measurement (envelope power measurement as a function of time, NRP trace mode). The R&S SMA100B samples power over a time interval and assigns the internal power values that have been determined to several points.
This mode also provides gated measurement and pulse data analysis, e.g. with a connected R&S NRP-Z81, and the corresponding graphical display "Gate View" and "Pulse Data View". |

Remote command:

`:SENSe[:POWER]:SWEep:MODE` on page 483

Min - Power Analysis

Sets the minimum frequency/power/time of the measurement.

The available frequency/power range depends on the frequency/power range of the generator and the used power sensor.

The range for the start time is -1s to +1s. Value 0 defines the trigger point. By choosing a negative time value, the trace can be shifted in the diagram.

It is possible, that the measurement cannot be performed over the complete time range because of limitations due to sensor settings. In this case, the R&S SMA100B generates an error message.

If you change this value for a finished single measurement, only the scaling of the x-axis changes. This way, you can zoom the trace. However, for subsequent measurements, the measurement range is changed according to the new setting.

If you change this value during a continuous measurement, only the scaling of the x-axis changes for measurement cycles that have been triggered before the change. For subsequent measurement cycles, the measurement range changes according to the new setting.

Remote command:

`:SENSe[:POWer]:SWEep:FREQuency:START` on page 472

`:SENSe[:POWer]:SWEep:POWer:START` on page 485

`:SENSe[:POWer]:SWEep:TIME:START` on page 490

Max - Power Analysis

Sets the maximum frequency/power/time of the measurement.

The available frequency/power range depends on the frequency/power range of the instrument and the used power sensor.

The range for the stop time is 0 s to 2 s. Value 0 defines the trigger point.

It is possible, that the measurement cannot be performed over the complete time range because of limitations due to sensor settings. In this case, an error message is output.

If you change this value for a finished single measurement, only the scaling of the x-axis changes. This way, you can zoom the trace. However, for subsequent measurements the measurement range is changed according to the new setting.

If you change this value during a continuous measurement, only the scaling of the x-axis changes for measurement cycles that have been triggered before the change. For subsequent measurement cycles, the measurement range changes according to the new setting.

Remote command:

`:SENSe[:POWer]:SWEep:FREQuency:STOP` on page 473

`:SENSe[:POWer]:SWEep:POWer:START` on page 485

`:SENSe[:POWer]:SWEep:TIME:STOP` on page 491

Steps - Power Analysis

Sets the number of steps for the sweep. The number of measured points is steps + 1.

The number of steps is one of the parameters that define the measurement speed. The higher the number of steps, the longer the measurement takes (frequency and power mode).

Remote command:

`:SENSe[:POWer]:SWEep:FREQuency:STEPS` on page 473

`:SENSe[:POWer]:SWEep:POWer:STEPS` on page 485

`:SENSe[:POWer]:SWEep:TIME:STEPS` on page 490

Timing - Power Analysis

Selects the timing mode in frequency or power domain.

This parameter is only available for [Configure Measurement Settings](#) > "Frequency"/"Power".

- "Fast" Fast measurement with an integration time of 2 ms for each measurement step.
- "Normal" A longer but more precise measurement (integration time is 20 ms/step).

Remote command:

[:SENSe\[:POWER\]:SWEep:FREQuency:TIMing\[:MODE\]](#) on page 473

[:SENSe\[:POWER\]:SWEep:POWer:TIMing\[:MODE\]](#) on page 486

Average - Power Analysis

Selects the averaging factor in time domain.

The factor determines how many measurement cycles are used to form a measurement result. Higher averaging counts reduce noise but increase the measurement time. Averaging requires a stable trigger event so that the measurement cycles have the same timing. If factor 1 is selected, no averaging is performed.

This parameter is only available for [Configure Measurement Settings](#) > "Time".

Remote command:

[:SENSe\[:POWER\]:SWEep:TIME:AVERAge\[:COUNT\]](#) on page 488

Spacing - Power Analysis

Sets the mode for calculating the sweep steps.

In power versus frequency mode, selection between linear and logarithmic spacing is possible.

- "Linear"
- Power versus frequency
In a linear sweep, the frequency is swept in equidistant steps over the continuous frequency range. The x-axis is a linear frequency axis.
 - Power versus power
The sweeps are performed at constant frequency but with variable generator power that is swept in linear, equidistant steps over a continuous range. The x-axis is a dB-linear power axis.
 - Power versus time
The sweeps are performed at constant frequency and stimulus power. The measurement is repeated over a specified period of time at constant time intervals.
- "Logarithmic" Power versus frequency
In a logarithmic sweep, the frequency is swept in equidistant steps on a logarithmic scale. The x-axis is a logarithmic frequency axis.

Remote command:

[:SENSe\[:POWER\]:SWEep:FREQuency:SPACing\[:MODE\]](#) on page 472

[:SENSe\[:POWER\]:SWEep:POWer:SPACing\[:MODE\]](#) on page 485

[:SENSe\[:POWER\]:SWEep:TIME:SPACing\[:MODE\]](#) on page 490

Execution - Power Analysis

Selects single or continuous mode in power analysis.

The measurement is started in the diagram using the "Start" button. During measurement, the "Start" button is replaced by a "Stop" button which can be used to abort the measurement. The progress bar indicates the status of the measurement.

"Single" Selects single measurement.

"Cont." Selects continuous measurements.

Remote command:

[:SENSe\[:POWer\]:SWEep:RMODe](#) on page 488

[:SENSe\[:POWer\]:SWEep:POWer:RMODe](#) on page 485

[:SENSe\[:POWer\]:SWEep:FREQuency:RMODe](#) on page 472

[:SENSe\[:POWer\]:SWEep:TIME:RMODe](#) on page 490

All Trigger Events - Power Analysis

Selects the trigger mode for measurements in the time domain.

The measurement data processing starts with a trigger event in one of the sensors (Logical OR), or when all channels are triggered (logical AND). Each sensor evaluates a trigger event according to its setting independently.

This function supports the internal or external trigger modes with multi-channel time measurements.

"Wired AND" The measurement starts when all channels are triggered.

"Wired OR" The measurement starts when a trigger event occurs.

Remote command:

[:SENSe\[:POWer\]:SWEep:TIME:TEVents](#) on page 491

Configure Sensors Settings

Access:

1. Select "Clk Syn/Power Sens" > "NRP-Z Power Analysis".
2. Select "Configure" > "Configure Sensors"

Configure Measurement	Configure Sensors	Configure Diagram	Configure Time Mode	Next Window List		X
	2 - NRP-Z81		Zero			
Level Offset	On				3.00 dB	
S-Parameter	Unused					
Separate Frequency						
Use Separate Frequ.	<input checked="" type="checkbox"/>					
	1.000 000 MHz					

The "Configure Sensors" dialog provides specific parameters for the power sensor. This part of the dialog can differ from the following description depending on the sensor used. Refer to the manual of the power sensor in this case.

Power Sensor - Power Analysis

Selects the power sensor to be set if more than one sensor is connected to the instrument.

Remote command:

n.a.

In remote control, the sensor is selected via the numeric suffix in the sense key word of the command, for example `SENSe2:POWer:SWEp:....`

Zero - Power Analysis

Activates the auto zero function.

Zeroing calibrates the external power sensor by adjusting its reading at zero signal power. For this purpose, the RF power source must be switched off or disconnected from the sensor. If a Rohde & Schwarz power sensor receives an input power during the zeroing process, it aborts zeroing and generates an error message. Zeroing takes a few seconds, depending on the sensor model. Refer to the documentation of your power sensor for more information.

Tips for zeroing

When to perform zeroing:

- During warm up after switching on or connecting the instrument
- After a substantial change of the ambient temperature
- After fastening the power sensor module to an RF connector at high temperature
- After several hours of operation
- When low-power signals are to be measured, e.g. less than 10 dB above the lower measurement limit.

- Switch off the RF power source for zeroing, but do not disconnect it from the power sensor. This proceeding keeps the thermal equilibrium, and the zeroing process also compensates the noise that superimposes the measured signal (e.g. from a broadband amplifier).

Pulse Data

Accesses the dialog for configuring the settings for pulse data analysis.

See "[Trace Settings](#)" on page 244.

Trigger..

Accesses the dialog for configuring the trigger settings.

See "[Trigger Settings](#)" on page 251

Level Offset State- Power Analysis

Activates a level offset at the sensor input. Set the offset value in the entry field on the right.

Remote command:

`:SENSe<ch>[:POWER]:SWEep:FREQuency[:SENSor]:OFFSet:STATe`

on page 463

`:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:OFFSet:STATe` on page 466

`:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:OFFSet:STATe` on page 466

Level Offset - Power Analysis

Sets the level offset at the sensor input. To consider the value, activate the offset.

Remote command:

`:SENSe<ch>[:POWER]:SWEep:FREQuency[:SENSor]:OFFSet` on page 462

`:SENSe<ch>[:POWER]:SWEep:POWer[:SENSor]:OFFSet` on page 464

`:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:OFFSet` on page 466

Use S-Parameter - Power Analysis

Activates the use of the S-parameters correction data of the connected power sensor. For sensors with attenuator, this checkbox is automatically checked.

Refer also to the manual of the connected R&S power sensor for a description on how to use the S-parameters table.

Use Separate Frequency- Power Analysis

This setting is offered for measurements with DUTs that change the measurement frequency (like modulators), thus changing the input frequency of the sensor.

The parameters vary depending on the measurement modes:

- Power versus frequency measurement
Activates the use of a different frequency range other than the set signal generator frequency range for the measurement. The separate minimum and maximum frequency values are set below.
The x-scale of the diagram can be adjusted to the separate frequency range with functions "Use as X Scale" and "Map to X Scale".
- Power versus power measurement / Power versus time measurement

Activates the use of a different frequency other than the set signal generator frequency for the measurement. The separate frequency value is set in the entry window below.

Remote command:

`:SENSe<ch>[:POWER]:SWEep:FREQuency[:SENSor]:SRANge[:STATe]`

on page 464

`:SENSe<ch>[:POWER]:SWEep:POWer[:SENSor]:SFRequency:STATe`

on page 465

`:SENSe<ch>[:POWER]:SWEep:POWer[:SENSor]:SFRequency` on page 465

`:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:SFRequency:STATe`

on page 468

`:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:SFRequency` on page 468

Min Frequency - Power Analysis

This parameter is only available for [Configure Measurement Settings](#) > "Frequency" and [Use Separate Frequency- Power Analysis](#) > "Active".

Sets the minimum frequency of the measurement.

Remote command:

`:SENSe<ch>[:POWER]:SWEep:FREQuency[:SENSor]:SRANge:START`

on page 463

Max Frequency - Power Analysis

This parameter is only available for [Configure Measurement Settings](#) > "Frequency" and [Use Separate Frequency- Power Analysis](#) > "Active".

Sets the maximum frequency of the measurement.

Remote command:

`:SENSe<ch>[:POWER]:SWEep:FREQuency[:SENSor]:SRANge:STOP`

on page 463

Use as X Scale - Power Analysis

This parameter is only available for [Configure Measurement Settings](#) > "Frequency" and [Use Separate Frequency- Power Analysis](#) > "Active".

Activates the use of the separate frequency min and max values for the scaling of the x-axis. Thus, the trace for this sensor is visible in the diagram, especially for frequency ranges that differ substantially from the generator settings.

If more than one sensor is active, which use separate frequencies, the option is only available for one sensor. To indicate the traces of the other sensors, use function "Map to X Scale".

Remote command:

n.a.

Map to X Scale - Power Analysis

This parameter is only available for [Configure Measurement Settings](#) > "Frequency" and [Use Separate Frequency- Power Analysis](#) > "Active".

Maps the trace of a sensor that uses separate frequency to the current scaling of the diagram. Usually the scale is determined by the set frequency range of the generator. If more than one sensor is active, which use separate frequencies, the scale can also be determined by the separate frequency range of one of the other sensors.

Remote command:
n.a.

Configure Diagram

Access:

1. Select "Clk Syn/Power Sens" > "NRP-Z Power Analysis".
2. Select "Configure" > "Configure Diagram"

Configure Measurement	Configure Sensors	Configure Diagram	Configure Time Mode	Next Window List		✕
Min Level		-40.00 dBm	Max Level		30.00 dBm	
Auto Scale		Expand Only (Coarse)	Reset Auto Scale			
Show Grid		<input checked="" type="checkbox"/>				
Background Color		Black				

The "Configure Diagram" covers the parameters for scaling the y-axis and the appearance of the diagram.

Min - Max Level - Power Analysis

Selects the minimum and maximum value of the y-axis.

Remote command:

[:SENSe\[:POWER\]:SWEep:FREQuency:YSCale:MAXimum](#) on page 474
[:SENSe\[:POWER\]:SWEep:FREQuency:YSCale:MINimum](#) on page 475
[:SENSe\[:POWER\]:SWEep:POWer:YSCale:MAXimum](#) on page 487
[:SENSe\[:POWER\]:SWEep:POWer:YSCale:MINimum](#) on page 488
[:SENSe\[:POWER\]:SWEep:TIME:YSCale:MAXimum](#) on page 492
[:SENSe\[:POWER\]:SWEep:TIME:YSCale:MINimum](#) on page 493

Auto Scale - Power Analysis

Activates autoscaling of the y-axis of the diagram. The "Auto Scale" function adjusts the scale divisions so that the entire trace fits into the diagram area.

"Off" Auto scale is deactivated. Switching from activated to deactivated, the scaling is maintained.

"Expand Only (Coarse/Fine)"

Auto scale is activated. Automatically selects the appropriate scaling of the y-axis so that the trace is always visible. The range is expanded when a value is out of the right or the left end-of-scale value. The step width is 5 dB for selection "Exp. (Coarse)" and variable in the range of 0.2 db to 5 dB for selection "Exp. (Fine)".

"Float (Coarse/Fine)"

Auto scale is activated, that means this parameter automatically selects the appropriate scaling of the y-axis so that the trace is always visible. The range is either expanded, when a value is out of the right/left end-of-scale value or it is reduced when the trace fits into a smaller scale area. The step width is 5 dB for selection "Fit. (Coarse)" and variable in the range of 0.2 db to 5 dB for selection "Fit. (Fine)".

Remote command:

`:SENSe[:POWER]:SWEep:FREQuency:YSCale:AUTO` on page 474

`:SENSe[:POWER]:SWEep:POWer:YSCale:AUTO` on page 486

`:SENSe[:POWER]:SWEep:TIME:YSCale:AUTO` on page 491

Reset Auto Scale - Power Analysis

Resets the scaling of the y-axis to suitable values after the use of auto scaling in the expanding mode. For this mode, the Y scale can get too expanded because of temporary high-power values. The reset function resets the diagram again, to indicate smaller power values.

Remote command:

`:SENSe[:POWER]:SWEep:FREQuency:YSCale:AUTO:RESet` on page 474

`:SENSe[:POWER]:SWEep:POWer:YSCale:AUTO:RESet` on page 487

`:SENSe[:POWER]:SWEep:TIME:YSCale:AUTO:RESet` on page 492

Show Grid - Power Analysis

Activates the indication of a grid in the diagram area.

Remote command:

`:DISPlay[:WINDow][:POWER]:SWEep:GRID:STATe` on page 460

Background Color - Power Analysis

Sets the background color of the diagram to black or white. The background color is also effective for the hardcopy of the diagram.

Remote command:

`:DISPlay[:WINDow][:POWER]:SWEep:BACKground:COLor` on page 459


Configure Time Mode Settings

The time measurement mode enables you to analyze internally generated or externally supplied signals. In time mode, the measurement requires an additional trigger event, with selectable level, hysteresis and drop time. In time domain, you can also analyze measured pulse data.

Trace Settings

Access:

1. Select "Clk Syn/Power Sens" > "NRP-Z Power Analysis".
2. Select "Configure" > "Configure Measurement".
3. Set "Mode" > "Time".
4. Select "Configure Time Mode"
5. Select the "Trace" tab.



The "Trace" tab contains the parameters for the evaluation of important pulse parameters, provided the used power sensor supports automatic pulse analysis.

Trace

Selects the trace the sensor is assigned to.

To assign a sensor to a trace, use the trace buttons, see [Off / NRP-Zxx](#).

Indication

Indicates the type of power sensor assigned to the selected trace. This field is automatically updated if the sensor is connected or disconnected. Also, this sensor is indicated on the trace button in the measurement diagram.

This parameter is only available for [Configure Measurement Settings](#) > "Time".

Remote command:

n.a.

Pulse Analysis

Activates pulse data analysis.

To start the automatic pulse analysis, select "Start Cont." button in the main measurement diagram.

Remote command:

`:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:PULSe:STATe` on page 466

All Annotations Off

Indicates the state of the annotations.

Remote command:

n.a.

Base

Selects the calculation basis for the threshold parameters.

"Voltage related"

Calculates the pulse parameters rise/fall time and pulse width by the voltage over time $U(t)$.

Voltage-related parameters represent the usual case.

"Power related"

Represents the pulse parameters as power values.

To obtain equivalent power-dependent values, the voltage-dependent threshold values are converted (squared), (see example in table below).

	Distal	Mesial	Proximal
Voltage related:	90%	50%	10%
Power related:	81%	25%	1 %
log. Scale (for example): (approximately, difference between top- base power > 30 dB)	-0.9dB	-6dB	-20dB

Remote command:

`:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:PULSe:THReshold:BASE`
on page 467

`:TRACe<ch>[:POWER]:SWEep:PULSe:THReshold:BASE?` on page 499

Distal

Sets the upper reference level in terms of percentage of the overall pulse level (power or voltage related). The distal power defines the end of the rising edge and the start of the falling edge of the pulse.

Remote command:

`:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:PULSe:THReshold:POWER:HREFerence`
on page 467

`:TRACe<ch>[:POWER]:SWEep:PULSe:THReshold:POWER:HREFerence`
on page 500

Mesial

Sets the medial reference level in terms of percentage of the overall pulse level (power or voltage related). This level is used to define the pulse width (τ) and pulse period.

Remote command:

```
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:THReshold:POWer:
REFerence on page 468
:TRACe<ch>[:POWer]:SWEep:PULSe:THReshold:POWer:REFerence
on page 500
```

Proximal

Sets the lower reference level in terms of percentage of the overall pulse level (power or voltage related).

The proximal power defines the start of the rising edge and the end of the falling edge of the pulse.

Remote command:

```
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:THReshold:POWer:
LREFerence on page 467
:TRACe<ch>[:POWer]:SWEep:PULSe:THReshold:POWer:LREFerence
on page 500
```

Pulse Data Notifications Settings

Access:

1. Select "Clk Syn/Power Sens" > "NRP-Z Power Analysis".
2. Select "Configure" > "Configure Measurement".
3. Set "Mode" > "Time".
4. Select "Configure Time Mode"


5. Select the "Pulse Data notifications" tab.

Configure Measurement	Configure Sensors	Configure Diagram	Configure Time Mode	Next Window List	
Duty Cycle	<input type="checkbox"/>		Rise Time	<input checked="" type="checkbox"/>	Trace
Pulse Width	<input checked="" type="checkbox"/>		Pulse Start Time	<input type="checkbox"/>	Pulse Data Notifications
Pulse Period	<input checked="" type="checkbox"/>		Overshoot (Rising Edge)	<input type="checkbox"/>	Trigger
Pulse Off Time	<input checked="" type="checkbox"/>		Fall Time	<input checked="" type="checkbox"/>	Gate Mode
			Pulse Stop Time	<input type="checkbox"/>	
			Overshoot (Falling Edge)	<input type="checkbox"/>	
Signal Power		Pulse Power			
Peak Power	<input checked="" type="checkbox"/>		Top Power	<input type="checkbox"/>	
Average Power	<input type="checkbox"/>		Base Power	<input checked="" type="checkbox"/>	
Minimal Power	<input type="checkbox"/>		Distal Power	<input checked="" type="checkbox"/>	
			Mesial Power	<input checked="" type="checkbox"/>	
			Proximal Power	<input type="checkbox"/>	

In the "Pulse Data Notification" tab, you can determine the parameter values to be indicated on bottom of the diagram.

Notifications - Pulse Data Analysis

Selects the pulse parameters to be indicated below the measurement diagram.



Duty Cycle ← Notifications - Pulse Data Analysis

Indicates the ratio between the pulse duration (τ) and the pulse period (T) of the measured pulse signal in per cent:

$$\text{Duty Cycle} = (\text{pulse duration} / \text{pulse period}) * 100$$

Remote command:

`:TRACe<ch>[:POWER]:SWEep:MEASurement:PULSe:DCYClE?` on page 497

`:TRACe<ch>[:POWER]:SWEep:MEASurement:PULSe:DCYClE:DISPlay:`

`ANNOtation[:STATe]` on page 498

Pulse Width ← Notifications - Pulse Data Analysis

Indicates the pulse duration of the pulse data measurement in seconds.

Remote command:

`:TRACe<ch>[:POWER]:SWEep:MEASurement:PULSe:DURation?` on page 497

`:TRACe<ch>[:POWER]:SWEep:MEASurement:PULSe:DURation:DISPlay:`

`ANNOtation[:STATe]` on page 498

Pulse Period ← Notifications - Pulse Data Analysis

Indicates the time the pulse signal needs to complete one cycle.

Remote command:

`:TRACe<ch>[:POWER]:SWEep:MEASurement:PULSe:PERiod?` on page 497

`:TRACe<ch>[:POWER]:SWEep:MEASurement:PULSe:PERiod:DISPlay:`

`ANNOtation[:STATe]` on page 498

Pulse Off Time ← Notifications - Pulse Data Analysis

Determines the time the pulse signal is low, that means as long as the signal level is below the proximal value.

Remote command:

`:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:SEPARation?` on page 497
`:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:PERiod:DISPlay:ANNotation[:STATe]` on page 498

Transition Times - Pulse Data Analysis

Selects the transition parameters of the pulse signal to be indicated below the measurement diagram.

The R&S NRP-Z sensor searches for the first rising edge and the first falling edge in the trace.

Rise Time / Fall Time ← Transition Times - Pulse Data Analysis

Displays the time the signal requires from crossing low reference until it reaches high reference level and vice versa.

Remote command:

`:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:DURation?` on page 497
`:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:DURation:DISPlay:ANNotation[:STATe]` on page 498
`:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:DURation?` on page 497
`:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:DURation:DISPlay:ANNotation[:STATe]` on page 498

Pulse Start Time / Pulse Stop Time ← Transition Times - Pulse Data Analysis

Displays the time when the pulse signal crosses the medial reference level.

Remote command:

`:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:OCCurrence?` on page 497
`:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:OCCurrence:DISPlay:ANNotation[:STATe]` on page 498
`:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:OCCurrence?` on page 497
`:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:OCCurrence:DISPlay:ANNotation[:STATe]` on page 499

Overshoot (Rising Edge / Falling Edge) ← Transition Times - Pulse Data Analysis

Display the maximum value of the pulse signal following a rising transition and the minimum value of the signal after a falling transition, respectively.

Overshoot values are given in per cent of the pulse amplitude as shown below:

- $\text{Overshoot}(\text{pos}) = 100 \cdot (\text{maximum} - \text{top level}) / (\text{top level} - \text{base level})$
- $\text{Overshoot}(\text{neg}) = 100 \cdot (\text{base level} - \text{minimum}) / (\text{top level} - \text{base level})$

Remote command:

`:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:OVERshoot?` on page 497
`:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:OVERshoot:DISPlay:ANNotation[:STATe]` on page 499

`:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:OVERshoot?` on page 497

`:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:OVERshoot:DISPlay:ANNOtation[:STATe]` on page 498

Signal Power - Pulse Data Analysis

Selects the power parameters of the pulse signal to be indicated below the measurement diagram.

Minimal / Peak / Average Power ← Signal Power - Pulse Data Analysis

Display the minimum, the maximum and the average power of the pulse signal in dBm.

Remote command:

`:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:MINimum?` on page 497

`:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:MINimum:DISPlay:ANNOtation[:STATe]` on page 498

`:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:MAXimum?` on page 497

`:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:MAXimum:DISPlay:ANNOtation[:STATe]` on page 498

`:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:AVErage?` on page 497

`:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:AVErage:DISPlay:ANNOtation[:STATe]` on page 498

Pulse Power - Pulse Data Analysis

Selects which pulse power parameters are indicated in the diagram (pulse data view only).

Top / Base Power ← Pulse Power - Pulse Data Analysis

Indicate the pulse top and base level of the analyzed signal in dBm.

Remote command:

`:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:PULSe:BASE?` on page 497

`:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:PULSe:BASE:DISPlay:ANNOtation[:STATe]` on page 498

`:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:PULSe:TOP?` on page 497

`:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:PULSe:TOP:DISPlay:ANNOtation[:STATe]` on page 498

Distal / Mesial / Proximal Power ← Pulse Power - Pulse Data Analysis

Display the absolute power values of the medial, low and high reference level in dBm.

Remote command:

`:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:LREFerence?` on page 497

`:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:LREFerence:DISPlay:ANNOtation[:STATe]` on page 498

`:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:HREFerence?` on page 497


`:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:HREFerence:DISPlay:ANNOtation[:STATe]` on page 498

[:TRACe<ch>\[:POWer\]:SWEep:MEASurement:POWer:REFerence?](#) on page 497
[:TRACe<ch>\[:POWer\]:SWEep:MEASurement:POWer:REFerence:DISPlay:ANNOtation\[:STATe\]](#) on page 498

Trigger Settings

Access:

1. Select "Clk Syn/Power Sens" > "NRP-Z Power Analysis".
2. Select "Configure" > "Configure Measurement".
3. Set "Mode" > "Time".
4. Select "Configure Time Mode"
5. Select the "Trigger" tab.



Sensor - Power Analysis

Selects the power sensor to be set if more than one sensor is connected to the instrument.

Remote command:

n.a.

In remote control the sensor is selected via the numeric suffix in the sense key word of the command, for example `SENSe2:POWer:SWEep:...`

Mode - Power Analysis

Selects if the measurement is free running, or starts only after an internal or external trigger event.

Remote command:

[:SENSe<ch>\[:POWer\]:SWEep:TIME\[:SENSor\]:TRIGger:SOURce](#) on page 470

Level - Power Analysis

Sets the trigger threshold. This setting is also possible by the trigger marker on the left side of the diagram.

Remote command:

`:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:TRIGger:LEVel` on page 470

Slope - Power Analysis

Sets the polarity of the active slope of the trigger signals.

"Positive" The rising edge of a trigger signal is active.

"Negative" The falling edge of a trigger signal is active.

Remote command:

`:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:TRIGger:SLOPe` on page 470

Hysteresis - Power Analysis

Sets the hysteresis of the internal trigger threshold. Hysteresis is the magnitude (in dB) the trigger signal level must drop below the trigger threshold (positive trigger slope) before triggering can occur again.


Remote command:

`:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:TRIGger:HYSTeresis`
on page 469

Drop out Time - Power Analysis

Determines the minimum time for which the signal must be below (above) the power level defined by [Level - Power Analysis](#) and [Hysteresis - Power Analysis](#) before triggering can occur again. This prevents the trigger system from being activated too early if the trigger threshold is briefly underranged or exceeded.

The dropout time parameter is useful when dealing with, for example, GSM signals with several active slots. When performing a measurement in sync with the signal, a trigger event is to be produced at A, but not at B or C. As the RF power between the slots is below the threshold defined by [Level - Power Analysis](#) and [Hysteresis - Power Analysis](#), the trigger hysteresis alone cannot prevent triggering at B or at C. This is why the dropout time parameter is selected to be greater than the time elapsed between points E and B and between F and C, but less than the time elapsed between G and A. This ensures that triggering takes place at A.



As the mechanism associated with the dropout time parameter is reactivated whenever the trigger threshold is crossed, unambiguous triggering can also be obtained for many complex signals. By contrast, all triggering is suppressed during the hold-off time. For the example described, this would mean that although stable triggering conditions could be obtained with a suitable hold-off time (regular triggering at the same point), it would not be possible to set exclusive triggering at A.

Remote command:

`:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:TRIGger:DTIME` on page 469

Auto Set - Power Analysis

Sets the trigger level, the hysteresis and the drop out time to default values.

Remote command:

`:SENSe<ch>[:POWER]:SWEep:TIME[:SENSor]:TRIGger:AUTO` on page 469

Gate Mode Settings



For "Time" measurement mode only.

Access:

1. Select "Clk Syn/Power Sens" > "NRP-Z Power Analysis".
2. Select "Configure" > "Configure Measurement".
3. Set "Mode" > "Time".
4. Select "Configure Time Mode"

5. Select the "Gate Mode" tab.

Configure Measurement	Configure Diagram	Configure Gate Mode	Configure Sensors	NEXT WINDOW List		✕
Trace		2	Indication	2 - NRP-Z81		
State						
<input checked="" type="radio"/> On						
Gate 1						
Start			Stop			
5.000 000 μ s			15.000 000 μ s			
Gate 2						
Start			Stop			
25.000 000 μ s			35.000 000 μ s			

The "Gate Mode" tab contains the parameters for defining the time gates for the measurement.

Almost all R&S NRP sensors also support time gated measurements of peak and average power (see the data sheet or operating manual of the respective sensor). Two user-configurable gates can be assigned to one of the traces. Both gates are active at the same time. The values are calculated from the trace data, the time resolution is determined by the resolution of the sensor. An external trigger signal or signal triggering is required for synchronization.

The start and stop time of the gates are indicated as gate markers, a bar between the start and stop marker shows the gate length. The indication state of the gate borders and measurement values is only available for certain diagram views which are switched with the "Next Window List" key. The "Next Window List" dialog provides a selection of views, between which is toggled (see "[Next Window List](#)" on page 255).

Trace - Gate

Selects the trace of the sensor assigned for the gate measurement. Both gates are assigned to the same trace.

To assign the sensor to a trace, use the trace buttons, see [Off / NRP-Zxx](#).

Remote command:

`:CALCulate[:POWER]:SWEep:TIME:GATE<ch>:FEED` on page 457

Indication

Indicates the type of power sensor assigned to the selected trace. This field is automatically updated if the sensor is connected or disconnected. Also, this sensor is indicated on the trace button in the measurement diagram.

This parameter is only available for [Configure Measurement Settings](#) > "Time".

Remote command:

n.a.

State - Gate

Enables time gated measurement. The measurement is started with the "Start" button in the main measurement diagram. Both gates are active at one time.

The gate borders and the measurement values (average and peak power) are indicated in/below the measurement diagram. The indication is only available for certain diagram views which are switched with the "Rearrange" key.

Remote command:

[:CALCulate\[:POWer\]:SWEep:TIME:GATE<ch>:STATe](#) on page 458

[:CALCulate\[:POWer\]:SWEep:TIME:GATE<ch>:AVERAge?](#) on page 457

[:CALCulate\[:POWer\]:SWEep:TIME:GATE<ch>:MAXimum?](#) on page 457

[:TRACe\[:POWer\]:SWEep:MEASurement:GATE:DISPlay:ANNotation\[:STATe\]](#)
on page 502

Start / Stop - Gate

Sets the start and the stop times for the respective gate.

Remote command:

[:CALCulate\[:POWer\]:SWEep:TIME:GATE<ch>:START](#) on page 458


[:CALCulate\[:POWer\]:SWEep:TIME:GATE<ch>:STOP](#) on page 458

Next Window List

Access:

1. Select "Clk Syn/Power Sens" > "NRP-Z Power Analysis".


2. Select "Configure" > "Next Window List"



The "Next Window List" dialog provides functions to activate only the required "Views" on the checkboxes to the right.

Standard View

Shows the graph and the button bar at the left for frequency power and level sweep measurement.



Remote command:

```
:TRACe[:POWER]:SWEep:MEASurement:STANdard:DISPlay:ANNotation[:STATE] on page 503
```


Marker View

Shows the graph and the corresponding marker values at the bottom for frequency power and level sweep measurement.

Up to four markers can be used to display the current power according to the position of the marker. The value(s) are displayed at the bottom of the window below the graph.

To move the marker lines you can select them and drag them with your finger. Alternatively you can move them with the rotary knob.

For details on configuring the markers, see "Markers Settings" on page 233.



Remote command:

```
:TRACe[:POWER]:SWEep:MEASurement:MARKer:DISPlay:ANNotation[:STATE] on page 502
```

Gate View


Shows the graph with the corresponding gate data for time trace and pulse data measurements.

Remote command:

```
:TRACe[:POWER]:SWEep:MEASurement:GATE:DISPlay:ANNotation[:STATE] on page 502
```

Pulse Data View

Shows the graph and the corresponding pulse data for time trace and pulse data measurements.




Remote command:

```
:TRACE[:POWER]:SWEep:MEASurement:PULSe:DISPlay:ANNotation[:STATE] on page 502
```

Full Screen

Shows the graph in fullscreen, and fades out buttons and list values for frequency power and level sweep measurement.



Remote command:

:TRACe[:POWer]:SWEep:MEASurement:FULLscreen:DISPlay:ANNotation[:STATE] on page 501

8.4.4.7 Creating Screenshots of Power Analysis Settings

The power analysis save function enables you to save current settings in a file. To document the most important settings for a performed signal generation, you can also save a hardcopy of the current display.


Save (Power Analysis) Settings

In the "Save ..." dialog you can find the settings to store a screenshot of the current measurement diagram. The current screen shot is stored as indicated, that means with or without marker indication.

Main Settings

Access:

1. Select "Clk Syn/Power Sens" > "NRP Power Analysis".
2. In the diagram window, open the context-sensitive menu.
3. In the menu, select "Save... (Power Analysis)".



File name - Power Analysis

Indicates the file name and directory.

Remote command:

:SENSe[:POWER]:SWEep:HCOPY[:EXECute] on page 483

:SENSe[:POWER]:SWEep:HCOPY:FILE[:NAME] on page 479

:SENSe[:POWER]:SWEep:HCOPY:FILE[:NAME]:AUTO:STATe on page 480

:SENSe[:POWER]:SWEep:HCOPY:FILE[:NAME]:AUTO:FILE? on page 480

Format - Power Analysis

Selects the file format.

Several bitmap graphic formats are offered. In addition, format *.csv is available which stores the measurement values as ASCII data.

You can refine the csv settings further, see "CSV Options" on page 262.

Remote command:

:SENSe[:POWER]:SWEep:HCOPY:DEVIce:LANGUage on page 477


Options

Opens a dialog to select the screenshot format and also to activate and select the automatic naming settings.

Common Settings

Access:

1. Select "Clk Syn/Power Sens" > "NRP Power Analysis".
2. In the diagram window, open the context-sensitive menu.
3. In the menu, select "Save... (Power Analysis)".
4. Select "Options".



Automatic Naming

If enabled, the file names are created by selected rules. The filename includes at least one number and optionally additional information.

Remote command:

:SENSe[:POWER]:SWEep:HCOPY:FILE[:NAME]:AUTO:STATe on page 480

Format - Power Analysis

Selects the file format.

Several bitmap graphic formats are offered. In addition, format *.csv is available which stores the measurement values as ASCII data.

You can refine the csv settings further, see "CSV Options" on page 262.

Remote command:

:SENSe[:POWER]:SWEep:HCOPY:DEVIce:LANGUage on page 477

Automatic Naming Settings

Access:

1. Select "Clk Syn/Power Sens" > "NRP Power Analysis".
2. In the diagram window, open the context-sensitive menu.
3. In the menu, select "Save... (Power Analysis)".
4. Select "Options".
5. In the "Save NRP-Z Analysis Options" dialog, enable "Automatic Naming."

Save NRP-Z Analysis Options

Path ... C:\Users\Bozhanov\Documents

Delete All Image Files In Path Clear Path

Prefix smab

Year Month Day

Current Auto Number 000

Resulting File Name
smab20181113000.bmp

Common Automatic Naming

Path

Sets the directory for saving the files.

Remote command:

:SENSe[:POWER]:SWEep:HCOPY:FILE[:NAME]:AUTO:DIRectory on page 479

Clear Parth

Deletes all image files with extensions "bmp", "img", "png", "xpm" and "csv" in the directory set for automatic naming.

Remote command:

```
:SENSe[:POWer]:SWEep:HCOPY:FILE[:NAME]:AUTO:DIReCTory:CLEAr
```

on page 479

Prefix, Year, Month, Day, Instrument Name

A selection of the prefix, year, month, day and instrument name are included in the file name.

Remote command:

```
:SENSe[:POWer]:SWEep:HCOPY:FILE[:NAME]:AUTO[:FILE]:PREFix:STATe
```

on page 482

```
:SENSe[:POWer]:SWEep:HCOPY:FILE[:NAME]:AUTO[:FILE]:PREFix
```

on page 482

```
:SENSe[:POWer]:SWEep:HCOPY:FILE[:NAME]:AUTO[:FILE]:DAY:STATe
```

on page 481

```
:SENSe[:POWer]:SWEep:HCOPY:FILE[:NAME]:AUTO[:FILE]:DAY?
```

on page 480

```
:SENSe[:POWer]:SWEep:HCOPY:FILE[:NAME]:AUTO[:FILE]:MONTH:STATe
```

on page 481

```
:SENSe[:POWer]:SWEep:HCOPY:FILE[:NAME]:AUTO[:FILE]:MONTH?
```

on page 481

```
:SENSe[:POWer]:SWEep:HCOPY:FILE[:NAME]:AUTO[:FILE]:YEAR:STATe
```

on page 483

```
:SENSe[:POWer]:SWEep:HCOPY:FILE[:NAME]:AUTO[:FILE]:YEAR?
```

on page 482

Current Auto Number

Indicates the number which is used in the automatically generated file name.

Remote command:

```
:SENSe[:POWer]:SWEep:HCOPY:FILE[:NAME]:AUTO[:FILE]:NUMBer?
```

on page 482

Resulting File Name

Indicates the automatically generated file name.

Remote command:

```
:SENSe[:POWer]:SWEep:HCOPY:FILE[:NAME]:AUTO:FILE? on page 480
```

CSV Options

Access:

1. Select "Clk Syn/Power Sens" > "NRP Power Analysis".
2. In the diagram window, open the context-sensitive menu.
3. In the menu, select "Save... (Power Analysis)".

4. Set "Format" > "CSV".
5. Select "Options".
6. Select the "CSV Options" tab.

Save NRP-Z Analysis Options		✕
Orientation	Vertical	Common
Separator	,	Automatic Naming
Decimal Point	.	CSV Options
Row Header	Off	

If file format `*.csv` is selected, the trace data is saved as an ASCII file with separated values. CSV files can be imported into the program MS Excel and then processed further. Adjust the value separator and the decimal point according to the language version, to import the data correctly.

Orientation

Defines the orientation of the X/Y value pairs:

- **Horizontal:**
 - X/Y values of trace 1 in rows 1 and 2,
 - X/Y values of trace 2 in rows 3 and 4,
 - X/Y values of trace 3 in rows 5 and 6,
 - X/Y values of trace 4 in rows 7 and 8.

Example:

```
Trace1,X[Hz]: 10000.0; 10010.0; 10020.0; 10030.0; ...
Trace1,Y[dBm]: -20.09; -19.17; -18.19; -15.43; ...
Trace2,X[Hz]: 10000.0; 10010.0; 10020.0; 10030.0; ...
Trace2,Y[dBm]: -19.09; -18.17; -17.19; -14.43; ...
Trace3,X[Hz]: 10000.0; 10010.0; 10020.0; 10030.0; ...
Trace3,Y[dBm]: -21.09; -20.17; -19.19; -16.43; ...
Trace4,X[Hz]: 10000.0; 10010.0; 10020.0; 10030.0; ...
Trace4,Y[dBm]: -22.07; -20.14; -21.56; -17.67; ...
```

- **Vertical:**

- X/Y values of trace 1 in column 1 and 2,
- X/Y values of trace 2 in column 3 and 4,
- X/Y values of trace 3 in column 5 and 6,
- X/Y values of trace 4 in column 7 and 8.

Example:

```
Trace1,X[Hz]; Trace1,Y[dBm]; Trace2,X[Hz]; Trace2,Y[dBm]; Trace3,X[Hz];
Trace3,Y[dBm]; Trace4,X[Hz]; Trace4,Y[dBm];
10000.0;-20.09;10000.0; -19.09;10000.0;21.09;10000.0;22.07;
10010.0;-19.17;10010.0;-18.17;10010.0; -20.17;10010.0; -20.14;
10020.0;-18.19;10020.0;-17.19;10020.0;-19.19;10020.0;-21.56;
10030.0; -15.43;10030.0; -14.43;10030.0;-16.43;10030.0;-17.67;...
```

Remote command:

```
:SENSe[:POWER]:SWEep:HCOPY:DEVIce:LANGUage:CSV:ORientation
on page 478
```

Separator

Defines the character to be used to separate the values: tabulator, semicolon, comma or blank.

Remote command:

```
:SENSe[:POWER]:SWEep:HCOPY:DEVIce:LANGUage:CSV[:COLumn]:
SEParator on page 478
```

Decimal Point

Defines the character to be used as the decimal point of the values: dot or comma.

Remote command:

```
:SENSe[:POWER]:SWEep:HCOPY:DEVIce:LANGUage:CSV:DPoint on page 477
```

Row Header

Defines a header for each row or column, depending on the orientation. A header contains information on the trace, e.g. the trace index, or frequency, power or time values.

Example:


```
Trace=2;Source=detecting..;X[Hz]";"Trace=2;Source=detecting..;Y[dBm]"
```

Remote command:


`:SENSe[:POWER]:SWEep:HCOPY:DEVIce:LANGUage:CSV:HEADer` on page 477

How to Save a Hardcopy of the Power Analysis Window

1. Select "Clk Syn/Power Sens" > "NRP Power Analysis".
2. In the diagram window, open the context-sensitive menu.
3. In the menu, select "Save... (Power Analysis)".



4. To define the output format, select "Format > JPG".
5. Select "Options...".
6. To enable the instrument to create output filenames, select "Automatic Naming > On".



In the "Automatic Naming" tab:

- a) To change the default directory the file is saved in, select "Path" and define a path and a filename. For example, select the default directory `/var/user`.
 - b) If necessary, disable or change some of the parameters in the "Automatic Naming Settings".
 - c) Close the "Save NRP-Z Analysis Options" dialog.
8. In the "Save NRP-Z Analysis" dialog, select "Save".
- The instrument saves a hardcopy of the current instrument display as a `*.jpg` file. The filename is automatically created.
9. To print the hardcopy, connect the instrument to a LAN and:
- a) Transfer the file to a remote computer as described in [Chapter 11.9, "How to Transfer Files from and to the Instrument"](#), on page 310.
 - b) On the remote computer, navigate through the file system.
 - c) Print the selected file.
- For more information, refer to the online help of the operating system.

8.4.4.8 How to Setup a Frequency Sweep Measurement

Prerequisites: the sensor is connected to the instrument and configured, see [Chapter 8.4, "Using Power Sensors"](#), on page 214.

1. Select "Clk Syn/Power Sens" > "NRP Power Analysis".
2. Select "Configure" > "Configure Measurement".

3. Set "Mode" > "Frequency".
4. Configure the measurement:
 - a) Set "Min = 8 KHz".
 - b) Set "Max = 6 GHz".
 - c) Set "Steps = 200".
5. Select the "Configure Diagram" tab. Configure the diagram, see [Chapter 8.4.4.11, "How to Configure the Power Analysis Diagram"](#), on page 269.
6. Select the "Configure Sensors" tab.
7. Select the connected sensor, e.g. "2-NRP-Z81".
8. If you want that the frequency settings of the sensor are configured differently than the generator settings, enable "Use Separate Frequ.".
 - a) Set "Min = 1 MHz".
 - b) Set "Max = 10 MHz".
9. In the "Next Window List" tab, enable the "Standard View".
10. Close the "Configure" dialog.
11. Press "Start Cont" to start the measurement.

8.4.4.9 How to Setup a Power Sweep Measurement

Prerequisites: the sensor is connected to the instrument and configured, see [Chapter 8.4, "Using Power Sensors"](#), on page 214.

1. Select "Clk Syn/Power Sens" > "NRP Power Analysis".
2. Select "Configure" > "Configure Measurement".
3. Set "Mode" > "Power".
4. Configure the measurement:
 - a) Set "Min = -20 dBm".
 - b) Set "Max = 30 dBm".
 - c) Set "Steps = 200".
5. Select the "Configure Diagram" tab. Configure the diagram, see [Chapter 8.4.4.11, "How to Configure the Power Analysis Diagram"](#), on page 269.
6. Select the "Configure Sensors" tab.
7. Select the connected sensor, e.g. "2-NRP-Z81".
8. If you want that the frequency settings of the sensor are configured differently than the generator settings, enable "Use Separate Frequ.".
 - a) Set "1 MHz".
9. In the "Next Window List" tab, enable the "Standard View".

10. Close the "Configure" dialog.
11. Press "Start Cont" to start the measurement.

8.4.4.10 How to Setup a Pulse Measurement

Prerequisites: the sensor is connected to the instrument and configured, see [Chapter 8.4, "Using Power Sensors"](#), on page 214.

1. Select "Clk Syn/Power Sens" > "NRP Power Analysis".
2. Select "Configure" > "Configure Measurement".
3. Set "Mode" > "Time".
4. Configure the measurement:
 - a) Set "Min = -5 us".
 - b) Set "Max = 45 us".
 - c) Set "Steps = 200".
5. Select the "Configure Diagram" tab. Configure the diagram, see [Chapter 8.4.4.11, "How to Configure the Power Analysis Diagram"](#), on page 269.
6. Select the "Configure Sensors" tab.
7. Select the connected sensor, e.g. "2-NRP-Z81".
8. In the "Next Window List" tab, enable the "Pulse Data View".
9. Close the "Configure" dialog.
10. In the diagram window, open the context-sensitive menu.
11. Select "Trace/Pulse Data Notifications/ Trigger".
12. Select the "Trace" tab.
13. Set "State > On".
14. Set the thresholds:
 - a) Set "Base > Voltage Related".
 - b) Set "Distal = 90%".
 - c) "Mesial = 50%".
 - d) "Proximal = 10%".
15. Select the "Pulse Data Notifications" tab.
16. Enable up to six parameters, for example:
 - "Duty Cycle"
 - "Pulse Width"
 - "Pulse Period"
 - "Off Time"
 - "Start Time"

17. Close the "Trace/Pulse Data Notifications/ Trigger" dialog.
18. Press "Start Cont" to start the measurement.

8.4.4.11 How to Configure the Power Analysis Diagram

1. Select "Clk Syn/Power Sens" > "NRP Power Analysis".
2. Select "Configure" > "Configure Diagram".
3. Set "Max Level = 30 dBm".
4. Set "Min Level = -40 dBm".
5. Select "Auto Scale > Expand Only (Coarse)".
6. Enable "Show Grid".
7. Set "Background Color > Black."

8.5 How to Calibrate the Power Level with an R&S NRP Power Sensor

Using a R&S NRP power sensor and the user correction function of the instrument, you can compensate external frequency responses. The R&S SMA100B utilizes the readings of the power sensor and creates a correction value table for controlling the output level during operation.


To connect the R&S NRP to the R&S SMA100B

1. Connect the power sensor.
See [Chapter 8.4.1, "Connecting R&S NRP Power Sensors to the R&S SMA100B"](#), on page 214.
2. Select "Clk Syn/Power Sens" > "NRP Sensor Mapping".
3. If the sensor is not detected automatically, select "Scan > Start".
The instrument scans the network and the USB connections for connected sensors and lists all detected R&S NRP sensors in the mapping table.
4. In the "Mapping" column, assign the sensor to a sensor channel (see [Chapter 8.4.2, "NRP Sensor Mapping"](#), on page 215).
5. Close the dialog.

To configure and calibrate the R&S NRP in the R&S SMA100B

Provided the power sensor is connected to the R&S SMA100B and is assigned to a sensor channel, we recommend that you calibrate and configure the power sensor in the "NRP Power Viewer" dialog.

1. Select "Level" > "RF ON > Off"
2. Select "Clk Syn/Power Sens" > "NRP Power Viewer".




3. If the R&S SMA100B has detected several connected power sensors, select the tab of the sensor you want to use.
4. Select "Zero" to start zeroing of the sensor.
Note: Always turn the RF power off or disconnect the sensor from RF before zeroing, since the function calibrates the power sensor at zero signal power.
The zeroing process takes a few seconds, depending on the power sensor type.
5. Configure additional parameters for the selected sensor as required.
6. Select "State > On".
7. Close the dialog.

To create user correction data with an R&S NRP and the R&S SMA100B

We assume, that the power sensor is connected, assigned and ready for operation.

1. Select "Level" > "User Correction".



2. Select "UCOR Data > UCOR Data...".
3. Create a file: "New > Filename" and confirm with "OK".
4. Select the new file with "Select".
5. Select "Edit UCOR Data...".

6. Select "Edit > Fill".

The "Fill Table" dialog enables you to fill in the values of the columns automatically.

7. To fill in the frequency column:

From	0	Range	15
Column To Fill	Frequency/Hz		
Start Value	1.560 000 000 00 GHz	End Value	1.574 000 000 00 GHz
Increment Value	1.000 000 00 MHz		
<input checked="" type="checkbox"/> Fill			

- Select "Select Column To Fill > Frequency / Hz".
- Select "Range > e.g. 15" to determine the number of values.
- Select "Start Value > e.g. 1.56 GHz".
- Select "Increment Value > e.g. 1 MHz", to determine the frequency steps.
- Select "Fill", to insert the frequency values.

The "Fill" function also fills the column of the "Correction Value / dB" values with a predefined value, since empty cells lead to the data loss of the entire line. If you need different values, you can change them manually, or you can use the automatic function "Fill with Sensor" as described in the next steps.

8. Select "Fill with Sensor".

The "Fill User Correction Data With Sensor" dialog provides an overview of the sensor configuration.

9. Select "Execute".

The R&S SMA100B successively sets each frequency point, reads the measured power of the sensor and fills in the value in the correction table.

	Frequency /Hz	Correction Value /dB
0	1 560 000 000.00	11.51
1	1 561 000 000.00	11.03
2	1 562 000 000.00	10.55
3	1 563 000 000.00	10.07
4	1 564 000 000.00	9.59
5	1 565 000 000.00	9.11
6	1 566 000 000.00	8.63
7	1 567 000 000.00	8.15
8	1 568 000 000.00	7.67
9	1 569 000 000.00	7.19
10	1 570 000 000.00	6.71
11	1 571 000 000.00	6.23

Go To Edit Fill with Sensor ... Save As ... Save

10. Select "Save" to save the data in the file.
11. Close the dialog.

To perform power leveling calibration with user correction data

We assume that a user correction file is available in the user directory of the R&S SMA100B or on a memory stick or in a shared directory.

If you have created and saved the file immediately before this step, the file is loaded in the "User Correction" dialog automatically. Otherwise you can load a previously saved file.

1. Select "Level" > "User Correction".
2. Select "UCOR Data > UCOR Data...", if there is no file loaded already.
3. Select the directory and file you want to use.
4. Load the file with "Select".
5. To view the file content, select "Edit UCOR Data".
6. Select "UCOR Data > State > On" to apply the user correction values.

When you activate the RF output, the R&S SMA100B considers the user correction data and adjusts the signal level accordingly to compensate external frequency responses.

9 Reference Oscillator

The R&S SMA100B is equipped with an internal reference oscillator that generates a reference frequency of 10 MHz. It is used as internal reference source for the synthesizer. Alternatively, you can apply an external reference signal. If equipped with the required options, the R&S SMA100B can process external reference frequency in the range 1 MHz to 100 MHz and the 1 GHz reference frequency.

Regardless of the used reference source (internal or external), the R&S SMA100B always outputs the reference frequency at the output connector. You can use it, for example to synchronize further connected instruments.

See:

- **Data sheet**, for a comprehensive description of the possible reference frequency inputs and outputs, their characteristics and the required options
- [Chapter 9.2, "Using the Reference Frequency for Instruments Synchronization"](#), on page 273, for an overview of typical test situations

The reference oscillator settings are not affected by an instrument preset ([Preset] key or *RST) and the "Save/Recall" function. They are reset only by factory preset.

The remote commands required to define these settings are described in [Chapter 14.16.12, "SOURCE:ROSCillator Subsystem"](#), on page 642.

9.1 Required Options

R&S SMA100B base unit equipped with the following options:

- Reference frequencies 1 MHz to 100 MHz (R&S SMAB-K704)
- Ultra low noise 1 GHz (R&S SMAB-K703)

For more information, see data sheet.

9.2 Using the Reference Frequency for Instruments Synchronization

Test setups with two or more instruments often require that the instruments use a common reference frequency. Depending on the availability of external reference frequency source and its quality, the instruments are connected and configured in different ways.

This section gives an overview of the possible test setups and the related settings. The following situations are considered:

- External reference source is not available or the **built-in reference oscillator** is of better quality than the external source (see ["Distributing the internal 10 MHz reference signal to further instruments"](#) on page 274)

- **Clean external reference source** with quality exceeding the quality of the built-in reference oscillator
(see ["Using external reference source"](#) on page 275)
- **Interfered or noisy external reference signal**
(see ["Deriving 10 MHz from the external reference frequency"](#) on page 276)
- **1 GHz reference coupling** for phase coherence of the RF signals with reasonable long-term phase stability
(see ["Sharing the 1 GHz reference frequency to obtain phase-coherent signals"](#) on page 275)

Connectors overview

Use the "Show Connector" function to indicate the connector on the front/real panel:

- Ref In/Ref Out
- Ref In/Ref Out 1GHz
- ["EFC"](#) on page 43

Distributing the internal 10 MHz reference signal to further instruments

The internal reference oscillator provides the reference frequency:

- Internal $f_{\text{ref}} = 10 \text{ MHz}$ (10 MHz at connector Ref Out)
- [Source](#) = "Internal"
- [Reference Output/1GHz Reference Output](#) = "10 MHz"
- Optional:
 - [External Tuning Active](#) = "On"
 - [External Tuning Slope](#) = "Low"




Figure 9-1: Synchronizing instruments using the internal 10 MHz reference signal of the R&S SMA100B

EFC = External frequency control
EFC, Ref In, Ref Out = Connectors

In phase noise measurement systems, for example, you can also use the EFC (external frequency control) function and shift the frequency. EFC is a function that transforms an external tuning voltage into frequency shift, where the value range of the resulting frequency is a technical characteristic listed in the data sheet. See the data sheet also for information on the sensitivity, input voltage range, impedance and maximum bandwidth for external tuning signal.

Consider the following interdependency:

- EFC in combination with an external PLL

If the EFC is applied in combination with an external PLL (phase locked loop), the PLL bandwidth must be smaller than the bandwidth of the external tuning signal.

- FM-DC mode

If the measurement requires higher PLL bandwidth, we recommend that you use the external FM modulation (DC coupling) in low noise mode.

The FM-DC mode yields a fixed tuning sensitivity that is independent of the RF output frequency and corresponds to the selected FM deviation.

Sharing the 1 GHz reference frequency to obtain phase-coherent signals

Compared to 10 MHz, a 1 GHz reference signal significantly improves the achievable phase stability between two signal sources. Because the synchronization increases by a factor of 100, the relative phase fluctuations between the sources can be reduced.

1 GHz at connector Ref In 1GHz and 1 GHz at Ref Out 1GHz

- External $f_{\text{Ref}} = 1 \text{ GHz}$
- **Source** = "External"
- **External Reference Frequency** = "1 GHz"
- **1GHz Reference Output** = "1 GHz"

Using external reference source

If you have a clean external reference signal with 10 MHz or 100 MHz frequency, for example, you can **directly pass it to the output**. The signal quality remains the same.

10 MHz/100 MHz at connector Ref Out and Ref In

- External $f_{\text{Ref}} = 10 \text{ MHz}$ or 100 MHz
- **Source** = "External"
- **Reference Output** = "10 MHz/100 MHz" or "Input Signal (loop through)"
- Set the synchronization bandwidth according to the requirements of the application.




Figure 9-2: Synchronizing instruments with a 10 MHz external reference signal

Ref. Frequency Source = e.g. Rohde & Schwarz signal analyzer

f_{Ref} = 10 MHz/100 MHz/1 to 100 MHz external reference frequency

Ref In, Ref Out = Connectors

You can forward reference frequency between 1 MHz and 100 MHz directly to the output in the same way.

- External $f_{\text{Ref}} = 1 \text{ MHz}$ to 100 MHz
(**1 MHz to 100 MHz at connector Ref In and Ref Out**)
- **Source** = "External"

- **Variable Reference Frequency** = "Variable"
- **External Reference Frequency** = current external frequency
- **Reference Output** = "Input Signal (loop through)" or specify the reference frequency the synchronized instrument supports
- Set the synchronization bandwidth according to the requirements of the application.

Deriving 10 MHz from the external reference frequency

10 MHz reference frequency can be derived from the following external reference signals:

- 10 MHz from internal oscillator locked to external input
- 100 MHz and 1 GHz external reference signals
- External reference signal between 1 MHz and 100 MHz
- If the external reference signal is interfered (noisy)




Figure 9-3: Synchronizing instruments with 10 MHz (derived from an external reference frequency)

Ref. Frequency Source = e.g., Rohde & Schwarz signal analyzer
 f_{Ref} = 10 MHz/100 MHz/1 to 100 MHz/1GHz** external reference frequency
 ** = 1 GHz uses Ref In 1 GHz connector
 Ref In, Ref Out = Connectors


1 GHz/1 to 100 MHz at connector Ref In 1 GHz/Ref In and 10 MHz at Ref Out

- E.g., External Ref. f_{ref} = 100 MHz
- **Source** = "External"
- **External Reference Frequency** = "100 MHz"
- **Reference Output/1GHz Reference Output** = "10 MHz"
- **Synchronization Bandwidth** = "Narrow"

9.3 Reference Frequency Settings

Access:


1. Select one of the following:
 - "Frequency" > "Reference Frequency"
 - "System Config" > "Setup" > "General" > "Reference Frequency"



In the "Reference Frequency" tab, you can select the signal source of the reference frequency and define the frequency of an external reference signal.

2. Observe the information on the home screen, "Frequency" tile.

The "Frequency" tile indicates the current reference oscillator configuration, including the reference oscillator source, external reference frequency (rounded value) and output connector. A warning symbol in the "Frequency" tile indicates a missing external source.



The remote commands required to define these settings are described in [Chapter 14.16.12, "SOURCE:ROSCillator Subsystem"](#), on page 642.

Settings:

Set to Default	278
Source	278
Show Connector	278
Deactivate RF Output (if external reference is missing)	278
External Reference Frequency	278

Variable Reference Frequency.....	279
Synchronization Bandwidth.....	279
Nominal Synchronization Bandwidth.....	279
Minimum Locking Range.....	279
External Tuning Active.....	279
External Tuning Slope.....	280

Set to Default

Calls the default settings.

Remote command:

`[:SOURce] :ROSCillator :PRESet` on page 643

Source

Selects the reference frequency source.

"Internal" Uses the internal reference oscillator, either with calibrated or a user-defined adjustment value.

"External" Uses an external reference signal.
The frequency of the external reference signal must be set with the parameter "External Reference Frequency".

Note: If the external reference is missing, the R&S SMA100B issues a warning message and indicates the icon ⚠ (external reference missing).

See "External Reference Frequency" on page 278.

Remote command:

`[:SOURce] :ROSCillator :SOURce` on page 643



Show Connector

Accesses a dialog that displays the physical location of the selected connector on the front/rear panel of the instrument.

Deactivate RF Output (if external reference is missing)

Turns off the RF output when the external reference signal is selected, but no signal is supplied.

This function prevents that no improper RF signal due to the missing external reference signal is used for measurements. A message indicates that the RF output is deactivated.

Remote command:

`[:SOURce] :ROSCillator :EXTernal :RFOFf [:STATe]` on page 644

External Reference Frequency

Sets the frequency of the external reference signal.

"Variable" Option: R&S SMAB-K704

The external reference signal has an arbitrary frequency, within the permissible range from 1 MHz to 100 MHz.

Set the output frequency with the parameters in the [Reference Output](#) dialog.

"10 MHz, 100 MHz, 1GHz"

Selects the external reference frequency.

Remote command:

[\[:SOURce\]:ROSCillator:EXTernal:FREQuency](#) on page 644

Variable Reference Frequency

Option: R&S SMAB-K704

Sets the variably settable external reference frequency.

Remote command:

[\[:SOURce\]:ROSCillator:EXTernal:FREQuency:VARiable](#) on page 644

Synchronization Bandwidth

("External Reference Frequency = 10 MHz, 100 MHz or 1 GHz")

Selects the synchronization bandwidth for an external reference signal.

The resulting bandwidth is indicated with the parameter [Nominal Synchronization Bandwidth](#).

"Narrow" The internal reference oscillator is synchronized to the external signal with narrow bandwidth (< 1 Hz). This setting is recommended if the phase noise of the external signal is worse than the phase noise of the internal OCXO.

"Wide" This mode is the recommended standard mode and for precise reference sources of high spectral purity.

Note: If the frequency of the external reference signal is outside the locking range of the internal reference oscillator, spurs due to the difference of the internal and external reference frequency are generated in the reference PLL.
An error message is displayed.

For more information, see data sheet.

Remote command:

[\[:SOURce\]:ROSCillator:EXTernal:SBANdwidth](#) on page 645

Nominal Synchronization Bandwidth

Indicates the nominal synchronization bandwidth for the selected external reference frequency and synchronization bandwidth.

Remote command:

[\[:SOURce\]:ROSCillator:EXTernal:NSBandwidth?](#) on page 645

Minimum Locking Range

Indicates the minimum locking range for the selected external reference frequency.

Remote command:

[\[:SOURce\]:ROSCillator:EXTernal:MLRange?](#) on page 645

External Tuning Active

For "Source > Internal", activates the EFC (external frequency control).

EFC is a function that transforms an external tuning voltage into frequency shift, where the value range of the resulting frequency is a technical characteristic listed in the data sheet.

See the data sheet also for information on the sensitivity, input voltage range, impedance and maximum bandwidth for external tuning signal.

Remote command:

`[:SOURce] :ROSCillator :INTernal :TUNing [:STATe]` on page 643

External Tuning Slope

Sets the sensitivity of the external tuning voltage.


Remote command:

`[:SOURce] :ROSCillator :INTernal :TUNing :SLOPe` on page 643

9.4 Reference Output Settings

Access:

1. Select "Frequency" > "Reference Frequency"
2. Select "Reference Output".



In the "Reference Output" tab, you can set the reference frequency value at the output connectors.

As a result of parameter dependencies, "Preset This Parameter" sometimes does not affect output dialogs.

The remote commands required to define these settings are described in [Chapter 14.16.12, "SOURce:ROSCillator Subsystem"](#), on page 642.

Settings:

Reference Output/1GHz Reference Output	280
Show Connector	281

Reference Output/1GHz Reference Output

Selects the signal that is to be output as frequency reference for downstream instruments.

"Off" Disables the reference signal output.

"10 MHz/100 MHz"

Derives a signal with 10 MHz or 100 MHz frequency from the internal reference oscillator and forwards this signal to the output.

"1 GHz" Outputs a 1 GHz signal.

"Input Signal (loop through)"

Forwards the external reference frequency to the output directly.

Remote command:

[\[:SOURce\]:ROSCillator:OUTPut:FREQuency:MODE](#) on page 645

[\[:SOURce\]:ROSCillator:OUTPut:ALternate:FREQuency:MODE](#) on page 646



Show Connector

Accesses a dialog that displays the physical location of the selected connector on the front/rear panel of the instrument.

9.5 Adjustment Settings

Access:

1. Select "Frequency" > "Reference Freq"
2. Select "Adjustment".

Adjustment Active <input checked="" type="checkbox"/>	Adjustment Value	0
---	------------------	---

Settings:

Adjustment Active	281
Adjustment Value	281

Adjustment Active

Selects the adjustment mode.

"OFF" Uses the calibrated internal reference frequency.

"ON" Allows you to apply a deviation to the internal reference frequency, according to your requirements.
Enter the value in the [Adjustment Value](#) field.

Remote command:

[\[:SOURce\]:ROSCillator\[:INTernal\]:ADJust\[:STATe\]](#) on page 647

Adjustment Value

Sets a user-defined adjustment value for the internal reference frequency. This value takes effect when it is activated with [Adjustment Active](#).

- "0" represents the calibrated state.
- The setting range depends on the reference oscillator type and its factory calibration value.

Note:

The setting is not affected by an instrument preset ([Preset] key or *RST) and the "Save/Recall" function. It is reset only by factory preset.

Remote command:

`[:SOURce] :ROSCillator [:INTernal] :ADJust :VALue` on page 646

10 Clock Synthesis

The clock synthesis provides a separate system clock with a freely selectable frequency for test setups that require an additional clock reference. For example, in a test setup that uses an A/D converter, the required system clock for data sampling can be provided without the need of additional signal generator.

Output connectors

The generated clock reference is synchronized to the selected reference clock of the signal generator (internal or external). The differential signal is output at the [Clk Syn] and [Clk Syn N] connectors.

Required options

- Option frequency R&S SMAB-B10x
- Option differential clock synthesis up to 3 GHz R&S SMAB-B29
- Option clock synthesis extension 6 GHz R&S SMAB-K722 (requires at least R&S SMAB-B106)

For more information, see data sheet.


Settings

Access:


1. Select "Clk Syn/Power Sens > Clock Synthesis".

Clock Synthesis		User Variation	✕
State	<input checked="" type="checkbox"/>		
Output Type	Differential Sine		
Frequency	10.000 000 000 MHz	Level	-20.00 dBm
DC Offset State	<input checked="" type="checkbox"/>	DC Offset	0 mV
Delta Phase	0.0 deg	Reset Delta Phase Display	

2. Select "User Variation" to set the step width to be used when setting the clock frequency using the rotary knob.



3. Observe the information on the home screen, "Clk Syn/Power Sens" tile.



The "Clk Syn/Power Sens" tile indicates that clock synthesis is activated and gives an overview of the key parameters.

Settings

State	284
Output Type.....	284
Frequency	285
Level	285
DC Offset State	285
DC Offset	286
Voltage.....	286
Delta Phase.....	286
Reset Delta Phase Display.....	286
User Variation.....	286
└ Variation Active.....	286
└ Variation Step.....	286

State

Activates/deactivates generation of a system clock.

The signal is output at the [Clk Syn] connector.

Remote command:

:CSYNthesis:STATe on page 432

Output Type

Defines the shape of the generated clock signal.

"Single-Ended/Differential Sine"

Sine signals with user-definable amplitude.

"Differential Square"

Squared signal with fixed amplitude.

"CMOS"

CMOS-like signal with user-definable amplitude and limited frequency range.

Remote command:

`:CSYNthesis:OTYPe` on page 432

Frequency

Sets the frequency of the generated clock signal.

Output Type	Min. frequency	Max. frequency
Single-ended sinus Differential sinus	100 kHz	6 GHz
Differential square	10 MHz	6 GHz
CMOS	100 kHz	200 MHz

Remote command:

`:CSYNthesis:FREQuency` on page 432

Level

For **Output Type** = "Single-Ended/Differential Sine", sets the amplitude of the generated clock signal.

Remote command:

`:CSYNthesis:POWer` on page 433

DC Offset State

Activates a DC offset for both clock synthesis signal outputs.

The DC offset can be used e.g. to shift the clock synthesis output signal into the trigger threshold of some logic elements.




Figure 10-1: Example: DC offset = 1.65V and Output Type = Differential Square

Remote command:

`:CSYNthesis:OFFSet:STATe` on page 433

DC Offset

Sets the value of the DC offset for both clock synthesis signal outputs.

Remote command:

`:CSYNthesis:OFFSet` on page 433

Voltage

For **Output Type** = "CMOS", sets the high-level of the output signal.

Remote command:

`:CSYNthesis:VOLTagE` on page 434

Delta Phase

Shifts the phase of the generated clock signal.

Remote command:

`:CSYNthesis:PHASe` on page 434

Reset Delta Phase Display

Resets the parameter **Delta Phase**.

User Variation

Defines and activates a user-defined step width for varying the frequency or level with the rotary knob.

If disabled, the step width varies in steps of one unit at the cursor position.

Variation Active ← User Variation

Activates the set user-defined step width.

Remote command:

`:CSYNthesis:FREQuency:STEP:MODE` on page 435

`:CSYNthesis:POWer:STEP:MODE` on page 435

Variation Step ← User Variation

Sets the user-defined step width.

Remote command:

`:CSYNthesis:FREQuency:STEP` on page 435

`:CSYNthesis:POWer:STEP[:INCRement]` on page 435

11 File and Data Management

The R&S SMA100B uses files to save all instrument data. The instrument allows you to store and to load instrument settings, and to import and to export user data for processing in another instrument or later. Finally, you can create a screenshot of the current settings displayed on the screen and save it as a file.

This section focuses on the functions provided for managing of user data files and covers the topics listed below.

For information on the related remote control commands, refer to [Chapter 14.5, "Memory Subsystem"](#), on page 418.

For information on how to save the displayed setting in a file, refer to [Chapter 11.10, "Creating Screenshots of Current Settings"](#), on page 316.

• About the File System	287
• Restoring the (Default) Instrument Configuration	290
• Protecting Data	295
• Saving and Recalling Instrument Settings	296
• Accessing Files with User Data	300
• Exporting Remote Command Lists	302
• Loading, Importing and Exporting Lists	303
• Using the File Manager	303
• How to Transfer Files from and to the Instrument	310
• Creating Screenshots of Current Settings	316

11.1 About the File System

Depending on the contained information, two file groups can be distinguished: system and user files.



Due to security reasons, system files and the system directory are protected and therefore not accessible.

The scope of this section is only the files with user data.

This section is an overview of the R&S SMA100B file system and covers the following topics:

- ["Types of user data"](#) on page 288
- ["File storage location"](#) on page 288
- ["File handling"](#) on page 289
- ["File naming conventions"](#) on page 289
- ["File extensions"](#) on page 289
- ["File contents"](#) on page 290

Types of user data

Depending on the **content**, the **user data** can be roughly divided into the following data types:

- *Settings*, e.g. the current instrument settings, can be saved and loaded later or used in other instrument of the same kind.
See [Chapter 11.4, "Saving and Recalling Instrument Settings"](#), on page 296
- *SCPI scripts*, a series of commands that can be run to perform a task.
See [Chapter 11.6, "Exporting Remote Command Lists"](#), on page 302
- Externally or internally generated *lists*, e.g. user correction lists, or data lists can be loaded in the instrument.
See [Chapter 11.7, "Loading, Importing and Exporting Lists"](#), on page 303 and [Chapter 11.5, "Accessing Files with User Data"](#), on page 300

Depending on the **data storage method**, user data can be:

- *Persistent*, i.e. user files that are recorded on the data storage.
Data is preserved when instrument is powered off and can be accessed and modified subsequently.
- *Temporary*, i.e. volatile data that the instrument retains while it is powered on.
Volatile data is immediately lost when the R&S SMA100B is switched off.

File storage location

Without any additional measures, the R&S SMA100B stores user files on the internal memory, the removable memory, or if connected, on a memory stick.

Both, the user directory `/var/user/` on the internal memory or the `/usb/` directory on the memory stick, can be used to **preserve** user-defined data. Any directory structure can be created.

The `/var/volatile` directory serves as a RAM drive and can be used to protect sensitive information. The data is available **temporarily**.

If option R&S SMAB-B85 is installed, the R&S SMA100B maps the user directory to the removable memory. If a memory is mounted, user data is saved there. Otherwise user data is redirected to the volatile memory.

Default storage location

The R&S SMA100B stores user data in the user directory.

Depending on the installed options, the user directory is physically located on the internal memory or on the removable memory.

In the file system, user directory is always indicated as `/var/user/`.

In manual control, you access this directory via the "File Manager", see [Chapter 11.8, "Using the File Manager"](#), on page 303. In remote control, you can query it with the command `:SYSTem:MMEMory:PATH:USER?`.

To query and change the default directory used for mass storage, use the command `:MMEMory:CDIRectory`.

File handling

To *access files* and the file system of the instrument or to use the general file management functions such as copying and moving data, use the standard "File Manager" dialog.

See [Chapter 11.8, "Using the File Manager"](#), on page 303.

To *transfer files* from and to the instruments or to exchange files, use one of the following alternatives:

- Connect a memory stick to one of the USB interfaces.
The instrument recognizes automatically a connected memory stick and assigns the `/usb/` drive to it.
- Connect the instrument to a LAN.
An instrument connected to a LAN supports two standard file transfer methods from a remote client:
 - FTP (file transfer protocol)
 - File sharing according to the SAMBA/SMB (server message block) protocol.Both file transfer methods access the folder `/user`, that is the `/var/user/` folder on the instrument.
For step-by-step description, see [Chapter 11.9, "How to Transfer Files from and to the Instrument"](#), on page 310.
- Map a network folder or a computer to an instrument connected to a LAN.
A mapped network folder is indicated as `/shares/<"Local Folder">`.
For step-by-step description, see [Chapter 11.8.4, "How to Map a Network Folder"](#), on page 307.

File naming conventions

To enable files to be used in different file systems, consider the following file naming conventions:

- The *filename* can be of any length and *is case-sensitive*, i.e it is distinguished between uppercase and lowercase letters.
- All letters and numbers are permitted (numbers are, however, not permitted at the beginning of the filename).
- Avoid using special characters.
- Do not use slashes "\" and "/". These symbols are used in file paths.
- Avoid using the following filenames: `CLOCK$, CON, COM1 to COM4, LPT1 to LPT3, NUL or PRN`
They are reserved by the operating system.

File extensions

The R&S SMA100B distinguishes the files according to their extensions; each type of file is assigned a specific file content and also a specific file extension. The extension is usually of no consequence to you since access to the files occurs in the individual dialogs where only the relevant type of file is available. For example, files with user correction data can only be saved and loaded in the "UCOR" dialog.

See [Chapter C, "Extensions for User Files"](#), on page 744 for an overview of the supported file extensions.

File contents

To maintain the file size and to accelerate the loading and processing times, not all instrument settings but rather the settings in state different than the preset one are stored. Considered is also configuration data for the operating elements and lists with user data, e.g. dialog positions and a list of user correction data. However, if a list data is part of the instrument settings, a reference to this list is stored, not the list itself.

This approach ensures that the created files contain only relevant information and allows you to transfer instrument settings even between different equipped signal generators. During the recall process, the instrument interprets only the relevant settings; all non-referenced parameters are set to their preset values. Error messages indicate the settings which cannot be implemented, like referencing non-existing lists or the attempt to activate settings which are not supported by the instrument.



Network settings and remote settings cannot be saved and restored.

11.2 Restoring the (Default) Instrument Configuration

The R&S SMA100B has various options to set default settings, see [Figure 11-1](#). You can preset the R&S SMA100B to an initial state at any time as a known starting point for configurations. It is often useful as a first step in troubleshooting when unusual results arise.

The graph on [Figure 11-1](#) shows the impact of the particular reset functions.





Figure 11-1: Parameter and operating modes, reset by the respective preset functions

Overview of the characteristics of the preset functions

Select the preset option that most fits to your particular application:




- [Preset]
It is the most frequently used function.
A [Preset](#) executes a defined instrument setup to provide an initial instrument state as a basis for a new configuration. It resets all parameters and switching states, including also the states of inactive operating modes.
Network, remote access or system settings are retained.
- ▶ To execute a preset, press the [Preset] key at the front panel.



- "Set to Default"
[Set To Default](#) relates to individual dialogs or tabs and resets the associated settings of the corresponding dialog. All other settings are retained.
- ▶ To reset the grouped settings, click "Set To Default".



- "Preset this parameter"
Sets a single parameter to its default value.
- ▶ To reset an individual parameter: Open its context-sensitive menu and select "Preset this parameter...".



- "Factory Preset"
A factory preset is the most profound preset function that resets almost all instrument settings, including reference oscillator, network and remote access settings.
Retained are the following settings:
 - Security, password, and settings protected by these passwords
 - User-defined data, like setups or data lists
 - Settings that relate to an integration of the instrument in a measurement setup.
- ▶ To restore the factory defaults, select [System Config > Setup > Settings > Factory Preset](#).

Note: Perform a "Factory Preset" only if it is necessary. After a "Factory Preset", the network connection to the instrument no longer exists.

Presetting the instrument to a user-defined instrument state

The reset functions set the parameters and operating modes to default values predefined by the factory. Alternatively to these default settings, you can:

- Define user-specific recall settings to be restored after a preset (see [Chapter 11.2.3, "How to Recall User Settings Automatically after Preset"](#), on page 293)
- Store and reload user-defined instrument states (see [Chapter 11.4.2, "How to Save and Recall Instrument Settings"](#), on page 299)

Mark / Do not mark parameters changed from preset

To survey the current state of the settings concerning default values, the R&S SMA100B offers a feature that visually identifies deviations from the default values.

For more information, see [Chapter 11.2.2, "How to Identify Parameters Which Are Not in a Preset State"](#), on page 293.

11.2.1 Preset, Set to Default and Factory Preset Settings

Preset	292
Set To Default	292
Preset this Parameter	292
Execute Factory Preset	292

Preset

Resets all parameters and switching states, and closes all opened dialogs.

Consider also the following possibilities:

- You can define the settings that are restored when you preset the instrument (see [Chapter 11.2.3, "How to Recall User Settings Automatically after Preset"](#), on page 293)
- You can reset the instrument to the factory state (see ["Execute Factory Preset"](#) on page 292)

See also [Table 11-1](#) that contains the key parameters that are reset by the corresponding preset functions.

Remote command:

*RST on page 415

Set To Default

Resets the associated settings of the corresponding dialog or tab.

Preset this Parameter

Restores the default value of a single parameter.

Execute Factory Preset

Resets the instrument to its factory settings.

Note: "Factory Preset" retains all security settings and does not delete any user files like setups or user data.

See also [Table 11-1](#) that contains the key parameters that are reset by the corresponding preset functions.

Remote command:


:SYSTem:FPReset on page 418

11.2.2 How to Identify Parameters Which Are Not in a Preset State

To recognize the current state of the settings related to their default values at the first glance, enable a function that visually identifies parameters in states different than pre-set.

To activate this display:

1. Open the context-sensitive menu (touch and hold the screen anywhere in the GUI of the R&S SMA100B).
2. Select "Mark all parameters changed from preset".



If enabled, the corresponding settings are marked.

Example:

Frequency	4.000 000 000 000 GHz		
Offset	10.000 000 kHz	Multiplier	1.000
User Variation			
Variation Active	<input checked="" type="checkbox"/>	Variation Step	1.000 000 000 MHz

Figure 11-2: Labeled parameters show that the value deviates from its default

Frequency = changed (default = 1 GHz)
 Offset = changed (default = 0 kHz)
 Multiplier = unchanged
 Variation active = changed (default = disabled)
 Variation step = unchanged

11.2.3 How to Recall User Settings Automatically after Preset

You can define the settings that are restored when you preset the instrument.

1. Configure the settings as required. Save them as described in [Chapter 11.4.2, "How to Save and Recall Instrument Settings"](#), on page 299.

2. Save the settings as a file with the predefined filename `UserPreset.savrcltxt`. Save this file in the directory `/var/user/`.

The filename `UserPreset.savrcltxt` and the directory `/var/user/` are mandatory.

Now when you press the [Preset] key or send the `*RST` command to the instrument, the defined settings are restored.

An "Info" message appears and confirms, that a file with user-defined preset setting is loaded.

11.2.4 Reference

See [Table 11-1](#) for an overview of the main generator settings that are affected by the corresponding preset functions. While the regular [Preset] key primarily resets the signal relevant parameters of the instrument, the "Factory Preset" affects almost all instrument settings.

For information on the default values of further parameters, refer to the description of the corresponding remote commands.

Table 11-1: Key parameters affected by preset and factory preset

Parameter	Preset value	Preset	Factory Preset
RF frequency	1 GHz	x	x
RF level (RF output)	off	x	x
RF OFF mode	-	-	x
Offsets	0	x	x
Modulation state	off	x	x
Uninterrupted level settings	off	x	x
Level attenuator mode	auto	x	x
Level ALC (internal level control)	auto	x	x
Level UCOR (user correction)	off	x	x
LF output state	off	x	x
Sweep state	off	x	x
List mode state	off	x	x
Reference frequency settings (reference oscillator)	-	-	x
Power on settings (Level/EMF)	-	-	x
Network settings	-	-	x
Hostname	-	-	x
GPIB address	-	-	x
Start/Stop display update	-	-	x

Parameter	Preset value	Preset	Factory Preset
Display and keyboard settings	-	-	x
Password and settings protected by passwords (e.g. disabled LAN or USB)	-	-	-
Security settings	-	-	-
User files (setups ²⁾ , data lists, etc.)	-	-	-

- ²⁾ `UserPreset.savrc1txt` is renamed as `UserPresetInactive.savrc1txt`; an existing file with the same name is overwritten.



If the default values in the "Remote Access" dialog had been changed, a factory preset via remote control (`:SYSTem:FPReset`) terminates the connection to the instrument.

Security settings are never reset.

Resets all parameters and switching states, and closes all opened dialogs.

11.3 Protecting Data

During operation, the R&S SMA100B saves user data permanently in the user directory, see "[File storage location](#)" on page 288.

To protect any classified data and to avoid saving any sensitive data on the R&S SMA100B permanently, you can:

- Install the option **removable memory** R&S SMAB-B85
This option ensures that user data is never saved on the internal memory.
 - Per default, if removable memory is **mounted**, user data is **saved permanently and only on this storage medium**.
You can access data saved on the removable memory just as data stored in the `/var/user/`.
 - If volatile mode is activated or there is **no memory mounted or it is removed** during operation, user data is stored **temporarily in the volatile memory** of the instrument.
This data is lost once the instrument is switched off.
- Store user files **temporarily in the `/var/volatile` directory**, which remains available only until the instrument is switched off.
You can access data saved in volatile memory just as data stored permanently in the `/var/user/`.
See also [Chapter 11.8.3, "How to Display All Saved Files"](#), on page 307.
- Activate the **volatile mode** so that no user data can be written to the internal memory permanently.
The removable memory is protected, too.

Instead, you can only save user data:

- Temporary in the volatile memory
- On a connected external storage device, such as a memory stick

See also:

- ["Default storage location"](#) on page 288
- ["Volatile Mode"](#) on page 341
- [Chapter 11.9.4, "Using a USB Storage Device for File Transfer"](#), on page 315

11.4 Saving and Recalling Instrument Settings

Possibly you would like to restore or repeat a signal generation you performed under specific conditions on the instrument. Or, in a test setup with more than one signal generator, you want to transfer the used settings to another R&S SMA100B. In these cases, you can save and recall instrument and user settings, and possibly other related data.

Save/Recall the complete instrument settings

Two different methods are available for managing *complete instrument settings*:

- Immediate (quick) Save/Recall
A defined set of instrument settings are saved or recalled quickly in just one step, without defining a filename or storage location. This function enables a fast switching between different instrument settings.
- Save/Recall in files with user-defined names
The defined set of instrument settings are stored to a definable storage location. The file extension is `*.savrc1.txt`.
Settings files created in this way are visible in the file system and accessible with the supported methods for file handling.

In the general case, a recall process replaces the instruments settings with the saved values. An exception is the frequency and level settings. During recall of the instrument settings, it is possible to retain the current settings or to overwrite them with the stored values.



Accessing and recalling instrument setups

For quick access to a stored instrument setup file, assign the appropriate action to the [**★** (User)] key.


See [Chapter 12.2.3, "Assigning Actions to the \[**★** \(User\)\] Key"](#), on page 331.

11.4.1 Save/Recall Settings

To access the dialog for storing and loading the complete instrument settings

1. Select "System Config > Save/Recall".

2. Select "Operation Mode > Save or Recall" to access the corresponding settings.
The provided settings for both operations are similar and closely related.



Settings:

Operation Mode.....	297
Directory, File List and Filename.....	297
Recent files.....	298
Show SCPI List.....	298
SCPI List.....	298
Save.....	298
Save Immediate x.....	298
Exclude Frequency.....	298
Exclude Level.....	299
Recall.....	299
Recall Immediate x.....	299
File Manager.....	299

Operation Mode

Accesses the settings for storing ("Save") and loading ("Recall") of the instrument settings, or for exporting created SCPI files ("SCPI-Export").

See [Chapter 11.6, "Exporting Remote Command Lists"](#), on page 302.

Directory, File List and Filename

Note:

You access this generic standard function each time you perform one of the following:

- Save or load (settings) files
- Define a folder in that these files are saved

- Navigate through the file system.

The dialog name changes depending on the context. The provided functions are self-explanatory and similar.

Use the settings for example as follows:

- To navigate through the file system, use the directory tree.
- To create a file, load and save files, use the dedicated functions **"New"**, **"Select"**, **Save**, and **Recent files**.
- To access the general data list editor, use the **"Edit"** button (see also [Chapter 7.7, "List Editor"](#), on page 191).
- To perform standard file management functions, like create directories, move, copy, delete files and/or directories, use the standard **"File Manager"** function (see [Chapter 11.8, "Using the File Manager"](#), on page 303).

Remote command:

To list all files in a directory:

`:MMEMory:CDIRectory` on page 424

`:MMEMory:CATalog?` on page 423

`[:SOURce] :CORRection:CSET:CATalog?` on page 591

Recent files

Displays the files last used.

Show SCPI List

Opens the "SCPI List", which lists the current settings of the R&S SMA100B as SCPI commands.

The R&S SMA100B provides this function for [Operation Mode > SCPI-Export](#).

SCPI List

Contains a list of all SCPI commands corresponding to the current instrument settings.

See also ["How to create a SCPI list with the current instrument settings in one step"](#) on page 398

Save

Saves the current instrument settings under the defined filename.

Remote command:

`:MMEMory:STORe:STATe` on page 427

Save Immediate x

Stores the current instrument setting in one of the intermediate memories.

These instrument settings are retained until a different instrument setting is stored in the intermediate memory. When the instrument is switched off, the contents of the intermediate memories are retained.

Remote command:

`*SAV` on page 415

Exclude Frequency

The current frequency is retained when a stored instrument setting is loaded.

Remote command:

[\[:SOURce<hw>\]:FREQuency\[:CW|FIXed\]:RCL](#) on page 597

Exclude Level

The current level is retained when a stored instrument setting is loaded.

Remote command:

[\[:SOURce<hw>\]:POWer\[:LEVel\]\[:IMMediate\]:RCL](#) on page 640

Recall

Restores the selected configuration.

During recall, the instrument considers all related settings, for example sweeps in active state or lists. An error message indicates the settings which cannot be implemented.

Remote command:

[:MMEMory:LOAD:STATe](#) on page 426

Recall Immediate x

Loads the selected configuration from one of the intermediate memories. A message appears if no instrument configuration is stored in this memory.

Remote command:

[*RCL](#) on page 415

File Manager

Accesses the "File Manager" dialog, see [Chapter 11.8, "Using the File Manager"](#), on page 303.

11.4.2 How to Save and Recall Instrument Settings

Instrument settings can be saved to a file and loaded again later, so that you can repeat the tests with the same settings.



Accessing and recalling instrument setups

For quick access to a stored instrument setup, assign the appropriate action to the [**★** (User)] key.

See [Chapter 12.2.3, "Assigning Actions to the \[**★** \(User\)\] Key"](#), on page 331.

To save and recall instrument settings quickly

1. Select "System Config > Save/Recall" > "Operation Mode > Save".
2. Select "Save Immediate 1".

The instrument saves its settings in the intermediate memory 1. The filename and the storage location cannot be changed.

3. Adapt the instrument settings as required. Select "Save Immediate 2"
4. To restore the settings, select the "Operation Mode > Recall"

5. Select "Recall Immediate 1"
The instrument is restored to the previous state.
6. Select "Recall Immediate 2" to switch to the settings stored in the second file.

To save complete instrument settings

1. Select "System Config > Save/Recall" > "Operation Mode > Save".
2. In the file selection dialog, select a filename and storage location for the settings file.
3. Select "Save".
A file with the defined name and path and the extension *.savrc1.txt is created.

To restore instrument's configuration

Save the configuration as described in ["To save complete instrument settings"](#) on page 300.

1. To restore settings, select "System Config > Save/Recall" > "Operation Mode > Recall".
2. To retain the current frequency and level settings, enable "Save/Recall > Exclude Frequency/Level"
3. In the file selection dialog, select the filename and storage location of the settings file.
The settings are restored, but the frequency and level settings are retained; you can repeat the signal generation with the same settings.
See also [Chapter 11.2.3, "How to Recall User Settings Automatically after Preset"](#), on page 293.

11.5 Accessing Files with User Data


Signal generation in list mode, the generation of pulse train signals or applying user correction values use data from list files. Whenever a list file is required as a data source, the instrument provides direct access to the standard "File Select" function. This function enables you to select, create and edit the list files.

11.5.1 File Select Settings

The "File Select" dialog opens automatically each time the signal generation requires list file as data source.

To access a loadable data list file

1. Select "Sweep" > List Mode Data > List Mode Data.
A "File Select" dialog for loading, creating and modifying a file is displayed.



Tip: The name of the dialog is context-sensitive and differs depending on the particular function this dialog is from. However, the provided functions are similar.

2. To load an existing file:
Navigate through the file system.
Select the file and confirm with "Select".
3. To create a file, for example if there is no data list file specified:
Navigate through the file system.
Select "New" and specify the filename.
A new empty file is created and saved in the selected folder.
4. To edit an existing or newly created file:
Navigate through the file system.
Select the file and select "Edit".
The standard "Data List Editor" dialog opens
5. Edit the file content.
Confirm with "Save".

Settings:

Directory, File List and Filename	301
Functions for handling of data lists	302
Recent files	302
File Manager	302

Directory, File List and Filename

Note:

You access this generic standard function each time you perform one of the following:

- Save or load (settings) files
- Define a folder in that these files are saved
- Navigate through the file system.

The dialog name changes depending on the context. The provided functions are self-explanatory and similar.

Use the settings for example as follows:

- To navigate through the file system, use the directory tree.
- To create a file, load and save files, use the dedicated functions "New", "Select", Save, and Recent files.
- To access the general data list editor, use the "Edit" button (see also [Chapter 7.7, "List Editor"](#), on page 191).
- To perform standard file management functions, like create directories, move, copy, delete files and/or directories, use the standard "File Manager" function (see [Chapter 11.8, "Using the File Manager"](#), on page 303).

Remote command:

To list all files in a directory:

`:MMEMory:CDIRectory` on page 424

`:MMEMory:CATalog?` on page 423

`[:SOURce] :CORRection:CSET:CATalog?` on page 591

Functions for handling of data lists

Provided are the following standard functions for file handling:

"Select" Select and load the file.

Remote command:

`[:SOURce<hw>] :LIST:SElect` on page 626

`[:SOURce<hw>] :PULM:TRAI:n:SElect` on page 542

`[:SOURce<hw>] :CORRection:CSET [:SElect]` on page 590

"New" Creates file with the specified "Filename".
To confirm, select "OK"; use "Cancel" to undo the operation.
To edit the file content, select "File Select > Edit".

"Edit" Accesses the "Data List Editor" and loads the selected file for editing

Recent files

Displays the files last used.

File Manager

Accesses the "File Manager" dialog, see [Chapter 11.8, "Using the File Manager"](#), on page 303.

11.6 Exporting Remote Command Lists

To set specific instrument settings or perform tasks automatically, you can create scripts that contain the settings in the form of remote control command sequences.

The R&S SMA100B also offers an SCPI macro recorder with code generator that is used to record manual settings and create an executable script, see [Chapter 13.14, "How to Record / Create SCPI Lists"](#), on page 397.

Completed scripts are stored in files and possibly converted to different formats, depending on the used language of the source code.

The R&S SMA100B supports the following commonly used languages:

- Plain SCPI: *.txt
- MATLAB: *.m
- NICVI: *.c

It is also possible to convert the SCPI command list to a user-specific language, see [Chapter 13.15, "How to Convert and Save SCPI Lists"](#), on page 400.

11.7 Loading, Importing and Exporting Lists

The R&S SMA100B provides built-in editors for creating list files, for example for the list mode or lists with user correction data. You can also create or evaluate them with an external application. The instrument provides interfaces with the following functionality:

- Import and export list files in a standard ASCII format file

Lists are saved and loaded in the corresponding dialogs. For example, the user correction data list is created and stored in the "User Correction" dialog.

11.8 Using the File Manager

The "File Manager" is a tool similar to a standard Windows Explorer. It helps you manage mass storage media and files stored on the R&S SMA100B.


You can perform the following tasks:

- Copying multiple files from disk to other media
See [Chapter 11.9, "How to Transfer Files from and to the Instrument"](#), on page 310
- Copying files into another directory
See [Cut, Copy&Paste and Delete](#)
- Renaming and deleting files
- Creating directories
See [Create New Directory](#)
- Mapping shared network folders
See [Chapter 11.8.4, "How to Map a Network Folder"](#), on page 307
- Displaying saved files
See [Chapter 11.8.3, "How to Display All Saved Files"](#), on page 307

Access:

- ▶ Select "System Config > Save/Recall" > "File Manager".

Tip: Each "Save/Recall" dialog and each "File Select" dialog provides a quick access to the "File Manger", i.e. whenever you select data lists or files with user data.



The "File Manager" dialog provides all standard functions required for file management. It displays the contents of the selected folder on the R&S SMA100B and provides functions to rename, delete, copy, or move individual files.

11.8.1 File Manager Settings

Access:

- ▶ Select "System Config > Save/Recall" > "File Manager".

Settings:

Map Network Share.....	305
File Type.....	305
Directory and Filename.....	305
Cut, Copy&Paste and Delete.....	305
Rename	305
Create New Directory.....	305

Map Network Share

Accesses the [Map Network Share Settings](#) dialog where you can map one or more network folders.

See also [Chapter 11.8.4, "How to Map a Network Folder"](#), on page 307.

File Type

Selects the file type to be listed. If a file type with a specific file extension is selected, only files with this extension are listed.

See [Chapter C, "Extensions for User Files"](#), on page 744 for an overview of the supported file extensions.

Directory and Filename

Selects the directory in which the file to be deleted or copied is located. The dialog lists all files in this directory. Selected files are highlighted. The path is indicated above the directory tree.

Unlike the "Save/Recall" and "File Select" dialogs, the "File Manager" displays the full filenames including extensions.

Remote command:

[:MMEMory:CDIRectory](#) on page 424

Cut, Copy&Paste and Delete

Standard file management functions.

Before a file is deleted, you have to confirm the delete operation.

Remote command:

[:MMEMory:DELeTe](#) on page 426

[:MMEMory:COpy](#) on page 424

Rename

Renames the selected file or directory.

Remote command:

[:MMEMory:MOVE](#) on page 427

Create New Directory

Creates a folder and opens an edit dialog box to enter name and path (absolute or relative to the current directory) of the new folder.

Remote command:

[:MMEMory:MDIRectory](#) on page 426


11.8.2 Map Network Share Settings

Access:

- ▶ Select "System Config > Save/Recall" > "File Manager > Map Network Share".

The "Map Network Share" dialog provides settings that are similar to the standard Windows Explorer function "Map network drive". These settings help you to create up to 10 "shortcuts" to shared folders or computers in the network.

The dialog displays a list of current mapped network folders. The directory tree of the "File Manager", "Save/Recall", and "File Select" dialogs indicate a mapped network folder as /shares/<"Local Folder">.



See also [Chapter 11.8.4, "How to Map a Network Folder"](#), on page 307.

Settings:

Network Folder	306
Local Folder	306
User Name	307
Password	307
Reconnect at Startup	307
Connect	307
Change	307
Disconnect	307

Network Folder

Enter the path of the folder or computer, e.g. //<IP Address>/user or //<server name>/user.

Local Folder

Enter a letter or an alias name to describe the folder.

In the directory tree, a mapped network folder is indicated as `/shares/`
<"Local Folder">.

User Name

Enter a user name of a user that has the permission to access the selected network folder.

Password

Enter the password of the selected user.

Reconnect at Startup

Enables reconnecting every time you start up the instrument.

Connect

Triggers the instrument to prove the credential and to map (i.e. connect) the selected network folder or computer to the instrument.

You can map up to 10 network folders.

Change

Applies the changes.

Disconnect

Disconnects the network drive.

11.8.3 How to Display All Saved Files

To display all files on the internal memory

1. Select "System Config > Save/Recall" > "File Manager".
2. Navigate to `/var/user/`.

To display all files on a connected USB flash drive

1. Select "System Config > Save/Recall" > "File Manager".
2. Navigate to `/usb/`.

To display all files in the volatile memory

1. Select "System Config > Save/Recall" > "File Manager".
2. Navigate to `/var/volatile/`.

11.8.4 How to Map a Network Folder

Possibly you would like to transfer instrument or user settings to another R&S SMA100B, distribute waveform files to several instruments or you have to access

frequently the same network drive. In these cases, on a R&S SMA100B connected to a LAN you can create a shortcut to this network folder or this computer.


For information on how to set up a LAN connection, refer to:

- [Chapter 3.1.3, "Setting Up a Network \(LAN\) Connection"](#), on page 29
- [Chapter 13, "Network Operation and Remote Control"](#), on page 351

To map a network folder, proceed as follows:


1. On the computer or the network folder you want to map, enable remote access. You can specify a list of users allowed for remote access. The remote access settings depend on the operating system the remote computer is using. For step-by-step instructions, refer to the documentation of the particular operating system.
2. On the R&S SMA100B, [enable file transfer via SMB \(samba\)](#).
3. Select "System Config > Setup > Remote Access > Network". Select:
 - a) "Address Mode > Auto (DHCP)"
 - b) Check that the "DNS Suffix" and "DNS Server" are correct.
4. In the "Save/Recall" dialog, select "File Manager > Map Network Share".
5. In the "Map Network Share" dialog, select:
 - a) In the "Network Folder" field, enter `//<IP Address>/user` or `//<Server Name>/user`.
 - b) In the "Local Folder" field, enter an alias name, e.g. *setups*.
 - c) Enter the "User Name" and "Password" of a user with a remote access permission to the selected network folder.
 - d) If necessary, enable "Reconnect at Startup".
 - e) Select "Connect".

The selected network folder is mapped to your instrument. The list of mapped network folders is updated.



6. Close the "Map Network Share" dialog.

The navigation tree in the "File Manager" dialog displays the mapped network folder as /shares/Setups.





If the connection does not succeed, consider to check the following:

- Is the network folder or computer you try to map turned on?
- Is the network folder or computer enabled for remote access?
- Does the selected user name have the necessary permissions?

See also [Chapter 11.9.5, "Using a File Server for Test Files Exchange"](#), on page 315.

11.9 How to Transfer Files from and to the Instrument

As explained in ["File handling"](#) on page 289, you access the file system of the R&S SMA100B via one of the following ways:

- Via the built-in "File Manager"
See [Chapter 11.8, "Using the File Manager"](#), on page 303.
- On an instrument connected to a LAN:
 - Via one of the standard functions ftp or SMB (samba)
See [Chapter 11.9.2, "Accessing the File System of the R&S SMA100B Via ftp"](#), on page 312 and
[Chapter 11.9.3, "Accessing the R&S SMA100B File System Via SMB \(Samba\)"](#), on page 313
 - Via mapped network drives
See [Chapter 11.8.4, "How to Map a Network Folder"](#), on page 307.
- Via a connected USB storage device
See [Chapter 11.9.4, "Using a USB Storage Device for File Transfer"](#), on page 315

Mainly because of security reasons, the access to the file system of your R&S SMA100B can be denied, because one or all these access methods are deliberately disabled. Access to the file system via LAN and/or USB requires that the corresponding service is enabled and a write access to the file system is enabled. Refer to [Chapter 11.9.1, "Removing File System Protection"](#), on page 310 for description of the required steps.

This section provides an introduction to the topic. For comprehensive information, refer to the application note [1GP72: Connectivity of Rohde&Schwarz Signal Generators](#).

- [Removing File System Protection](#)..... 310
- [Accessing the File System of the R&S SMA100B Via ftp](#)..... 312
- [Accessing the R&S SMA100B File System Via SMB \(Samba\)](#)..... 313
- [Using a USB Storage Device for File Transfer](#)..... 315
- [Using a File Server for Test Files Exchange](#)..... 315

11.9.1 Removing File System Protection

Before you try to access the file system via ftp, SMB (samba) or USB, fulfill the following:

- Disable write protection on the file system

- Enable the corresponding service or interface

To enable write permission on the file system

1. Select "System Config > Setup > Security > Security > General"
2. Enable "Volatile Mode"
3. Enter the "Security Password".
The default password is 123456. For more information, see [Chapter 12.4, "Using the Security Settings"](#), on page 337.
4. Select "System Config > Setup > Maintenance > Shut Down"
5. Select "Reboot".
The system reboots. The enabled settings are active.

To enable file transfer via ftp

1. Select "System Config > Setup > Security > Security > LAN Services".
2. Enable "LAN Interface"
3. Enable "FTP"
4. Enter the "Security Password".
The default password is 123456. For more information, refer to [Chapter 12.4, "Using the Security Settings"](#), on page 337.
5. Select "Accept".

To enable file transfer via SMB (samba)

1. Select "System Config > Setup > Security > Security > LAN Services"
2. Enable "LAN Interface"
3. Enable "SMB (Samba)"
4. Enter the "Security Password".
The default password is 123456. For more information, refer to [Chapter 12.4, "Using the Security Settings"](#), on page 337.
5. Select "Accept".

To enable file transfer via USB

1. Select "System Config > Setup > Security > Security > General"
2. Enable "USB Storage"
3. Enter the "Security Password".
The default password is 123456. For more information, refer to [Chapter 12.4, "Using the Security Settings"](#), on page 337.
4. Select "Accept".

11.9.2 Accessing the File System of the R&S SMA100B Via ftp

If the R&S SMA100B is connected to a LAN, you can use file transfer protocol (ftp) to access the file system and to transfer files from and to the instrument.

For information on how to set up a LAN connection, refer to:

- [Chapter 3.1.3, "Setting Up a Network \(LAN\) Connection"](#), on page 29
- [Chapter 13, "Network Operation and Remote Control"](#), on page 351

To access the file system via ftp

We assume that the instrument and the remote PC are connected to a LAN.

1. [Enable file transfer via ftp](#)
2. [Enable write permission on the file system](#)
3. On the remote PC, start the Windows Explorer.
4. In the address field, enter `ftp://<"IP Address" of the Instrument>`, e.g. `ftp://10.124.0.166`.

Tip: The R&S SMA100B indicates its IP address on the home screen.

A log-on dialog opens and requests a password.

The default user name and password is *instrument*.

Tip:


Default password

The FTP and SAMBA file access use the user "instrument" with default password "instrument".

We recommend that you change this password in the "Setup > Security > Password Management > Change User Password" dialog before connecting the instrument to the network.

See [Chapter 12.4.4, "Password Management"](#), on page 347.

5. Enter the password to access the `user` directory.
The `user` directory corresponds to the `/var/user/` directory of the instrument.




There, you can perform standard functions like creating directory, or saving files.

6. In the `user` directory, create a directory, e.g. `test ftp`.
7. Select "System Config > Save/Recall".

Open the `/var/user/` directory.

The dialog displays the `/var/user/test ftp` directory.



11.9.3 Accessing the R&S SMA100B File System Via SMB (Samba)

The SMB (Samba) protocol is an alternative way to access the file system of the instrument from a remote PC. This protocol works if both the instrument and the PC are connected to a LAN.

For information on how to set up a LAN connection, refer to:


- [Chapter 3.1.3, "Setting Up a Network \(LAN\) Connection"](#), on page 29
- [Chapter 13, "Network Operation and Remote Control"](#), on page 351

To access the file system via SMB

We assume that the instrument and the remote PC are connected to a LAN.

1. [Enable file transfer via ftp](#)
2. [Enable write permission on the file system](#)
3. On the remote PC, start the Windows Explorer.
4. In the address field, enter `\\<"IP Address" of the Instrument>`, e.g. `ftp://10.124.0.166`.

Tip: The R&S SMA100B indicates its IP address on the home screen.



The `user` directory corresponds to the `/var/user/` directory of the instrument; the `volatile` directory - to the `/var/volatile` directory.

To map the R&S SMA100B as a network drive to the remote PC

We assume that the instrument and the remote PC are connected to a LAN.

1. [Enable file transfer via SMB \(Samba\)](#)
2. [Enable write permission on the file system](#)
3. On the remote PC, start the Windows Explorer. Open the "Map Network Drive" dialog.
 - a) Select a valid "Drive", e.g. *W*.
 - b) In the "Folder" field, enter `//<"IP Address" of the Instrument>/user` or `//<"Hostname" of the Instrument>/user`
For example: `//10.124.0.166/user` or `//SMA100B-102030/user`.
Tip: The R&S SMA100B indicates its IP address on the screen.
 - c) Select "Finish".

A log-on dialog opens and requests a user name and a password.

The default user name and password is *instrument*.

Tip:

Default password


The FTP and SAMBA file access use the user "instrument" with default password "instrument".

We recommend that you change this password in the "Setup > Security > Password Management > Change User Password" dialog before connecting the instrument to the network.

See [Chapter 12.4.4, "Password Management"](#), on page 347.

4. Enter the user name and the password of your instrument.

The `/var/user/` directory of the instrument is mapped to and displayed as a network drive of the remote PC.



You can access the files in the `/var/user/` directory, perform standard function like creating directory, or storing files.

11.9.4 Using a USB Storage Device for File Transfer

Alternatively to the file transfer possibility via LAN, you can use a USB storage device for direct file transfer from and to the instrument.

We recommend that you transfer files with user data (like lists or instrument setup files) to the instrument, rather than load and play them from a connected USB storage device.

To transfer a file with user data to the instrument

1. Connect a USB storage device, for example a USB memory stick to one of the USB interfaces of the instrument.
The R&S SMA100B recognizes the connected USB storage device automatically.
2. [Enable file transfer via USB](#)
3. [Enable write permission on the file system](#)
4. Select "System Config > Save/Recall".
The dialog displays the `/var/user/` directory and the `/usb/` drive.
5. In the "Save/Recall" dialog, select "File Manager".
6. In the directory tree, navigate to the `/usb/` drive.
Select the required file with user data.
7. Select "Copy".
8. In the directory tree, navigate to the `/var/user/` directory.
Select "Paste".
The file with user data is transferred to the instrument.

11.9.5 Using a File Server for Test Files Exchange

You can use a central file storage location like a file server in your company network to store setup files, SCPI scripts, application programs, or waveform files on it. Usually, you would like to distribute the files to several instruments. If the R&S SMA100Bs are connected to a LAN, you can create a shortcut on the instruments to the file server.

To access the file server

1. On each R&S SMA100B, map the required directory of the file server to the instrument.
Perform the steps described in [Chapter 11.8.4, "How to Map a Network Folder"](#), on page 307.

- On each R&S SMA100B, use the same alias name for the directory of the file server, i.e. enter the same "Local Folder" (in this example *Setups*).

On any of the R&S SMA100B, you access the file server directly from the "File Manager" and under the same name, e.g. `/shares/Setups`.

An extra advantage in remote control is that the same application program would control the instruments.

For example, use the remote control command `MMEemory:CDIRectory "/shares/Setups"` to set the default directory for mass storage.

11.10 Creating Screenshots of Current Settings


The save/recall function enables you to save current settings in a file. To document the most important settings for a performed signal generation, you can also save a hardcopy of the current display.

- [Hardcopy Settings](#).....316
- [How to Save a Hardcopy of the Display](#).....320

11.10.1 Hardcopy Settings

Access:

- ▶ Select "System Config > Setup > User Interface > Hardcopy".



The remote commands required to define these settings are described in [Chapter 14.11, "HCOPY Subsystem"](#), on page 444.

Settings:

File.....	317
Format.....	317
Options.....	317
Save.....	317
Hardcopy Options > Common.....	317
L Automatic Naming.....	318
L Format.....	318
L Region.....	318
Hardcopy Options > Automatic Naming.....	318
L Path.....	319
L Clear Path.....	319
L Prefix, Year, Month, Day.....	319
L Current Auto Number.....	319

File...

In "Automatic Naming > Off" mode, accesses the standard file select dialog for selecting the filename and folder the hardcopy is stored in.

If you have enabled "Automatic Naming", the instrument displays the automatically generated filename.

Remote command:

`:HCOPY:FILE[:NAME]` on page 446

Format

Selects the output file format, for example *.bmp, *.jpg*.xpm and *.png.

Remote command:

`:HCOPY:IMAGe:FORMat` on page 446

`:HCOPY:DEVIce:LANGUage` on page 446

Options...

Accesses [Hardcopy Options](#) dialog.

Save

Saves a hardcopy of the current display as a file.


Remote command:

`:HCOPY[:EXECute]` on page 447

Hardcopy Options > Common

Access: select "Hardcopy > Options... > Common".

With the provided settings, you can customize the file format and the syntax of the automatically assigned filename.



Automatic Naming ← Hardcopy Options > Common

If enabled, creates the output filenames automatically according to the rules set with the [Hardcopy Options > Automatic Naming](#) settings.

Remote command:

[:HCOPY:FILE\[:NAME\]:AUTO:STATE](#) on page 448

Format ← Hardcopy Options > Common

Selects the output file format, for example *.bmp, *.jpg*.xpm and *.png.

Remote command:

[:HCOPY:IMAGE:FORMAT](#) on page 446

[:HCOPY:DEVICE:LANGUAGE](#) on page 446

Region ← Hardcopy Options > Common


Displays the snapshot area.

Remote command:

[:HCOPY:REGION](#) on page 446

Hardcopy Options > Automatic Naming

Access: select "Hardcopy > Options... > Automatic Naming".



Provided are the following settings:

Path... ← Hardcopy Options > Automatic Naming

Selects the directory.

Note: To select the destination path, specify also a filename. Otherwise an error message is displayed and selection is canceled.

Remote command:

[:HCOPY:FILE\[:NAME\]:AUTO:DIRectory](#) on page 447

Clear Path ← Hardcopy Options > Automatic Naming

Deletes all image files with extensions *.bmp, *.jpg, *.png and *.xmp in the directory set for automatic naming.

Before the command is executed, a warning message prompts you to confirm the deletion of the files.

Remote command:

[:HCOPY:FILE\[:NAME\]:AUTO:DIRectory:CLEar](#) on page 448

Prefix, Year, Month, Day ← Hardcopy Options > Automatic Naming

Determines the rules for "Automatic Naming".

Per default, the automatically generated filename is composed of:

<Path>/<Prefix><YYYY><MM><DD><Number>.<Format>, where Y, M and D mean year, month, Day; Number is the [Current Auto Number](#).

You can activate or deactivate each component separately.

The "Resulting filename" indicates the current filename syntax.

Remote command:

[:HCOPY:FILE\[:NAME\]:AUTO\[:FILE\]:PREFix](#) on page 449

[:HCOPY:FILE\[:NAME\]:AUTO\[:FILE\]:PREFix:STATe](#) on page 449

[:HCOPY:FILE\[:NAME\]:AUTO\[:FILE\]:YEAR:STATe](#) on page 448

[:HCOPY:FILE\[:NAME\]:AUTO\[:FILE\]:MONTH:STATe](#) on page 448

[:HCOPY:FILE\[:NAME\]:AUTO\[:FILE\]:DAY:STATe](#) on page 448

Current Auto Number ← Hardcopy Options > Automatic Naming

Indicates the number which is used in the automatically generated filename.


Note: When initially switching on the instrument, the number is reset to the lowest possible value. Starting with number 0 the output directory is scanned for existing files. As long as files with the same name are existing, the number is increased by 1. The number is automatically set so that the resulting filename is unique within the selected path. The current number is not in the save/recall file but is temporarily stored within the database. At the following save operation, the number is increased.

Remote command:

[:HCOPY:FILE\[:NAME\]:AUTO\[:FILE\]:NUMBer?](#) on page 449

11.10.2 How to Save a Hardcopy of the Display

1. Select "System Config > Setup > User Interface > Hardcopy".



2. To define the output format, select "Format > JPG".
3. To enable the instrument to create output filenames, select "Automatic Naming > On".
4. Select "Options...".
5. In the "Hardcopy Options" dialog:
 - a) To change the default directory the file is saved in, select "Automatic Naming Settings > Path" and define a path and a filename. For example, select the default directory `/var/user`.
 - b) If necessary, disable or change some of the parameters in the "Automatic Naming Settings".
 - c) Close the "Hardcopy Options" dialog.
6. In the "Hardcopy" dialog, select "Save".
The instrument saves a hardcopy of the current instrument display as a `*.jpg` file. The filename is automatically created.
7. To print the hardcopy, connect the instrument to a LAN and:
 - a) Transfer the file to a remote computer as described in [Chapter 11.9, "How to Transfer Files from and to the Instrument"](#), on page 310.
 - b) On the remote computer, navigate through the file system.

- c) Print the selected file.
For more information, refer to the online help of the operating system.

12 General Instrument Functions

The general instrument functions include basic instrument settings, regardless of the selected operating mode and measurement. Some of these settings like screen display and peripherals are initially configured at the setup of the instrument, according to personal preferences and requirements. However, you can individually adjust the settings at any time, for example, if necessary for specific applications.

The following special functions help you in service and basic system configuration:

- [Chapter 12.1, "Customizing the User Interface"](#), on page 322
Allows you to adjust the display and keyboard language settings.
- [Chapter 12.3, "Managing Licenses and License Keys"](#), on page 333
If you have purchased an additional option for the R&S SMA100B, you can enable it using a license key.
- [Chapter 11.2, "Restoring the \(Default\) Instrument Configuration"](#), on page 290
At any time, you can restore a default configuration to start a measurement at a defined instrument state, or set the instrument to factory preset.
- [Chapter 15.3, "Performing Maintenance Tasks"](#), on page 692
Special functions like calibration routines and self-tests put your instrument to an initial state.
- [Chapter 12.4, "Using the Security Settings"](#), on page 337
Special security and protection functions protect your instrument from unauthorized use or activate specific test routines.

12.1 Customizing the User Interface

The R&S SMA100B provides basic alignments of instrument settings regarding the user interface, that means the touch panel (screen), the appearance of the displayed dialogs and graphics, and an external keyboard.

Start / stop display update

The operating system of the R&S SMA100B refreshes the displayed settings by default in almost real-time, to keep the display updated with the internally used values. However, you can turn off this function to reduce settling times when the instrument is remote controlled.



We recommend that you switch off the display update for optimum sweep performance with short dwell times and for fast settling times.

Consider that in this case the displayed values can differ from the operated values.

In detail described in the following paragraphs, you can:


- Set display and keyboard language, see [Chapter 12.1.1, "Display and Keyboard Settings"](#), on page 323

- Set date and time for the system clock, see [Chapter 15.3.1, "Date and Time Settings"](#), on page 694
- Configure and activate a [Screen Saver](#)
- Deactivate display update to improve performance, see [Chapter 12.1.2, "Display Update Settings"](#), on page 324
- Determine the state of the RF signal, and the level display in the status bar when you turn on the R&S SMA100B, see [Chapter 12.1.3, "Defining the RF Signal State On Power On"](#), on page 325.

12.1.1 Display and Keyboard Settings

Access:

1. Select "System Config > Setup > User Interface > Display/Keyboard > Display".



2. Select "Display/Keyboard > USB Keyboard".



In the "Display/Keyboard" dialog, you can change regional and language options for the GUI and an external keyboard, and define the screen saver settings.

The remote commands required to configure the display and keyboard are described in [Chapter 14.9, "DISPlay Subsystem"](#), on page 438 and [Chapter 14.12, "KBOard Subsystem"](#), on page 449.

Screen Saver	324
Wait Time	324
Display	324
RF Hardkey	324
USB Keyboard > Layout	324

Screen Saver

Activates the screensaver.

If activated, the display including backlight is switched off after the selected **Wait Time** elapses and if no entries via touch panel, front panel, external mouse, or external keyboard are made

Remote command:

`:DISPlay:PSAVe[:STATe]` on page 439

Wait Time

Enters the idle time that must elapse before the display lamp is shut off when no entries are made.

Remote command:

`:DISPlay:PSAVe:HOLDoff` on page 439

Display

Adjusts the brightness of the display.

Increase the value to turn up the display brightness.

Remote command:

`:DISPlay:BRIGhtness` on page 440

RF Hardkey

Adjusts the brightness of the [RF on/off] key.

Increase the value to change the contrast between the key and the front panel background color.

Remote command:

`:DISPlay:BUtTon:BRIGhtness` on page 440

USB Keyboard > Layout

Selects the language of an externally connected keyboard via USB. The function assigns the corresponding keys automatically.


Remote command:

`:KBOard:LAYout` on page 449

12.1.2 Display Update Settings

Access:

- ▶ Select "System Config > Setup > User Interface > Start/Stop Display Update".



This dialog enables you, to deactivate updating the display.

The remote command to switch off the display update is described in [Chapter 14.9, "DISPlay Subsystem"](#), on page 438.

Display Update is

Disables the automatic refreshing of the displayed values.

Remote command:

:DISPlay:UPDate on page 440


12.1.3 Defining the RF Signal State On Power On

As additional functions for the level settings, you can determine the state of the RF signal, and the level display in the status bar when you turn on the R&S SMA100B.

Power-On/EMF settings

Access:

- ▶ Select "Level" > "Power-On / EMF".



The "Power-On/EMF" dialog contains all settings for configuring the power-on behavior and the level display.

Settings:

Power-On State	325
Display Level as Voltage of EMF	325

Power-On State

Determines the RF signal output state when the instrument is switched on.

You can disable the RF output signal in general, or start it in the same state as it had been when it was switched off.

Remote command:

:OUTPut<hw>[:STATe]:PON on page 451

Display Level as Voltage of EMF

Activates display of the signal level as voltage of the EMF (no-load voltage).

If disabled, the level is displayed as a voltage over a 50 Ohm load.

Note:

The setting is not affected by an instrument preset ([Preset] key or *RST) and the "Save/Recall" function. It is reset only by factory preset.

Remote command:

[:SOURce<hw>] :POWer:EMF:STATe on page 635

12.1.4 How to Set the Initial Instrument Settings

This section describes how to set up the R&S SMA100B initially.

12.1.4.1 Setting the Keyboard Language

You can select the language of the external keyboard connected to the instrument.

To adjust the keyboard settings

1. Press the [Setup] key.
2. Select "User Interface > Keyboard".



3. Select the "Layout".


The dialog closes and the changes take effect immediately.

12.1.4.2 Setting the Screen Saver

You can enable a screen saver that automatically turns off the display after a user-defined period of time. The screen saver is activated if no settings are made on the touch screen, or via keys or the rotary knob during the selected wait time.

To activate the screen saver

1. Press the [Setup] key.
2. Select "User Interface > Display"
3. Activate the "Screen Saver".



4. Define the "Wait Time" in minutes.
The instrument turns off the display after the defined period of time.
5. To reactivate the display, tap the screen or press any key on the front panel.

To deactivate the screen saver

1. Press the [Setup] key.
2. Select "User Interface > Display"
3. Disable the "Screen Saver" state.

12.2 Organizing Frequently Used Settings as Favorites

The [★ (User)] key is a key with customizable function. Per default, pressing the key opens the "User Menu" but you can add or remove actions, too. You can add actions to be executed or function to be accessed upon pressing this key.

User menu and [★ (User)] key

These two functions work similar to the favorites function of browser or other programs. They allow you to create a list of frequently used actions or to group frequently used settings in one single dialog.

Possible applications

The ★ (User) key is useful in the following situations:

- There are functions or tasks you have to perform in a defined order but they are distributed among several dialogs
- There are functions or tasks you have to perform more frequently than others but they are not accessible via a front panel key.
- The required functions are grouped in a dialog that is not directly accessible from the blocks on the home screen.
- Your task involves the frequently loading and executing of certain SCPI scripts. Refer to [Chapter 13.14, "How to Record / Create SCPI Lists"](#), on page 397 for information on how to create an SCPI script.
- A quick access to saved setups is required.

Dialog identification

To identify each dialog, the instrument uses a dedicated dialog ID. The dialog ID contains the dialog position on the display and the current active tab. The action that triggers the instrument to open a dialog uses this identification.

Save/Recall vs. recall setup

Sometimes, you would like to restore a specific signal generation setup and perform further configurations based on this particular instrument state. The R&S SMA100B provides two ways to achieve this, by the "Save/Recall" function and by the "Recall Setup" function.

- "Save/Recall"
For a detailed description, refer to [Chapter 11.4, "Saving and Recalling Instrument Settings"](#), on page 296.
- "Recall Setup"
If the "Recall Setup" is the only one user action assigned to the [★ (User)] key, pressing this key triggers the R&S SMA100B to load *immediately* the user-defined preset file.


12.2.1 Using the User Menu for Fast Adjustments

By default, there is one predefined action assigned to the [★ (User)] key.




1. Press the [★ (User)] key.
The "User Menu" dialog opens.
If you execute this action for the first time, the dialog is empty.
2. Follow the instructions displayed in the "User Menu" dialog to build your own dialog with settings.
3. Alternatively, proceed as follows:
 - a) Open a dialog with settings you frequently use.
 - b) Select a parameter.

- c) Open the context menu and select "Add to User Menu".




A favorites icon ★ indicates that the parameter is used in the "User Menu".



The "User Menu" indication in the task bar confirms that "User Menu" with favorites is created.

- d) Press the [★ (User)] key.


The "User Menu" dialog shows all parameters that you have added to the list.



You can configure them, e.g .change state or set values, as you do in the particular dialog the entry originally appears.

4. To remove an entry, in select it (in the "User Menu" or in the particular dialog the entry originally appears).

Open the context menu and select "Remove from User Menu".



5. In the "User Menu", select "Clear User Menu" to remove all entries at once.

Settings


Clear User Menu

Removes all entries from the "User Menu" at once.

12.2.2 Define User Key Actions Settings

Access:

- ▶ Select "System Configuration > Setup > User Interface > Define User Key".



The dialog displays a list of the currently enabled actions and provides functions to define new, edit or remove existing actions. If no actions have been defined, the list is empty.

See [Chapter 12.2.3, "Assigning Actions to the \[★ \(User\)\] Key"](#), on page 331.

The remote commands required to define these settings are described in [Chapter 14.9, "DISPlay Subsystem"](#), on page 438.

Name

Enters a user-defined name for the action.

Wizard

Defines the action to be executed.

"Load SCPI Script"

Selecting the action load and executes the SCPI script.

"Recall Setup" Load a setup for quick access to the user-defined settings.

"Open Dialog"

Quick access to the selected dialog.

Select

Depending on the selected "Wizard", provides access to:

- The standard "File Select" function for loading of an SCPI script or setup file
- A list of the dialog IDs of all currently opened dialogs. The dialog ID is used for dialog identification in the remote control.
See [SCPI](#).

SCPI

For the currently selected action, displays the corresponding SCPI command with the associated parameter for dialog identification (dialog ID). The automatically displayed SCPIs are enabled for subsequent modification.

Remote command:

[:DISPlay:DIALog:OPEN](#) on page 442

See also [:DISPlay:DIALog:ID?](#) on page 441

Add, Change, Remove

Standard functions for managing of the actions.


Back to Execute Mode

Opens the "Select Action to Execute" dialog. Select an Action form the list to execute it.

To return to the "Define User Key Actions" dialogs, select [Select Action to Execute > Define Actions](#).

Select Action to Execute > Define Actions

Name	Action
Open User Menu	:DISP:DIAL:OPEN "CSetupDIgUserMenu"
Open	:DISP:DIAL:OPEN "CSetupFrontPanelKe..."

 Define Actions ...

Accesses the "Define User Key Actions" dialog.

12.2.3 Assigning Actions to the [★ (User)] Key

1. Open the dialog for that you are creating a quick access.
For example, select "Level > UCOR > Import/Export"
2. Select "System Configuration > Setup > User Interface > Define User Key".

3. To create an action:
 - a) Specify the "Name".
 - b) Select "Wizard > Open Dialog"
 - c) Select "Select" and select the dialog ID from the list

The corresponding SCPI command is automatically displayed and can be later modified.

4. Select "Add" to store the new action in the list of user key actions.

Name	Action
Open User Menu	:DISP:DIAL:OPEN "CSetupDlgUserMenu"
OpenUCORImportExportList	:DISP:DIAL:OPEN "DlgKeyRf_Ucor\$t3\$t0...

Name: OpenUCORImportExportList Wizard: Open Dialog Select

SCPI: :DISP:DIAL:OPEN "DlgKeyRf_Ucor\$t3\$t0\$t1"

Buttons: Add, Change, Remove, Back to Exec Mode ...

5. To execute the created action, press ★ (User).
 In the list of actions ("Select Action to Execute" dialog), navigate to the required action.
 In this example, this is "OpenUCORImportExportList".

Name	Action
OpenUCORImportExportList	:DISP:DIAL:OPEN "DlgKeyRf_Ucor\$t3\$t0...
Open User Menu	:DISP:DIAL:OPEN "CSetupDlgUserMenu"

The action is executed. The dialog opens.

12.3 Managing Licenses and License Keys

An option is ready to operate after it is enabled with a license keycode supplied with the option. The license key is delivered as a file or on paper. Unregistered licenses must be registered for a particular instrument before the corresponding option can be enabled for operation.



For reliable operation, a software option usually requires the latest firmware version. The required version is specified in the delivery. If your instrument works with a former firmware version, update the firmware before enabling the software option.

The firmware update is described in the R&S SMA100B service manual.


12.3.1 Manage License Keys Settings

This dialog is the central dialog for licenses registration and performing the required instrument-related steps during the process of unregistration.

Access:

1. Select "System Config > Setup > Instrument Assembly > Manage License Keys > New License".

2. Select "System Config > Setup > Instrument Assembly > Manage License Keys > Installed License Keys".



In the "New License" tab, you can activate licenses for newly purchased or newly registered options. The "Installed License Keys" tab enables you to cancel already registered options, or move licenses.

Settings

Device ID.....	334
Enter License Key.....	334
Import License Key from File.....	334
Export Deactivation Response to File.....	334
License Installation Info.....	334
Installed License Keys.....	335
L Show Inactive.....	335
L Show Deactivated.....	335
L Installed License Keys Table.....	335

Device ID

Displays the instrument-specific identification number. The device ID is a unique string with the following structure:

```
<stock number>-<serial number>-<checksum>
```

Enter License Key

Type here the license key provided with the option.

For license keys delivered as a file, use [Import License Key from File...](#)

Import License Key from File...

Opens a dialog for selecting the file with the license key.

Use this function also to import the deactivation key file generated by the R&S License Manager online tool (see [How to Move a Portable License](#)).

Export Deactivation Response to File...

Exports the generated deactivation response key to a file and opens a file management dialog to save the file.

This key is required during the unregistration process, e.g. when you want to deinstall an option or have a portable option, which you want to register later on another instrument (see [How to Move a Portable License](#)).

License Installation Info

Indicates status information on the performed actions.

Installed License Keys

Access: select "System Config > Setup > Instrument Assembly > Manage License Keys > Installed License Keys".

Comprises information on the installed options.

Show Inactive ← Installed License Keys

Enables the display of the inactive (expired) licenses in the [Installed License Keys Table](#).

Show Deactivated ← Installed License Keys

Enables the display of the deactivated licenses in the [Installed License Keys Table](#).

See [How to Move a Portable License](#) for information on how to activate deactivated licenses.

Installed License Keys Table ← Installed License Keys

Shows information on the currently installed options.

"Export License Key to File"

Opens a dialog to save the generated license key file. This file is required during the unregistration process.

If you have a portable unregistered option, you can register it later on another instrument (see [How to Move a Portable License](#)).

"Option"

Displays the option short designation.

Tip: Open the [Hardware Options/Software Options](#) dialog to retrieve more information about the installed options.

"License Count"

Displays the number of the licenses for the selected option key.

"License Type"

Displays the type of license.

A license type determines the common qualification application duration and the portability of a license. The following license types are provided: evaluation, permanent, portable, quantified, time-controlled with a duration of 1, 3, 6 or 12 months. A license can also be deactivated or expired.

For time limited licenses, the left time of applicability is displayed too.

"Registrations" (reserved for future use)**12.3.2 How to Move a Portable License**

This example is intended to explain how to perform the required steps at the instrument.

Use a USB flash drive to transfer the license key files between the instruments and the browser.



We assume knowledge about the handling of the R&S License Manager online tool and the description of the whole process.

1. Open your browser. Enter <https://extranet.rohde-schwarz.com/service>.
Select "Manage Licenses > Move Portable License".
The first step requires the Device IDs of the source and target instruments.
2. To find out the Device IDs, proceed as follows:
 - a) On the source instrument, select "System Config > Setup > Instrument Assembly > Manage License Keys > New License > Device ID".
 - b) On the target instrument, select "System Config > Setup > Instrument Assembly > Manage License Keys > New License > Device ID".
 - c) In the browser, select "Manage Licenses > Move Portable License > Select Devices" and enter the Device IDs.
3. On the source instrument, select "System Config > Setup > Instrument Assembly > Manage License Keys > Installed License Keys > License Keys Table".
Navigate to the portable license you want to move.
Select the "Export License to File" column.
A standard file manager dialog opens.
4. Enter a filename. Save the exported license key, e.g.
`k123_portable_key_to_move.xml`.
5. In the browser, select "Manage Licenses > Move Portable License > Select License (from file)" and select the exported license key.
Check the selection. Create the deactivation key. Save it to file.
6. On the source instrument, select "System Config > Setup > Instrument Assembly > Manage License Keys > New Licences > Import License Keys from File".
Select the transferred deactivation key.
7. On the source instrument, select "System Config > Setup > Instrument Assembly > Manage License Keys > New Licences > Export Deactivation Response to File".
8. In the browser, go to "Manage Licenses > Move Portable License > Install Deactivation Key (from file)".
Enter the deactivation response of the instrument.
The license is deactivated for the source instrument.
9. In the "Manage Licenses > Move Portable License", go to step "Create License" to generate a license key for this portable option and the selected target instrument.
Download the license key as a file. Transfer it to the target instrument.
10. In the target instrument, select "System Config > Setup > Instrument Assembly > Manage License Keys > New License > Import License Keys from File".
Select the created license key file.

The portable option is installed on the target instrument.

12.4 Using the Security Settings

The protection function of the R&S SMA100B offers several levels to activate particular functions like self-test or tests for service purposes specifically.

Protection

The five protection levels are automatically active on startup, the protection levels, that means all protected functions are locked.

To unlock a protection level:

- ▶ In the "System Config > Setup > Security > Protection", enter the correct password.

To lock a protection level:

- ▶ Clear the corresponding checkbox.

Protection levels

The following functions are protected in the respective levels:

- Protection level 1
Protects against accidental changes, like, for example, the clock and date, several internal adjustments functions and the self-test, as well as network settings or the instrument hostname.
You can access this level with the password 123456.
- Protection level 2
Unlocks protected service functions. It is accessible to authorized personnel of Rohde & Schwarz service department only.
- Protection level 3 to 5
Are reserved for factory internal use.

Security

The security concept of the R&S SMA100B helps you to protect your instrument against uncontrolled access and changes. All provided security services require that you enter the security password.

Provided security services are:

- **General** security parameters, such as:
 - **USB storage** that secures controlled access to the mass memory of the instrument
 - **Volatile mode** that prevents information to be written to the internal memory permanently.
 - **Sanitizing** that prevents the instrument from leaving a secure environment with stored user information.
 - **Annotation** frequency and amplitude prevent reading the display.
 - **Secure Update Policy** check that verifies the integrity and origin of the firmware package to be installed.

To access the settings of these topics, see [Setting Security Parameters > "Secure Update Policy"](#) on page 340.

- **Password** management secures controlled user access to the instrument
With the two-step password concept, you can assign a user-defined password for the operating system, and a security password for accessing the mass storage of the instrument.
See also [Chapter 12.4.4, "Password Management"](#), on page 347.
- **LAN services** secure controlled network access
You can individually lock and unlock the supported LAN interface services, see [Chapter 12.4.3, "Configuring LAN Services"](#), on page 345.
Remote control via LAN interface requires that the interface is activated, but you can enable the required services specifically.
- **User interface** prevents front panel operation and/or reading the display.

For more information, see the document R&S SMA100B Instrument Security Procedures.

12.4.1 Protection Level Settings

Access:

- ▶ Select "System Config > Setup > Security > Protection".

Protection Level 1	<input checked="" type="checkbox"/>	<div style="border: 2px solid orange; padding: 2px;"> Password ***** </div>
Protection Level 2	<input checked="" type="checkbox"/>	Password *****
Protection Level 3	<input checked="" type="checkbox"/>	Password *****
Protection Level 4	<input checked="" type="checkbox"/>	Password *****
Protection Level 5	<input checked="" type="checkbox"/>	Password *****

The "Protection" dialog provides access to the unlocking of different protection levels.

Several functions in the instrument are password-protected to prevent for example accidental changes, ["Protection"](#) on page 337.

The remote commands required to unlock a protected stage are described in [Chapter 14.17, "SYSTEM Subsystem"](#), on page 657.

Protection Level/Password

Unlocks the selected level of protection, if you enter the correct password.

The default protection level 1 password is 123456.

To lock the protection level again, clear the checkbox.


Remote command:

:SYSTem:PROTect<ch> [:STATe] on page 666

12.4.2 Setting Security Parameters

Access:

- ▶ Select "System Config > Setup > Security > Security > General".



In the "General" tab, you can determine the security level for firmware updates, and configure the security settings for the mass memory and manual operation.



All modified settings in this dialog are not applied until you enter the [Security Password](#) and confirm with [Accept](#).

12.4.2.1 Update Policy Security Settings

Access:

- ▶ Select "System Config > Setup > Security > Security > General > SW Update".



The SW Update tab enables you to select the security mode for firmware updates.

The remote commands available to control security settings are described in [Chapter 14.17, "SYSTem Subsystem"](#), on page 657.

Secure Update Policy

Allows you to configure the automatic signature verification for firmware installation.

To apply the change: enter the security password and confirm with "Accept". Otherwise the change has no effect.

See also:

- [Chapter 12.4, "Using the Security Settings"](#), on page 337 for more information on the security concept.
- The release notes for details on signature verification when installing new or former firmware versions, available at www.rohde-schwarz.com/firmware/sma100b.

"Confirm Unsigned"

Performs the signature verification.

If the check detects any discrepancies, the instrument issues a warning message. You can still update the firmware or reject updating.

This setting also enables you to downgrade the firmware version.

"All Packages" Accepts all packages without signature verification.

"R&S Signed Packages"

Performs the signature check.

If the check detects any discrepancies, the instrument issues a warning message and locks the update to this firmware.


Remote command:

`:SYSTem:SECurity:SUPolicy` on page 674

12.4.2.2 Disk & Memory Security Settings

Access:

- ▶ Select "System Config > Setup > Security > Security > General > Disk & Memory".



The "Disk & Memory" tab secures controlled access to the mass memory and prevents information from leaving a secure environment.

The remote commands available to control security settings are described in [Chapter 14.17, "SYSTEM Subsystem"](#), on page 657.

USB Storage

Activates the access to external USB storage media.

To apply the change: enter the security password and confirm with "Accept". Otherwise the change has no effect.

See also [Chapter 11.9.4, "Using a USB Storage Device for File Transfer"](#), on page 315.

Note: Remove all USB memory devices before disabling the USB storage. If any USB memory device remains connected, disabling is blocked, and the instrument returns a warning message.

The microSD card is also considered a USB memory device and must be removed. If you have sealed the SD card slot, you can not disable the USB storage.



Volatile Mode

Activates volatile mode, so that no user data can be written on the internal memory permanently.

In volatile mode:

- Data that the instrument normally stores on the internal memory is redirected to volatile memory.
- The user directory is mapped to the volatile memory. You access the temporary data just as data stored in the `/var/user/`, see [Chapter 11.3, "Protecting Data"](#), on page 295.
- Data on the internal memory cannot be changed. It is protected against modification or erasure.
- You can only save data:
 - Temporarily in the volatile memory
 - On a connected external storage device, such as a memory stick

To activate volatile mode: enter the security password, confirm with "Accept" and reboot the instrument. Otherwise the change has no effect.

Activated volatile mode is indicated by an icon.

Remote command:

`:SYSTem:SECurity:VOLMode[:STATe]` on page 666

Sanitize

Executes the erase procedure that sanitizes the internal memory.

If the instrument is subject to high security, and you have not enabled the volatile mode, the internal flash memory holds user-data, i.e. it poses a security risk. The sanitizing function makes sure that no user information is stored on the instrument when it leaves the secure environment.

To apply the change: enter the security password and confirm with "Accept". Otherwise the change has no effect.

See also [Chapter 12.4, "Using the Security Settings"](#), on page 337 for more information on the security concept.


Remote command:

`:SYSTem:SECurity:SANitize[:STATe]` on page 674

12.4.2.3 Manual Operation Security Settings

Access:

- ▶ Select "System Config > Setup > Security > Security > General > Manual Operation".



The "SW Update" tab enables you to lock front panel operation and/or reading the display.

The remote commands available to control security settings are described in [Chapter 14.9, "DISPlay Subsystem"](#), on page 438, and the [Chapter 14.17, "SYSTem Subsystem"](#), on page 657.

Annotation Frequency

Enables the display of the currently used frequency in the status bar.

To apply the change: enter the security password and confirm with "Accept". Otherwise the change has no effect.

Remote command:

:DISPlay:ANNotation:FREQuency on page 441

Annotation Amplitude

Enables the display of the currently selected level in the status bar.

To apply the change: enter the security password and confirm with "Accept". Otherwise the change has no effect.

Remote command:

:DISPlay:ANNotation:AMPLitude on page 440

User Interface

Allows you to lock the controls for manual operation and the display individually.

To apply the change: enter the security password and confirm with "Accept". Otherwise the change has no effect.

See also [Chapter 12.4, "Using the Security Settings"](#), on page 337 for more information on the security concept.

"Enabled" Enables the display and all controls for the manual operation of the instrument.

"Touchscreen Off"

Locks the touch sensitivity of the screen.

This security feature protects the instrument against unintentional change of settings by accidentally touching of the screen.

Still available controls for manual operation are:

- The keys at the front panel, including the rotary knob
- The external mouse and keyboard
- Remote operation over VNC


The instrument indicates the locked touchscreen by an icon .

Unlocking is possible via VNC, external controls or remote control.



"VNC Only"

Locks the keys at the front panel, the touchscreen and externally connected keyboard and mouse.

The display on the screen remains and shows the current settings and changes.

The instrument indicates the activated "VNC only" feature by the icon .

Unlocking is possible via VNC or turning off and on again.

- "Display Only" Locks the manual operation of the instrument. The display on the screen remains and shows the current settings and changes. This security feature protects the instrument against unauthorized access, but still shows the current settings and processes, for example when you operate the instrument via remote control.
- The function disables:
- The touchscreen functionality of the display
 - The keys at the front panel of the instrument
 - The external mouse and keyboard
- The instrument indicates the locked controls by a padlock  softkey. Unlocking is possible by entering the security password, see [Enabling a locked user interface for manual operation](#).
- "Disabled" Locks the display and all controls for the manual operation of the instrument. This security feature protects the instrument against unauthorized reading and access, for example when you operate the instrument via remote control.
- The function disables:
- The display
 - The touchscreen
 - The keys at the front panel of the instrument
 - The external mouse and keyboard
- The screen shuts off and displays a padlock symbol  instead. Unlocking is possible by entering the security password, see also [Enabling a locked user interface for manual operation](#).

Remote command:

:SYSTem:ULOCK on page 664


:SYSTem:DLOCK on page 663

:SYSTem:KLOCK on page 664

Enabling a locked user interface for manual operation

To unlock the user interface for manual operation, use one of the following:

- On the instrument's keypad or external keyboard, press any key. The instrument prompts you to enter the security password for unlocking.



Note: The character of the first key you pressed is immediately added in the input field. Delete the entry before inserting the password.

Enter the security password *123456*.

- In remote control mode, send the command `SYST:ULOC ENABled` to release all locks at once.
Alternatively:
 - Send the command `SYST:KLOC OFF` to unlock the keyboard and touchscreen
 - Send the command `SYST:DLOC OFF` to release all locks.

Via remote control, there is no password required.

Remote command:

:SYSTem:ULOCK on page 664


:SYSTem:DLOCK on page 663

:SYSTem:KLOCK on page 664

12.4.3 Configuring LAN Services

Access:

- ▶ Select "System Config > Setup > Security > Security > LAN Services".



In the "LAN Services" dialog, you can individually enable or disable the supported LAN interface services.



The activated LAN services are not activated until you enter the "Security Password" on page 346 and confirm with [Accept](#).

LAN

Enables the LAN interface in general, and thus provides remote access via all unlocked services.

Enable LAN Services individually

Enables or disables the following interface services individually.

"SCPI over LAN"	Activates access over LAN to control the instrument remotely, by using SCPI (Standard Commands for Programmable Instruments) commands. See also "Starting a remote control session over LAN with R&S VISA" on page 385.
"VNC"	Activates access via VNC (Virtual Network Computing) interface, a graphical desktop sharing system that uses RFB protocol to control the instrument remotely. See also Chapter 13.16, "How to Set Up Remote Operation via VNC" , on page 401.
"SSH"	Activates access via SSH (Secure Shell), a network protocol for secure data communication.
"HTTP"	Activates access via HTTP (Hyper Text Transfer Protocol), the application protocol for hypermedia information systems.
"FTP"	Activates access via FTP (File Transfer Protocol), used to transfer files from a host to the instrument and vice versa. See also Chapter 11.9.2, "Accessing the File System of the R&S SMA100B Via ftp" , on page 312.
"SMB (Samba)"	Activates access to SMB (Server Message Block), used for providing shared access to files, printers and serial ports of a network. See also Chapter 11.9.3, "Accessing the R&S SMA100B File System Via SMB (Samba)" , on page 313.
"Avahi (Zeroconf)"	Activates Avahi, a service for automatic configuration of the instrument in a network environment.
"Software Update"	Allows updating the software.

Security Password

Enters the password that is required to enable or to disable the settings protected by a security password. Default is 123456.

Note:

- We recommend that you change the default security password before connecting the instrument to the network.
- The security settings are not assigned until you select the "Accept" button.

Accept

Applies the modified settings, provided the security password is entered and correct.

12.4.4 Password Management

Access:

1. Select "System Config > Setup > Security > Security > Password Management > User Password".

The screenshot shows the 'Password Management' configuration page. At the top, there are tabs for 'General', 'LAN Services', and 'Password Management'. The 'Password Management' tab is active. Below the tabs, there is a section titled 'Valid for VNC, FTP and SMB (Samba) access'. This section contains several input fields: 'User Name' (with the value 'instrument'), 'Old Password', 'New Password', and 'Confirm Password'. To the right of these fields are two vertical tabs: 'User Password' (which is selected) and 'Security Password'. At the bottom of the form is a 'Change Password' button with a wrench icon.

In this tab, you can assign the security and a user-defined password.

2. Select "System Config > Setup > Security > Security > Password Management > Security Password".

This screenshot shows the same 'Password Management' configuration page, but with the 'Security Password' tab selected on the right. The 'User Name' field is no longer highlighted. The 'Old Password' field is now highlighted with an orange border. The 'New Password' and 'Confirm Password' fields remain visible. The 'Change Password' button is still present at the bottom.



A new password does not take effect until you confirm it with the corresponding "Change Password" button.

To confirm the new password, always press:

- "User Password" > [Change Password](#)
Or
- "Security Password" > [Change Password](#)

User Name

Indicates the user name used for access to the Linux operating system and valid for VNC, FTP and SMB (Samba) access.

User Password

Access: select "System Config > Setup > Security > Security > Password Management > User Password".

Allows you to change and confirm the user password.

Old Password ← User Password

Enters the current user password. The default password is "instrument".

Note: We recommend that you change the default password before connecting the instrument to a network.

New Password ← User Password

Enters the new user password.

The security password can contain decimal characters only.

Confirm Password ← User Password

Confirms the new user password by repeating.

Note: The new password is not assigned until you select the [Change Password](#) button.

Change Password ← User Password

Changes the user password accordingly.

Security Password

Access: select "System Config > Setup > Security > Security > Password Management > Security Password".

Enables you to change and confirm the security password.

Old Password ← Security Password

Enters the currently used security password. The default password is '123456'.

Note: We recommend that you change the default password before connecting the instrument to a network.

The security password is required when changing the status of the USB and LAN interface.

New Password ← Security Password

Enters the new security password.

The security password can contain decimal characters only.

Confirm Password ← Security Password

Confirms the new security password by repeating.

Note: The new password is not assigned until you select [Change Password](#) button.

Change Password ← Security Password

Changes the password accordingly.

12.5 Undoing or Restoring Actions


"Undo" is a function that removes the effect of the last action on the instrument and reverts it to an older state. Conversely, "Redo" restores a previously undone action.

You can "Undo/Redo" actions according to two criteria:

- Step by step
Gradually undo/redo the actions in reverse order as previously performed. Depending on the available memory the "Undo/Redo" steps may restore all actions.
- Multiple steps at once
Select any specific action in the history list to "Undo/Redo" multiple actions in a single step.
Note: This mode requires a system restoration file on the instrument.

Access:

- ▶ Select "Setup > Settings > Undo/Redo".



The dialog contains all functions for enabling the "Undo/Redo" functionality.

Settings:

State.....	350
History List.....	350
Clear History.....	350
Apply.....	350

State

Enables the recording of the performed actions.

History List

Lists the performed actions, provided "Undo/Redo" state is "On".

Clear History

Deletes the recorded list of the performed steps.

Apply

Performs the "Undo/Redo".

If you select a previously performed action of the list, all subsequent actions are undone. The list entries remain.


If you select a subsequently executed action, you can restore all the actions undone up to this state.

12.6 Shutting Down and Rebooting the Instrument

The [Power On/Standby] front panel key switches the instrument from the standby to the ready state or vice versa. In remote operation from a remote computer or in manual control, there is another possibility to shut down the instrument or to reboot the system.

Access:

- ▶ Select "System Config > Setup > Maintenance > Shut Down".

**Remote command:**

- `:SYSTEM:REBoot` on page 681
- `:SYSTEM:SHUTdown` on page 682

13 Network Operation and Remote Control



The description in this section requires basic knowledge of the remote control operation. Definitions specified in the SCPI standard are not provided.

You find some basic information to the SCPI syntax, command lists, and general programming recommendations in [Chapter A.1, "Additional Basics on Remote Control"](#), on page 715. See also [Chapter A.1.5, "Status Reporting System"](#), on page 727 for information on the status reporting system of the instrument.

As an alternative to the interactive operation directly at the instrument, you can operate the R&S SMA100B also from a remote location.

The [Figure 13-1](#) shows the possibilities of the physical connection (interfaces) for the remote access.




Figure 13-1: Supported remote connections



For information on how to configure a network, see the [Chapter 3.1.3, "Setting Up a Network \(LAN\) Connection"](#), on page 29.

The various interfaces provide flexible access to the instrument, such as *remote control*, *remote operation* or *remote file access*. These remote access modes are fundamentally different, although they are often considered interchangeable. Refer to [Overview of Remote Access Modes](#) for details on these modes.

For comprehensive information on these topics, refer to the application note [1GP72: Connectivity of Rohde&Schwarz Signal Generators](#).

13.1 Overview of Remote Access Modes

This section outlines the possible access modes and their major characteristics.

Remote control (SCPI)

- A remote PC controls the instrument, usually via VISA (Virtual Instrument Software Architecture) interfaces.
- Remote control disables the manual operation of the instrument; you can set different lock states.
- The GUI is not visible.
- Remote control commands (SCPI) perform the settings, either individually or in sequences (SCPI programs).
- Using SCPI programs is faster than the manual operation, since they automate repeating applications.

Remote operation (VNC)**NOTICE****Risk of unauthorized access**

If the VNC service is enabled on the instrument, any user in the network who knows the computer name and password can access it.

Disable the VNC service on the instrument to prevent unauthorized access.

- A remote device accesses the instrument via the common platform technology VNC (Virtual Network Computing).
- The protocol allows simultaneous operation from several remote devices and the instrument nevertheless remains locally operable.
- The GUI is visible.
- To perform the settings, you can operate the instrument as with the manual control.
- Clients supporting remote operation depend on the used remote device, see [Table 13-1](#).

Table 13-1: Supported VNC operation modes

Remote device	VNC client	Requirements	Characteristics
Desktop (Windows, Linux, Mac™OS)	<ul style="list-style-type: none"> • Ultr@VNC • Other dedicated client software 	<i>Ultr@VNC or Client Software</i> must be installed.	Fast, supports several options like full screen mode or auto-login.
	<ul style="list-style-type: none"> • Any web browser 	<i>Java Runtime</i> must be installed and activated in the browser settings.	Fast and convenient - only the instrument address required. Java runtime is sometimes considered as security concern.
	<ul style="list-style-type: none"> • Web browser with HTML5 	<i>Web sockets</i> must be supported.	Slower than the other modes. No additional installation or activation required. No security concern.

Remote device	VNC client	Requirements	Characteristics
Smart device (Tablet/ smartphone)	<ul style="list-style-type: none"> Dedicated client App 	<i>App</i> must be installed.	Fast, supports several options like full screen mode or auto-login.
	<ul style="list-style-type: none"> Web browser with HTML5 	<i>Web sockets</i> must be supported.	Support of QR code scanning Slower than a dedicated App.

Remote file access (FTP, SAMBA/SMB)

- A remote client accesses the instrument's file system, using the protocols FTP (file transfer protocol) and SAMBA/SMB (server message block).
- The protocols enable you to transfer files from or to the instrument and to get direct access to its file sharing directory *share*.

For more information, refer to [Chapter 11.9, "How to Transfer Files from and to the Instrument"](#), on page 310.

13.2 Remote Control Interfaces and Protocols

The instrument supports various interfaces for remote control. The table gives an overview on the connectivity:

Table 13-2: Remote control interfaces and protocols

Interface	Protocols, VISA ^{*)} address string and library	Remarks
Local area network (LAN)	<ul style="list-style-type: none"> HiSLIP High-Speed LAN Instrument Protocol (IVI-6.1) TCP/IP::host address::hislip0[::INSTR] VISA VXI-11 TCP/IP::host address[::LAN device name][::INSTR] VISA Socket communication (Raw Ethernet, simple Telnet) TCP/IP::host address[::LAN device name]::<port>::SOCKET VISA or socket controller 	<p>The LAN connector is on the rear panel of the instrument.</p> <p>The interface is based on TCP/IP and supports various protocols.</p> <p>For a description of the protocols, refer to:</p> <ul style="list-style-type: none"> Chapter 13.2.1.2, "HiSLIP Protocol", on page 356 Chapter 13.2.1.3, "VXI-11 Protocol", on page 356 Chapter 13.2.1.4, "Socket Communication", on page 356
USB	<ul style="list-style-type: none"> USBTMC USB::<vendor ID>::<product ID>::<serial number>[::INSTR] VISA 	<p>The USB In connector is located at the rear panel of the instrument.</p> <p>For a description of the interface, refer to Chapter 13.2.2, "USB Interface", on page 357</p>
GPIB (IEC/IEEE Bus Interface)	<ul style="list-style-type: none"> – GPIB::<address>[::INSTR] (no secondary address) VISA 	<p>Optional GPIB bus interfaces according to standard IEC 625.1/IEEE 488.1 are located on the rear panel of the instrument.</p> <p>For a description of the interface, refer to Chapter 13.2.3, "GPIB Interface (IEC/IEEE Bus Interface)", on page 358.</p>

^{*)} VISA (Virtual Instrument Software Architecture) is a standardized software interface library providing input and output functions to communicate with instruments. A VISA installation on the controller is a prerequisite for remote control over LAN (when using VXI-11 or HiSLIP protocol), USB and serial interface. For remote control via socket communication VISA installation is optional. For more information, see [Chapter 13.3.1, "VISA Library"](#), on page 359.



Rohde & Schwarz provides the standardized I/O software library R&S VISA for communication with the instruments via TCP/IP (LAN: HiSLIP, VXI-11 and raw socket) or USB (USBTMC) interfaces.

R&S VISA is available for download at the Rohde & Schwarz website <http://www.rohde-schwarz.com/rsvisa>.

How to configure the remote control interfaces is described in [Chapter 13.8, "How to Set Up a Remote Control Connection"](#), on page 380.

SCPI (Standard Commands for Programmable Instruments)

SCPI commands - messages - are used for remote control. Commands that are not taken from the SCPI standard follow the SCPI syntax rules. The instrument supports the SCPI version 1999. The SCPI standard is based on standard IEEE 488.2 and aims at the standardization of device-specific commands, error handling and the status registers. The tutorial "Automatic Measurement Control - A tutorial on SCPI and IEEE 488.2" from John M. Pieper (Rohde & Schwarz order number 0002.3536.00) offers detailed information on concepts and definitions of SCPI.

Tables provide a fast overview of the bit assignment in the status registers. The tables are supplemented by a comprehensive description of the status registers.

For more information, see also [Chapter A.1, "Additional Basics on Remote Control"](#), on page 715.

13.2.1 LAN Interface

To be integrated in a LAN, the instrument is equipped with a LAN interface, consisting of a connector, a network interface card and protocols.

For remote control via a network, the PC and the instrument must be connected via the LAN interface to a common network with TCP/IP network protocol. The TCP/IP network protocol and the associated network services are preconfigured on the instrument. Software for instrument control and (for specified protocols only) the VISA program library must be installed on the controller.



Identifying instruments in a network

If several instruments are connected to the network, each instrument has its own IP address and associated resource string. The controller identifies these instruments by the resource string.

13.2.1.1 VISA Resource Strings

The VISA resource string is required to establish a communication session between the controller and the instrument in a LAN. The resource string is a unique identifier, composed of the specific IP address of the instrument and some network and VISA-specific keywords.

TCPIP::host address[::LAN device name][::INSTR]

TCPIP = designates the network protocol
 host address = designates the IP address or hostname of the instrument
 [::LAN device name] = defines the protocol and the instance number of a subinstrument
 [::INSTR] = indicates the instrument resource class (optional)

The **IP address** (host address/computer name) is used by the programs to identify and control the instrument. It is automatically assigned by the DHCP server the first time the device is registered on the network. Alternatively, you can also assign its **LAN device name**.

If assigned, the IP address is displayed on home screen. You can adjust it manually with the parameter the "System Config > Remote Access > Network" > [IP AddressEnabling a locked user interface for manual operation](#).

The following section lists the characteristics of the VISA resource strings for the corresponding interface protocols. The highlighted characters are crucial.

HiSLIP

TCPIP::host address::**hislip0**[::INSTR]

hislip0 = HiSLIP device name, designates that the interface protocol HiSLIP is used (mandatory)

hislip0 is composed of [::HiSLIP device name[,HiSLIP port]] and must be assigned.

For details of the HiSLIP protocol, refer to [Chapter 13.2.1.2, "HiSLIP Protocol"](#), on page 356.

VXI-11

TCPIP::host address[::**inst0**][::INSTR]

[::inst0] = LAN device name, indicates that the VXI-11 protocol is used (optional)

inst0 currently selects the VXI-11 protocol by default and can be omitted.

For details of the VXI-11 protocol, refer to [Chapter 13.2.1.2, "HiSLIP Protocol"](#), on page 356.

Socket communication

TCPIP::host address::**port::SOCKET**

port = determines the used port number
 SOCKET = indicates the raw network socket resource class

Socket communication requires the specification of the port (commonly referred to as port number) and of "SOCKET" to complete the VISA resource string with the associated protocol used.

The registered port for socket communication is port 5025.

See also [Chapter 13.2.1.4, "Socket Communication"](#), on page 356.

13.2.1.2 HiSLIP Protocol

The HiSLIP (**H**igh **S**peed **L**AN **I**nstrument **P**rotocol) is the successor protocol for VXI-11 for TCP-based instruments specified by the IVI foundation. The protocol uses two TCP sockets for a single connection - one for fast data transfer, the other for non-sequential control commands (e.g. `Device Clear` or `SRQ`).

HiSLIP has the following characteristics:

- High performance as with raw socket network connections
- Compatible IEEE 488.2 support for Message Exchange Protocol, Device Clear, Serial Poll, Remote/Local, Trigger, and Service Request
- Uses a single IANA registered port (4880), which simplifies the configuration of firewalls
- Supports simultaneous access of multiple users by providing versatile locking mechanisms
- Usable for IPv6 or IPv4 networks



Using VXI-11, each operation is blocked until a VXI-11 device handshake returns. However, using HiSLIP, data is sent to the device using the "fire and forget" method with immediate return. Thus, a successful return of a VISA operation such as `viWrite()` does not guarantee that the instrument has finished or started the requested command, but is delivered to the TCP/IP buffers.

For more information see also the application note:

[1MA208: Fast Remote Instrument Control with HiSLIP](#)

13.2.1.3 VXI-11 Protocol

The VXI-11 standard is based on the ONC RPC (Open Network Computing Remote Procedure Call) protocol which in turn relies on TCP/IP as the network/transport layer. The TCP/IP network protocol and the associated network services are preconfigured. TCP/IP ensures connection-oriented communication, where the order of the exchanged messages is adhered to and interrupted links are identified. With this protocol, messages cannot be lost.

13.2.1.4 Socket Communication

An alternative way for remote control of the software is to establish a simple network communication using sockets. The socket communication, also referred to as "Raw Ethernet communication", does not necessarily require a VISA installation on the remote controller side. It is available by default on all operating systems.

The simplest way to establish socket communication is to use the built-in telnet program. The telnet program is part of every operating system and supports a communi-

cation with the software on a command-by-command basis. For more convenience and to enable automation by means of programs, user-defined sockets can be programmed.

Socket connections are established on a specially defined port. The socket address is a combination of the IP address or the host name of the instrument and the number of the port configured for remote-control. All R&S SMA100B use port number 5025 for this purpose. The port is configured for communication on a command-to-command basis and for remote control from a program.

13.2.2 USB Interface

Option: R&S SMAB-B86

For remote control via the USB connection, the PC and the instrument must be connected via the USB type B interface. A USB connection requires the VISA library to be installed. VISA detects and configures the R&S instrument automatically when the USB connection is established. You do not have to install a separate driver.

USBTMC (USB Test & Measurement Class Specification) is a protocol that is built on top of USB for communication with USB devices, like GPIB. It defines class code information of the instrument, that identifies its functionality to load the respective device driver. Using VISA library, it supports service request, triggers, and other specific operations, similar to GPIB.

13.2.2.1 USB Resource String

The resource string represents an addressing scheme that is used to establish a communication session with the instrument. It is based on the instrument address and some instrument- and vendor-specific information.

The USB resource string syntax is as follows:

`USB::<vendor ID>::<product ID>::<serial number>[::INSTR]`

USB	= denotes the used interface
<vendor ID>	= is the manufacturer ID for Rohde & Schwarz
<product ID>	= is the product identification of the instrument
<serial number>	= is the individual serial number on the rear of the instrument
[:: INSTR]	= indicates the instrument resource class (optional)

To set the USB resource string, see [Remote Access Settings](#).

Example:

`USB::0x0AAD::0x01DD::100001`

0x0AAD is the vendor ID for Rohde & Schwarz.

0x01DD is the product ID for the R&S SMA100B

100001 is the serial number of the particular instrument.

13.2.3 GPIB Interface (IEC/IEEE Bus Interface)

Option: R&S SMAB-B86

To be able to control the instrument via the GPIB bus, the instrument and the controller must be linked by a GPIB bus cable. A GPIB bus card, the card drivers and the program libraries for the programming language used must be provided in the controller.

GPIB address

The controller must address the instrument with the GPIB bus channel (see [Chapter 13.4.3, "GPIB Address Settings"](#), on page 367). GPIB provides channel addresses from 0 to 30.

The GPIB resource string syntax is as follows:

GPIB::<address>[:INSTR]

GPIB = denotes the used interface
 <channel address> = the used channel
 [:INSTR] = indicates the instrument resource class (optional)

Note: If the VISA implementation supports the GPIB interface, you can optionally define the VISA Instrument Control Resource (INSTR). It is used to define the basic operations and attributes for a device, such as reading, writing, or triggering.

Notes and characteristics

In connection with the GPIB interface, note the following:

- Up to 15 instruments can be connected.
- The total cable length is restricted to a maximum of 15 m, or 2 m times the number of devices, whichever is less. The maximum recommended cable length between two instruments is 2 m.
- A wired "OR"-connection is used if several instruments are connected in parallel, since the slowest instrument determines the speed.



Any connected IEC bus cable must be terminated by an instrument or controller.

13.2.4 LXI Browser Interface

The LXI browser interface allows easy configuration of the LAN and remote control of the R&S SMA100B without additional installation requirements. The instrument's LXI browser interface works correctly with all W3C compliant browsers.

See [Chapter 13.17.1, "LXI Functionality"](#), on page 407 for more about LXI.

The LAN settings are configured using the instrument's LXI browser interface described in [Chapter 13.5.2.1, "LAN Configuration"](#), on page 375. The LXI status settings in

the R&S SMA100B are described in [Chapter 13.5.1, "LXI Status Settings"](#), on page 372.

13.3 Remote Control Programs and Libraries

This section shows how the remote-control programs access the instrument, and the libraries they require for the appropriate interface protocols.




Figure 13-2: Overview of remote control interfaces, protocols and libraries

13.3.1 VISA Library

VISA is a standardized software interface library providing input and output functions to communicate with instruments. Thus, you can configure the interface without having to adjust the application program to the used interface. The I/O channel (LAN or TCP/IP, USB, GPIB,...) is selected at initialization time with the channel-specific address string ("VISA resource string"), or by an appropriately defined VISA alias (short name). See also [Table 13-2](#) for an overview.

Instrument access via VXI-11 or HiSLIP protocols is achieved from high level programming platforms using VISA as an intermediate abstraction layer. VISA encapsulates the low-level VXI or GPIB function calls and thus makes the transport interface transparent for the user.

A VISA installation is a prerequisite for remote control using the following interfaces:

- LAN interface using [HiSLIP Protocol](#)
- LAN interface using [VXI-11 Protocol](#)
- [USB Interface](#)

Instrument access via the LAN socket protocol or GPIB connections can be operated both, with or without the VISA library. See also [Chapter 13.2.1.4, "Socket Communication"](#), on page 356 and [Chapter 13.2.3, "GPIB Interface \(IEC/IEEE Bus Interface\)"](#), on page 358.

For more information about VISA library, refer to the user documentation.

13.3.2 Possible Setups and Access Functions

The following examples give an overview of dependencies between the available libraries, the possible interfaces and protocols, and whether an instrument driver is provided. The involved parts are **highlighted**. For more information, see the application note [1GP72: Connectivity of Rohde&Schwarz Signal Generators](#).

- Remote control (application) program using VISA




Figure 13-3: Application program using VISA

Protocol	Remote control program
Socket	<code>viOpen (... , "TCPIP:SMA100B-102030::5025::SOCKET", ...)</code> <code>viPrintf (... , "SOUR:FREQ 2GHz\n")</code>
VXI-11	<code>viOpen (... , "TCPIP:SMA100B-102030::inst0::INSTR", ...)</code> <code>viPrintf (... , "SOUR:FREQ 2GHz\n")</code>
HiSLIP	<code>viOpen (... , "TCPIP:SMA100B-102030::hislip0::INSTR", ...)</code> <code>viPrintf (... , "SOUR:FREQ 2GHz\n")</code>
USBTMC	<code>viOpen (... , "USB::0x0AAD::0x01DD::100001::INSTR", ...)</code> <code>viPrintf (... , "SOUR:FREQ 2GHz\n")</code>
GPIB	<code>viOpen (... , "GPIB::28::INSTR", ...)</code> <code>viPrintf (... , "SOUR:FREQ 2GHz\n")</code>

- Remote control program using instrument driver (VISA available)




Figure 13-4: Application using instrument driver (VISA available)

Protocol	Remote control program
Socket	<code>rssma_init ("TCPIP:SMA100B-102030::5025::SOCKET", ...)</code> <code>rssma_SetFrequency (... , 2e9)</code>
VXI-11	<code>rssma_init ("TCPIP:SMA100B-102030::inst0::INSTR", ...)</code> <code>rssma_SetFrequency (... , 2e9)</code>
HiSLIP	<code>rssma_init ("TCPIP:SMA100B-102030::hislip0::INSTR", ...)</code> <code>rssma_SetFrequency (... , 2e9)</code>
USBTMC	<code>rssma_init ("USB::0x0AAD::0x01DD::100001::INSTR", ...)</code> <code>rssma_SetFrequency (... , 2e9)</code>
GPIB	<code>rssma_init ("GPIB::28::INSTR", ...)</code> <code>rssma_SetFrequency (... , 2e9)</code>

- Remote control program using instrument driver (VISA **not** available)




Figure 13-5: Remote control program using instrument driver (VISA not available)

Protocol	Remote control program
Socket	<pre>rssma_init ("TCPIP:SMA100B-102030::5025::SOCKET", ...) rssma_SetFrequency (... , 2e9)</pre>
GPIB	<pre>rssma_init ("GPIB::28::INSTR", ...) rssma_SetFrequency (... , 2e9)</pre>

13.4 Remote Access Settings

This section outlines the settings required for accessing and configuring the provided remote control interfaces. It includes network settings, access addresses, emulation settings for using the command sets of other generators, and the access via smart devices.

About instrument emulations

You can also remotely control the R&S SMA100B via the command set of another signal generator, as, for example, of an HP generator. With this function you can, for example, replace a signal generator with an R&S SMA100B in an automated test setup, without adjusting the command scripts used.



The R&S SMA100B also covers command sets of Rohde & Schwarz signal generators. To achieve optimal compatibility when replacing an instrument, we recommend that you select the emulation command set for the corresponding signal generator.

You find all the remote control command sets supported by the R&S SMA100B in a selection list.

For more information, see the application note:

[1GP120: Remote Emulation with the R&S SMA100B Signal Generator.](#)

The selected instrument also defines the identification string that is retrieved with query `*IDN?`. If necessary, use the parameter [Mode](#) and [IDN String](#) to change this string.

As any other parameter, the remote control command set can also be changed remotely by the command `:SYSTem:LANGuage`.

While working in an emulation mode, the R&S SMA100B specific command set is disabled and the SCPI command `:SYSTem:LANGuage` is discarded.

To return to the SCPI command set of the R&S SMA100B, use the appropriate command of the selected command set. If for example an HP generator is emulated, the HP command `EX` returns to the instrument-specific GPIB command set.

13.4.1 Network Settings

NOTICE

Risk of network failure

Consult your network administrator before performing the following tasks:

- Connecting the instrument to the network
- Configuring the network
- Changing IP addresses

Errors can affect the entire network.

Access:

- ▶ Select "System Config > Remote Access > Network".

Net-work	Visa Res. Strings	GPIB Addr.	RS232	Instrument Emulations	Remote Connections	QR-Code	✕
Network Status		Connected		Restart Network			
Instrument Name							
Hostname		Workgroup					
instrument		INSTRUMENT					
Instrument Address							
Address Mode		Auto (DHCP)					
IP Address		Subnet Mask		Default Gateway			
10.124.0.211		255.255.252.0		10.124.0.1			
DNS Suffix		DNS Server		MAC Address			
rsint.net		10.0.2.166		08 00 27 b7 82 49			

In the "Network" dialog, you can configure the settings of the general network environment and specific identification parameters of the instrument in the network.

The remote commands required to configure the network remotely are described in [Chapter 14.17, "SYSTEM Subsystem"](#), on page 657.

How to connect the signal generator to the network is described in the [Chapter 3.1.3, "Setting Up a Network \(LAN\) Connection"](#), on page 29.

Network Status

Indicates that the instrument is connected to the network.

Remote command:

`:SYSTem:COMMunicate:NETWork:STATus?` on page 669

Restart Network

Terminates the network connection of the instrument and subsequently sets it up again. You can use this function to fix network problems.

Note: This function restarts only the connection of the instrument to the network. It does not impact the network itself.

Remote command:

`:SYSTem:COMMunicate:NETWork:REStart` on page 669

Hostname

Displays the hostname.

Each instrument is delivered with an assigned hostname, a logical name which can be used instead of the IP address. With the default network settings, the IP address is allocated by the DHCP server. This address can change each time the instrument is reconnected. Unlike the IP address, the hostname name does not change.

Note:

This function is password-protected. Unlock the protection level 1 to access it.

- We recommend that you do not change the default network settings or the hostname to avoid problems with the network connection.
If you change the hostname, be sure to use a unique name.

Remote command:

`:SYSTem:COMMunicate:NETWork[:COMMON]:HOSTname` on page 669

Workgroup

Sets the individual windows workgroup name of the R&S SMA100B. This parameter is required in case the instrument is integrated in a windows network.

This function is password-protected. Unlock the protection level 1 to access it.

Remote command:

`:SYSTem:COMMunicate:NETWork[:COMMON]:WORKgroup` on page 670

Address Mode

Selects the mode for assigning the IP address.

NOTICE! Risk of network failure.

Consult your network administrator before performing the following tasks:

- Connecting the instrument to the network
- Configuring the network
- Changing IP addresses

Errors can affect the entire network.

"Auto (DCHP)"

Assigns the IP address automatically, provided the network supports DHCP (Dynamic Host Configuration Protocol).

"Static"

Enables you to assign the IP address manually.

Remote command:

`:SYSTem:COMMunicate:NETWork:IPAddress:MODE` on page 668

IP Address

Displays the IP address of the instrument in the network.

By default, the R&S SMA100B is configured to use dynamic TCP/IP configuration and to obtain the whole address information automatically.

If the network does not support DHCP or the attempt does not succeed, the instrument tries to obtain the IP address via Zeroconf (APIPA) protocol. IP addresses assigned via Zeroconf start with the number blocks 169.254.*.*.

Note: An IP address that is assigned via the Zeroconf protocol although the network requires an IP address assigned via the DHCP server can cause network connection failures.

See [Chapter 16.5, "Resolving Network Connection Failures"](#), on page 712.

To assign the IP address manually, select [Address Mode](#) > "Static".

Remote command:

`:SYSTEM:COMMunicate:NETWork:IPADdress` on page 668

Subnet Mask

Displays the bit group of the subnet in the host identifier.

To assign the subnet mask manually, select [Address Mode](#) > "Static".

Remote command:

`:SYSTEM:COMMunicate:NETWork[:IPADdress]:SUBNet:MASK` on page 670

Default Gateway

Displays the gateway address.

This address identifies the router on the same network as the instrument that is used to forward traffic to destinations beyond the local network.

To assign the gateway address manually, select [Address Mode](#) > "Static".

Remote command:

`:SYSTEM:COMMunicate:NETWork[:IPADdress]:GATeway` on page 670

DNS Suffix

Displays the primary DNS (Domain Name System) suffix, that means the DNS name without the hostname part.

The DNS system uses the suffix for registration and name resolution for unique identification of the instrument in the entire network.

To assign the DNS suffix manually, select [Address Mode](#) > "Static".

Remote command:

`:SYSTEM:COMMunicate:NETWork[:COMMON]:DOMain` on page 669

DNS Server

Determines the preferred server for name resolution. The DNS server contains the underlying numerical values that are required for name resolution of the hostname as part of the IP address.

To select the DNS server manually, select [Address Mode](#) > "Static".

Remote command:

`:SYSTEM:COMMunicate:NETWork[:IPADdress]:DNS` on page 670

MAC Address

Indicates the MAC (Media Access Control) address, a unique identifier of the network adapter in the R&S SMA100B.


Remote command:

:SYSTem:COMMunicate:NETWork:MACaddress on page 668

13.4.2 VISA Resource Strings

Access:

- ▶ Select "System Config > Remote Access > Visa Resource Strings".



The "Visa Resource String" dialog displays the Visa resource strings provided for remote control via the different interfaces.

Remote command:

:SYSTem:COMMunicate:HISLip:RESource? on page 668

:SYSTem:COMMunicate:NETWork:RESource? on page 669

:SYSTem:COMMunicate:SOCKet:RESource? on page 672

:SYSTem:COMMunicate:GPIB:RESource? on page 667

:SYSTem:COMMunicate:USB:RESource? on page 672

:SYSTem:COMMunicate:SERial:RESource? on page 671

13.4.3 GPIB Address Settings

Access:

1. Select "System Config > Remote Access > GPIB Address".

Network	Visa Res. Strings	GPIB Addr.	RS232	Instrument Emulations	Remote Connections	QR-Code	X
GPIB Channel Address							
28							

2. Set the GPIB channel address of the connected instrument.

Remote command:

`:SYSTEM:COMMunicate:GPIB[:SELF]:ADDRESS` on page 667

13.4.4 RS232 Settings

Remote control via a serial interface is possible via a USB. The controller and the instrument must be connected with the external USB/serial-adapter R&S TS1-USB (see recommended extras in the data sheet) and a serial crossover (null modem) cable. A USB connection requires the Visa library to be installed on the controller. Visa detects and configures the R&S SMA100B automatically when the USB connection is established.

Access:

- ▶ Select "System Config > Remote Access > RS232".

Network	Visa Res. Strings	GPIB Addr.	RS232	Instrument Emulations	Remote Connections	QR-Code	X
Needs USB Adapter (R&S TS1-USB)							
Baud Rate		Parity		Stop Bits			
115200		None		1			

In the "RS232" dialog, you can configure the settings of the serial interface.

The remote commands required to configure the settings remotely are described in [Chapter 14.17, "SYSTEM Subsystem"](#), on page 657.

Baud Rate

Sets the baudrate for the serial remote control interface.

Remote command:

`:SYSTEM:COMMunicate:SERial:BAUD` on page 671

Parity

Sets the parity for the serial remote control interface.

Remote command:

:SYSTem:COMMunicate:SERial:PARity on page 671

Stop Bits

Sets the number of stop bits for the serial remote control interface.


Remote command:

:SYSTem:COMMunicate:SERial:SBITs on page 671

13.4.5 Instrument Emulations Settings

Access:

- Select "System Config > Remote Access > Instrument Emulations".



The "Instrument Emulations" dialog enables you to emulate a remote control command set of another signal generator.

The remote commands required to configure the emulation settings remotely are described in [Chapter 14.17, "SYSTem Subsystem"](#), on page 657.

Language

Selects the instrument whose remote command set is emulated by the R&S SMA100B.

Remote command:

:SYSTem:LANGuage on page 674

Mode

Selects the way the instrument identification is performed.

"Automatic" Sets the "IDN String" and the "OPT String" automatically for the instrument selected with the parameter [Language](#).

"User Defined" Enables you to define the "IDN String" and the "OPT String".

Remote command:

[:SYSTem:IDENtification](#) on page 672

Set to Default

In "Mode > User Defined", resets the *IDN and *OPT strings.

Remote command:

[:SYSTem:IDENtification:PRESet](#) on page 673

IDN String

Indicates the identification string of the instrument when queried with the common command *IDN?.

In addition to the preset values, you can define your own identification string so that each generator uses an individual identification, like `My_SigGen` for instance, see [Mode](#) .

Remote command:

[*IDN?](#) on page 413

[:SYSTem:IRESpOnse](#) on page 673

OPT String

Indicates the option string of the instrument as queried with common command *OPT?.

In [Mode](#) > "User Defined", you can define your own option string, additionally to the automatically created one.

Remote command:

[*OPT?](#) on page 414

[:SYSTem:ORESpOnse](#) on page 673


13.4.6 Remote Connections Settings

The "Remote Connections" dialog covers the active SCPI and TCP/IP connections, and a history list of the connections that have accessed the instrument before.

13.4.6.1 Active Connections

Access:

- ▶ Select "System Config > Remote Access > Remote Connections > Active".



The "Active " tab shows the currently active remote connections, and you can enable the display of the active connections in the task bar.

Show Remote Connections in Taskbar

Displays the currently active connections in the taskbar.

SCPI Connections

Displays the VISA resources strings of the remote connections currently controlling the instrument via the LAN interface.

Remote command:

n.a.

TCP/IP Connections

Displays the types and client addresses of the remote connections currently controlling the instrument via the LAN interface.


Remote command:

n.a.

13.4.6.2 Closed Connections

Access:

- ▶ Select "System Config > Remote Access > Remote Connections > Closed".



The "Closed" tab shows the currently active remote connections, and you can enable the display of the active connections in the task bar.

SCPI Connections

Lists the VISA resource strings of the last remote connections that have accessed the instrument via the LAN interface before.

Remote command:
n.a.

TCP/IP Connections

Lists the types and client addresses of the last remote connections that had accessed the instrument via the LAN interface before.

Remote command:
n.a.

13.4.7 QR Code

Access:

- ▶ Select "System Config > Remote Access > QR Code".



The "QR Code" dialog shows the current instrument address (IP address) in quick response (QR) format.

This functionality provides fast access to the instrument via VNC with, for example, a smartphone or a tablet.

See [Chapter 13.16.2, "Setting Up a Remote Operation from a Smart Device"](#), on page 404.

13.5 LXI Settings

On the R&S SMA100B the LXI functionality is already installed and enabled, see [LXI Status Settings](#). Thus, the instrument can be accessed via any web browser (like the Microsoft Internet Explorer) to perform the following tasks:


- Modifying network configurations
- Remote control the instrument
- Performing SCPI remote diagnostics

The LAN settings are configured using the instrument's LXI browser interface described in [Chapter 13.5.2.1, "LAN Configuration"](#), on page 375.

13.5.1 LXI Status Settings

Access:

- ▶ Select "System Config > Setup > Remote Access > LXI Status...".



The "LXI - Status" dialog shows the parameters of the LAN connection.

Alternatively, you can change the LAN settings using the LXI web browser interface, see [Chapter 13.5.2.1, "LAN Configuration"](#), on page 375.

LAN Status

The LED indicates the LXI status.

"green"	Normal operation
"green (flashing)"	Device identification
"red"	LAN fault

Hostname / MAC Address / IP Address

See ["Hostname"](#) on page 364.

LAN Reset

Initiates the network configuration reset mechanism for the instrument and resets the hostname, MAC address, and IP address.

According to the LXI standard, a LAN reset must place the following network settings to a default state:

Parameter	Value
TCP/IP mode	DHCP + Auto IP address
Dynamic DNS	Enabled
ICMP ping	Enabled
Password for LAN configuration	LxiWebIfc

The LAN reset also resets the following parameters for the Signal Generator:

Parameter	
Hostname	Instrument-specific hostname
Description	Vector signal generator
Negotiation	Auto detect
VXI-11 discovery	Enabled

13.5.2 LXI Browser Settings

To access the instrument via the web browser:

- ▶ In the address field of the browser on your PC, type the instrument's host name or IP address, for example *http://10.113.1.151*.

Note: Do not add the missing zeros in the IP address, while opening the instrument homepage.

The instrument homepage (welcome page) opens.

The navigation pane of the browser interface contains the following elements:

- "LXI"
 - "Home" opens the instrument homepage.
The homepage displays the device information required by the LXI standard, including the VISA resource string in read-only format.
 - "Device Indicator" activates or deactivates the LXI status indication.
When activated, the LXI LEDs flash, both in the browser dialog and in the LXI dialog of the connected instrument, see [LAN Status](#). A green LXI status symbol indicates that a LAN connection has been established; a red symbol indicates that no LAN cable is connected.
 - "Lan Configuration" allows you to configure LAN parameters and to initiate a ping, see ["Ping Client"](#) on page 376.
 - "Status" displays information about the LXI status of the instrument.
 - "Utilities" provides access to the LXI event log functionality required by the LXI standard.
- "Instrument Control"
 - "Web Control" provides remote access to the instrument, see ["Starting a remote control via the LXI web browser"](#) on page 381.
- "Diagnostics"
 - "SCPI Remote Trace" records messages exchanged via the remote control interface, see ["SCPI Remote Trace"](#) on page 377.
- "Help"
 - "Glossary" explains terms related to the LXI standard.
 - www.rohde-schwarz.com opens the Rohde & Schwarz homepage.
- "Data Sheet"
 - Provides the data sheet with the specification data of the instrument at the time of delivery, see ["Data Sheet"](#) on page 378.

13.5.2.1 LAN Configuration

The "LAN Configuration" web page displays all mandatory LAN parameters and allows their modification.

It comprises the following navigation entries.

- [IP Configuration](#)..... 375
- [Advanced Config](#).....376
- [Ping Client](#).....376
- [SCPI Remote Trace](#)..... 377
- [Data Sheet](#)..... 378

IP Configuration

The "IP configuration" web page displays all mandatory LAN parameters and allows their modification.

The screenshot shows the LXI LAN Parameters configuration page. The page has a navigation menu on the left with options like Home, LAN Configuration, IP Configuration, Advanced Config, Ping Client, Status, Utilities, Instrument Control, Web Control, Diagnostics, SCPI Remote Trace, Help, Glossary, and Datasheet. The main content area is titled 'LAN Parameters' and contains the following fields:

- Hostname: instrument
- DNS Hostname(s): instrument.rsint.net
- Domain: rsint.net
- Description: Instrument (FW version) Serial number
- IP Address Mode: DHCP + Auto IP Address
- IP Address: 10.113.1.151
- Subnet Mask: 255.255.252.0
- Default Gateway: 10.113.0.1
- Obtain DNS Server Address automatically:
- DNS Server(s): 10.0.2.166
- Register Device at DNS Server dynamically:

There is a 'Submit' button and a password field labeled '(Password required)'. A status bar at the bottom indicates 'No error'.

The "IP Address Mode" selects a configuration mode for the IP address of the instrument. With static configuration, the entered IP address, subnet mask, and default gateway are used. With dynamic configuration, DHCP or dynamic link local addressing (automatic IP) is used to obtain the instrument IP address.



Changing the LAN configuration

This function is password-protected. Unlock the protection level 1 to access it.

Note: We recommend that you change the default password before connecting the instrument to a network.

See [Chapter 12.4.4, "Password Management"](#), on page 347.

Advanced Config

The "Advanced Config" web page provides LAN settings that are not declared mandatory by the LXI standard.

The screenshot shows the LXI web interface. The left sidebar contains navigation links: Home, Lan Configuration (with sub-links for IP Configuration, Advanced Config, and Ping Client), Status, Utilities, Instrument Control (with sub-links for Web Control), Diagnostics (with sub-link for SCPI Remote Trace), Help (with sub-links for Glossary and www.rohde-schwarz.com), and Datasheet (with sub-link for Production Version). The main content area is titled "LAN Parameters" and contains three settings: "mDNS and DNS-SD" with a dropdown menu, "ICMP Ping enabled" with a checkbox, and "VXI-11 Discovery" with a checkbox. Below these settings is a "Submit" button and a password field labeled "(Password required)". At the bottom, a "Status" section shows "No error" and a copyright notice for © 2016 ROHDE&SCHWARZ.

The following advanced parameters are available:

- "mDNS and DNS-SD": The additional protocols "multicast DNS" and "DNS service discovery" are used for device communication in zero configuration networks, working without DNS and DHCP.
- "ICMP Ping": Must be enabled to use the ping utility. If you disable this setting, the instrument does not answer ping requests. The setting does not affect the LXI ping client. You can ping other hosts from the instrument, even if the setting is disabled.
- "VXI-11 Discovery": Must be enabled to detect the instrument in the LAN. If you disable this setting, the instrument cannot be detected by the VXI-11 discovery protocol mechanism. The setting does not affect other detection mechanisms. Setting up a VXI-11 connection via the IP address or the host name is independent of this setting.



Changing the LAN configuration

This function is password-protected. Unlock the protection level 1 to access it.

Note: We recommend that you change the default password before connecting the instrument to a network.

See [Chapter 12.4.4, "Password Management"](#), on page 347.

Ping Client

The "Ping Client" page provides the ping utility to verify the connection between the LXI-compliant instrument and another device.

The ping is initiated from the instrument. Using the ICMP echo request and echo reply packets, this function checks whether the communication with a device via LAN is working. Ping is useful for the diagnosis of IP network or router failures.

To initiate a ping at the instrument:

1. On the "Ping Client" page, enter the IP address of the host in the "Destination Address" field (for example 10.113.1.151).
2. Select "Submit".



SCPI Remote Trace


The remote trace functionality allows you to trace input and output strings at the remote control interface of the R&S SMA100B, see [Chapter 13.9, "Tracing SCPI Commands and Messages Exchanged via the LXI Web Browser Interface"](#), on page 389.

A recorded trace (message log) can be evaluated directly in the dialog. Use the highlighting and navigation functions provided by the lower toolbar to locate error messages and messages containing arbitrary search strings. You can also export the message log to a *.csv file and evaluate the file using a suitable program.

To trace and display messages, switch on "logging" and "live mode" in the toolbar.

Toolbars

The toolbar at the top of the dialog provides basic settings and functions.



- "Live mode" / "logging": If logging is switched on, messages are traced. They are stored in an internal database and can be displayed upon request, using the refresh button (live mode off) or they can be displayed automatically (live mode on).

- "Filter": applies a filter to columns and/or rows when working (live mode off)
- "Refresh": reads the message log from the internal database and displays it
- "Download": stores the SCPI trace log to a *.CSV file
- "Clear": deletes all message log entries in the database and at the screen
- "Details": displays details of the selected message, for example an SCPI command in hex format (also possible by double-clicking a message)

Columns


The following columns are available if no column filter is applied:

- "Rec": record number of the message within the message log
- I: number of the subinstrument
- "MT": indicates the type of the message. Possible values and related message contents are:
 - > = incoming command
 - < = outgoing response to a query
 - E = error message, highlighted by red color
 - T = execution time, i.e. time required by the instrument to process the command internally.
- "message": indicates the type of the message. Possible values and related message contents are:
 - > = incoming command
 - < = outgoing response to a query
 - E = error message, denoted in red
 - T = execution time, i.e. time required by the instrument to process the command internally

Data Sheet

The data sheet functionality allows you to retrieve the specification data of the instrument at the time of delivery.

The document contains all specified value ranges and information of the data sheet, for example important as reference values for recalibration.



13.6 How to Find the VISA Resource String

- ▶ Select "System Config > Remote Access > VISA Resource Strings".

Network	Visa Resource Strings	GPIB Address	RS232	Instrument Emulations	Remote Connections	QR-Code
HISLIP					TCPIP::10.124.1.212::hislip0::INSTR	
VXI11					TCPIP::10.124.1.212::inst0::INSTR	
Socket					TCPIP::10.124.1.212::5025::SOCKET	
GPIB						GPIB::28::INSTR
USB						USB::0x0AAD::0x01df::000000::INSTR
SERIAL						ASRL1::INSTR

The dialog shows all specified resource strings of the supported remote control interfaces.



- For information on how to assign the IP address manually, see [Chapter 3.1.3.3, "Assigning the IP Address"](#), on page 31.
- Also note that using the RS232 serial interface via USB requires the USB serial adapter R&S TS-USB1.

13.7 How to Change the GPIB Instrument Address

Option: R&S SMAB-B86

To control the instrument remotely via the GPIB bus, it must be addressed using the GPIB address. The remote control address is factory-set to 28, but it can be changed if it does not fit in the network environment. For remote control, addresses 0 through 30 are allowed. The GPIB address is maintained after a reset of the instrument settings.

To set the GPIB address:

1. Select "System Config > Remote Access > GPIB Address".
2. Select "GPIB Channel Address" and enter a value between 0 and 30.



Risk of losing remote connection

If the remote access and network settings had been configured to values different to the default, executing a factory preset via remote control terminates the connection to the instrument.

13.8 How to Set Up a Remote Control Connection

This section guides you through the steps required to set up remote control connections of the available interfaces.

- [Chapter 13.8.1, "Establishing a Remote Control Connection over the LXI Browser Interface", on page 381](#)
- [Establishing a Remote Control Connection over LAN Using VXI-11 Protocol](#)
- [Setting Up a Remote Control Connection over LAN Using Socket Communication](#)
- [Setting Up a Remote Control Connection over GPIB](#)
- [Setting Up a Remote Control Connection over USB](#)

The instrument and the controller have to be connected with the suitable cable and switched on.

A remote control program must open a connection to the instrument, before it can send commands to and receive device responses from the instrument.



Instrument address

To operate the instrument via remote control, it must be addressed using the defined interface address.

See:

- [Chapter 13.2.1, "LAN Interface"](#), on page 354
- [Chapter 13.2.2, "USB Interface"](#), on page 357
- [Chapter 13.2.3, "GPIB Interface \(IEC/IEEE Bus Interface\)"](#), on page 358

You find the VISA resource strings in the "System Config > Remote Access > VISA Resource Strings" dialog.



Securing the display

To prevent unauthorized personnel from reading the display, you can disable the frequency and level display explicitly. This is useful when you remotely control the instrument from a different location.

For more information, see:

- ["Annotation Frequency"](#) on page 342
- ["Annotation Amplitude"](#) on page 343

13.8.1 Establishing a Remote Control Connection over the LXI Browser Interface

Via the LXI browser interface to the R&S SMA100B one or more users can control the instrument remotely from another PC without additional installation. Most instrument controls are available via the front panel simulation. File upload and download between the instrument and the remote PC is also available.

Starting a remote control via the LXI web browser

This section assumes that the instrument and the controller PC are connected in the LAN.

1. Start a web browser that supports HTML5 (W3C compliant).
2. Enter the IP address of the R&S SMA100B in the browser's address bar.
The R&S SMA100B's welcome page is displayed.
3. In the navigation pane, select "Instrument Control" > "Web Control".
Remote access to the instrument requires the password. The default password is *instrument*.
4. Enter the password and confirm with the [Enter] key.
After the connection is established, the current screen of the R&S SMA100B is displayed in the browser window.

5. Use the mouse cursor and keyboard to access the functionality of the instrument as you would directly perform on the instruments touchscreen and front panel.

13.8.2 Establishing a Remote Control Connection over LAN Using VXI-11 Protocol

In this example, the I/O software library R&S VISA from Rohde & Schwarz is used to set up a LAN remote control link and remotely control the R&S SMA100B. R&S VISA is running on a controller PC with Windows operating system. When the connection is set up, you can send commands to the instrument and receive the responses.

The remote control connection requires a VISA installation but no additional hardware on the controller PC. The LAN I/O channel is selected at initialization time using the VISA resource string (also referred to as "address string"). A VISA alias (short name) is used to replace the complete resource string. The host address is the R&S SMA100B's hostname or its IP address.

See also [Chapter 13.2.1, "LAN Interface"](#), on page 354.

In the following, we assume that:

- A LAN remote control link between the controller and the R&S SMA100B is set up.
- The R&S VISA program is installed on the remote PC
See <http://www.rohde-schwarz.com/rsvisa> > "RS VISA Release Notes".



Setting up the controller with R&S VISA

To remote control the R&S SMA100B, we use the R&S VISA Tester application. The application communicates via TCP/IP protocol.




The instrument is preconfigured for networks using DHCP (dynamic host configuration protocol). If this configuration is used, enter the computer name in the position of the IP address.

1. Connect the controller and the instrument in the same network (network cable). Switch them on.
2. On the controller, start "R&S VISA > Tester 32bit" or "R&S VISA > Tester 64bit".



- In the menu bar, select "Choose VISA Implementation > Rohde & Schwarz Visa" and confirm with "OK".

- In the menu bar, select "Find Resource" to search for the instrument in the LAN.




- Select "VXI-11" and "Find Resources".

R&S VISA scans the network for connected instruments and lists all detected instruments in the "Resource" list.


Note: The search may take some time, particularly in large networks.

- Select the required instrument and confirm with "Select".




The "Find and select resource" dialog closes and R&S VISA indicates the IP address in the "Resource" field of the main application window.

7. As an alternative to the IP address, you can assign an alias name to the R&S SMA100B:
 - a) In the menu bar, select "RsVisaConfig".




- b) In the toolbar, select "+" to access the "VISA Resource String Composer".

- c) Fill in the "Alias" name, the "VISA Resource String" and the "Device IP Address or host name" as shown in the figure, and confirm with "OK".



The "Alias" name is assigned.



- d) Close the dialog.
The R&S SMA100B is registered in the program. It can be addressed via the resource string or alias name.

8. In the main window, select "Connect".

R&S VISA establishes the connection to the R&S SMA100B.

You can send settings to configure the instrument and receive its responses.

Note: If the connection cannot be set up, R&S VISA displays an error in the log view.

For information on how to proceed when network failures occur, see [Chapter 16.5, "Resolving Network Connection Failures"](#), on page 712.

For further information on the functions to read and write to an open session, and the utility applications the software provides, see the R&S VISA user manual.

Starting a remote control session over LAN with R&S VISA


To set the instrument to remote control, you can use the addressed command `>R` or send any command from the controller.

1. Start the R&S VISA Tester. Establish the connection to the R&S SMA100B. See ["Setting up the controller with R&S VISA"](#) on page 382.

- In the R&S VISA "Basics" tab, enter an SCPI command, e.g. "*IDN?". Confirm with "Query".

The instrument is switched to remote control when it receives a command from the controller.

- Select "Read" to obtain the instrument response.



Tip: If the "Show Log" checkbox is checked, R&S VISA displays each VISA function call in the log-view on the left. If you check the "Write Log" checkbox, the log-view entry is written to the log file as well. You can operate the log-view in two modes: the "Live Mode" shows only the most recent messages whereas the "View Mode" allows you to scroll the history.

- To set, e.g. the frequency, enter `SOUR1:FREQ 4 GHz` and select "Write". To check the performed setting, `SOUR1:FREQ?` and select "Query". The instrument response is `4000000000`. The value corresponds to the frequency in Hz.

While remote control is active, the "Remote" icon in the status bar indicates that the instrument is in remote control mode. Currently ongoing communication (data transfer) is indicated by green colored arrows in the icon.

Operating via the front and touch panel or via mouse and keyboard are locked, allowing a remote control program to be performed without interruption. On the display, keys and entry fields are grayed out and cannot be activated or modified, but you can still open dialogs, for example to verify settings.

- To disable the access to the dialogs, use the command `SYST:KLOC ON`.
- To prevent unintentional return to manual operation, use the command `&LLO`. See also [Chapter A.1.2, "LAN Interface Messages"](#), on page 716.

The instrument switches to "Remote LLO" state. The [Setup] key is disabled.

7. To enable the [Setup] key, use the command `>R`.
8. To return to manual operation, see [Chapter 13.10, "How to Return to Manual Operation"](#), on page 390.

Tip: Switching from manual operation to remote control and vice versa does not affect the other instrument settings.

13.8.3 Setting Up a Remote Control Connection over LAN Using Socket Communication

This section provides an example on how to establish a remote control connection over Telnet client and a simple sockets-based program example that can be further developed (see also [Chapter A.2, "Telnet program examples"](#), on page 736).



The telnet client transmits information unencrypted. Therefore, for sensitive information we recommend that you use a client which supports secure protocols, like SSH.

In the following example, we assume basic knowledge of programming and operation of the controller. You can find information on the interface commands in the corresponding manuals.


Setting up a Telnet connection

To control the software, only a Telnet program is required. The Telnet program is part of every operating system.


1. To establish a Telnet connection with the R&S SMA100B, start the Telnet program. Enter the socket address.

The socket address is a combination of the IP address or the hostname of the R&S SMA100B and the number of the port configured for remote-control via Telnet.


Tip: The R&S SMA100B uses the port number 5025 for remote connection via Telnet.



The connection to the instrument is set up and you can send remote-control commands.



2. Note that Telnet does not reflect your first entry. Insert a command, e.g. *IDN and confirm with "Enter".
3. Observe the screen.
A response on the query confirms that the connection is working. The client displays all subsequent inputs and responses.
4. Even if the cursor is not visible on the screen, blindly enter a remote-control command. Confirm with Enter.



13.8.4 Setting Up a Remote Control Connection over GPIB

The program example in this section is written in VISUAL BASIC. A condition for programming in VISUAL BASIC is that the modules NIGLOBAL (Niglobal.bas) and VBIB32 (Vbib_32.bas) are added to the projects.



Drivers for instrument, for example IVI-COM and LabVIEW drivers, are available for download area on the product page at:

<https://www.rohde-schwarz.com/driver/sma100b/>

Starting a remote control session over GPIB

As a prerequisite, the GPIB address of the instrument must be the default value, which is factory-set to 28.

1. Connect instrument and controller using a GPIB cable. Switch them on.
2. Execute the following commands on the controller:

- a) Open the port to the instrument.
`CALL IBFIND("DEV1", generator%)`
- b) Inform the controller about instrument address.
`CALL IBPAD(generator%, 28)`
- c) Reset the instrument.
`CALL IBWRT(generator%, "*RST;*CLS")`
- d) Set the instrument to new address.
`CALL IBWRT(generator%, "SYST:COMM:GPIB:ADDR 18")`
- e) Inform the controller about new address.
`CALL IBPAD(generator%, 18)`

The GPIB address of the instrument is changed.

3. To return to manual operation, press the Local key at the front panel.

13.8.5 Setting Up a Remote Control Connection over USB

For remote control via the USB connection, the PC and the instrument must be connected via the USB type B interface. A USB connection requires the VISA library to be installed. VISA detects and configures the R&S instrument automatically when the USB connection is established. You do not have to enter an address string or install a separate driver.

Starting a remote control session over USB

1. Connect instrument and controller using USB cable. Switch them on.
2. Execute the following commands on the controller:
 - a) Open the port to the instrument.
`viOpen (... , "USB::0x0AAD::0x01DD::100001::INSTR", ...)`
 - b) Reset the instrument.
`viRST (generator%, "*RST;*CLS")`
 - c) Set 2 GHz frequency
`viPrintf (... , "SOUR:FREQ 2GHz\n")`
 - d) Set 20 dBm output level
`viPrintf (... , "SOUR:POW -20dBm\n")`

The RF frequency and signal level of the instrument are changed.

3. To return to manual operation, press the [Local] key.

13.9 Tracing SCPI Commands and Messages Exchanged via the LXI Web Browser Interface

The remote trace functionality allows you to trace commands and messages exchanged via a remote control interface of the R&S SMA100B.

To activate the SCPI remote trace:

1. Start a web browser that supports HTML5 (W3C compliant).
2. Enter the IP address of the R&S SMA100B in the browser's address bar.
The R&S SMA100B's welcome page is displayed.
3. In the navigation pane, select "Diagnostics > SCPI Remote Trace".
4. In the toolbar bar of the "SCPI Remote Trace" page, select "live mode > on" and "logging > on".

"live mode > on" displays all commands and responses, and "logging > on" also traces messages.

If you now control the R&S SMA100B with SCPI commands, using an appropriate tool, the LXI function records the information sent and received.

The function records all sent commands, received responses and messages, and saves them in an internal database. If "live mode" is disabled, you can display the recent traces upon request, using the "refresh" button. You can also save the log in a file.

Note: The diagnostics functionality will be extended in later releases, e.g. to download or upload SCPI command files from / to the instrument.

13.10 How to Return to Manual Operation



Before returning to manual control, command processing must be completed. Otherwise, the instrument switches back to remote control immediately.

1. To return from "Remote" state to manual state, perform one of the following:
 - On the controller, use the command `>L`
Note: If `&NREN` has been set before `>L` is locked. Use `>R` instead.
 - In the status bar, select the "Remote" icon.
 - On the front panel, press the [Local] key.
 - In the block diagram, select "Context sensitive menu > Key Emulation > Local"
2. To return from "Remote LLO" state to manual or to "Remote" state, perform one of the following:

Note: In the local lockout state, the command `>L` and the [Local] key are locked. You can unlock this state only via remote control.

 - On the controller, use the command `&LOCS`.
This command switches directly to manual operation.
 - Send the command `&REMS`.
This command changes the remote control state from "Remote LLO" to "Remote".
 - Use the Visual Basic command `CALL IBLOC (generator%)`.

- The command switches directly to manual operation.
- VISA function `viGpibControlREN()`
This function switches directly to manual operation.

13.11 Automating Tasks with Remote Command Scripts

To achieve fast configuration, make complex test setups or repeating measurements reproducible, you can automate the required settings with scripts. A script contains a series of SCPI commands corresponding to the settings. When completed, it is converted to an executable format, saved in a file and can be run whenever needed.



If you frequently need to load and run a script, assign the script to the [★ (User)], and you can quickly and easily perform the task.

See [Chapter 12.2.3, "Assigning Actions to the \[★ \(User\)\] Key"](#), on page 331.

Note: In contrast to "Recall Setup" via the [★ (User)] key, an assigned script execution does not close active dialogs and windows. On the contrary, even active window control (open / close) is possible.




Figure 13-6: Steps for performing SCPI Scripts

In the graph, you can see the main steps required to work with an SCPI script.

Creating a SCPI list

With the SCPI record functions, you can create a SCPI command list directly in the instrument and then export the list to the controller. If you want to edit or write a script manually, use a suitable editor on the controller. Even for manually creating, the instrument supports you by showing the corresponding command syntax and the current settings value.

Directly in the instrument, you can create a SCPI list at any time of operation, in the following ways:

- Recording steps
 - Both, automatic and manual SCPI recording of settings is possible. You can start, stop and resume automatic recording, and also record individual commands manually.
 - Manually record the steps selectively
 - In manual recording mode, you can deliberately record a SCPI command with the "Add CPI Command to Recording List" function, see [How to record SCPI lists manually](#).

- Automatically record all performed steps
The instrument records the SCPI command and settings value of each step you perform, and then writes the commands to the file system, see [How to record SCPI lists automatically](#).
You can also add a SCPI command manually to the recording list during automatic SCPI recording.

Note: The Signal Generator clears the SCPI list after booting automatically.

- Generating all settings at once
Generates the SCPI commands of the current instrument settings in one step, and writes the command list in a temporary list, see [How to create a SCPI list with the current instrument settings in one step](#).
Note: This function lists all commands in alphabetical order, in contrast to the recording or manual creation, which consider the order the settings are configured. Using this function can slow down the runtime or cause errors during execution. Therefore, always check and revise a script if necessary, see ["How to check an SCPI list"](#) on page 399.
- Manually create a command script with "Copy" and paste
Enables you to copy the SCPI command and the current setting, see [Chapter 13.11.1, "Show SCPI Command"](#), on page 393.



Some parameters cannot be set by an SCPI command.
If so, *no SCPI command found* is entered instead of a command when you record or generate all settings at once.



The difference between "Show SCPI Command" and the provided cross-reference

If you want to enter your settings in a script, or use a remote control program, you must know the corresponding SCPI command and the exact syntax.

If you need to look up the SCPI command, the instrument offers two ways to figure it out quickly.

- "Show SCPI command" (context-sensitive menu)
Displays the SCPI command syntax of a selected parameter including the current setting value, see [Chapter 13.12, "How to Find Out the SCPI Command Corresponding to the Manual Operation via Show SCPI Command"](#), on page 396. The "Copy" function enables you to write an SCPI script conveniently by hand.
 - Instrument help ([Help] key)
Opens a help topic that describes the selected parameter or instrument function, including a cross-reference to the corresponding SCPI command. The reference leads you to the description of the SCPI command comprising the complete SCPI syntax, all available setting values, value ranges, etc., see [Chapter 13.13, "How to Find Out the SCPI Command Corresponding to the Manual Operation Using the Online Help"](#), on page 396.
-

Creating and exporting a script file

When the script list is completed, a code generator translates the SCPI commands into the source code of a proprietary programming language, using a code template. Therefore, each language requires an appropriate code template. When converted, you can save the script in a file with an extension corresponding to the programming language.

The R&S SMA100B provides the following predefined code templates by default:

- Plain SCPI
Represents SCPI base format, that is ASCII format, saved as text file (*.txt).
- MATLAB
A programming environment, frequently used in signal processing and test and measurement applications (*.m).
You can directly use this format with MATLAB(c) Toolkit. For comprehensive information on this topic, refer to the application note [1GP60: MATLAB Toolkit for R&S Signal Generators](#).
- NICVI
An ANSI C programming environment designed for measurements and tests (*.c).
You can directly use this format with National Instruments LabWindows CVI.

You can also convert a script to a user-specific format. In this case, you need a code template with the extension *.expcodetmpl.

For information on how to select the code template and save the script in a file, see [Chapter 13.11.3, "SCPI Recording Export Settings"](#), on page 394.

Executing an SCPI script

An SCPI script primarily runs on the controller PC. In addition, you can execute a script directly on the instrument, by assigning the script to the [★ (User)] key.

See [Chapter 12.2.3, "Assigning Actions to the \[★ \(User\)\] Key"](#), on page 331.

13.11.1 Show SCPI Command

Access:

1. Select the parameter.
2. Open the context-sensitive menu (tap and hold).
3. Select "Show SCPI Command".

This function provides the syntax of the remote command with the current setting.

Copy

Copies the command and the current setting.


Close

Exits the "SCPI Command" dialog.

13.11.2 Displaying an SCPI List

The instrument displays a recorded SCPI list and thus provides viewing the recorded results before exporting.

- ▶ Depending on the starting point, you can access the "SCPI Recording List" dialog as follows:
 - During recording
 - Select "Show SCPI Recording List" in the context-sensitive menu.
 - At any time outside recording
 - Select "Show SCPI Recording List" in the context-sensitive menu.
 - This function assumes that at least one recording has been executed after power-on.
 - At the end of the recording
 - Select "Stop automatic SCPI recording". The dialog opens automatically.
 - After you have exported the script to a file.
 - Select "SCPI Recording Export > Show file content"
 - See [Chapter 13.11.3, "SCPI Recording Export Settings"](#), on page 394.



The "SCPI Recording List" shows the last recorded and exported commands.

SCPI Recording List

Lists the automatically or manually recorded recorded SCPI commands.

Export

Opens the [SCPI Recording Export](#) dialog for configuring the file parameters for export.

Remove All, Remove First, Remove Last

Deletes either the first, the last or all recorded SCPI commands.

To remove several recorded commands, repeat the removing.


For post processing, export the SCPI command list in a file, see [Chapter 13.15, "How to Convert and Save SCPI Lists"](#), on page 400.

13.11.3 SCPI Recording Export Settings

Scripts are configured and saved in the "SCPI Recording Export" dialog. This dialog opens automatically, when you stop recording.

Access:

1. Select "Show SCPI Recording List" in the context-sensitive menu.
The "SCPI Recording List" dialog opens.
2. Select "Export".



The "SCPI Recording Export" dialog contains all functions required for export of command lists to a file. It enables you to select the source code format, assign an individual filename and display the file content.

Format

Selects the source code format for the command list.

"Plain SCPI" Uses SCPI syntax.

"Predefined Code Generator"

Accesses the predefined templates for common source code generators that convert the recorded settings in the programming languages MATLAB or NICVI.

"User Code Generator"

Use this setting to convert a script by a user-specific code generator.

Select Code Template

Opens the standard "File Select" dialog and lists the predefined or user-defined code templates.

See [Chapter 11.5.1, "File Select Settings"](#), on page 300.

File

Opens the standard file select dialog "Select Output File", see [Chapter 11.5.1, "File Select Settings"](#), on page 300.

Export

Executes data export.

The SCPI list is saved in as file with the selected filename and in the selected directory, see [File](#).

Reload

Reloads a SCPI list from a file.


You can export recorded SCPI lists to files (see [File](#) and [Export](#)), that can be modified.

File content


Displays the content of the script in the selected format and code template.

13.12 How to Find Out the SCPI Command Corresponding to the Manual Operation via Show SCPI Command

1. To find out the SCPI command of a parameter in manual operation, select the respective parameter.
2. Open the context-sensitive menu and select "Show SCPI command"



You get the detailed command syntax, including the currently set value.



With the "Copy" function, you can conveniently paste the command including the current setting, e.g., in a command script.

13.13 How to Find Out the SCPI Command Corresponding to the Manual Operation Using the Online Help

If you are looking for the remote command to a function in manual operation, you find it in the description of the online help.

1. To find out the SCPI command of a parameter in manual operation, select the respective parameter.
2. To open the corresponding help topic, select one of the following:
 - In the display, select "context-sensitive menu > Help".



- On the front panel, press the [Help] key.

The help topic opens. Apart from the function description, it contains the SCPI command in detailed syntax.



How to find the corresponding GUI function to a command

Conversely, if you are looking for a function in the GUI, which belongs to a SCPI, you find it via a cross-reference in the online help and in the user manual.

13.14 How to Record / Create SCPI Lists

How to record SCPI lists automatically

The following example briefly explains how to proceed when you want to record SCPI lists.

For comprehensive information on this topic, refer to the application note [1GP98: SCPI Recorder Test Automation on a Fingertip](#).

1. On the screen, open the context-sensitive menu (touch and hold, or right mouse click) and select "Start SCPI recording".



Starting from now, all steps you perform are recorded.

2. To stop SCPI recording, select "context-sensitive menu > Stop SCPI recording".



The "SCPI Recording List" dialog opens automatically.


3. Proceed with [How to check an SCPI list](#).

How to record SCPI lists manually



We recommend that you activate the "Mark All Parameters Changed from Preset". This function facilitates to track the changes.


1. To retrace your settings, open the context-sensitive menu and select "Mark all Parameters Changed from Preset".



This function identifies and highlights all settings you have changed, both in the block diagram, and in the dialogs.

Frequency	4.000 000 000 000 GHz	
Offset	10.000 000 kHz	Multiplier 1.000
User Variation		
Variation Active	<input checked="" type="checkbox"/>	Variation Step 1.000 000 000 MHz

2. For selectively recording your steps:
 - a) Set the parameter.
 - b) Open the context-sensitive menu.
 - c) Select "Add SCPI Command to Recording List"



Tip: You cannot see "Add SCPI ..." in the menu?

A possible reason is opening the menu outside of a dialog or input field, for example in a block diagram. Open the context-sensitive menu within the corresponding dialog or input field, and the feature is available.

- d) Continue with the next setting, and repeat steps *a to b* whenever needed.

Each time you select "Add SCPI ...", the SCPI command is appended to a temporary list.

3. To check the progress of the recording, select "Context-Sensitive > Show SCPI Recording List".



The "SCPI Recording List" dialog opens, displaying all recorded settings so far.


4. Proceed with [How to check an SCPI list](#).

How to create a SCPI list with the current instrument settings in one step

You can also generate a SCPI list from a manually created instrument state at any time, in only one step.

To generate an SCPI list with commands for all settings performed:

1. Select "Save/Recall > SCPI Export".



The instrument opens the standard file select dialog, see [Chapter 11.4.1, "Save/Recall Settings"](#), on page 296.

2. In the "Format" entry field, select the source code.
3. Depending on the selected format, convert the script as described in [Chapter 13.15, "How to Convert and Save SCPI Lists"](#), on page 400
4. Enter a filename.
5. Select "Export".
The instrument writes all SCPI commands of the key parameters and the modified settings in the file. Also assigns the file extension automatically according to the source code format.
6. To preview the content of the SCPI list:
 - a) Select "System Config > Save/Recall".
 - b) Select "Operation Mode > SCPI-Export".
 - c) In the `/var/user/` directory, select a previously saved file.
 - d) Select "Show SCPI List".

The list of all SCPI commands is displayed, for example, for a final check.



Exporting the SCPI list of the instrument state in one step is a fast and convenient method. Nevertheless, it usually requires postprocessing on an external PC.

How to check an SCPI list

The easiest way to check a list, is to execute it. The generator returns a warning if a setting could not be performed.

However, we recommend that you check the list and possibly rework. It can be that ...

- A parameter has not assigned an SCPI command or an element of the user interface has not an assigned parameter. In these cases, `:SYST:INF:SCPI 'SCPI command not available'` is entered in the list instead.

Such entries are also detected during execution. The instrument recognizes these incomplete commands and displays an error message.

- A preset has been executed, but several standards subsequently perform some internal settings that are also assigned to the list with "SCPI Export".
- After a preset still some settings are defined, which are then written to the list generated with "SCPI Export."

Some suggestions on how you can check and revise a list:

1. Search and remove missing command entries.
2. Remove unnecessary content written after a preset.
3. Rearrange the commands to a reasonable order. If you, for example, set a `STATe` command to the last position of a list, you can avoid intermediate calculations of the signal.
4. Preview the list for completeness by comparing it with the modified settings in the manual mode.
 - a) To retrace your settings in manual operation, open the context-sensitive menu and select "Mark all parameters changed from preset".
The function identifies all settings you have changed, both in the block diagram, and in the dialogs. They appear orange.
 - b) Check whether there is a command in the list for all modified settings.
5. To perform modifications, export the list to a PC, using for example a USB flash drive.

13.15 How to Convert and Save SCPI Lists

After completing the recording, the "SCPI Recording Export" dialog opens.

1. Select the "Format" for the command syntax in which you want to save the list.
2. "Select Code Template"
Depending on the selected format, proceed accordingly:
Note: Select the code template **before** exporting.
 - a) Plain SCPI
Continue with the next step.
 - b) Predefined code generator
The "SCPI Recording Export - Select Predefined Code Template" dialog opens.
Select one of the predefined code templates.
 - c) User code generator
A file system ("SCPI Recording Export - Select User Code Template") dialog opens.
Select your user-defined code template. The code template must have file extension `*.expcodetmpl`.

3. Select "File..."
The "SCPI Recording Export - Select Output File" dialog opens.
4. Select "New" and assign a filename for saving the recorded list.
5. In the "SCPI Recording Export" dialog, select "Export".
Saves the recorded data either in ASCII format (plain SCPI), or in the corresponding format of the used code template, and shows the SCPI list in the "File Content" section.

13.16 How to Set Up Remote Operation via VNC

This section shows you some examples of the various possibilities to set up remote operation.

- Using a desktop system
 - [Chapter 13.16.1.1, "Using a Web Browser"](#), on page 401
 - [Chapter 13.16.1.2, "Using a VNC Client Software"](#), on page 402
- Using a smart device
 - [Chapter 13.16.2.1, "Using a VNC App"](#), on page 405
 - [Chapter 13.16.2.2, "Using a Web Browser with HTML5"](#), on page 405
 - [Chapter 13.16.2.3, "Special Mode QR Code "](#), on page 406



Enabled direct control

The direct control of the instrument is not disabled and the instrument can be controlled from the front panel and via the remote computer alternately.

13.16.1 Setting Up a Remote Operation from a Desktop System

13.16.1.1 Using a Web Browser

The R&S SMA100B supports remote operation via VNC with any web browser, like Windows Internet Explorer or Mozilla Firefox for instance, or alternatively, an HTML5 web browser.

To operate the instrument via a web browser remotely:

1. Install the *JRE (Java Runtime Environment)* on the remote computer.
Note: Skip this step if you are working with an HTML5 web browser.
2. Type the instruments' IP address in the address field of the web browser on your PC, e.g. `http://10.113.1.151`
The VNC authentication screen appears.

3. Enter the password and confirm with "OK".
The default password is *instrument*.

After the connection is established, the current screen of the signal generator is displayed and the instrument can be remotely operated from the remote computer.

13.16.1.2 Using a VNC Client Software

A VNC client software is an application which can be used to access and control the instrument from a remote computer through a LAN connection.

The VNC client software for setting up the connection is included in the operating system Linux/Unix per default. For Windows operating systems, a VNC client software must be installed manually.

Various free-of charge programs such as Ultr@VNC or similar VNC client programs are available for download on the Internet.


Setting up the VNC connection on a Linux/Unix desktop client

1. Start a web browser on the remote computer. Enter the IP address of the instrument.
2. Enter the following address:
`vnc://<IP-address of the instrument>`, for example `vnc://10.113.1.151`.
A dialog opens requesting the password for the remote VNC connection.
3. Enter the password and confirm with "OK".
The default password is *instrument*.

After the connection is established, the current screen of the signal generator is displayed and the instrument can be remotely operated from the remote computer.


Setting up the VNC connection on a Windows desktop client

1. Install the VNC viewer program component on the remote computer.
 - a) On the Internet, select a VNC client program and download it onto your PC.
For example the free of charge software Ultr@VNC (`vncviewer.exe` is available, see <http://www.uvnc.com/download/index.html>).
 - b) Execute the VNC client installation.
 - c) Select the VNC viewer program component and follow the installation instructions.
2. Start VNC viewer program component on the PC.



3. Select "VNC Server" and enter the IP address of the instrument.
4. To initialize the connection, select "Connect".

A dialog opens requesting the password.



5. Enter the password and confirm with "OK".
The default password is *instrument*.

After the connection is established, the current screen of the signal generator is displayed and the instrument can be remotely operated from the remote computer.

Terminating VNC connection

- ▶ Perform one of the following:
 - a) On an external Unix/Linux PC, close the Internet browser or the signal generator window.
 - b) On an external Windows PC, close the VNC viewer program.

The connection is terminated but not disabled. It can be established again any time.

In the "Active Connections" tab, the displayed TCP/IP connection disappears. Consider, however, the note concerning unauthorized access due to VNC connection ("[Risk of unauthorized access](#)" on page 352).

13.16.2 Setting Up a Remote Operation from a Smart Device

The R&S SMA100B supports remote operation via VNC from a smart device (remote client), like a tablet (tablet computer) or a smartphone. The smart device accesses the instrument via WLAN, either by a suitable App, or an HTML5 web browser, that means with embedded *javascript*.



There are several possibilities to establish a WLAN connection between the smart device and the R&S SMA100B, which are, however, not all described here. This section gives an example of how a network environment can be built up, and some essential configuration steps.

For comprehensive information on this topic refer to the application notes:

- [1MA216: Remote Operation of Windows Based Instruments with Apple iPad](#)
- [7BM82: Apple iPad Remote Control of Broadcasting T&M Instruments](#)

Example:




Figure 13-7: Example of a network configuration for remote operation with a smart device

As shown in the figure, the R&S SMA100B and the WLAN router are connected to the LAN router. The smart device accesses the Rohde & Schwarz instrument via the WLAN router.

Prerequisites

For this network configuration, the following prerequisites must be met:

- The required equipment is:
 - A LAN router
 - A WLAN router (hot spot)
Required for accessing the R&S SMA100B
- The smart device must be known and accepted in the network of the R&S SMA100B.

- The *App* or web browser implements the VNC functionality on the smart device for remote operation.

It is recommended that all components in the network use DHCP, which automatically assigns the relevant address information.



With the configuration in the example, you can reach the instrument from a great distance, since the WLAN router acts as an additional access point.

13.16.2.1 Using a VNC App

Using a *VNC App* enables the smart device to access the R&S SMA100B via WLAN.



The VNC Apps are available from various manufacturers of the smart devices. The list of supported devices is different according to the smart device. Refer to the manufacturer's website to find out whether a VNC App is available for your device, and how it is installed.

1. In the network, establish the connection of the WLAN router to the LAN router. We assume the connection of the LAN router and the R&S SMA100B and their configuration in the LAN.
2. Configure the WLAN router according to the manufacturer's instructions.
3. Install the required *VNC App* on your smart device.
4. On the smart device, start the *VNC App*.

5. In the address field, enter the IP address of the instrument.

Tip: The R&S SMA100B indicates IP address on the screen.

A log-on dialog opens and requests the password for the VNC connection.

The default user name and password is *instrument*.

Tip: Default password. Remote access via VNC uses the user name "instrument" with default user password "instrument".

Note: We recommend that you change the default password before connecting the instrument to a network.

See [Chapter 12.4.4, "Password Management"](#), on page 347.

6. Enter the password to establish the remote access.

After the connection is established, the current screen of the signal generator is displayed and the instrument can be remotely operated.

13.16.2.2 Using a Web Browser with HTML5

The R&S SMA100B supports remote operation from a smart device via VNC with any HTML5 compliant web browser, like Internet Explorer, Firefox, Google Chrome, or Safari for instance.

To operate the instrument remotely via a web browser, proceed as follows:

1. In the web browser enter the IP address of the instrument, e.g. *http://10.113.1.151*.
2. Type the instrument IP address in the address field of the web browser on your PC, e.g. *http://10.113.1.151*

Tip: The R&S SMA100B indicates IP address on the screen.

The VNC authentication screen appears.

3. Enter the password and confirm with "OK".
The default password is *instrument*.

After the connection is established, the current screen of the signal generator is displayed and the instrument can be remotely operated.

13.16.2.3 Special Mode QR Code

If your smart device is equipped with a camera and a QR code reader, you can scan the instrument's IP address or access the instrument with the Safari web browser.



QR code readers are available from various manufacturers of the smart devices. The list of supported devices is different according to the smart device. Refer to the manufacturer's website to find out whether a reader is available for your device, and how it is installed.

1. Install the required QR code reader software on your device.
2. Start the reader.
3. On the R&S SMA100B, select "System Config > Remote Access".
4. In the "Remote Access" dialog, select the "QR-Code" tab.
5. Scan the QR code of the instrument with your smart device.
6. On the device, decode the scanned QR code and pass it to the web browser.
A dialog opens requesting the password for the VNC connection.
7. Enter the password and confirm with "OK".
The default password is *instrument*.

After the connection is established, the current screen of the signal generator is displayed and the instrument can be remotely operated.

13.17 References

13.17.1 LXI Functionality

LAN Extensions for Instrumentation (LXI) is an instrumentation platform for measuring instruments and test systems that is based on standard Ethernet technology. LXI is intended to be the LAN-based successor to GPIB, combining the advantages of Ethernet with the simplicity and familiarity of GPIB.

Like GPIB, LXI determines and standardizes the way the instrument behaves in a LAN. The LXI implementation in the R&S SMA100B allows you to change certain LAN settings, to reset the LAN connection, and to identify the instrument.



For information about the LXI standard, refer to the LXI website at <http://www.lxistandard.org>.

See also "News from Rohde & Schwarz, article 2006/II - 190".

The LXI functionality in the R&S SMA100B is characterized by a common LAN implementation, including an ICMP ping responder for diagnostics. The instrument can be configured via a web browser. A LAN Configuration Initialize (LCI) mechanism resets the LAN configuration. The instrument also supports automatic detection in a LAN via the VXI-11 discovery protocol and programming by IVI drivers.

In addition the R&S SMA100B provides the following LXI-related functionality:

- Integrated "LXI Status" dialog for LXI status indication and reset of the LAN configuration, see [Chapter 13.5.1, "LXI Status Settings"](#), on page 372.
- "LXI Browser Interface", as described in [Chapter 13.5.2.1, "LAN Configuration"](#), on page 375.
- "SCPI Remote Trace" utility, see ["SCPI Remote Trace"](#) on page 377.



Firmware update

To enable the full LXI functionality after a firmware update, shut down and restart the instrument.

13.17.2 Code Generator Templates

This section describes the main structure of the code generator templates, and shows the method by means of the NICVI template.

The code generation is controlled by templates with the following blocks:

Command	Function
#EXTENSION_START #EXTENSION_END	Defines the output file extension.
#INIT_CODE_START #INIT_CODE_END	Contains initial entries, such as included files and libraries, buffer size, commands for synchronization, or creating a VISA session. All entries between start and end are written once at the beginning of the output file.
#COMMAND_CODE_START #COMMAND_CODE_END	Frame for an SCPI command. A command is accessed with %COMMAND.
#NO_COMMAND_CODE_START #NO_COMMAND_CODE_END	Frame for a parameter with no SCPI command available. A parameter is accessed with %PARAMETER.
#EXIT_CODE_START #EXIT_CODE_END	Closes the visa session. All entries between start and end are written once at the end of the output file.

Templates are created in ASCII format with file extension *.expcodetempl.

Example:

Example to the code generator template NICVI.expcodetmpl:

```
#EXTENSION_START
.c
#EXTENSION_END

#INIT_CODE_START
#include <ansi_c.h>
#include <visa.h>
#include <cvirte.h>

#define MAX_BUFFER_SIZE 200
static ViStatus status;
static ViSession defaultRM, handle;

static void write_command(char *command)
{
    char writeBuffer[MAX_BUFFER_SIZE];
    char readBuffer[MAX_BUFFER_SIZE];
    int length;
    int readCount;

    strcpy(writeBuffer, command);
    //append "*OPC?" to sync
    strcat(writeBuffer, "*OPC?");
    length = strlen (writeBuffer);
    writeBuffer[length]='\n';
```

```

        length = length+1;
        viWrite (handle, writeBuffer, length, VI_NULL);
        //read result
        viRead(handle, readBuffer, 100, &readCount);
    }
int main (int argc, char *argv[])
{
    if (InitCVIRTE (0, argv, 0) == 0)
        return -1;    /* out of memory */
        //create a VISA session and return a handle to it
        viOpenDefaultRM (&defaultRM);
        //create a VISA session to the serial port and return a handle to it
        viOpen (defaultRM, (ViRsrc)"TCPIP::localhost::INSTR", VI_NULL, VI_NULL,
&handle);
#INIT_CODE_END

#COMMAND_CODE_START
    write_command("%COMMAND");
#COMMAND_CODE_END

#NO_COMMAND_CODE_START
    //no SCPI command available for parameter %PARAMETER !
#NO_COMMAND_CODE_END

#EXIT_CODE_START
    viClose (handle);
        viClose (defaultRM);
        return 0;
}
#EXIT_CODE_END

```

13.17.3 Remote Control States

How to I recognize if there is an active remote connection to the instrument?

- Observe the indication on the taskbar.



**SCPI, VNC,
SMB, FTP**

A softkey in the taskbar indicates if and what kind of remote connections are currently set up.

See also [Chapter 13.4.6, "Remote Connections Settings"](#), on page 369.

The following table shows the different remote control states and the associated commands or actions to return to manual control.

Table 13-3: Remote control status icons

GUI symbol	Transition to remote control state...	Transition to manual operation...(local state)
 	<p>&GTR (controller)</p> <p>Remote control, but usable front panel keys. The parameters are in read-only mode.</p>	<ul style="list-style-type: none"> • &GTL (controller) • Tap the "Remote" icon (display) • [Local] (front panel or key emulation) <p>A currently performed setting is indicated by the green arrows.</p> <p>The setting must be completed (white arrows), otherwise the instrument remains in remote state.</p>
	<p>&LLO (controller)</p> <p>Remote control with locked front panel keys to prevent user interaction. The parameters are in read-only mode.</p> <p>You can unlock LLO, and thus return to manual operation only via remote control.</p>	<ul style="list-style-type: none"> • &LOCS (controller) • CALL IBLOC (generator%) (controller) <p>Note: The command &REMS returns to "Remote" state.</p>

14 Remote Control Commands

In the following, all remote-control commands are presented in detail with their parameters and the ranges of numerical values.

For an introduction to remote control and the status registers, refer to:

- [Chapter 13, "Network Operation and Remote Control"](#), on page 351
- [Chapter A.1, "Additional Basics on Remote Control"](#), on page 715

14.1 Conventions used in SCPI Command Descriptions

Note the following conventions used in the remote command descriptions:

- **Command usage**
If not specified otherwise, commands can be used both for setting and for querying parameters.
If a command can be used for setting or querying only, or if it initiates an event, the usage is stated explicitly.
- **Parameter usage**
If not specified otherwise, a parameter can be used to set a value and it is the result of a query.
Parameters required only for setting are indicated as **Setting parameters**.
Parameters required only to refine a query are indicated as **Query parameters**.
Parameters that are only returned as the result of a query are indicated as **Return values**.
- **Conformity**
Commands that are taken from the SCPI standard are indicated as **SCPI confirmed**. All commands used by the R&S SMA100B follow the SCPI syntax rules.
- **Asynchronous commands**
A command which does not automatically finish executing before the next command starts executing (overlapping command) is indicated as an **Asynchronous command**.
- **Reset values (*RST)**
Default parameter values that are used directly after resetting the instrument (*RST command) are indicated as ***RST values**, if available.
- **Factory preset values**
Default parameter values that are reset only by factory preset.
- **Default unit**
The default unit is used for numeric values if no other unit is provided with the parameter.
- **Manual operation**
If the result of a remote command can also be achieved in manual operation, a link to the description is inserted.

14.2 Programming Examples

The corresponding sections of the same title provide simple programming examples for the R&S SMA100B. The purpose of the examples is to present **all** commands for a given task. In real applications, one would rather reduce the examples to an appropriate subset of commands.

The programming examples have been tested with a software tool which provides an environment for the development and execution of remote tests. To keep the examples as simple as possible, only the "clean" SCPI syntax elements are reported. Non-executable command lines (for example comments) start with two // characters.

At the beginning of the most remote control program, an instrument (p)reset is recommended to set the R&S SMA100B to a definite state. The commands `*RST` and `SYSTem:PRESet` are equivalent for this purpose. `*CLS` also resets the status registers and clears the output buffer.

In all the examples we assume that:

- A remote PC is connected to the instrument
- The remote PC and the instrument are switched on
- A connection between them is established
- The security setting "System Config > Setup > Security > SCPI over LAN" is enabled.

14.3 Common Commands

Common commands are described in the IEEE 488.2 (IEC 625-2) standard. These commands have the same effect and are employed in the same way on different devices. The headers of these commands consist of "*" followed by three letters. Many common commands are related to the Status Reporting System.

Available common commands:

<code>*CLS</code>	413
<code>*ESE</code>	413
<code>*ESR?</code>	413
<code>*IDN?</code>	413
<code>*IST?</code>	414
<code>*OPC</code>	414
<code>*OPT?</code>	414
<code>*PRE</code>	414
<code>*PSC</code>	414
<code>*RCL</code>	415
<code>*RST</code>	415
<code>*SAV</code>	415
<code>*SRE</code>	416
<code>*STB?</code>	416

*TRG.....	416
*TST?.....	416
*WAI.....	416

*CLS

Clear status

Sets the status byte (STB), the standard event register (ESR) and the `EVENT` part of the `QUESTIONABLE` and the `OPERATION` registers to zero. The command does not alter the mask and transition parts of the registers. It clears the output buffer.

Usage: Setting only

*ESE <Value>

Event status enable

Sets the event status enable register to the specified value. The query returns the contents of the event status enable register in decimal form.

Parameters:

<Value> Range: 0 to 255

*ESR?

Event status read

Returns the contents of the event status register in decimal form and then sets the register to zero.

Return values:

<Contents> Range: 0 to 255

Usage: Query only

*IDN?

Identification

Returns the instrument identification.

Return values:

<ID> "Rohde&Schwarz,<device type>,<part number>/<serial number>,<firmware version>"

Example: Rohde&Schwarz,SMA100B,1419.8888K02/0,4.00.033

Usage: Query only

Manual operation: See "[IDN String](#)" on page 369

***IST?**

Individual status query

Returns the contents of the IST flag in decimal form. The IST flag is the status bit which is sent during a parallel poll.

Return values:

<ISTflag> 0 | 1

Usage: Query only

***OPC**

Operation complete

Sets bit 0 in the event status register when all preceding commands have been executed. This bit can be used to initiate a service request. The query writes a "1" into the output buffer when all preceding commands have been executed, which is useful for command synchronization.

***OPT?**

Option identification query

Queries the options included in the instrument. For a list of all available options and their description, refer to the data sheet.

Return values:

<Options> The query returns a list of options. The options are returned at fixed positions in a comma-separated string. A zero is returned for options that are not installed.

Usage: Query only

Manual operation: See "[OPT String](#)" on page 369

***PRE <Value>**

Parallel poll register enable

Sets parallel poll enable register to the indicated value. The query returns the contents of the parallel poll enable register in decimal form.

Parameters:

<Value> Range: 0 to 255

***PSC <Action>**

Power on status clear

Determines whether the contents of the `ENABLe` registers are preserved or reset when the instrument is switched on. Thus a service request can be triggered when the instrument is switched on, if the status registers ESE and SRE are suitably configured. The query reads out the contents of the "power-on-status-clear" flag.

Parameters:

<Action> 0 | 1

0

The contents of the status registers are preserved.

1

Resets the status registers.

***RCL** <Number>

Recall

Loads the instrument settings from an intermediate memory identified by the specified number. The instrument settings can be stored to this memory using the command `*SAV` with the associated number.

It also activates the instrument settings which are stored in a file and loaded using the `MMEMory:LOAD <number>, <file_name.extension>` command.

Manual operation: See "[Recall Immediate x](#)" on page 299

***RST**

Reset

Sets the instrument to a defined default status. The default settings are indicated in the description of commands.

The command is equivalent to `SYSTem:PRESet`.

Usage: Setting only

Manual operation: See "[Preset](#)" on page 292

***SAV** <Number>

Save

Stores the current instrument settings under the specified number in an intermediate memory. The settings can be recalled using the command `*RCL` with the associated number.

To transfer the stored instrument settings in a file, use the command `:MMEMory:STORe:STATe`.

Manual operation: See "[Save Immediate x](#)" on page 298

***SRE** <Contents>

Service request enable

Sets the service request enable register to the indicated value. This command determines under which conditions a service request is triggered.

Parameters:

<Contents> Contents of the service request enable register in decimal form.
Bit 6 (MSS mask bit) is always 0.
Range: 0 to 255

***STB?**

Status byte query

Reads the contents of the status byte in decimal form.

Usage: Query only

***TRG**

Trigger

Triggers all actions waiting for a trigger event. In particular, *TRG generates a manual trigger signal. This common command complements the commands of the TRIGger subsystem.

Usage: Event

***TST?**

Self-test query

Initiates self-tests of the instrument and returns an error code.

Return values:

<ErrorCode> **integer > 0 (in decimal format)**
An error occurred.
(For details, see the Service Manual supplied with the instrument).
0
No errors occurred.

Usage: Query only

***WAI**

Wait to continue

Prevents servicing of the subsequent commands until all preceding commands have been executed and all signals have settled (see also command synchronization and *OPC).

Usage: Event

14.4 Preset Commands

The preset commands are not bundled in one subsystem. Therefore, they are listed separately in this section.

Four presetting actions are available:

- Activating the default state of all internal instrument functions (*RST on page 415). Functions that concern the integration of the instrument into a measurement setup are not changed, e.g. GPIB address or reference oscillator source settings.
- Activating the preset state of the parameters related to the selected signal path (:SOURce<hw>:PRESet on page 417)
- Activating the preset state of all parameters that are not related to the signal path (:DEVIce:PRESet on page 417)
- Activating the original state of delivery (factory reset, :SYSTem:FPRreset on page 418). Only functions that are protected by a password remain unchanged as well as the passwords themselves.

:DEVIce:PRESet.....	417
:SOURce<hw>:PRESet.....	417
:SYSTem:PRESet.....	418
:SYSTem:FPRreset.....	418

:DEVIce:PRESet

Presets all parameters which are not related to the signal path, including the LF generator.

Example: DEV:PRESet
Presets all instruments settings that are not related to the signal path.

Usage: Event

:SOURce<hw>:PRESet

Presets all parameters which are related to the selected signal path.

Example: SOUR:PRESet
Presets all settings that are related to signal path

Usage: Event

:SYSTem:PRESet

Triggers an instrument reset. It has the same effect as:

- The [Preset] key
- The *RST command

For an overview of the settings affected by the preset function, see [Table 11-1](#)

Example: SYST:PRES
All instrument settings (also the settings that are not currently active) are reset to their default values.

Usage: Setting only

:SYSTem:FPRreset

Triggers an instrument reset to the original state of delivery.

Example: SYST:FPR
All instrument settings (also the settings that are not currently active) are reset to the factory values.

Usage: Event

Manual operation: See "[Execute Factory Preset](#)" on page 292

14.5 MMEMory Subsystem

The MMEMory subsystem (Mass MEMory) contains the commands for managing files and directories as well as for loading and storing complete instrument settings in files.

Mass storage location

Without any additional measures, the R&S SMA100B stores user files on the internal memory, the removable memory, or if connected, on a memory stick.

Both, the user directory `/var/user/` on the internal memory or the `/usb/` directory on the memory stick, can be used to **preserve** user-defined data. Any directory structure can be created.

The `/var/volatile` directory serves as a RAM drive and can be used to protect sensitive information. The data is available **temporarily**.

If option R&S SMAB-B85 is installed, the R&S SMA100B maps the user directory to the removable memory. If a memory is mounted, user data is saved there. Otherwise user data is redirected to the volatile memory.

Default storage location

The R&S SMA100B stores user data in the user directory.

Depending on the installed options, the user directory is physically located on the internal memory or on the removable memory.

In the file system, user directory is always indicated as `/var/user/`.

In manual control, you access this directory via the "File Manager", see [Chapter 11.8, "Using the File Manager"](#), on page 303. In remote control, you can query it with the command `:SYSTEM:MMEMory:PATH:USER?`.

To query and change the default directory used for mass storage, use the command `:MMEMory:CDIRectory`.

14.5.1 File Naming Conventions

To enable files to be used in different file systems, consider the following file naming conventions:

- The *filename* can be of any length and *is case-sensitive*, i.e. it is distinguished between uppercase and lowercase letters.
- All letters and numbers are permitted (numbers are, however, not permitted at the beginning of the filename).
- Avoid using special characters.
- Do not use slashes "\" and "/". These symbols are used in file paths.
- Avoid using the following filenames: CLOCK\$, CON, COM1 to COM4, LPT1 to LPT3, NUL or PRN
They are reserved by the operating system.

File extension

The file and the optional file *extension* are separated by a period sign. The R&S SMA100B distinguishes the files according to their extensions; each type of file is assigned a specific file content and hence a specific file extension. Refer to [Chapter C, "Extensions for User Files"](#), on page 744 for an overview of the supported file extensions.

Wildcards

The two characters "*" and "?" function as "wildcards", i.e. they are used for selecting several files. The "?" character represents exactly one character, while the "*" character represents all characters up to the end of the filename. "*.*" therefore represents all files in a directory.

Filename and file path

When used in remote control commands, the parameter `<filename>` is specified as a string parameter with quotation marks. It can contain either the complete path including the root user directory `/var/user` and filename, or only the filename. The filename must include the file extension. The same applies for the directory `/var/volatile` and for the parameters `<directory_name>` and `<path>`.

Depending on how much information is provided, the values specified in the parameter or with the command `MMEM:CDIR` are used for the path and drive setting in the commands.

14.5.2 Accessing Files in the Default or in a Specified Directory

For better overview and easy file handling, you may not save all user files in the user directory `/var/user` but rather organize them into subdirectories.

The command syntax defines two general ways to access files with user data in a *specific* directory:

- **Change the current default directory** for mass memory storage and then directly access the files in this default directory, like stored list files, files with user data or save/recall files.
The subsequent commands for file handling (select, delete, read out files in the directory, etc.) require only specification of the filename. File extension can be omitted; after syntax evaluation of the used command, the R&S SMA100B filters out the relevant files.
- Define the **absolute file path**, including the user directory `/var/user`, created subdirectories and filename (see [Example "Load file with user data from a specific directory"](#) on page 420).
As a rule, whenever an absolute file path is determined, it overwrites a previously specified default directory.

The following example explains this rule as a principle. Exceptions of this general rule are stated in the description of the corresponding command. The [Chapter 14.5.3, "Programming Examples"](#), on page 421 explains the general working principle with the commands for mass memory storage.

The same rule applies to the `/var/volatile` directory, see [Example "Working with files in the volatile memory"](#) on page 422.

Example: Load file with user data from a specific directory

This example shows the principle of file handling in remote environment by using list commands. Working with the files of other subsystems is analogical. We assume that the directory `/var/user/my_files` is existing and contains the files `list_test.lsw` and `list_2.lsw`.

```
//Query files in the user directory
SOURCE1:LIST:CATalog?
// -
// no files

// Set the default directory
MMEMory:CDIRECTory "/var/user/my_files"
SOURCE1:LIST:CATalog?
// "list_test","list_2"

// Specify the complete path to select a list file (*.lsw)
// in the specific directory
SOURCE1:LIST:SElect "/var/user/my_files/list_test"
SOURCE1:LIST:DElete "/var/user/my_files/list_2"
```


14.5.3 Programming Examples

Example: Storing and loading current settings

This example shows two ways of how to store the current instrument setting in the file `settings.savrc1.txt` in the directory `/var/user/savrc1`.



Before the instrument settings can be stored in a file, they have to be stored in an intermediate memory using common command `*SAV <number>`. The specified number is then used in the `:MMEMory:STORe:STATe` command.

Also, after loading a file with instrument settings with command `:MMEMory:LOAD:STATe`, these settings have to be activated with the common command `*RCL <number>`.

```
// Store the current settings in an intermediate memory with number 4
*SAV 4

// store the settings in a file in a specific directory;
// the complete path has to be specified
MMEMory:STORe:STATe 4, "/var/user/savrc1/settings.savrc1.txt"

// store the settings in a file in the default directory;
// set the default directory; specify only the file name
MMEMory:CDIRectory "/var/user/savrc1"
*SAV 4
MMEMory:STORe:STATe 4, "settings.savrc1.txt"

// Load the stored settings in the intermediate memory 4 and activate them
MMEMory:LOAD:STATe 4, "/var/user/settings.savrc1.txt"
*RCL 4
```

Example: Working with files and directories

This example shows how to list files in a directory, list the subdirectories, query the number of files in a directory, create directory, rename and delete files.

```
// Query the current default directory for mass storage,
// change the directory to the default user directory "/var/user"
// and read out the files in it
MMEMory:CDIRectory?
// "/var/user/temp"
MMEMory:CDIRectory
MMEMory:CDIRectory?
// "/var/user/"
MMEMory:CATalog?
// 1282630,8102817792,".,DIR,4096",".,DIR,4096","Log,DIR,4096",
// "settings.savrc1.txt,BIN,16949","temp,DIR,4096","test,DIR,4096",
// "list.lsw,BIN,1245201"
// the directory "/var/user" contains the predefined directory "Log",
```

```

// the subdirectories "test" and "temp"
// as well as the files "settings.savrc1.txt" and "list.lsw"

// query only the subdirectories of the current or specified directory
MMEemory:DCATalog? "/var/user"
// ".", "..", "Log", "temp", "test"

// query only number of subdirectories in the current or specified directory
MMEemory:DCATalog:LENGth? "/var/user"
// 5

// query number of files in the current or specified directory
MMEemory:CATalog:LENGth? "/var/user"
// 7

// Create a new directory for mass memory storage in the specified directory
MMEemory:MDIRectory "/var/user/new"

// Copy the file "settings.savrc1.txt" into the new directory
MMEemory:COpy "/var/user/settings.savrc1.txt", "/var/user/new/settings.savrc1.txt"

// Rename the file "settings.savrc1.txt" into the new directory
// and read out the files in this specific directory
MMEemory:CDIRectory "/var/user/new"
MMEemory:MOve "settings.savrc1.txt", "settings_new.savrc1.txt"
MMEemory:CATalog? "/var/user/new"
// 25141,8102789120, ".", DIR, 4096", ".., DIR, 4096", "settings_new.savrc1.txt, BIN, 16949"

// Delete the "test" directory
MMEemory:RDIRectory "/var/user/test"

```

Example: Working with files in the volatile memory

This example shows how to work with files in the `/var/volatile` directory.

```

// Change the default directory for mass storage,
// read out the files, load and play a file with the ARB
MMEemory:CDIRectory "/var/volatile"
MMEemory:CDIRectory?
// "/var/volatile"
MMEemory:CATalog?
//13928,525352960, ".", DIR, 60", ".., DIR, 4096", "list.lst, BIN, 9772"

:SOURce1:LIST:SElect "/var/volatile/list"
:SOURce1:FREquency:MODE LIST
:OUTPut1:STATe 1

```

14.5.4 Remote Control Commands

:MMEMory:CATalog?	423
:MMEMory:CATalog:LENGth?	423
:MMEMory:CDIRectory	424
:MMEMory:COpy	424
:MMEMory:DATA	425
:MMEMory:DCATalog?	425
:MMEMory:DCATalog:LENGth?	426
:MMEMory:DELeTe	426
:MMEMory:LOAD:STATe	426
:MMEMory:MDIRectory	426
:MMEMory:MOVE	427
:MMEMory:MSIS	427
:MMEMory:RDIRectory	427
:MMEMory:STORe:STATe	427
:MEMory:HFRee?	428

:MMEMory:CATalog? <path>

Returns the content of a particular directory.

Query parameters:

<path>	string
--------	--------

String parameter to specify the directory.
If you leave out the path, the command returns the contents of the directory selected with [:MMEMory:CDIRectory](#).
The path may be relative or absolute.

Return values:

<UsedDiskSpace>	Byte size of all files in the directory.
<FreeDiskSpace>	Remaining disk space in bytes.
<FileInfo>	<NameFileN>,<SuffixFileN>,<SizeFileN> List of files, separated by commas
	<NameFileN> Name of the file.
	<SuffixFileN> Type of the file. Possible suffixes are: ASCii, BINary, DIRectory
	<SizeFileN> Size of the file in bytes.

Usage: Query only

Manual operation: See "[Directory, File List and Filename](#)" on page 297

:MMEMory:CATalog:LENGth? <Path>

Returns the number of files in the current or in the specified directory.

Query parameters:

<Path> string
String parameter to specify the directory. If the directory is omitted, the command queries the content of the current directory, queried with `:MMEMory:CDIRectory` command.

Return values:

<FileCount> integer
Number of files.

Usage: Query only

:MMEMory:CDIRectory <Directory>

Changes the default directory for mass memory storage. The directory is used for all subsequent `MMEM` commands if no path is specified with them.

Parameters:

<Directory> <directory_name>
String containing the path to another directory. The path can be relative or absolute.
To change to a higher directory, use two dots '..'.

Usage: SCPI confirmed

Manual operation: See "[Directory, File List and Filename](#)" on page 297

:MMEMory:COPY <SourceFile>[,<DestinationFile>]

Copies an existing file to a new file. Instead of just a file, this command can also be used to copy a complete directory together with all its files.

Setting parameters:

<SourceFile> string
String containing the path and file name of the source file

<DestinationFile> string
String containing the path and name of the target file. The path can be relative or absolute.
If <DestinationFile> is not specified, the <SourceFile> is copied to the current directory, queried with the `:MMEMory:CDIRectory` command.

Note: Existing files with the same name in the destination directory are overwritten without an error message.

Usage: Setting only
SCPI confirmed

Manual operation: See "[Cut, Copy&Paste and Delete](#)" on page 305

:MMEMory:DATA <Filename>, <BinaryBlock>

:MMEMory:DATA? <Filename>

The setting command writes the block data <BinaryBlock> to the file identified by <Filename>.

Tip: Use this command to read/transfer stored instrument settings or waveforms directly from/to the instrument.

Parameters:

<BinaryBlock> #<number><length_entry><data>

#: Hash sign; always comes first in the binary block
 <number>: the first digit indicates how many digits the subsequent length entry has
 <length_entry>: indicates the number of subsequent bytes
 <data>: binary block data for the specified length.
 For files with a size with more than nine digits (gigabytes), the instrument allows the syntax # (<Length>), where <Length> is the file size in decimal format.

Parameters for setting and query:

<Filename> string

String parameter to specify the name of the file.

Example:

```
MMEMory:DATA '/var/user/test.txt',#15hallo
```

Writes the block data to the file test.txt.

The digit 1 indicates a length entry of one digit; the digit 5 indicate a length of the binary data (hallo) in bytes.

```
MMEMory:DATA? '/var/user/test.txt'
```

Sends the data of the file test.txt from the instrument to the controller in the form of a binary block.

Response: #15hallo

Usage: SCPI confirmed

:MMEMory:DCATalog? <path>

Returns the subdirectories of a particular directory.

Query parameters:

<path> String parameter to specify the directory. If the directory is omitted, the command queries the content of the current directory, queried with [:MMEMory:CDIRectory](#) command.

Return values:

<Catalog> <file_entry>

Names of the subdirectories separated by colons. The first two strings are related to the parent directory.

Usage: Query only

:MMEMory:DCATalog:LENGth? [<Path>]

Returns the number of subdirectories in the current or specified directory.

Query parameters:

<Path> String parameter to specify the directory. If the directory is omitted, the command queries the contents of the current directory, to be queried with `:MMEMory:CDIRectory` command.

Return values:

<DirectoryCount> integer
Number of parent and subdirectories.

Usage: Query only

:MMEMory:DELeTe <Filename>

Removes a file from the specified directory.

Setting parameters:

<Filename> string
String parameter to specify the name and directory of the file to be removed.

Usage: Event
SCPI confirmed

Manual operation: See "[Cut, Copy&Paste and Delete](#)" on page 305

:MMEMory:LOAD:STATe <SavRclStateNumb>, <file_name>

Loads the specified file stored under the specified name in an internal memory.

After the file has been loaded, the instrument setting must be activated using an `*RCL` command.

Setting parameters:

<SavRclStateNumb> Determines to the specific <number> to be used with the `*RCL` command, e.g. `*RCL 4`.

<file_name> String parameter to specify the file name with extension `*.savrc1txt`.

Usage: Setting only

Manual operation: See "[Recall](#)" on page 299

:MMEMory:MDIRectory <Directory>

Creates a subdirectory for mass memory storage in the specified directory. If no directory is specified, a subdirectory is created in the default directory. This command can also be used to create a directory tree.

Setting parameters:

<Directory> string
String parameter to specify the new directory.

Usage: Event

Manual operation: See ["Create New Directory"](#) on page 305

:MMEMory:MOVE <SourceFile>, <DestinationFile>

Moves an existing file to a new location or, if no path is specified, renames an existing file.

Setting parameters:

<SourceFile> string
String parameter to specify the name of the file to be moved.

<DestinationFile> string
String parameters to specify the name of the new file.

Usage: Event
SCPI confirmed

Manual operation: See ["Rename "](#) on page 305

:MMEMory:MSIS <Msis>

Defines the drive or network resource (in the case of networks) for instruments with windows operating system, using `msis` (MSIS = Mass Storage Identification String).

Note: Instruments with Linux operating system ignore this command, since Linux does not use drive letter assignment.

Usage: SCPI confirmed

:MMEMory:RDIRectory <Directory>

Removes an existing directory from the mass memory storage system. If no directory is specified, the subdirectory with the specified name is deleted in the default directory.

Setting parameters:

<Directory> string
String parameter to specify the directory to be deleted.

Usage: Event

:MMEMory:STORE:STAtE <savrcl_state_nr>, <file_name>

Stores the current instrument setting in the specified file.

The instrument setting must first be stored in an internal memory with the same number using the common command `*SAV`.

Setting parameters:

<savecl_state_nr> Corresponds to the specific <number> defined with the *SAV command, e.g. *SAV 4.

<file_name> String parameter to specify the file name with extension *.savecl.txt.

Usage: Event

Manual operation: See "Save" on page 298

:MEMory:HFRee?

Returns the used and available memory in Kb.

Return values:

<TotalPhysMemKb> integer
Total physical memory.

<ApplicMemKb> integer
Application memory.

<HeapUsedKb> integer
Used heap memory.

<HeapAvailableKb> integer
Available heap memory.

Usage: Query only

14.6 CALibration Subsystem

The CALibration subsystem contains the commands needed for performing internal adjustments. This procedure is triggered by the query commands.

Suffix <hw>

Suffix	Value range	Description
CALibration<hw>	[1]	Optional suffix

Understanding the query response

- 0: error-free execution of the adjustments
- 1: indicates that an error occurred; the process has been canceled

:CALibration:ALL[:MEASure]?	429
:CALibration<hw>:ALL:DATE?	429
:CALibration<hw>:ALL:INformation?	429
:CALibration<hw>:ALL:TEMP?	430

:CALibration<hw>:ALL:TIME?.....	430
:CALibration:DATA:FACTory:DATE?.....	430
:CALibration<hw>:CONTInueonerror.....	431

:CALibration:ALL[:MEASure]? [<Force>]

Starts all internal adjustments that do not need external measuring equipment.

NOTICE: Risk of DUT damage

During level adjustments, the instrument temporarily applies high power at the RF output. This high power can destroy a connected DUT.

Do not start level adjustments if DUT is connected. Disconnect the DUT and replace it by a terminating resistor with adequate power rating. We recommend that you use a 50 Ohm, 10 W or larger terminating resistor.

Query parameters:

<Force> string

Return values:

<Measure> 0 | 1 | OFF | ON

Example:

```
CAL:ALL:MEAS?
```

```
0
```

Executes the adjustments of all instrument functions. When completed, it indicates that the adjustment has been performed successfully.

Usage: Query only

Manual operation: See "[Adjust All](#)" on page 700

:CALibration<hw>:ALL:DATE?

Queries the date of the most recently executed full adjustment.

Suffix:

<hw> [1]
Optional suffix

Return values:

<Date> string

Example:

```
CAL:ALL:DATE?  
// "2016-01-01"
```

Usage: Query only

Manual operation: See "[Last Full Adjustment](#)" on page 701

:CALibration<hw>:ALL:INFormation?

Queries the current state of the internal adjustment.

Return values:

<CallInfoText> string

Example:

```
CAL:ALL:INF?
"Instrument is calibrated, no adjustment required."
"UNCAL, instrument is warming up."
"UNCAL, Please perform full adjustment after warming up."
"UNCAL, Please perform full adjustment."
```

Usage: Query only

Manual operation: See ["Information"](#) on page 701

:CALibration<hw>:ALL:TEMP?

Queries the temperature deviation compared to the calibration temperature.

Suffix:

<hw> [1]
Optional suffix

Return values:

<Temperature> string

Example:

```
CALibration:ALL:TEMP?
// "+39.00 K"
```

Usage: Query only

Manual operation: See ["Temperature Offset Since Last Full Adjustment"](#) on page 701

:CALibration<hw>:ALL:TIME?

Queries the time elapsed since the last full adjustment.

Return values:

<Time> string

Example:

```
CAL:ALL:TIME?
// "22 days"
```

Usage: Query only

Manual operation: See ["Time Since Last Full Adjustment"](#) on page 701

:CALibration:DATA:FACTory:DATE?

Queries the date of the last factory calibration.

Return values:

<Date> string

Example:

```
CAL:DATA:FACT:DATE?
// "2016-01-01"
```

Usage: Query only

Manual operation: See "[Last Factory Calibration](#)" on page 704

:CALibration<hw>:CONTinueonerror <State>

Continues the calibration even though an error was detected. By default adjustments are aborted on error.

Suffix:

<hw> [1]
Optional suffix

Parameters:

<State> 0 | 1 | OFF | ON
*RST: n.a. (factory preset: 0)

Example:

```
CAL:CONT ON
// Continues calibration after an error
```

Manual operation: See "[Continue Adjustment on Error](#)" on page 701

14.7 CSYNthesis Subsystem

This subsystem contains the commands used to define the frequency settings for the separate clock source (clock synthesis).

Option: see "[Required options](#)" on page 283.

Example:

```
CSYNthesis:OTYPE DSIN
CSYNthesis:FREQuency 10000000
CSYNthesis:POWer -15
CSYNthesis:OFFSet:STATe 1
CSYNthesis:OFFSet 0.1
CSYNthesis:PHASe 180
CSYNthesis:PHASe:REFerence
CSYNthesis:PHASe?
// 0
CSYNthesis:FREQuency:STEP:MODE DEC
CSYNthesis:POWer:STEP:MODE DEC
// CSYNthesis:FREQuency:STEP:MODE USER
// CSYNthesis:FREQuency:STEP 1000
// CSYNthesis:FREQuency UP
// 10001000
// CSYNthesis:POWer:STEP:MODE USER
// CSYNthesis:POWer:STEP:INCRement 0.5
CSYNthesis:STATe 1
```

:CSYNthesis:STATe.....	432
:CSYNthesis:OTYPe.....	432
:CSYNthesis:FREQUency.....	432
:CSYNthesis:POWer.....	433
:CSYNthesis:OFFSet:STATe.....	433
:CSYNthesis:OFFSet.....	433
:CSYNthesis:VOLTagE.....	434
:CSYNthesis:PHASe.....	434
:CSYNthesis:PHASe:REFerence.....	434
:CSYNthesis:POWer:STEP:MODE.....	435
:CSYNthesis:FREQUency:STEP:MODE.....	435
:CSYNthesis:POWer:STEP[:INCRement].....	435
:CSYNthesis:FREQUency:STEP.....	435

:CSYNthesis:STATe <State>

Activates the clock synthesis.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 0

Example: See [Chapter 14.7, "CSYNthesis Subsystem"](#), on page 431.

Manual operation: See " [State](#) " on page 284

:CSYNthesis:OTYPe <Mode>

Defines the shape of the generated clock signal.

Parameters:

<Mode> SESine | DSquare | CMOS | DSINe
 SESine = single-ended sine
 DSINe = differential sine
 DSquare = differential square
 CMOS = CMOS
 *RST: SESine

Example: See [Chapter 14.7, "CSYNthesis Subsystem"](#), on page 431.

Manual operation: See "[Output Type](#)" on page 284

:CSYNthesis:FREQUency <Frequency>

Sets the frequency of the generated clock signal.

Parameters:

<Frequency> float
Numerical value
 Sets the frequency

UP|DOWN

Varies the frequency step by step.

The frequency is increased or decreased by the value set with the command `:CSYNthesis:FREQuency:STEP`.

Range: 100E3 to 1.5E9

Increment: 0.001

*RST: 10E6

Example: See [Chapter 14.7, "CSYNthesis Subsystem"](#), on page 431.

Manual operation: See " [Frequency](#) " on page 285

:CSYNthesis:POWer <Power>

Sets the power level of the generated clock signal.

Parameters:

<Power> float

Numerical value

Sets the level

UP|DOWN

Varies the level step by step.

The level is increased or decreased by the value set with the command `:CSYNthesis:POWer:STEP[:INCRement]`.

Range: -24 to 10

Increment: 0.01

*RST: -20

Example: See [Chapter 14.7, "CSYNthesis Subsystem"](#), on page 431.

Manual operation: See " [Level](#) " on page 285

:CSYNthesis:OFFSet:STATe <State>

Activates a DC offset.

Parameters:

<State> 0 | 1 | OFF | ON

*RST: 0

Example: See [Chapter 14.7, "CSYNthesis Subsystem"](#), on page 431.

Manual operation: See " [DC Offset State](#) " on page 285

:CSYNthesis:OFFSet <Offset>

Sets the value of the DC offset.

Parameters:

<Offset> float
 Range: -5 to 5
 Increment: 0.001
 *RST: 0

Example: See [Chapter 14.7, "CSYNthesis Subsystem"](#), on page 431.

Manual operation: See "[DC Offset](#)" on page 286

:CSYNthesis:VOLTage <Voltage>

Sets the voltage for the CMOS signal.

Parameters:

<Voltage> float
 Range: 0.8 to 2.7
 Increment: 0.001
 *RST: 1.8

Example:

```
CSYNthesis:OTYPe CMOS
CSYNthesis:VOLTage 1.8
CSYNthesis:FREQuency 100000000
CSYNthesis:STATe 1
```

Manual operation: See "[Voltage](#)" on page 286

:CSYNthesis:PHASe <Phase>

Shifts the phase of the generated clock signal.

Parameters:

<Phase> float
 Range: -36000 to 36000
 Increment: 0.1
 *RST: 0

Example: See [Chapter 14.7, "CSYNthesis Subsystem"](#), on page 431.

Manual operation: See "[Delta Phase](#)" on page 286

:CSYNthesis:PHASe:REFerence

Resets the delta phase value.

Example: See [Chapter 14.7, "CSYNthesis Subsystem"](#), on page 431.

Usage: Event

:CSYNthesis:POWer:STEP:MODE <Mode>

:CSYNthesis:FREQUency:STEP:MODE <Mode>

Defines the type of step size to vary the frequency and level at discrete steps.

Parameters:

<Mode> DECimal | USER

DECimal

Increases or decreases the level in steps of 10.

USER

Increases or decreases the value in increments, set with the command:

`:CSYNthesis:FREQUency:STEP`

`:CSYNthesis:POWer:STEP[:INCRement]`

*RST: DECimal

Example: See [Chapter 14.7, "CSYNthesis Subsystem"](#), on page 431.

Manual operation: See ["Variation Active"](#) on page 286

:CSYNthesis:POWer:STEP[:INCRement] <Increment>

Sets the step width of the rotary knob and, in user-defined step mode, increases or decreases the level.

Parameters:

<Increment> float

Range: 0 to 35

Increment: 0.01

*RST: 1

Example: See [Chapter 14.7, "CSYNthesis Subsystem"](#), on page 431.

Manual operation: See ["Variation Step"](#) on page 286

:CSYNthesis:FREQUency:STEP <Step>

Sets the step width of the rotary knob and, in user-defined step mode, increases or decreases the frequency.

Parameters:

<Step> float

Range: 0 to 14999E5

Increment: 0.001

*RST: 1E6

Example: See [Chapter 14.7, "CSYNthesis Subsystem"](#), on page 431.

Manual operation: See ["Variation Step"](#) on page 286

14.8 DIAGnostic Subsystem

The `DIAGnostic` subsystem contains the commands used for instrument diagnosis and servicing. SCPI does not define any `DIAGnostic` commands; the commands listed here are all device-specific. All `DIAGnostic` commands are query commands which are not affected by `*RST`.



The test functions are intended for services purposes.

They are thus password-protected functions. Unlock the corresponding protection level to access them, see `:SYSTEM:PROTECT<ch>[:STATE]`

For more information, see R&S SMA100B Service Manual.

Common suffixes

The following common suffixes are used in remote commands:

Suffix	Value range	Description
<code>DIAGnostic<hw></code>	[1]	Optional suffix

Example: Programming example

The example lists the commands required to query assemblies and test points for diagnosis purposes.

```
// Query the modules available in the instrument
// and variant and revision state of a certain assembly
DIAGnostic1:BGInfo:CATalog?
// FRONT_AF, PSU300, IFB.BV, MB2_AF, ...
DIAGnostic1:BGInfo? "PSU300"
// PSU300 2118.2067.02 01.00 100000

// Query the test points available in the instrument
// and trigger the measurement in a selected test point
DIAGnostic1:POINt:CATalog?
// ATT6HP_AF_DET_N, ATT6HP_AF_DET_P, ATT6HP_AF_DET_TEMP...
DIAGnostic1:MEASure:POINt? "ATT6HP_AF_DET_N"
// 0.000000V
```

<code>:DIAGnostic<hw>:BGInfo:CATalog?</code>	436
<code>:DIAGnostic<hw>:BGInfo?</code>	437
<code>:DIAGnostic<hw>:POINt:CATalog?</code>	437
<code>:DIAGnostic<hw>[:MEASure]:POINt?</code>	438

`:DIAGnostic<hw>:BGInfo:CATalog?`

Queries the names of the assemblies available in the instrument.

Return values:

<Catalog> string
List of all assemblies; the values are separated by commas
The length of the list is variable and depends on the instrument equipment configuration.

Example: See [Example "Programming example"](#) on page 436.

Usage: Query only

:DIAGnostic<hw>:BGInfo? [<Board>]

Queries information on the modules available in the instrument, using the variant and revision state.

Query parameters:

<Board> string
Module name, as queried with the command :
[DIAGnostic<hw>:BGInfo:CATalog?](#).
To retrieve a complete list of all modules, omit the parameter.
The length of the list is variable and depends on the instrument equipment configuration.

Return values:

<BgInfo> <Module name> <Module stock number incl. variant> <Module revision> <Module serial number>
List of comma-separated entries, one entry per module.
Each entry for one module consists of four parts that are separated by space characters.

Example: See [Example "Programming example"](#) on page 436.

Usage: Query only

Manual operation: See ["Assembly"](#) on page 704

:DIAGnostic<hw>:POINT:CATalog?

Queries the test points available in the instrument.

For more information, see R&S SMA100B Service Manual.

Return values:

<Catalog> string
List of comma-separated values, each representing a test point

Example: See [Example "Programming example"](#) on page 436.

Usage: Query only

:DIAGnostic<hw>[:MEASure]:POINT? <Name>

Triggers the voltage measurement at the specified test point and returns the measured voltage.

For more information, see R&S SMA100B Service Manual.

Query parameters:

<Name> <test point identifier>
 Test point name, as queried with the command :
`DIAGnostic<hw>:POINT:CATalog?`

Return values:

<Value> <value><unit>

Example: See [Example "Programming example"](#) on page 436.

Usage: Query only

14.9 DISPlay Subsystem

The DISPlay system contains the commands to set the power-save mode of the instrument.

Programming Examples

Example: Activating screen saver mode and display update

Use the following commands to switch on the screen saver of your instrument or to automatic display. These settings are particularly useful when you control the instrument remotely.

```
// Set the wait time interval and activate the screen saver
:DISPlay:PSAVe:HOLDoff 10
:DISPlay:PSAVe:STATe ON

// Disable the display of the current frequency and level values in remote control
:DISPlay:ANNotation:ALL ON
// :DISPlay:ANNotation:FREQuency ON
// :DISPlay:ANNotation:AMPLitude ON

// Enable automatic update of the display at defined time intervals
:DISPlay:UPDate ON
```

Example: Querying the dialog IDs, opening and closing dialogs

Use the following commands to query the dialog IDs of all currently open dialogs. The dialog ID is a prerequisite for opening and closing dialogs via the remote control.



The dialog ID is also required to define user key actions.

See [Chapter 12.2.3, "Assigning Actions to the \[★ \(User\)\] Key"](#), on page 331.

```
// Query the dialog IDs of all open dialogs
:DISPlay:DIALog:ID?
// CEUltraDLGenSetDlg,_, $A DlgKeyRf_Rosc

// Open and close dialogs via remote control
:DISPlay:DIALog:OPEN "CEUltraDLGenSetDlg,_, $A"
:DISPlay:DIALog:OPEN "DlgKeyRf_Rosc"
:DISPlay:DIALog:CLOSe "DlgKeyRf_Rosc"
:DISPlay:DIALog:CLOSe:ALL

:DISPlay:PSAVe:HOLDOff..... 439
:DISPlay:PSAVe[:STATe]..... 439
:DISPlay:BRIGhtness..... 440
:DISPlay:BUtTon:BRIGhtness..... 440
:DISPlay:UPDate..... 440
:DISPlay:ANNOtation:AMPLitude..... 440
:DISPlay:ANNOtation:FREQUency..... 441
:DISPlay:ANNOtation[:ALL]..... 441
:DISPlay:DIALog:ID?..... 441
:DISPlay:DIALog:OPEN..... 442
:DISPlay:DIALog:CLOSe..... 442
:DISPlay:DIALog:CLOSe:ALL..... 443
```

:DISPlay:PSAVe:HOLDOff <HoldoffTimeMin>

Sets the wait time for the screen saver mode of the display.

Parameters:

<HoldoffTimeMin> integer
 Range: 1 to 60
 *RST: n.a. (factory preset: 10)
 Default unit: minute

Example: see [Example "Activating screen saver mode and display update"](#) on page 438

Manual operation: See ["Wait Time"](#) on page 324

:DISPlay:PSAVe[:STATe] <State>

Activates the screen saver mode of the display.

We recommend that you use this mode to protect the display, if you operate the instrument in remote control.

To define the wait time, use the command `:DISPlay:PSAVe:HOLDOff`.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: n.a. (factory preset: 0)

Example:

See [Example "Activating screen saver mode and display update"](#) on page 438

Manual operation: See ["Screen Saver"](#) on page 324

:DISPlay:BRIGhtness <BRIGhtness>

Sets the brightness of the display.

Parameters:

<BRIGhtness> float
 Range: 1.0 to 20.0
 Increment: 1.0
 *RST: 14.0

Example:

DISPlay:BRIGhtness 14

Manual operation: See ["Display"](#) on page 324

:DISPlay:BUtTon:BRIGhtness <ButTonBRIghtness>

Sets the brightness of the [RF on/off] key.

Parameters:

<ButTonBRIghtness> integer
 Range: 1 to 20
 *RST: n.a. (no preset. default: 14)

Example:

DISPlay:BUtTon:BRIGhtness 15

Manual operation: See ["RF Hardkey"](#) on page 324

:DISPlay:UPDate <Update>

Activates the refresh mode of the display.

Parameters:

<Update> 0 | 1 | OFF | ON
 *RST: n.a. (factory preset: 1)

Example:

See [Example "Activating screen saver mode and display update"](#) on page 438

Manual operation: See ["Display Update is"](#) on page 325

:DISPlay:ANNOtation:AMPLitude <State>

Indicates asterisks instead of the level values in the status bar.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: n.a. (factory preset: 1)

Example: See [Example "Activating screen saver mode and display update"](#) on page 438

Manual operation: See ["Annotation Amplitude"](#) on page 343

:DISPlay:ANNOtation:FREQuency <State>

Indicates asterisks instead of the frequency values in the status bar.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: n.a. (factory preset: 1)

Example: See [Example "Activating screen saver mode and display update"](#) on page 438

Manual operation: See ["Annotation Frequency"](#) on page 342

:DISPlay:ANNOtation[:ALL] <State>

Displays asterisks instead of the level and frequency values in the status bar of the instrument.

We recommend that you use this mode if you operate the instrument in remote control.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 1

Example: See [Example "Activating screen saver mode and display update"](#) on page 438

:DISPlay:DIALog:ID?

Returns the dialog identifiers of the open dialogs in a string separated by blanks.

Return values:

<DialogIDList> <DialogID#1>< ><DialogID#2>< > ... < ><DialogID#n>
 Dialog identifiers are string without blanks. Blanks are represented as \$\$.
 Dialog identifiers <DialogID> are composed of two main parts:
 <DialogName>[<OptionalParts>]
<DialogName>
 Meaningful information, mandatory input parameter for the commands:
 :DISPlay:DIALog:OPEN on page 442
 :DISPlay:DIALog:CLOSe on page 442

<Optional parts>

String of $\$<X>$ values, where $<X>$ is a character, interpreted as follows:

$\$q<DialogQualifier>$: optional dialog qualifier, usually the letter A or B, as displayed in the dialog title.

$\$i<Instances>$: comma-separated list of instance indexes, given in the order h, c, s, d, g, u, 0. Default is zero; the terminating ", 0" can be omitted.

$\$t<TabIds>$: comma-separated indexes or tab names; required, if a dialog is composed of several tabs.

$\$x<Left>\$y<Top>\$h<Left>\$w<Top>$: position and size; superfluous information.

Example: See [Example "Querying the dialog IDs, opening and closing dialogs"](#) on page 438

Usage: Query only

Manual operation: See ["SCPI"](#) on page 331

:DISPlay:DIALog:OPEN <DialogId>

Opens the specified dialog.

Setting parameters:

<DialogId> string

To find out the dialog identifier, use the query [:DISPlay:DIALog:ID?](#).

The <DialogName> part of the query result is mandatory.

Example: See [Example "Querying the dialog IDs, opening and closing dialogs"](#) on page 438

Usage: Setting only

Manual operation: See ["SCPI"](#) on page 331

:DISPlay:DIALog:CLOSe <DialogId>

Closes the specified dialog.

Setting parameters:

<DialogId> string

To find out the dialog identifier, use the query [:DISPlay:DIALog:ID?](#).

The <DialogName> part of the query result is sufficient.

Example: See [Example "Querying the dialog IDs, opening and closing dialogs"](#) on page 438

Usage: Setting only

:DISPlay:DIALog:CLOSe:ALL

Closes all open dialogs.

Example: See [Example "Querying the dialog IDs, opening and closing dialogs"](#) on page 438

Usage: Event

14.10 FORMat Subsystem

The commands in the FORMat subsystem determine the format of data returned by the R&S SMA100B to the controller. This affects all query commands that return a list of numerical data or block data, noted in the descriptions of the commands. The set data format applies to both paths.

:FORMat:BORDer	443
:FORMat:SREGister	443
:FORMat[:DATA]	444

:FORMat:BORDer <Border>

Determines the sequence of bytes within a binary block. This only affects blocks which use the IEEE754 format internally.

Parameters:

<Border> NORMal | SWAPped

NORMal

Expects/sends the *least* significant byte of each IEEE754 floating-point number first and the *most* significant byte last.

SWAPped

Expects/sends the *most* significant byte of each IEEE754 floating-point number first and the *least* significant byte last.

*RST: NORMal

Example: FORM:BORD SWAP
transfers the data with the most significant bit first.

:FORMat:SREGister <Format>

Determines the numeric format for responses of the status register.

Parameters:

<Format> ASCii | BINary | HEXadecimal | OCTal

ASCii

Returns the register content as a decimal number.

BINary|HEXadecimal|OCTal

Returns the register content either as a binary, hexadecimal or octal number. According to the selected format, the number starts with #B (binary), #H (hexadecimal) or #O (octal).

*RST: ASCII

Example:

```
FORM:SREG HEX
```

returns the register content as a hexadecimal number.

:FORMat[:DATA] <Data>

Determines the data format the instrument uses to return data via the IEC/IEEE bus.

The instrument automatically detects the data format used by the controller, and assigns it accordingly. Data format determined by this SCPI command is in this case irrelevant.

Parameters:

<Data>

ASCII | PACKed

ASCII

Transfers numerical data as plain text separated by commas.

PACKed

Transfers numerical data as binary block data.

The format within the binary data depends on the command.

The various binary data formats are explained in the description of the parameter types.

*RST: ASCII

Example:

```
FORM ASC
```

transfers the data as ASCII data.

14.11 HCOpy Subsystem

The HCOpy subsystem contains the commands to generate and save a hard copy of the display.



To access a stored hard copy file, use the commands of the MEMM subsystem.

Example: Store a hard copy of the display

The following example lists commands to configure and execute a hard copy to an automatic named file.

```
:HCOpy:DEvice:LANGUage PNG
:HCOpy:FILE:NAME:AUTO:STATe 1
// defines the output format
// sets the instrument to automatically create output file names
```



```

// *****
// Configure hard copy options, set automatic naming rules
// An automatically generated file name consists of:
// <Prefix><YYYY><MM><DD><Number>.<Format>
// *****
:HCOPY:DEVIce:LANGUage BMP
// defines output format *.bmp
:HCOPY:REGion DIALog
// selects the region to be copied
:HCOPY:FILE:AUTO:DIR "/usb/HCopy"
// sets destination directory of automatic named file
:HCOPY:FILE:NAME:AUTO:FILE:PREFIx:STATe 1
:HCOPY:FILE:NAME:AUTO:FILE:PREFIx:"hardcopy"
:HCOPY:FILE:NAME:AUTO:FILE:YEAR:STATe 1
:HCOPY:FILE:NAME:AUTO:FILE:MONTH:STATe 1
// uses automatic naming prefix
// sets automatic naming prefix to "hardcopy"
// uses automatic naming date parameters year and month

// *****
// Execute and transfer the hard copy
// *****
:HCOPY:EXECute
:HCOPY:DATA
// generates a hard copy
// transfers the hard copy to the remote client
:HCOPY:FILE:AUTO:FILE?
// queries the automatic file name
// "hardcopy1607001.bmp"
:HCOPY:FILE:AUTO:NUMBer?
// queries the number in the automatic file name
// "001"
:HCOPY:FILE:AUTO?
// queries the path and file name of the automatically generated file
// "/usb/HCopy/hardcopy1607001.bmp"

```

14.11.1 Hard Copy Settings

With the following commands, you can configure the settings of a hard copy.

:HCOPY:DATA?	446
:HCOPY:IMAGe:FORMat	446
:HCOPY:DEVIce:LANGUage	446
:HCOPY:REGion	446
:HCOPY:FILE[:NAME]	446
:HCOPY[:EXECute]	447

:HCOPY:DATA?

Transfers the hard copy data directly as a NByte stream to the remote client.

Return values:

<Data> block data

Example: See [Example "Store a hard copy of the display"](#) on page 444

Usage: Query only

:HCOPY:IMAGe:FORMat <Format>**:HCOPY:DEVIce:LANGUage <Language>**

Selects the graphic format for the hard copy. You can use both commands alternatively.

Parameters:

<Language> BMP | JPG | XPM | PNG

*RST: PNG

Example: See [Example "Store a hard copy of the display"](#) on page 444

Manual operation: See ["Format"](#) on page 317

:HCOPY:REGion <Region>

Selects the area to be copied.

You can create a snapshot of the screen or an active dialog.

Parameters:

<Region> ALL | DIALog

*RST: ALL

Example: See [Example "Store a hard copy of the display"](#) on page 444

Manual operation: See ["Region"](#) on page 318

:HCOPY:FILE[:NAME] <Name>

Determines the file name and path to save the hard copy, provided automatic naming is disabled.

Note: If you have enabled automatic naming, the instrument automatically generates the file name and directory, see [Chapter 14.11.2, "Automatic Naming"](#), on page 447.

Parameters:

<Name> string

Example: See [Example "Store a hard copy of the display"](#) on page 444

Manual operation: See ["File..."](#) on page 317

:HCOPY[:EXECute]

Generates a hard copy of the current display. The output destination is a file.

Example: See [Example "Store a hard copy of the display"](#) on page 444

Usage: Event

Manual operation: See ["Save"](#) on page 317

14.11.2 Automatic Naming

Use the following commands to automatically assign a file name.

:HCOPY:FILE[:NAME]:AUTO?	447
:HCOPY:FILE[:NAME]:AUTO:DIRectory	447
:HCOPY:FILE[:NAME]:AUTO:DIRectory:CLear	448
:HCOPY:FILE[:NAME]:AUTO:FILE?	448
:HCOPY:FILE[:NAME]:AUTO:STATe	448
:HCOPY:FILE[:NAME]:AUTO[:FILE]:DAY:STATe	448
:HCOPY:FILE[:NAME]:AUTO[:FILE]:MONTH:STATe	448
:HCOPY:FILE[:NAME]:AUTO[:FILE]:YEAR:STATe	448
:HCOPY:FILE[:NAME]:AUTO[:FILE]:NUMBer?	449
:HCOPY:FILE[:NAME]:AUTO[:FILE]:PREFix	449
:HCOPY:FILE[:NAME]:AUTO[:FILE]:PREFix:STATe	449

:HCOPY:FILE[:NAME]:AUTO?

Queries path and file name of the hardcopy file, if you have enabled *Automatic Naming*.

Return values:

<Auto> string

Example: See [Example "Store a hard copy of the display"](#) on page 444

Usage: Query only

:HCOPY:FILE[:NAME]:AUTO:DIRectory <Directory>

Determines the path to save the hard copy, if you have enabled *Automatic Naming*.

If the directory does not yet exist, the instrument automatically creates a new directory, using the instrument name and `/var/user/` by default.

Parameters:

<Directory> string
*RST: `/var/user/`

Example: See [Example "Store a hard copy of the display"](#) on page 444

Manual operation: See ["Path..."](#) on page 319

:HCOPY:FILE[:NAME]:AUTO:DIRectory:CLEar

Deletes all files with extensions *.bmp, *.jpg, *.png and *.xpm in the directory set for automatic naming.

Example: See [Example "Store a hard copy of the display"](#) on page 444

Usage: Event

Manual operation: See ["Clear Path"](#) on page 319

:HCOPY:FILE[:NAME]:AUTO:FILE?

Queries the name of the automatically named hard copy file.

An automatically generated file name consists of:

<Prefix><YYYY><MM><DD><Number>.<Format>.

You can activate each component separately, to individually design the file name.

Return values:

<File> string

Example: See [Example "Store a hard copy of the display"](#) on page 444.

Usage: Query only

:HCOPY:FILE[:NAME]:AUTO:STATe <State>

Activates automatic naming of the hard copy files.

Parameters:

<State> 0 | 1 | OFF | ON
*RST: 1

Example: See [Example "Store a hard copy of the display"](#) on page 444

Manual operation: See ["Automatic Naming"](#) on page 318

:HCOPY:FILE[:NAME]:AUTO[:FILE]:DAY:STATe <State>**:HCOPY:FILE[:NAME]:AUTO[:FILE]:MONTH:STATe <State>****:HCOPY:FILE[:NAME]:AUTO[:FILE]:YEAR:STATe <State>**

Uses the date parameters (year, month or day) for the automatic naming. You can activate each of the date parameters separately.

Parameters:

<State> 0 | 1 | OFF | ON
*RST: 1

Example: See [Example "Store a hard copy of the display"](#) on page 444

Manual operation: See ["Prefix, Year, Month, Day"](#) on page 319

:HCOPY:FILE[:NAME]:AUTO[:FILE]:NUMBER?

Queries the number that is used as part of the file name for the next hard copy in automatic mode.

At the beginning, the count starts at 0. The R&S SMA100B searches the specified output directory for the highest number in the stored files. It increases this number by one to achieve a unique name for the new file.

The resulting auto number is appended to the resulting file name with at least three digits.

Return values:

<Number> integer
 Range: 0 to 999999
 *RST: 0

Example: See [Example "Store a hard copy of the display"](#) on page 444

Usage: Query only

Manual operation: See ["Current Auto Number"](#) on page 319

:HCOPY:FILE[:NAME]:AUTO[:FILE]:PREFIX <Prefix>**:HCOPY:FILE[:NAME]:AUTO[:FILE]:PREFIX:STATe <State>**

Uses the prefix for the automatic generation of the file name, provided `PREF:STAT` is activated.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 1

Example: See [Example "Store a hard copy of the display"](#) on page 444

Manual operation: See ["Prefix, Year, Month, Day"](#) on page 319

14.12 KBOard Subsystem

The KBOard subsystem contains the commands to set a connected keyboard.

[:KBOard:LAYout](#).....449

:KBOard:LAYout <Layout>

Selects the language for an external keyboard and assigns the keys accordingly.

Parameters:

<Layout> CHINese | DANish | DUTCh | DUTBe | ENGLish | ENGUk |
 FINNish | FRENch | FREBe | FRECa | GERMan | ITALian |
 JAPANese | KORean | NORWegian | PORTuguese | RUSSian |
 SPANish | SWEDish | ENGUS
 *RST: n.a. (factory preset: ENGLISH)

Example:

```
:KBOard:LAYout US
// activates American keyboard
```

Manual operation: See "[USB Keyboard > Layout](#)" on page 324

14.13 OUTPut Subsystem

In the OUTPut subsystem, you can configure the output signals.

The LF output signal is defined with the commands of the [Chapter 14.16.6, "SOURce:LFOutput Subsystem"](#), on page 603 system.

Common suffixes

The following common suffixes are used in remote commands:

Suffix	Value range	Description
OUTPut<hw>	[1]	Optional suffix

:OUTPut:ALL[:STATe].....	450
:OUTPut<hw>[:STATe].....	451
:OUTPut<hw>[:STATe]:PON.....	451
:OUTPut<hw>:AMODE.....	451
:OUTPut<hw>:FILTer:MODE.....	452
:OUTPut<hw>:IMPedance?.....	452
:OUTPut:FPRoportional:SCALE.....	452
:OUTPut:USER:MARKer.....	453
:OUTPut<hw>:AFIXed:RANGe:LOWer?.....	453
:OUTPut<hw>:AFIXed:RANGe:UPPer?.....	453
:OUTPut<hw>:PROTection:CLEar.....	453
:OUTPut<hw>:PROTection:TRIPped?.....	454

:OUTPut:ALL[:STATe] <State>

Activates the RF output signal of the instrument.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: n.a. (factory preset: 0)

Example:

```
OUTPut:ALL:STATe 0
```

:OUTPut<hw>[:STATe] <State>

Activates the RF output signal.

Parameters:

<State> 0 | 1 | OFF | ON
*RST: 0

Example: OUTP ON
 Activates the RF output.

Manual operation: See "[RF State/RF ON](#)" on page 63

:OUTPut<hw>[:STATe]:PON <Pon>

Defines the state of the RF output signal when the instrument is switched on.

Parameters:

<Pon> OFF | UNCHanged
*RST: n.a. (factory preset: UNCHanged)

Example: OUTP:PON OFF
 The RF output is deactivated when the instrument is switched on.

Manual operation: See "[Power-On State](#)" on page 325

:OUTPut<hw>:AMODe <AMode>

Sets the step attenuator mode at the RF output.

Parameters:

<AMode> AUTO | FIXEd

AUTO

The step attenuator adjusts the level settings automatically, within the full variation range.

FIXEd

The step attenuator and amplifier stages are fixed at the current position, providing level settings settings with constant output VSWR. The resulting variation range is calculated according to the position.

*RST: AUTO

Example: SOURce:POWer:ALC:STATe 1
 OUTPut:AMODe FIXEd

Manual operation: See "[Mode](#)" on page 199

:OUTPut<hw>:FILTer:MODE <Mode>

Activates low harmonic filter or enables its automatic switching.

Parameters:

<Mode> ON | AUTO | 1

ON|1
Ensures best low harmonics performance but decreases the level range

AUTO
Applies an automatically selected harmonic filter that fits to the current level setting.

*RST: AUTO

Example: OUTPut:FILTer:MODE AUTO

Manual operation: See " [Harmonic Filter](#) " on page 71

:OUTPut<hw>:IMPedance?

Queries the impedance of the RF outputs.

Return values:

<Impedance> G1K | G50 | G10K

*RST: G50

Example: OUTP:IMP?
queries the impedance of RF output.
Response: 50
the impedance is 50 ohms

Usage: Query only

Manual operation: See "[RF output impedance](#)" on page 63

:OUTPut:FPRoportional:SCALE <OutpSelScale>

Selects the mode the voltage is supplied depending on the frequency.

The R&S SMA100B supplies the signal at the V/GHz X-Axis connector.

Parameters:

<OutpSelScale> S0V25 | S0V5 | S1V0 | XAXis

S0V25|S0V5|S1V0
Supplies the voltage proportional to the set frequency, derived from the selected setting.

XAXis
Supplies a voltage range from 0 V to 10 V proportional to the frequency sweep range, set with [:SOURce<hw>] :FREQuency:STARt and [:SOURce<hw>] :FREQuency:STOP.

*RST: S0V25

Options: R&S SMAB-B28
Manual operation: See " [V/GHz / X-Axis](#) " on page 182

:OUTPut:USER:MARKer <SelUserMarker>

Selects the signal for output at the Marker User1 connector.

Parameters:

<SelUserMarker> MARK | USER
MARK
 Assigns a marker signal to the output.
USER
 Intended for future use.
 *RST: MARK

Options: R&S SMAB-B28
Manual operation: See " [Marker / User](#) " on page 183

:OUTPut<hw>:AFIXed:RANGe:LOWer?

:OUTPut<hw>:AFIXed:RANGe:UPPer?

Queries the settable minimum/maximum value in mode :OUTPut:AMODE FIXed, i.e. when the attenuator is not being adjusted.

See :OUTPut<hw>:AMODE on page 451

Return values:

<Upper> float
 Increment: 0.01
 Default unit: dBm

Example:

```
OUTPut1:AMODE FIXed
OUTPut1:AFIXed:RANGe:UPPer?
// -27
OUTPut1:AFIXed:RANGe:LOW?
// -50
```

Usage: Query only
Manual operation: See " [Level Range](#) " on page 199

:OUTPut<hw>:PROTection:CLEar

Resets the protective circuit after it has been tripped.

To define the output state, use the command :OUTPut<hw>[:STATE].

Example: OUPt:PROT:CLE
 Resets the protective circuit of the RF output.

Usage: Event

Manual operation: See "Overload" on page 200

:OUTPut<hw>:PROTection:TRIPped?

Queries the state of the protective circuit.

Return values:

<Tripped> 0 | 1 | OFF | ON
 *RST: 0

Example:

OUTP:PROT:TRIP
 queries the state of the protective circuit of the RF output.
 Response: 0
 the protective circuit has not tripped.

Usage: Query only

Manual operation: See "Overload" on page 200

14.14 Power Sensor Measurement Subsystems

The power sensor measurement uses several subsystems:

- The CALCulate subsystem is used to configure the time gated measurements in power analysis.
- The DISPLAY subsystem is used to configure the diagram appearance.
- The INITiate command switches the local state of the continuous power measurement on and off.
- The READ system is used to start and to retrieve the measurement result of the power viewer measurement.
- The SENSE subsystem contains the commands for configuring the power viewer and power analysis measurements with power sensors connected to the generator. Up to four sensors can be connected to the signal generator.
- The TRACE subsystem is used to configure the traces in power analysis and to retrieve the measurement results.

Power Viewer

The power viewer measurement is started with the READ command, this command also retrieves the measurement results.

The sensors are distinguished by the suffix under SENSE:

- Power sensor connected to the SENSOR port = SENSE[1]
- First Power sensor connected to the USB interface = SENSE2
- Second Power sensor connected to the USB interface = SENSE3
- Third Power sensor connected to the USB interface = SENSE4

Power and Pulse Data Analysis, Gated Measurements (option R&S SMA100B-K28)

The power analysis measurement commands are subsumed under the `SENSe[:POWER]:SWEep:...` commands. Three measurement modes are available: Frequency, Power and Time.

The power analysis measurement is started with the `SENSe[:POWER]:SWEep:INITiate` command and the measurement result retrieved with the `TRACe[:POWER]:SWEep:...` commands.

The four sensors are distinguished by the suffix at the second key word `SENSe`.

The time gate settings are performed using the `CALCulate[:POWER]:SWEep:...` commands.

The measurement diagram and results can be stored in a hardcopy with the `SENSe[:POWER]:SWEep:HCOpy:...` commands.

General parameter and measurement settings are valid for all connected sensors, therefore, no suffix is used in these commands.

14.14.1 CALCulate Subsystem

<code>:CALCulate[:POWER]:SWEep:FREQuency:MATH<ch>:STATe</code>	455
<code>:CALCulate[:POWER]:SWEep:FREQuency:MATH<ch>:SUBTract</code>	456
<code>:CALCulate[:POWER]:SWEep:POWer:MATH<ch>:STATe</code>	456
<code>:CALCulate[:POWER]:SWEep:POWer:MATH<ch>:SUBTract</code>	456
<code>:CALCulate[:POWER]:SWEep:TIME:GATE<ch>:AVERAge?</code>	457
<code>:CALCulate[:POWER]:SWEep:TIME:GATE<ch>:FEED</code>	457
<code>:CALCulate[:POWER]:SWEep:TIME:GATE<ch>:MAXimum?</code>	457
<code>:CALCulate[:POWER]:SWEep:TIME:GATE<ch>:START</code>	458
<code>:CALCulate[:POWER]:SWEep:TIME:GATE<ch>:STOP</code>	458
<code>:CALCulate[:POWER]:SWEep:TIME:GATE<ch>:STATe</code>	458
<code>:CALCulate[:POWER]:SWEep:TIME:MATH<ch>:STATe</code>	459
<code>:CALCulate[:POWER]:SWEep:TIME:MATH<ch>:SUBTract</code>	459

`:CALCulate[:POWER]:SWEep:FREQuency:MATH<ch>:STATe <State>`

Activates the trace mathematics mode for "Frequency" measurement. This feature enables you to calculate the difference between the measurement values of two traces. For further calculation, a math result can also be assigned to a trace.

Parameters:

`<State>` 0 | 1 | OFF | ON
`*RST:` 0

Example:

`CALC:POW:SWE:FREQ:MATH2:STATe`
 Switches on math mode in trace 2.

Options:

R&S SMAB-K28

Manual operation:

See " [Mathematics - Trace Power Analysis](#) " on page 232

:CALCulate[:POWer]:SWEep:FREQuency:MATH<ch>:SUBTract <Subtract>

Subtracts the operands 1 and 2 and assigns the result to the selected trace in "Frequency" measurement mode.

Parameters:

<Subtract> T1T1 | T1T2 | T1T3 | T1T4 | T1REf | T2T1 | T2T2 | T2T3 | T2T4 |
T2REf | T3T1 | T3T2 | T3T3 | T3T4 | T3REf | T4T1 | T4T2 |
T4T3 | T4T4 | T4REf

Example:

CALC:POW:SWE:FREQ:MATH4:SUBT T2REF

Subtracts the Reference and Trace 2, and assigns the result to Trace 4. The resulting curve is shown in the diagram.

Options:

R&S SMAB-K28

Manual operation: See "[Mathematics - Trace Power Analysis](#)" on page 232

:CALCulate[:POWer]:SWEep:POWer:MATH<ch>:STATe <State>

Activates the trace mathematics mode for "Power" measurement. This feature enables you to calculate the difference between the measurement values of two traces. For further calculation, a math result can also be assigned to a trace.

Parameters:

<State> 0 | 1 | OFF | ON
*RST: 0

Example:

CALC:POW:SWE:POW:MATH2:STATe

Switches on math mode in trace 2.

Options:

R&S SMAB-K28

Manual operation: See "[Mathematics - Trace Power Analysis](#)" on page 232

:CALCulate[:POWer]:SWEep:POWer:MATH<ch>:SUBTract <Subtract>

Subtracts the operands 1 and 2 and assigns the result to the selected trace in "Power" measurement mode.

Parameters:

<Subtract> T1T1 | T1T2 | T1T3 | T1T4 | T1REf | T2T1 | T2T2 | T2T3 | T2T4 |
T2REf | T3T1 | T3T2 | T3T3 | T3T4 | T3REf | T4T1 | T4T2 |
T4T3 | T4T4 | T4REf

Example:

CALC:POW:SWE:POW:MATH4:SUBT T2REF

Subtracts the Reference and Trace 2, and assigns the result to Trace 4. The resulting curve is shown in the diagram.

Options:

R&S SMAB-K28

Manual operation: See "[Mathematics - Trace Power Analysis](#)" on page 232

:CALCulate[:POWer]:SWEep:TIME:GATE<ch>:AVERage?

Queries the average power value of the time gated measurement.

Return values:

<Average> float
 Range: -1000 to 1000
 Increment: 1E-12
 *RST: 0

Example:

SENS:SWE:MODE TIME
 Activates time mode for power analysis.
 CALC:SWE:TIME:GATE:STAT ON
 Activates time gated measurement.
 SENS:SWE:INIT
 Activates a single power analysis measurement.
 CALC:SWE:TIME:GATE2:AVER?
 Queries the average power in time gate 2 for trace 1 (=default).

Usage: Query only

Options: Option R&S SMAB-K28

Manual operation: See " [State - Gate](#) " on page 255

:CALCulate[:POWer]:SWEep:TIME:GATE<ch>:FEED <Feed>

Selects the trace for time gated measurement. Both gates are assigned to the same trace.

Parameters:

<Feed> TRAC1 | TRAC2 | TRAC3 | TRACe1 | TRACe2 | TRACe3 |
 TRAC4 | TRACe4
 *RST: TRAC1

Example:

CALC:SWE:TIME:GATE:FEED TRAC2
 Assigns the gates to trace 2.

Options: Option R&S SMAB-K28

Manual operation: See " [Trace - Gate](#) " on page 254

:CALCulate[:POWer]:SWEep:TIME:GATE<ch>:MAXimum?

Queries the average power value of the time gated measurement.

Return values:

<Maximum> float
 Range: -1000 to 1000
 Increment: 1E-12
 *RST: 0

Example: SENS : SWE : MODE TIME
 Activates time mode for power analysis.
 CALC : SWE : TIME : GATE : STAT ON
 Activates time gated measurement.
 SENS : SWE : INIT
 Activates a single power analysis measurement.
 CALC : SWE : TIME : GATE2 : MAX?
 Queries the peak power in time gate 2 for trace 1 (=default).

Usage: Query only

Options: Option R&S SMAB-K28

Manual operation: See " [State - Gate](#) " on page 255

:CALCulate[:POWer]:SWEep:TIME:GATE<ch>:STARt <Start>
:CALCulate[:POWer]:SWEep:TIME:GATE<ch>:STOP <Stop>

Sets the start time of the selected gate. Insert value and unit.

Parameters:

<Stop> float
 Increment: 1E-12
 *RST: Start/Stop: 5/15 (Gate1), 25/35 (Gate2)

Example: CALC : SWE : TIME : GATE2 : STAR 20us
 Sets a start time of 20 us for gate 2.
 CALC : SWE : TIME : GATE2 : STOP 30us
 Sets a stop time of 30us for gate 2.

Options: Option R&S SMAB-K28

Manual operation: See " [Start / Stop - Gate](#) " on page 255

:CALCulate[:POWer]:SWEep:TIME:GATE<ch>:STATe <State>

Activates the gate settings for the selected trace. The measurement is started with command SENS : POW : INIT. Both gates are active at one time.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 0

Example: CALC : SWE : TIME : GATE : STAT ON
 Enables time gated measurement.

Options: Option R&S SMAB-K28

Manual operation: See " [State - Gate](#) " on page 255

:CALCulate[:POWER]:SWEep:TIME:MATH<ch>:STATe <State>

Activates the trace mathematics mode for "Time" measurement. This feature enables you to calculate the difference between the measurement values of two traces. For further calculation, a math result can also be assigned to a trace.

Parameters:

<State> 0 | 1 | OFF | ON
*RST: 0

Example:

CALC:POW:SWE:TIME:MATH1:STATe
Switches on math mode.

Options:

R&S SMAB-K28

Manual operation: See " [Mathematics - Trace Power Analysis](#) " on page 232

:CALCulate[:POWER]:SWEep:TIME:MATH<ch>:SUBTract <Subtract>

Subtracts the operands 1 and 2 and assigns the result to the selected trace in "Time" measurement mode.

Parameters:

<Subtract> T1T1 | T1T2 | T1T3 | T1T4 | T1REF | T2T1 | T2T2 | T2T3 | T2T4 |
T2REF | T3T1 | T3T2 | T3T3 | T3T4 | T3REF | T4T1 | T4T2 |
T4T3 | T4T4 | T4REF

Example:

CALC:POW:SWE:TIME:MATH4:SUBT T2REF
Subtracts the Reference and Trace 2, and assigns the result to Trace 4. The resulting curve is shown in the diagram.

Options:

R&S SMAB-K28

Manual operation: See " [Mathematics - Trace Power Analysis](#) " on page 232

14.14.2 DISPlay Subsystem

[:DISPlay\[:WINDow\]\[:POWER\]:SWEep:BACKground:COLor.....](#) 459

[:DISPlay\[:WINDow\]\[:POWER\]:SWEep:GRID:STATe.....](#) 460

:DISPlay[:WINDow][:POWER]:SWEep:BACKground:COLor <Color>

Defines the background color of the measurement diagram. The selected color applies also to the hardcopy of the diagram.

Parameters:

<Color> BLACK | WHITe
*RST: BLACK

Example:

DISP:SWE:BACK:COL WHIT
The measurement is indicated with a white background.

Manual operation: See " [Background Color - Power Analysis](#) " on page 243

```
:DISPlay[:WINDow][:POWer]:SWEep:GRID:STATe <State>
```

Indicates a grid in the diagram.

Parameters:

```
<State>          0 | 1 | OFF | ON
*RST:            1
```

Example: DISP:SWE:GRID:STAT OFF
Deactivates the indication of a grid in the diagram area.

Manual operation: See " [Show Grid - Power Analysis](#) " on page 243

14.14.3 INITiate Command

```
:INITiate<hw>[:POWer]:CONTInuous <Continuous>
```

Switches the local state of the continuous power measurement by R&S NRP power sensors on and off. Switching off local state enhances the measurement performance during remote control.

The remote measurement is triggered with `:READ<ch>[:POWer]?`. This command also returns the measurement results. The local state is not affected, measurement results can be retrieved with local state on or off.

Parameters:

```
<Continuous>    0 | 1 | OFF | ON
*RST:            0
```

Example: INIT1:CONT ON
Switches local state of continuous power measurement on.

Manual operation: See " [State](#) " on page 221

14.14.4 SENSE SWEep Subsystem

<code>:SENSe<ch>[:POWer]:SWEep:FREQUency[:SENSor]:OFFSet</code>	462
<code>:SENSe<ch>[:POWer]:SWEep:FREQUency[:SENSor]:OFFSet:STATe</code>	463
<code>:SENSe<ch>[:POWer]:SWEep:FREQUency[:SENSor]:SRANge:START</code>	463
<code>:SENSe<ch>[:POWer]:SWEep:FREQUency[:SENSor]:SRANge:STOP</code>	463
<code>:SENSe<ch>[:POWer]:SWEep:FREQUency[:SENSor]:SRANge[:STATe]</code>	464
<code>:SENSe<ch>[:POWer]:SWEep:POWer[:SENSor]:OFFSet</code>	464
<code>:SENSe<ch>[:POWer]:SWEep:POWer[:SENSor]:OFFSet:STATe</code>	465
<code>:SENSe<ch>[:POWer]:SWEep:POWer[:SENSor]:SFRequency</code>	465
<code>:SENSe<ch>[:POWer]:SWEep:POWer[:SENSor]:SFRequency:STATe</code>	465
<code>:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:OFFSet</code>	466
<code>:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:OFFSet:STATe</code>	466
<code>:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:STATe</code>	466
<code>:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:THReshold:BASE</code>	467

:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:THReshold:POWer:HREFerence.....	467
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:THReshold:POWer:LREFerence.....	467
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:THReshold:POWer:REFerence.....	468
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:SFRrequency.....	468
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:SFRrequency:STATe.....	468
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:TRIGger:AUTO.....	469
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:TRIGger:DTIME.....	469
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:TRIGger:HYSteresis.....	469
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:TRIGger:LEVel.....	470
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:TRIGger:SLOPe.....	470
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:TRIGger:SOURce.....	470
:SENSe<ch>[:POWer]:ZERO.....	470
:SENSe[:POWer]:SWEep:ABORT.....	471
:SENSe[:POWer]:SWEep:FREQuency:REFerence:DATA:COpy.....	471
:SENSe[:POWer]:SWEep:FREQuency:REFerence:DATA:POINts?.....	471
:SENSe[:POWer]:SWEep:FREQuency:REFerence:DATA:XVALues.....	471
:SENSe[:POWer]:SWEep:FREQuency:REFerence:DATA:YVALues.....	472
:SENSe[:POWer]:SWEep:FREQuency:RMODE.....	472
:SENSe[:POWer]:SWEep:FREQuency:SPACing[:MODE].....	472
:SENSe[:POWer]:SWEep:FREQuency:START.....	472
:SENSe[:POWer]:SWEep:FREQuency:STEPS.....	473
:SENSe[:POWer]:SWEep:FREQuency:STOP.....	473
:SENSe[:POWer]:SWEep:FREQuency:TIMing[:MODE].....	473
:SENSe[:POWer]:SWEep:FREQuency:YSCale:AUTO.....	474
:SENSe[:POWer]:SWEep:FREQuency:YSCale:AUTO:RESet.....	474
:SENSe[:POWer]:SWEep:FREQuency:YSCale:MAXimum.....	474
:SENSe[:POWer]:SWEep:FREQuency:YSCale:MINimum.....	475
:SENSe[:POWer]:SWEep:HCOPy:DATA?.....	475
:SENSe[:POWer]:SWEep:HCOPy:DEvice.....	476
:SENSe[:POWer]:SWEep:HCOPy:DEvice:LANGUage.....	477
:SENSe[:POWer]:SWEep:HCOPy:DEvice:LANGUage:CSV:DPOint.....	477
:SENSe[:POWer]:SWEep:HCOPy:DEvice:LANGUage:CSV:HEADer.....	477
:SENSe[:POWer]:SWEep:HCOPy:DEvice:LANGUage:CSV:ORientation.....	478
:SENSe[:POWer]:SWEep:HCOPy:DEvice:LANGUage:CSV[:COLumn]:SEParator.....	478
:SENSe[:POWer]:SWEep:HCOPy:DEvice:SIZE.....	478
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME].....	479
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO:DIRectory.....	479
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO:DIRectory:CLear.....	479
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO:FILE?.....	480
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO:STATe.....	480
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:DAY?.....	480
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:DAY:STATe.....	481
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:MONTH?.....	481
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:MONTH:STATe.....	481
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:NUMBer?.....	482
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:PREFix.....	482
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:PREFix:STATe.....	482
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:YEAR?.....	482
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:YEAR:STATe.....	483
:SENSe[:POWer]:SWEep:HCOPy[:EXECute].....	483

:SENSe[:POWER]:SWEep:INITiate.....	483
:SENSe[:POWER]:SWEep:MODE.....	483
:SENSe[:POWER]:SWEep:POWer:REFErence:DATA:COpy.....	484
:SENSe[:POWER]:SWEep:POWer:REFErence:DATA:POINts?.....	484
:SENSe[:POWER]:SWEep:POWer:REFErence:DATA:XVALues.....	484
:SENSe[:POWER]:SWEep:POWer:REFErence:DATA:YVALues.....	484
:SENSe[:POWER]:SWEep:POWer:RMODE.....	485
:SENSe[:POWER]:SWEep:POWer:SPACing[:MODE].....	485
:SENSe[:POWER]:SWEep:POWer:STARt.....	485
:SENSe[:POWER]:SWEep:POWer:STEPs.....	485
:SENSe[:POWER]:SWEep:POWer:STOP.....	486
:SENSe[:POWER]:SWEep:POWer:TIMing[:MODE].....	486
:SENSe[:POWER]:SWEep:POWer:YSCale:AUTO.....	486
:SENSe[:POWER]:SWEep:POWer:YSCale:AUTO:RESet.....	487
:SENSe[:POWER]:SWEep:POWer:YSCale:MAXimum.....	487
:SENSe[:POWER]:SWEep:POWer:YSCale:MINimum.....	488
:SENSe[:POWER]:SWEep:RMODE.....	488
:SENSe[:POWER]:SWEep:TIME:AVERAge[:COUNT].....	488
:SENSe[:POWER]:SWEep:TIME:REFErence:DATA:COpy.....	489
:SENSe[:POWER]:SWEep:TIME:REFErence:DATA:POINts?.....	489
:SENSe[:POWER]:SWEep:TIME:REFErence:DATA:XVALues.....	489
:SENSe[:POWER]:SWEep:TIME:REFErence:DATA:YVALues.....	489
:SENSe[:POWER]:SWEep:TIME:RMODE.....	490
:SENSe[:POWER]:SWEep:TIME:SPACing[:MODE].....	490
:SENSe[:POWER]:SWEep:TIME:STARt.....	490
:SENSe[:POWER]:SWEep:TIME:STEPs.....	490
:SENSe[:POWER]:SWEep:TIME:STOP.....	491
:SENSe[:POWER]:SWEep:TIME:TEVents.....	491
:SENSe[:POWER]:SWEep:TIME:YSCale:AUTO.....	491
:SENSe[:POWER]:SWEep:TIME:YSCale:AUTO:RESet.....	492
:SENSe[:POWER]:SWEep:TIME:YSCale:MAXimum.....	492
:SENSe[:POWER]:SWEep:TIME:YSCale:MINimum.....	493

:SENSe<ch>[:POWer]:SWEep:FREQuency[:SENSor]:OFFSet <Offset>

Defines the level offset at the sensor input in dB. Activate the offset with the command `:SENSe<ch>[:POWer]:SWEep:FREQuency[:SENSor]:OFFSet:STATe` on page 463.

Parameters:

<Offset>	float
Range:	-100 to 100
Increment:	0.01
*RST:	0

Example:

```
SENS2:SWE:FREQ:OFFS -3dB
Defines a level offset of -3 dB.
SENS2:SWE:FREQ:OFFS:STAT ON
Activates the specified level offset.
```

Options:

Option R&S SMAB-K28

Manual operation: See " [Level Offset - Power Analysis](#) " on page 240

:SENSe<ch>[:POWer]:SWEep:FREQuency[:SENSor]:OFFSet:STATe <State>

Activates a level offset at the sensor input. Define the appropriate value with the command `:SENSe<ch>[:POWer]:SWEep:FREQuency[:SENSor]:OFFSet` on page 462.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 0

Example: `SENS2:SWE:FREQ:OFFS:STAT ON`
 Activates the specified level offset.

Options: Option R&S SMAB-K28

Manual operation: See " [Level Offset State- Power Analysis](#) " on page 240

:SENSe<ch>[:POWer]:SWEep:FREQuency[:SENSor]:SRANge:STARt <Start>

Sets the start frequency for the frequency power analysis with separate frequencies.

Parameters:

<Start> integer
 Range: 0 to 1E12
 *RST: 1E6

Example: `SENS2:SWE:FREQ:SENS:SRAN:STAT ON`
 Activates use of a separate frequency range for frequency versus power measurement for sensor 2.
`SENS2:SWE:FREQ:SENS:STAR 2.0GHZ`
 Sets a sweep start at 2 GHz irrespective of the current signal generator frequency settings.

Manual operation: See " [Min Frequency - Power Analysis](#) " on page 241

:SENSe<ch>[:POWer]:SWEep:FREQuency[:SENSor]:SRANge:STOP <Stop>

Sets the stop frequency for the frequency power analysis with separate frequencies.

Parameters:

<Stop> integer
 Range: 0 to 1E12
 *RST: 10E6

Example: SENS:SWE:FREQ:SENS2:SRAN:STAT ON
 Activates use of a separate frequency range for frequency versus power measurement.
 SENS:SWE:FREQ:SENS2:STAR 2.0GHZ
 Sets a sweep start at 2 GHz irrespective of the current signal generator frequency settings.
 SENS:SWE:FREQ:SENS2:STOP 2.9GHZ
 Sets a sweep stop at 2.9 GHz irrespective of the current signal generator frequency settings.

Manual operation: See "[Max Frequency - Power Analysis](#)" on page 241

:SENSe<ch>[:POWer]:SWEep:FREQuency[:SENSor]:SRANge[:STATe] <State>

Activates the use of a frequency range for the power measurement that is different to the set signal generator frequency range. The separate frequency range is entered with commands [:SENSe<ch>\[:POWer\]:SWEep:FREQuency\[:SENSor\]:SRANge:STARt](#) on page 463 and [:SENSe<ch>\[:POWer\]:SWEep:FREQuency\[:SENSor\]:SRANge:STOP](#) on page 463.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 0

Example: SENS2:SWE:FREQ:SENS:SRAN ON
 Activates use of a separate frequency range for frequency versus power measurement for sensor 2.
 SENS2:SWE:FREQ:SENS:STAR 2.0GHZ
 Sets a sweep start at 2 GHz irrespective of the current signal generator frequency settings.
 SENS2:SWE:FREQ:SENS:STOP 2.9GHZ
 Sets a sweep stop at 2.9 GHz irrespective of the current signal generator frequency settings.

Manual operation: See "[Use Separate Frequency- Power Analysis](#)" on page 240

:SENSe<ch>[:POWer]:SWEep:POWer[:SENSor]:OFFSet <Offset>

Defines the level offset at the sensor input in dB. Activate the offset with the command [:SENSe<ch>\[:POWer\]:SWEep:POWer\[:SENSor\]:OFFSet:STATe](#) on page 465.

Parameters:

<Offset> float
 Range: -100 to 100
 Increment: 0.01
 *RST: 0

Example: SENS2:SWE:POW:OFFS -5dB
 Defines a level offset of -5 dB.
 SENS2:SWE:POW:OFFS:STAT ON
 Activates that the specified level offset is considered.

Options: Option R&S SMAB-K28

Manual operation: See " [Level Offset - Power Analysis](#) " on page 240

:SENSe<ch>[:POWer]:SWEep:POWer[:SENSor]:OFFSet:STATe <State>

Activates a level offset at the sensor input. Define the appropriate value with the command [:SENSe<ch>\[:POWer\]:SWEep:POWer\[:SENSor\]:OFFSet](#) on page 464.

Parameters:
 <State> 0 | 1 | OFF | ON
 *RST: 0

Example: SENS2:SWE:POW:OFFS:STAT ON
 Activates the specified level offset.

Options: Option R&S SMAB-K28

:SENSe<ch>[:POWer]:SWEep:POWer[:SENSor]:SFRrequency <SFRrequency>

Defines the separate frequency used for power vs. power measurement.

Parameters:
 <SFRrequency> float
 Range: 0 to 1E12
 Increment: 1
 *RST: 1E6

Example: SENS1:SWE:POW:SENS:SFR 2GHz
 The measurement is performed at 2 GHz

Manual operation: See " [Use Separate Frequency- Power Analysis](#) " on page 240

:SENSe<ch>[:POWer]:SWEep:POWer[:SENSor]:SFRrequency:STATe <State>

Activates the use of a different frequency for the power measurement.

Parameters:
 <State> 0 | 1 | OFF | ON
 *RST: 0

Example: SENS1:SWE:POW:SENS:SFR:STAT ON
 Activates the use of a separate frequency than the generator frequency for power analysis

Manual operation: See " [Use Separate Frequency- Power Analysis](#) " on page 240

:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:OFFSet <Offset>

Defines the level offset at the sensor input in dB. Activate the offset with the command `:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:OFFSet:STATe` on page 466.

Parameters:

<Offset> float
 Range: -100 to 100
 Increment: 0.01
 *RST: 0

Example:

`SENS2:SWE:TIME:OFFS -7dB`
 Defines a level offset of -7 dB.
`SENS2:SWE:TIME:OFFS:STAT ON`
 The specified level offset is considered.

Options:

Option R&S SMAB-K28

Manual operation: See "[Level Offset - Power Analysis](#)" on page 240

:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:OFFSet:STATe <State>

Activates a level offset at the sensor input. Define the appropriate value with the command `:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:OFFSet` on page 466.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 0

Example:

`SENS2:SWE:POW:TIME:STAT ON`
 Activates the specified level offset.

Options:

Option R&S SMAB-K28

Manual operation: See "[Level Offset State- Power Analysis](#)" on page 240

:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:STATe <State>

Enables pulse data analysis. The measurement is started with command `INITiate`.

Note: The command is only available in time measurement mode and with R&S NRP-Z81 power sensors.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 0

Example:

`SENS1:SWE:TIM:PULS:STAT ON`
 Enables pulse data analysis.

Options:

Option R&S SMAB-K28

Manual operation: See "[Pulse Analysis](#)" on page 245

:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:THReshold:BASE <Base>

Selects how the threshold parameters for pulse analysis are calculated.

Note: The command is only available in time measurement mode and with R&S NRPZ81 power sensors.

Parameters:

<Base> VOLTage | POWer
 *RST: VOLTage

Example: SENS1 : SWE : TIME : PULS : THR : BASE POW
 Activates threshold calculation related to power.

Options: Option R&S SMAB-K28

Manual operation: See " [Base](#) " on page 245

:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:THReshold:POWER: HREFerence <HReference>

Sets the upper reference level in terms of percentage of the overall pulse level (power or voltage). The distal power defines the end of the rising edge and the start of the falling edge of the pulse.

Note: The command is only available in time measurement mode and with R&S NRPZ81 power sensors.

Parameters:

<HReference> float
 Range: 0 to 100
 Increment: 0.01
 *RST: 90

Options: Option R&S SMAB-K28

Manual operation: See " [Distal](#) " on page 245

:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:THReshold:POWER: LREFerence <LReference>

Sets the lower reference level in terms of percentage of the overall pulse level. The proximal power defines the start of the rising edge and the end of the falling edge of the pulse.

Note: This parameter is only available in time measurement mode and R&S NRP-Z81 power sensors.

Parameters:

<LReference> float
 Range: 0.0 to 100.0
 Increment: 0.01
 *RST: 10.0

Example: `SENS:SWE:TIM:PULS:THR:LREF 10`
Sets the lower reference level to 10%.

Options: Option R&S SMAB-K28

Manual operation: See " [Proximal](#) " on page 246

**:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:THReshold:POWer:
REFerence <Reference>**

Sets the medial reference level in terms of percentage of the overall pulse level (power or voltage related). This level is used to define pulse width and pulse period.

Note: The command is only available in time measurement mode and with R&S NRPZ81 power sensors.

Parameters:

<Reference> float
Range: 0.0 to 100.0
Increment: 0.01
*RST: 50.0

Example: `SENS1:SWE:TIM:PULS:THR:REF 40`
Sets the medial reference level to 40% of the overall pulse level.

Options: Option R&S SMAB-K28

Manual operation: See " [Mesial](#) " on page 246

:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:SFRequency <SFrequency>

Defines the separate frequency used for power vs. time measurement.

Parameters:

<SFrequency> float
Range: 0 to 1E12
Increment: 1
*RST: 1E6

Example: `SENS1:SWE:TIME:SENS:SFR 2GHz`
The measurement is performed at 2 GHz

Manual operation: See " [Use Separate Frequency- Power Analysis](#) " on page 240

:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:SFRequency:STATe <State>

Activates the use of a different frequency for the power measurement.

Parameters:

<State> 0 | 1 | OFF | ON
*RST: 0

Example: `SENS1:SWE:TIME:SENS:SFR:STAT ON`
 Activates the use of a separate frequency than the generator frequency for power analysis

Manual operation: See " [Use Separate Frequency- Power Analysis](#) " on page 240

:SENSe<ch>[:POWer]:SWEp:TIME[:SENSor]:TRIGger:AUTO <Auto>

Sets the trigger level, the hysteresis and the dropout time to default values.

Parameters:

<Auto> ONCE
 *RST: ---

Example: `SENS1:SWE:TIME:SENS:TRIG:AUTO ONCE`
 The trigger level is automatically determined

Manual operation: See " [Auto Set - Power Analysis](#) " on page 253

:SENSe<ch>[:POWer]:SWEp:TIME[:SENSor]:TRIGger:DTIME <DTime>

Determines the minimum time for which the signal must be below (above) the power level defined by level and hysteresis before triggering can occur again.

Parameters:

<DTime> float
 Range: 0 to 10
 *RST: 200E-9

Example: `SENS1:SWE:TIME:SENS:TRIG:DTIM 10 us`
 The drop out time is 10 us

Manual operation: See " [Drop out Time - Power Analysis](#) " on page 252

:SENSe<ch>[:POWer]:SWEp:TIME[:SENSor]:TRIGger:HYSTeresis <Hysteresis>

Sets the hysteresis of the internal trigger threshold. Hysteresis is the magnitude (in dB) the trigger signal level must drop below the trigger threshold (positive trigger slope) before triggering can occur again.

Parameters:

<Hysteresis> float
 Range: 0 to 10
 Increment: 0.001
 *RST: 0.5

Example: `SENS1:SWE:TIME:SENS:TRIG:HYST 0.5 dB`
 The hysteresis is 0.5 dB

Manual operation: See " [Hysteresis - Power Analysis](#) " on page 252

```
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:TRIGger:LEVel <Level>
```

Sets the trigger threshold.

Parameters:

```
<Level>          float
                  Range:    -200 to 100
                  Increment: 0.001
                  *RST:     1
```

Example: `SENS1:SWE:TIME:SENS:TRIG:LEV -20 dBm`
Sets the trigger level to -20 dBm.

Manual operation: See "[Level - Power Analysis](#)" on page 252

```
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:TRIGger:SLOPe <TriggerSlope>
```

Sets the polarity of the active slope for the trigger signals.

Parameters:

```
<TriggerSlope>  POSitive | NEGative
                  *RST:    POSitive
```

Example: `SENS1:SWE:TIME:TRIG:SLOP POS`
The positive edge of a trigger signal is active.

Options: Option R&S SMAB-K28

Manual operation: See "[Slope - Power Analysis](#)" on page 252

```
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:TRIGger:SOURce <Source>
```

Selects if the measurement is free running (FREE) or starts only after a trigger event. The trigger can be applied internally or externally.

Parameters:

```
<Source>         FREE | AUTO | INTernal | EXTernal
                  *RST:    AUTO
```

Example: `SENS1:SWE:TIME:SENS:TRIG:SOUR FREE`
The power versus time measurement is performed free running

Manual operation: See "[Mode - Power Analysis](#)" on page 251

```
:SENSe<ch>[:POWer]:ZERO
```

The command activates the autozero function. Zeroing is required in regular interval (at least once a day) and if the temperature has varied more than about 5 °C, if the sensor has been replaced or if measurements of signals with very low power are to be performed. The RF power source must be switched off or disconnected from the sensor before starting the autozero function.

Example: SENS : ZERO
 activates autozero function.

Usage: Event

:SENSe[:POWer]:SWEep:ABORt

Aborts the power analysis with NRP power sensors.

Example: SENS : SWE : ABOR ; * OPC ?
 Aborts the current power measurement.

Usage: Setting only

:SENSe[:POWer]:SWEep:FREQUency:REFerence:DATA:COpy

Generates a reference curve for "Frequency" measurement.

Example: SENS : POW : SWE : FREQ : REF : DATA : COpy
 Generates a reference curve in frequency mode.

Usage: Event

Manual operation: See "[Save To Ref](#)" on page 232

:SENSe[:POWer]:SWEep:FREQUency:REFerence:DATA:POINt?

Queries the number of points from the reference curve in "Frequency" measurement.

Return values:

<Points> integer
 Range: 10 to 1000

Example: SENS : POW : SWE : FREQ : REF : DATA : POIN ?
 Queries the number of points from the reference curve in frequency mode.

Usage: Query only

:SENSe[:POWer]:SWEep:FREQUency:REFerence:DATA:XVALues <XValues>

Sets or queries the x values of the two reference points, i.e. "Frequency X (Point A)" and "Frequency X (Point B)" in "Frequency" measurement.

Parameters:

<XValues> string

Example: SENSe : POW : SWE : FREQ : REF : DATA : XVAL 100MHZ , 22GHZ
 Sets the x value of reference "Point A" to 10 MHz, and the value of "Point B" to 10 GHz.

Manual operation: See "[Freq \(X\) / Pow \(Y\)](#)" on page 232

:SENSe[:POWer]:SWEep:FREQUency:REFerence:DATA:YVALues <YValues>

Sets or queries the y values of the two reference points, i.e. "Pow Y (Point A)" and "Power Y (Point B)" in "Frequency" measurement.

Parameters:

<YValues> string

Example:

SENSe:POW:SWE:FREQ:REF:DATA:YVAL -10,25
Sets the y value of reference "Point A" to -10 dBm, and the value of "Point B" to -25 dBm.

Manual operation: See "[Freq \(X\) / Pow \(Y\)](#)" on page 232

:SENSe[:POWer]:SWEep:FREQUency:RMODE <RMode>

Selects single or continuous mode for measurement mode frequency in power analysis.

Parameters:

<RMode> SINGle | CONTInuous
*RST: CONTInuous

Example:

SENS:SWE:FREQ:RMOD SING
Selects single measurement

Manual operation: See "[Execution - Power Analysis](#)" on page 237

:SENSe[:POWer]:SWEep:FREQUency:SPACing[:MODE] <Mode>

Selects the spacing for the frequency power analysis.

Parameters:

<Mode> LINear | LOGarithmic
*RST: LINear

Example:

SENS:SWE:FREQ:SPAC:MODE LIN
Sets linear spacing of the sweep

Manual operation: See "[Spacing - Power Analysis](#)" on page 237

:SENSe[:POWer]:SWEep:FREQUency:STARt <Start>

Sets the start frequency for the frequency mode.

Parameters:

<Start> float
Range: 0 to 1E12
*RST: 1E6

Example:

SENS:SWE:FREQ:STAR 2.0GHZ
Sets a sweep start at 2 GHz.

Manual operation: See "[Min - Power Analysis](#)" on page 235

:SENSe[:POWer]:SWEep:FREQUency:STEPs <Steps>

Sets the number of measurement steps for the frequency mode.

Parameters:

<Steps> integer
 Range: 10 to 1000
 *RST: 200

Example: SENS:SWE:FREQ:STEP 500
 Sets 500 steps

Manual operation: See " [Steps - Power Analysis](#) " on page 236

:SENSe[:POWer]:SWEep:FREQUency:STOP <Stop>

Sets the stop frequency for the frequency mode.

Parameters:

<Stop> float
 Range: 0 to 1E12
 *RST: 22GHZ

Example: SENS:SWE:FREQ:STOP 20.0GHZ
 Sets the sweep stop to 20 GHz

Manual operation: See "[Max - Power Analysis](#)" on page 236

:SENSe[:POWer]:SWEep:FREQUency:TIMing[:MODE] <Mode>

Selects the mode in terms of speed and precision of the response of a measurement.

Parameters:

<Mode> FAST | NORMAl | HPRecision | FAST | NORMAl

FAST

Selection FAST leads to a fast measurement with a short integration time for each measurement step.

NORMAl

NORMAl leads to a longer but more precise measurement due to a higher integration time for each step.

*RST: FAST

Example: SENS:SWE:FREQ:TIM:MODE FAST
 The fast measurement mode is selected.

Manual operation: See " [Timing - Power Analysis](#) " on page 236

:SENSe[:POWer]:SWEep:FREQuency:YSCale:AUTO <Auto>

Activates autoscaling of the Y axis of the diagram.

Parameters:

<Auto>

OFF | CEXPanding | FEXPanding | CFLoating | FFLoating

OFF

Auto scaling is deactivated. If switching from activated to deactivated Auto scaling, the scaling is maintained.

CEXPanding | FEXPanding

Auto scale is activated. The scaling of the Y-axis is selected in such a way, that the trace is always visible. To this end, the range is expanded if the minimum or maximum values of the trace move outside the current scale. The step width is 5 dB for selection course and variable in the range of 0.2 db to 5 dB for selection fine.

CFLoating | FFLoating

Auto scale is activated. The scaling of the Y-axis is selected in such a way, that the trace is always visible. To this end, the range is either expanded if the minimum or maximum values of the trace move outside the current scale or scaled down if the trace fits into a reduced scale. The step width is 5 dB for selection course and variable in the range of 0.2 db to 5 dB for selection fine.

*RST: CEXPanding

Example:

SENS:SWE:FREQ:YSC:AUTO OFF

Deactivates auto scale

Manual operation: See "[Auto Scale - Power Analysis](#)" on page 242

:SENSe[:POWer]:SWEep:FREQuency:YSCale:AUTO:RESet

Resets the Y scale to suitable values after the use of auto scaling in the expanding mode. For this mode, the scale might get expanded because of temporarily high-power values. The reset function resets the diagram in such a way that it matches smaller power values again.

Example:

SENS:SWE:FREQ:YSC:AUTO:RES

Resets auto scale

Usage:

Event

Manual operation: See "[Reset Auto Scale - Power Analysis](#)" on page 243

:SENSe[:POWer]:SWEep:FREQuency:YSCale:MAXimum <Maximum>

Sets the maximum value for the y axis of the measurement diagram.

Parameters:

<Maximum> float
 Range: -200 to 100
 Increment: 0.01
 *RST: 40

Example:

SENS:SWE:FREQ:YSC:MAX 10DBM
 Sets 10 dBm as the upper limit of the measurement diagram.

Manual operation: See " [Min - Max Level - Power Analysis](#) " on page 242

:SENSe[:POWer]:SWEep:FREQuency:YSCale:MINimum <Minimum>

Sets the minimum value for the y axis of the measurement diagram.

Parameters:

<Minimum> float
 Range: -200 to 100
 Increment: 0.01
 *RST: -40

Example:

SENS:SWE:FREQ:YSC:MIN -10DB
 Sets -10 dBm as the lower limit of the measurement diagram.

Manual operation: See " [Min - Max Level - Power Analysis](#) " on page 242

:SENSe[:POWer]:SWEep:HCOPY:DATA?

Queries the measurement data directly. The data is transferred to the remote client as data stream.

Readable ASCII data is available for hardcopy language CSV. The representation of the values depends on the selected orientation for the CSV format.

Return values:

<Data> block data

Example:

```
SENS:SWE:HCOP:DEV:LANG CSV
```

selects output format *.csv.

```
SENS:SWE:HCOP:DEV:LANG:CSV:ORI HOR
```

selects horizontal orientation

```
SENS:SWE:HCOP:DEV:LANG:CSV:SEP SEM
```

selects ";" as the separator between the values

```
SENS:SWE:HCOP:DEV:LANG:CSV:DPO DOT
```

selects "." as decimal point

```
SENS:SWE:HCOP:DATA?
```

queries the measurement data of the current traces

Response:

```
#2651009500000;1019000000;1028500000;1038000000
```

```
-9.5;-9.7;-6.3;-2.5
```

The hash symbol # introduces the data block. The next number indicates how many of the following digits describe the length of the data block. In the example, the 2 following digit indicates the length to be 65 characters.

Because horizontal representation is selected, a row with all the x-values of the active trace (frequency) follows. The second row contains all the y-values of the active trace (power). The rows end with a new line (each counts as one character).

Note: if more than one trace is active, the third row contains the x values of the second active trace, and so on.

Example:

```
SENS:SWE:HCOP:DEV:LANG:CSV:ORI VERT
```

selects horizontal orientation

```
SENS:SWE:HCOP:DATA?
```

queries the measurement data of the current traces

Response:

```
#2681009500000;-9.5; 1019000000;-9.7; 1028500000;-6.3;
```

```
1038000000;-2.5;
```

for vertical representation the length of the data block is 68 the first power value, the second row contains the second frequency value of the active trace followed by the second power value, and so on. The rows end with a new line (each counts as one character).

Note: if more than one trace is active, the first row also contains the value pairs of the second active trace, and so on.

Usage:

Query only

```
:SENSe[:POWer]:SWEp:HCOPy:DEVIce <Device>
```

Defines the output device. The setting is fixed to FILE, i.e. the hardcopy is stored in a file.

Parameters:

<Device>

FILE | PRINter

*RST: FILE

Example: SENS:SWE:HCOP:DEV FIL
Selects output device file.

:SENSe[:POWer]:SWEep:HCOPy:DEVIce:LANGUage <Language>

Selects the bitmap graphic format for the screenshot of the power analysis trace.

In addition, ASCII file format *.csv is offered. If file format *.csv is selected, the trace data is saved as an ASCII file with comma separated values. It is also possible to directly retrieve the data using command :SENSe[:POWer]:SWEep:HCOPy:DATA? on page 475

Parameters:
<Language> BMP | JPG | XPM | PNG | CSV

*RST: BMP

Example: SENS:SWE:HCOP:DEV:LANG BMP
Selects output format *.bmp.

Manual operation: See "Format - Power Analysis" on page 260

:SENSe[:POWer]:SWEep:HCOPy:DEVIce:LANGUage:CSV:DPOint <DPoint>

Defines which character is used as the decimal point of the values, either dot or comma.

Parameters:
<DPoint> DOT | COMMa

*RST: DOT

Example: SENS:SWE:HCOP:DEV:LANG CSV
Selects output format *.csv.
SENS:SWE:HCOP:DEV:LANG:CSV:DPO DOT
Selects character dot for being used as decimal point.

Manual operation: See "Decimal Point" on page 264

:SENSe[:POWer]:SWEep:HCOPy:DEVIce:LANGUage:CSV:HEADer <Header>

Defines whether each row (or column depending on the orientation) should be preceded by a header containing information about the trace (see also :SENSe[:POWer]:SWEep:HCOPy:DATA? on page 475).

Parameters:
<Header> OFF | STANdard

*RST: OFF

Example: SENS:SWE:HCOP:DEV:LANG CSV
Selects output format *.csv.
SENS:SWE:HCOP:DEV:LANG:CSV:HEAD STAN
Selects the standard header for the *.csv file.

Manual operation: See ["Row Header"](#) on page 264

:SENSe[:POWer]:SWEep:HCOPy:DEVIce:LANGUage:CSV:ORIENTATION
<Orientation>

Defines the orientation of the X/Y value pairs.

Parameters:

<Orientation> HORizontal | VERTical
*RST: VERTical

Example:

SENS:SWE:HCOP:DEV:LANG CSV

Selects output format *.csv.

SENS:SWE:HCOP:DEV:LANG:CSV:ORI VERT

Selects vertical orientation, the value pairs are written in a column like structure (separated by the selected separator, e.g. tab)

Manual operation: See ["Orientation"](#) on page 263

:SENSe[:POWer]:SWEep:HCOPy:DEVIce:LANGUage:CSV[:COLumn]:SEParator
<Separator>

Defines which character is to separate the values, either tabulator, semicolon, comma or blank.

Parameters:

<Separator> TABulator | SEMicolon | COMMa | BLANK
*RST: COMMa

Example:

SENS:SWE:HCOP:DEV:LANG CSV

Selects output format *.csv.

SENS:SWE:HCOP:DEV:LANG:CSV:SEP TAB

A tab separates the values.

Manual operation: See ["Separator"](#) on page 264

:SENSe[:POWer]:SWEep:HCOPy:DEVIce:SIZE <Size>

Sets the size of the hardcopy in number of pixels. The first value of the size setting defines the width, the second value the height of the image.

Parameters:

<Size> 320,240 | 640,480 | 800,600 | 1024,768
*RST: 320,240

Example:

SENS:SWE:HCOP:DEV:LANG BMP

Selects output format *.bmp.

SENS:SWE:HCOP:DEV:SIZE 320,240

The size of the bitmap is 320 pixels by 240 pixels.

:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME] <Name>

Creates or selects a file for storing the hardcopy after the `:SENSe[:POWer]:SWEep:HCOPy[:EXECute]` on page 483 command is sent. The directory is either defined with the command `MMEMory:CDIR` or the path is specified together with the file name. Access to the file via remote control is possible using the commands of the MMEM-Subsystem. In contrast, command `:SENSe[:POWer]:SWEep:HCOPy:DATA?` on page 475 transfers the hardcopy contents directly to the remote client where they can be further processed.

Parameters:

<Name> string

Example:

```
SENS:SWE:HCOP:DEV:LANG BMP
```

Selects output format *, bmp.

```
SENS:SWE:HCOP:FILE:AUTO:STAT OFF
```

Switches off automatic naming.

```
SENS:SWE:HCOP:FILE 'var/trace/nrp_trace1'
```

creates the file `nrp_trace1.bmp` in the trace directory.

```
SENS:SWE:HCOP:EXEC
```

Triggers the generation of a hardcopy of the current trace. The hardcopy is stored in the file `nrp_trace1.bmp`.

Manual operation: See "[File name - Power Analysis](#)" on page 259

:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO:DIRectory <Directory>

Defines the directory into which the hardcopy files are stored if auto naming is activated (`SENS:SWE:HCOP:FILE:AUTO:STAT ON`).

Parameters:

<Directory> string

Example:

```
SENS:SWE:HCOP:FILE:AUTO:DIR 'var/nrp'
```

Hardcopy file are stored in directory `var/nrp` if automatic naming is activated.

Manual operation: See "[Path](#)" on page 261

:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO:DIRectory:CLEar

Deletes all files with extensions `bmp`, `img`, `png`, `xpm` and `csv` in the directory set for automatic naming.

Example:

```
SENS:SWE:HCOP:FILE:AUTO:DIR 'var/nrp'
```

Hardcopy file are stored in directory `var/nrp` if automatic naming is activated.

```
SENS:SWE:HCOP:FILE:AUTO:DIR:CLE
```

Deletes all hardcopy file that are stored in the directory `var/nrp`.

Usage: Event

Manual operation: See ["Clear Parth"](#) on page 262

:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO:FILE?

Queries the file name generated with the automatic naming settings.

Note: As default the automatically generated file name is composed of: >PAth>/<Prefix><YYYY><MM><DD><Number>.<Format>. Each component can be deactivated/ activated separately to individually design the file name.

Return values:

<File> string

Example:

```
SENS:SWE:HCOP:DEV:LANG BMP
```

Selects output format * .bmp.

```
SENS:SWE:HCOP:FILE:AUTO:DIR 'var/nrp'
```

Hardcopy files are stored in directory var/nrp if automatic naming is activated.

```
SENS:SWE:HCOP:FILE:AUTO:PREF 'sens1'
```

The file name starts with the prefix sens1. The usage of automatic naming with prefix and date in the file name is preset (...:STAT ON).

```
SENS:SWE:HCOP
```

Triggers the generation of a hardcopy of the current trace.

```
SENS:SWE:HCOP:FILE:AUTO:FILE?
```

Queries the file name

Usage: Query only

Manual operation: See [" File name - Power Analysis "](#) on page 259

:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO:STATe <State>

Activates/deactivates automatic naming of the hardcopy files.

Parameters:

<State> 0 | 1 | OFF | ON

*RST: 1

Example:

```
SENS:SWE:HCOP:FILE:AUTO:STAT OFF
```

Deactivates automatic naming of the hardcopy files. The file name and directory is now defined with command.

```
SENS:SWE:HCOP:FILE:NAME <psth>
```

Manual operation: See [" File name - Power Analysis "](#) on page 259

:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:DAY?

Queries the day of the date part in the automatic file name.

Return values:

<Day> integer
 Range: 1 to 31
 *RST: 1

Example:

SENS:SWE:HCOPY:FILE:AUTO:DAY?
 Queries the day of the date part in the automatic file name.

Usage:

Query only

Manual operation: See "[Prefix, Year, Month, Day, Instrument Name](#)" on page 262

:SENSe[:POWer]:SWEep:HCOPY:FILE[:NAME]:AUTO[:FILE]:DAY:STATe <State>

Activates the usage of the day in the automatic file name.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 1

Example:

SENS:SWE:HCOPY:FILE:AUTO:DAY:STAT OFF
 Deactivates the usage of the day in the automatic file name.

Manual operation: See "[Prefix, Year, Month, Day, Instrument Name](#)" on page 262

:SENSe[:POWer]:SWEep:HCOPY:FILE[:NAME]:AUTO[:FILE]:MONTH?

Queries the day of the date part in the automatic file name.

Return values:

<Month> integer
 Range: 1 to 12
 *RST: 1

Example:

SENS:SWE:HCOPY:FILE:AUTO:MONT?
 Queries the month of the date part in the automatic file name.

Usage:

Query only

Manual operation: See "[Prefix, Year, Month, Day, Instrument Name](#)" on page 262

:SENSe[:POWer]:SWEep:HCOPY:FILE[:NAME]:AUTO[:FILE]:MONTH:STATe
 <State>

Activates the usage of the month in the automatic file name.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 1

Example:

SENS:SWE:HCOPY:FILE:AUTO:MONT:STAT OFF
 Deactivates the usage of the month in the automatic file name.

Manual operation: See "[Prefix, Year, Month, Day, Instrument Name](#)" on page 262

:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:NUMBer?

Queries the generated number in the automatic file name.

Return values:

<Number>	integer
Range:	0 to 999999
*RST:	0

Example: SENS : SWE : HCOP : FILE : AUTO : NUMB ?
Queries the number in the automatic file name.

Usage: Query only

Manual operation: See "[Current Auto Number](#)" on page 262

:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:PREFix <Prefix>

Sets the prefix part in the automatic file name.

Parameters:

<Prefix>	string
----------	--------

Example: SENS : SWE : HCOP : FILE : AUTO : PREF 'sensor'
The prefix sensor is used in the automatically generated file name of the hardcopy file.

Manual operation: See "[Prefix, Year, Month, Day, Instrument Name](#)" on page 262

:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:PREFix:STATe <State>

Activates the usage of the prefix in the automatic file name.

Parameters:

<State>	0 1 OFF ON
*RST:	1

Example: SENS : SWE : HCOP : FILE : AUTO : PREF : STAT OFF
Deactivates the usage of the prefix in the automatic file name.

Manual operation: See "[Prefix, Year, Month, Day, Instrument Name](#)" on page 262

:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:YEAR?

Queries the year of the date part in the automatic file name.

Return values:

<Year>	integer
Range:	1784 to 8000
*RST:	0

Example: SENS : SWE : HCOP : FILE : AUTO : YEAR ?
Queries the year of the date part in the automatic file name.

Usage: Query only

Manual operation: See "[Prefix, Year, Month, Day, Instrument Name](#)" on page 262

:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:YEAR:STATe <State>

Activates the usage of the year in the automatic file name.

Parameters:

<State> 0 | 1 | OFF | ON
*RST: 1

Example: SENS:SWE:HCOP:FILE:AUTO:YEAR:STAT OFF
Deactivates the usage of the year in the automatic file name.

Manual operation: See "[Prefix, Year, Month, Day, Instrument Name](#)" on page 262

:SENSe[:POWer]:SWEep:HCOPy[:EXECute]

Triggers the generation of a hardcopy of the current measurement diagram. The data is written into the file selected/created with the [:SENSe\[:POWer\]:SWEep:HCOPy:FILE\[:NAME\]](#) on page 479 command.

Example: SENS:SWE:HCOP:DEV:LANG BMP
Selects output format *.bmp.
SENS:SWE:HCOP:FILE:AUTO:STAT OFF
Switches off automatic file naming.
SENS:SWE:HCOP:FILE 'var/nrp_tracel'
Creates the file nrp_tracel.bmp in the set path.
SENS:SWE:HCOP
Triggers the generation of a hardcopy of the current measurement diagram. The hardcopy is stored in the file nrp_tracel.bmp.

Usage: Event

Manual operation: See "[File name - Power Analysis](#)" on page 259

:SENSe[:POWer]:SWEep:INITiate

Starts the power analysis with NRP power sensor.

Example: SENS:SWE:INIT
Start the power measurement.

Usage: Setting only

:SENSe[:POWer]:SWEep:MODE <Mode>

Selects power versus frequency measurement (frequency response), power vs power measurement (power sweep, AM/AM) or power vs. time measurement.

Parameters:

<Mode> FREQuency | POWer | TIME
 *RST: FREQuency

Example:

SENS : SWE : MODE FREQ
 Selects frequency mode.

Manual operation: See "[Mode - Power Analysis](#)" on page 235

:SENSe[:POWer]:SWEep:POWer:REFerence:DATA:COPI

Generates a reference curve for "Power" measurement.

Example:

SENS : POW : SWE : POW : REF : DATA : COPY
 Generates a reference curve in power mode.

Usage:

Event

Manual operation: See "[Save To Ref](#)" on page 232

:SENSe[:POWer]:SWEep:POWer:REFerence:DATA:POINts?

Queries the number of points from the reference curve in "Power" measurement.

Return values:

<Points> integer
 Range: 10 to 1000

Example:

SENS : POW : SWE : POW : REF : DATA : POIN?
 Queries the number of points from the reference curve in power mode.

Usage:

Query only

:SENSe[:POWer]:SWEep:POWer:REFerence:DATA:XVALues <XValues>

Sets or queries the x values of the two reference points, i.e. "Power X (Point A)" and "Power X (Point B)" in "Power" measurement.

Parameters:

<XValues> string

Example:

SENSe : POW : SWE : POW : REF : DATA : XVAL -15DBM, 20DBM
 Sets the x value of reference "Point A" to -15 dBm, and the value of "Point B" to 20 dBm.

Manual operation: See "[Pow \(X\) / Pow \(Y\)](#)" on page 232

:SENSe[:POWer]:SWEep:POWer:REFerence:DATA:YVALues <YValues>

Sets or queries the y values of the two reference points, i.e. "Power Y (Point A)" and "Power Y (Point B)" in "Power" measurement.

Parameters:

<YValues> string

Example:

```
SENSe:POW:SWE:TIME:REF:DATA:YVAL -30,10
```

Sets the y value of reference "Point A" to -30 dBm, and the value of "Point B" to 10 dBm.

Manual operation: See "[Pow \(X\) / Pow \(Y\)](#)" on page 232

:SENSe[:POWer]:SWEep:POWer:RMODE <RMode>

Selects single or continuous mode for measurement mode power in power analysis.

Parameters:

<RMode> SINGLE | CONTInuous
*RST: CONTInuous

Example:

```
SENS:SWE:POW:RMODE SING
```

Selects single measurement.

Manual operation: See "[Execution - Power Analysis](#)" on page 237

:SENSe[:POWer]:SWEep:POWer:SPACing[:MODE] <Mode>

Selects the spacing for the frequency power analysis.

Parameters:

<Mode> LINear
*RST: LINear

Example:

```
SENS:SWE:FREQ:SPAC:MODE LIN
```

Sets linear spacing of the sweep.

Manual operation: See "[Spacing - Power Analysis](#)" on page 237

:SENSe[:POWer]:SWEep:POWer:STARt <Start>

Sets the start level for the power versus power measurement.

Parameters:

<Start> float
Range: -145 to 20
Increment: 0.01
*RST: 1MHZ

Example:

```
SENS:SWE:POW:STAR -20DBM
```

Sets the start level to -20 dBm

Manual operation: See "[Min - Power Analysis](#)" on page 235

:SENSe[:POWer]:SWEep:POWer:STEPs <Steps>

Sets the number of measurement steps for the power versus power measurement.

Parameters:

<Steps> integer
 Range: 10 to 1000
 *RST: 500

Example:

SENS:SWE:POW:STEP 500
 Sets the 500 measurement steps.

Manual operation: See "[Steps - Power Analysis](#)" on page 236

:SENSe[:POWer]:SWEep:POWer:STOP <Stop>

Sets the stop level for the power versus power measurement.

Parameters:

<Stop> float
 Range: -145 to 20
 Increment: 0.01
 *RST: 40

Example:

SENS:SWE:POW:STOP 20.0DBM
 Sets the stop level to 20 dBm.

:SENSe[:POWer]:SWEep:POWer:TIMing[:MODE] <Mode>

Selects the timing mode of the measurement.

Parameters:

<Mode> FAST | NORMal | HPRecision | FAST | NORMal

FAST

Selection FAST leads to a fast measurement with a short integration times for each measurement step.

NORMal

NORMal leads to a longer but more precise measurement due to a higher integration time for each step.

*RST: NORMal

Example:

SENS:SWE:POW:TIM:MODE FAST
 Selects fast mode.

Manual operation: See "[Timing - Power Analysis](#)" on page 236

:SENSe[:POWer]:SWEep:POWer:YSCale:AUTO <Auto>

Activates autoscaling of the Y axis of the diagram.

Parameters:

<Auto> OFF | CEXPanding | FEXPanding | CFLoating | FFLoating

OFF

Auto scaling is deactivated. When switching from activated to deactivated Auto scaling, the scaling is maintained. When switching from deactivated to activated Auto scaling, the scaling is reset to min = max = 0.

CExpanding | FExpanding

Auto scale is activated. The scaling of the Y-axis is selected in such a way, that the trace is always visible. To this end, the range is expanded if the minimum or maximum values of the trace move outside the current scale. The step width is 5 dB for selection course and variable in the range of 0.2 dB to 5 dB for selection fine.

CFloating | FFloating

Auto scale is activated. The scaling of the Y-axis is selected in such a way, that the trace is always visible. To this end, the range is either expanded if the minimum or maximum values of the trace move outside the current scale or scaled down if the trace fits into a reduced scale. The step width is 5 dB for selection course and variable in the range of 0.2 dB to 5 dB for selection fine.

*RST: CExpanding

Example:

```
SENS:SWE:POW:YSC:AUTO OFF
Deactivates auto scale.
```

Manual operation: See "[Auto Scale - Power Analysis](#)" on page 242

:SENSe[:POWer]:SWEep:POWer:YSCale:AUTO:RESet

Resets the Y scale to suitable values after the use of auto scaling in the expanding mode. For this mode, the scale might get expanded because of temporarily high power values. The reset function allows resetting the diagram to match smaller power values again.

Example:

```
SENS:SWE:POW:YSC:AUTO:RES
Resets auto scale.
```

Usage:

Event

Manual operation: See "[Reset Auto Scale - Power Analysis](#)" on page 243

:SENSe[:POWer]:SWEep:POWer:YSCale:MAXimum <Maximum>

Sets the maximum value for the y axis of the measurement diagram.

Parameters:

<Maximum>

float

Range: -200 to 100

Increment: 0.01

*RST: 30

Example: `SENS:SWE:POW:YSC:MAX 10DBM`
Sets 10 dBm as the upper limit of the measurement diagram.

Manual operation: See "[Min - Max Level - Power Analysis](#)" on page 242

:SENSe[:POWer]:SWEep:POWer:YSCale:MINimum <Minimum>

Sets the minimum value for the y axis of the measurement diagram.

Parameters:

<Minimum> float
Range: -200 to 100
Increment: 0.01
*RST: -40

Example: `SENS:SWE:POW:YSC:MIN -10DBM`
Sets -10 dBm as the lower limit of the measurement diagram.

Manual operation: See "[Min - Max Level - Power Analysis](#)" on page 242

:SENSe[:POWer]:SWEep:RMODE <RMode>

Selects single or continuous mode for power analysis (all measurement modes).

Parameters:

<RMode> SINGLE | CONTInuous
*RST: SINGLE

Example: `SENS:SWE:RMODE SING`
Selects single measurement.

Manual operation: See "[Execution - Power Analysis](#)" on page 237

:SENSe[:POWer]:SWEep:TIME:AVERAge[:COUNT] <Count>

Selects the averaging factor in time mode. The count number determines how many measurement cycles are used to form a measurement result. Higher averaging counts reduce noise but increase the measurement time. Averaging requires a stable trigger event so that the measurement cycles have the same timing.

Parameters:

<Count> 1 | 2 | 4 | 8 | 16 | 32 | 64 | 128 | 256 | 512 | 1024
*RST: 1

Example: `SENS:SWE:MODE TIME`
Selects time mode.
`SENS:SWE:TIME:AVER 128`
Selects averaging factor 128.

Options: Option R&S SMAB-K28

Manual operation: See "[Average - Power Analysis](#)" on page 237

:SENSe[:POWer]:SWEep:TIME:REFerence:DATA:COpy

Generates a reference curve for "Time" measurement.

Example: `SENS:POW:SWE:TIME:REF:DATA:COpy`
Generates a reference curve in time mode.

Usage: Event

Manual operation: See ["Save To Ref"](#) on page 232

:SENSe[:POWer]:SWEep:TIME:REFerence:DATA:POINts?

Queries the number of points from the reference curve in "Time" measurement.

Return values:

<Points> integer
Range: 10 to 1000
*RST: 0

Example: `SENS:POW:SWE:TIME:REF:DATA:POIN?`
Queries the number of points from the reference curve in time mode.

Usage: Query only

:SENSe[:POWer]:SWEep:TIME:REFerence:DATA:XVALues <XValues>

Sets or queries the x values of the two reference points, i.e. "Time X (Point A)" and "Time X (Point B)" in "Time" measurement.

Parameters:

<XValues> string

Example: `SENSe:POW:SWE:TIME:REF:DATA:XVAL 5,45`
Sets the x value of reference "Point A" to 5 μ s, and the value of "Point B" to 45 μ s.

Manual operation: See ["Time \(X\) / Pow \(Y\)"](#) on page 232

:SENSe[:POWer]:SWEep:TIME:REFerence:DATA:YVALues <YValues>

Sets or queries the y values of the two reference points, i.e. "Power Y (Point A)" and "Power Y (Point B)" in "Time" measurement.

Parameters:

<YValues> string

Example: `SENSe:POW:SWE:TIME:REF:DATA:YVAL -30,10`
sets the y value of reference "Point A" to -30 dBm, and the value of "Point B" to 10 dBm.

Manual operation: See ["Time \(X\) / Pow \(Y\)"](#) on page 232

:SENSe[:POWer]:SWEep:TIME:RMODe <RMode>

Selects single or continuous mode for measurement mode time in power analysis.

Parameters:

<RMode> SINGle | CONTInuous
 *RST: CONTInuous

Example: SENS:SWE:TIME:RMOD SING
 Selects single measurement.

Manual operation: See "[Execution - Power Analysis](#)" on page 237

:SENSe[:POWer]:SWEep:TIME:SPACing[:MODE] <Mode>

Queries the sweep spacing for the power versus time measurement. The spacing is fixed to linear.

Parameters:

<Mode> LINear
 *RST: LINear

Example: SENS:SWE:TIME:SPAC?
 Queries the sweep spacing.

Manual operation: See "[Spacing - Power Analysis](#)" on page 237

:SENSe[:POWer]:SWEep:TIME:STARt <Start>

Sets the start time for the power versus time measurement. Value 0 defines the trigger point. By choosing a negative time value, the trace can be shifted in the diagram. It is possible, that the measurement cannot be performed over the complete time range because of limitations due to sensor settings. In this case, an error message is output.

Parameters:

<Start> float
 Range: -1 to 1
 Increment: 1E-12
 *RST: -5E-6

Example: SENS:SWE:TIME:STAR 0s
 Sets the start time to 0 s.

Manual operation: See "[Min - Power Analysis](#)" on page 235

:SENSe[:POWer]:SWEep:TIME:STEPs <Steps>

Sets the number of measurement steps for the power versus time measurement. Value 0 defines the trigger point.

Parameters:

<Steps> integer
 Range: 10 to 1000
 *RST: 500

Example:

SENS:SWE:TIME:STEP 500
 Sets the 500 measurement steps.

Manual operation: See "[Steps - Power Analysis](#)" on page 236

:SENSe[:POWer]:SWEep:TIME:STOP <Stop>

Sets the stop time for the power versus time measurement.

Parameters:

<Stop> float
 Range: 0 to 2
 Increment: 1E-12
 *RST: 1E-3

Example:

SENS:SWE:TIME:STOP 1ms
 Sets the stop time to 1 ms.

Manual operation: See "[Max - Power Analysis](#)" on page 236

:SENSe[:POWer]:SWEep:TIME:TEVents <TriggerTEvents>

Determines, whether the measurement data processing starts with a trigger event in one of the sensors (Logical OR), or whether all channels have to be triggered (logical AND). Each sensor evaluates a trigger event according to its setting independently. This function supports the internal or external trigger modes with multi-channel time measurements.

Parameters:

<TriggerTEvents> AND | OR
 *RST: AND

Example:

SENS:POW:SWE:TIME:TEV AND
 The measurement data processing starts when all channels are triggered.

Options: Option R&S SMAB-K28

Manual operation: See "[All Trigger Events - Power Analysis](#)" on page 238

:SENSe[:POWer]:SWEep:TIME:YScale:AUTO <Auto>

Activates autoscaling of the Y axis in the diagram.

Parameters:

<Auto> OFF | CEXPanding | FEXPanding | CFLoating | FFLoating

OFF

Auto scaling is deactivated. When switching from activated to deactivated Auto scaling, the scaling is maintained. When switching from deactivated to activated Auto scaling, the scaling is reset to min = max = 0.

CEXPanding | FEXPanding

Auto scale is activated. The scaling of the Y-axis is selected in such a way, that the trace is always visible. To this end, the range is expanded if the minimum or maximum values of the trace move outside the current scale. The step width is 5 dB for selection course and variable in the range of 0.2 dB to 5 dB for selection fine.

CFloating | FFloating

Auto scale is activated. The scaling of the Y-axis is selected in such a way, that the trace is always visible. To this end, the range is either expanded if the minimum or maximum values of the trace move outside the current scale or scaled down if the trace fits into a reduced scale. The step width is 5 dB for selection course and variable in the range of 0.2 dB to 5 dB for selection fine.

*RST: CEXPanding

Example:

```
SENS:SWE:TIME:YSC:AUTO OFF
Deactivates auto scale
```

Manual operation: See "[Auto Scale - Power Analysis](#)" on page 242

:SENSe[:POWer]:SWEp:TIME:YSCale:AUTO:RESet

Resets the Y scale to suitable values after the use of auto scaling in the expanding mode. For this mode, the scale might get expanded because of temporarily high power values. The reset function allows resetting the diagram to match smaller power values again.

Example:

```
SENS:SWE:TIME:YSC:AUTO:RES
Resets auto scale.
```

Usage:

Event

Manual operation: See "[Reset Auto Scale - Power Analysis](#)" on page 243

:SENSe[:POWer]:SWEp:TIME:YSCale:MAXimum <Maximum>

Sets the maximum value for the y axis of the measurement diagram.

Parameters:

<Maximum>

float

Range: -200 to 100

Increment: 0.01

*RST: 30.0

Default unit: dBm

Example: SENS : SWE : TIME : YSC : MAX 10DBM
Sets 10 dBm as the upper limit of the measurement diagram.

Manual operation: See " [Min - Max Level - Power Analysis](#) " on page 242

:SENSe[:POWER]:SWEep:TIME:YSCale:MINimum <Minimum>

Sets the minimum value for the y axis of the measurement diagram.

Parameters:

<Minimum> float
Range: -200 to 100
Increment: 0.01
*RST: dBm

Example: SENS : SWE : TIME : YSC : MIN -10DBM
Sets -10 dBm as the lower limit of the measurement diagram.

Manual operation: See " [Min - Max Level - Power Analysis](#) " on page 242

14.14.5 TRACe Subsystem

:TRACe<ch>[:POWER]:SWEep:COLor.....	494
:TRACe<ch>[:POWER]:SWEep:COPY.....	495
:TRACe<ch>[:POWER]:SWEep:DATA:POINTs?.....	495
:TRACe<ch>[:POWER]:SWEep:DATA:XVALues?.....	495
:TRACe<ch>[:POWER]:SWEep:DATA:YSValue?.....	496
:TRACe<ch>[:POWER]:SWEep:DATA:YVALues?.....	496
:TRACe<ch>[:POWER]:SWEep:FEED.....	496
:TRACe<ch>[:POWER]:SWEep:MEASurement:POWer:AVERage?.....	497
:TRACe<ch>[:POWER]:SWEep:MEASurement:POWer:HREFerence?.....	497
:TRACe<ch>[:POWER]:SWEep:MEASurement:POWer:LREFerence?.....	497
:TRACe<ch>[:POWER]:SWEep:MEASurement:POWer:MAXimum?.....	497
:TRACe<ch>[:POWER]:SWEep:MEASurement:POWer:MINimum?.....	497
:TRACe<ch>[:POWER]:SWEep:MEASurement:POWer:PULSe:BASE?.....	497
:TRACe<ch>[:POWER]:SWEep:MEASurement:POWer:PULSe:TOP?.....	497
:TRACe<ch>[:POWER]:SWEep:MEASurement:POWer:REFerence?.....	497
:TRACe<ch>[:POWER]:SWEep:MEASurement:PULSe:DCYClE?.....	497
:TRACe<ch>[:POWER]:SWEep:MEASurement:PULSe:DURation?.....	497
:TRACe<ch>[:POWER]:SWEep:MEASurement:PULSe:PERiod?.....	497
:TRACe<ch>[:POWER]:SWEep:MEASurement:PULSe:SEPARation?.....	497
:TRACe<ch>[:POWER]:SWEep:MEASurement:PULSe:STATe?.....	497
:TRACe<ch>[:POWER]:SWEep:MEASurement:TRANSition:NEGative:DURation?.....	497
:TRACe<ch>[:POWER]:SWEep:MEASurement:TRANSition:NEGative:OCCurrence?.....	497
:TRACe<ch>[:POWER]:SWEep:MEASurement:TRANSition:NEGative:OVERshoot?.....	497
:TRACe<ch>[:POWER]:SWEep:MEASurement:TRANSition:POSitive:DURation?.....	497
:TRACe<ch>[:POWER]:SWEep:MEASurement:TRANSition:POSitive:OCCurrence?.....	497
:TRACe<ch>[:POWER]:SWEep:MEASurement:TRANSition:POSitive:OVERshoot?.....	497
:TRACe<ch>[:POWER]:SWEep:MEASurement:PULSe:DCYClE:DISPlay:ANNotation[:STATe].	498

:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:DURation:DISPlay:ANNotation[:STATE]	498
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:PERiod:DISPlay:ANNotation[:STATE]	498
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:AVERage:DISPlay:ANNotation[:STATE]	498
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:PULSe:BASE:DISPlay:ANNotation[:STATE]	498
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:HREFerence:DISPlay:ANNotation[:STATE]	498
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:LREFerence:DISPlay:ANNotation[:STATE]	498
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:MAXimum:DISPlay:ANNotation[:STATE]	498
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:MINimum:DISPlay:ANNotation[:STATE]	498
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:REFerence:DISPlay:ANNotation[:STATE]	498
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:PULSe:TOP:DISPlay:ANNotation[:STATE]	498
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:SEParation:DISPlay:ANNotation[:STATE]	498
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:DURation:DISPlay:ANNotation[:STATE]	498
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:OCCurrence:DISPlay:ANNotation[:STATE]	498
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:OVERshoot:DISPlay:ANNotation[:STATE]	498
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:DURation:DISPlay:ANNotation[:STATE]	498
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:OCCurrence:DISPlay:ANNotation[:STATE]	499
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:OVERshoot:DISPlay:ANNotation[:STATE]	499
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:ALL:DISPlay:ANNotation[:STATE]	499
:TRACe<ch>[:POWer]:SWEep:PULSe:THReshold:BASE?	499
:TRACe<ch>[:POWer]:SWEep:PULSe:THReshold:POWer:HREFerence	500
:TRACe<ch>[:POWer]:SWEep:PULSe:THReshold:POWer:LREFerence	500
:TRACe<ch>[:POWer]:SWEep:PULSe:THReshold:POWer:REFerence	500
:TRACe<ch>[:POWer]:SWEep:STATE	501
:TRACe[:POWer]:SWEep:MEASurement:FULLscreen:DISPlay:ANNotation[:STATE]	501
:TRACe[:POWer]:SWEep:MEASurement:GATE:DISPlay:ANNotation[:STATE]	502
:TRACe[:POWer]:SWEep:MEASurement:MARKer:DISPlay:ANNotation[:STATE]	502
:TRACe[:POWer]:SWEep:MEASurement:PULSe:DISPlay:ANNotation[:STATE]	502
:TRACe[:POWer]:SWEep:MEASurement:STANdard:DISPlay:ANNotation[:STATE]	503

:TRACe<ch>[:POWer]:SWEep:COLor <Color>

Defines the color of a trace.

Parameters:

<Color> INVers | GRAY | YELLow | BLUE | GREen | RED | MAGenta
 *RST: trace 1 = YELLow, trace 2 = GREen, trace 3 = RED.

Example:

TRAC2:SWE:COL GRAY
 Trace2 is indicated in gray color.

Manual operation: See "[Color - Trace Power Analysis](#)" on page 231

:TRACe<ch>[:POWer]:SWEep:COPIY <Copy>

Stores the selected trace data as reference trace.

Setting parameters:

<Copy> REFerence

Example:

TRAC2:SWE:COPIY REF
 Stores the current trace2 as reference trace'
 TRAC1:SWE:FEED REF
 Assigns the reference trace to trace 1.

Usage:

Setting only

Manual operation: See "[Indication - Trace Power Analysis](#)" on page 231

:TRACe<ch>[:POWer]:SWEep:DATA:POINts?

Queries the number of measurement points of the selected trace of the current power analysis.

Return values:

<Points> integer
 Range: 10 to 1000
 *RST: 0

Example:

TRAC1:SWE:DATA:POIN?
 Response: 624
 Measurement trace 1 contains 624 measurement points

Usage:

Query only

:TRACe<ch>[:POWer]:SWEep:DATA:XVALues?

Queries the x-axis values - frequency, power or time values - of the selected trace of the current power analysis.

Return values:

<XValues> string

Example: SENS:SWE:MODE FREQ
Sets measurement mode frequency versus power.
SENS:SWE:RMOD SING
Selects single measurement.
SENS:SWE:INIT
Starts the measurement.
*OPC?
Waits until measurement is performed.
TRAC1:SWE:DATA:XVAL?
Queries the x-axis values of trace 1.
TRAC1:SWE:DATA:YVAL?
Queries the y-axis values of trace 1

Usage: Query only

:TRACe<ch>[:POWer]:SWEep:DATA:YSValue? <XValue>

For a given x-axis value, queries the measurement (y-axis) value of the selected trace of the current power analysis.

Query parameters:

<XValue> float

Return values:

<YSValue> float

Increment: 1E-9

Example: TRACe1:SWE:DATA:YSValue? 2.3

Example: Queries the y-axis values of trace 1 at x-axis value of 2.3.
See [:TRACe<ch>\[:POWer\]:SWEep:DATA:XVALues?](#)
on page 495.

Usage: Query only

:TRACe<ch>[:POWer]:SWEep:DATA:YVALues?

Queries the measurement (y-axis) values of the selected trace of the current power analysis.

Return values:

<YValues> string

Example:

SENS:SWE:TRAC2:DATA:YVAL?

Queries the power values of trace 2.

See [:TRACe<ch>\[:POWer\]:SWEep:DATA:XVALues?](#)
on page 495.

Usage: Query only

:TRACe<ch>[:POWer]:SWEep:FEED <Feed>

Selects the source for the trace data.

Parameters:

<Feed>

SENS1 | SENS2 | SENS3 | REFERENCE | NONE | SENSOR1 |
SENSOR2 | SENSOR3 | SENS4 | SENSOR4

*RST: The preset value for each trace is evaluated during runtime as follows: If a sensor is plugged into the generator whose number corresponds to the trace number, this sensor is used to feed the trace and the state of the trace is ON; If no sensor is found with number corresponding to the trace number, the preset value of the trace is "Off".

Example:

TRAC2:SWE:COPY REF

Stores trace2 as reference trace.

TRAC1:SWE:FEED REF

Assigns the reference trace to trace 1.

TRAC1:SWE:STAT ON

Assigns the reference trace to trace 1.

SENS:SWE:RMOD SING

Selects single measurement

SENS:SWE:INIT

Starts the measurement

Manual operation: See "[Indication - Trace Power Analysis](#)" on page 231

```

:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:AVERAge?
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:HREFerence?
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:LREFerence?
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:MAXimum?
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:MINimum?
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:PULSe:BASE?
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:PULSe:TOP?
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:REFerence?
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:DCYClE?
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:DURation?
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:PERiod?
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:SEParation?
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:STATe?
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:DURation?
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:
  OCCurrence?
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:OVERshoot?
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:DURation?
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:OCCurrence?
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:OVERshoot?

```

The above listed commands query the measured pulse parameter values.

Note: These commands are only available in time measurement mode and with R&S NRP-Z81 power sensors.

Return values:

<Overshoot> float
 Range: 0 to 100
 Increment: 0.01
 *RST: 0

Example:

TRAC1 : SWE : MEAS : POW : HREF ?
 Queries the measured mesial threshold level of trace 1.
 TRAC3 : SWE : MEAS : POW : MAX ?
 Queries the measured peak power of trace 3.

Usage: Query only

Options: Option R&S SMAB-K28

Manual operation: See "[Overshoot \(Rising Edge / Falling Edge\)](#)" on page 249

```

:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:DCYClE:DISPlay:
  ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:DURation:DISPlay:
  ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:PERiod:DISPlay:
  ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:AVERage:DISPlay:
  ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:PULSe:BASE:DISPlay:
  ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:HREFerence:DISPlay:
  ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:LREFerence:DISPlay:
  ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:MAXimum:DISPlay:
  ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:MINimum:DISPlay:
  ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:REFerence:DISPlay:
  ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:PULSe:TOP:DISPlay:
  ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:SEPARation:DISPlay:
  ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:DURation:
  DISPlay:ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:OCCurrence:
  DISPlay:ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:OVERshoot:
  DISPlay:ANNotation[:STATe] <State>
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:DURation:
  DISPlay:ANNotation[:STATe] <State>

```

:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:OCCurrence:DISPlay:ANNotation[:STATe] <State>

:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:OVERshoot:DISPlay:ANNotation[:STATe] <State>

The above listed commands select the pulse parameters which are indicated in the display and hardcopy file. Only six parameters can be indicated at a time.

Note: These commands are only available in time measurement mode and with R&S NRP-Z81 power sensors.

Parameters:

<State> 0 | 1 | OFF | ON
*RST: 0

Example:

TRAC:SWE:MEAS:TRAC2:PULS:PER:DISP:ANN ON
Selects the pulse period to be indicated in the display.

TRAC:SWE:MEAS:PULS:DISP:ANN ON

Activates indication of the selected pulse data in the display.

Options:

Option R&S SMAB-K28

Manual operation:

See "[Overshoot \(Rising Edge / Falling Edge\)](#)" on page 249

:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:ALL:DISPlay:ANNotation[:STATe] <State>

Deactivates the indication of all pulse data of the selected trace. The parameters to be indicated can be selected with the TRAC:SWE:MEAS:... commands. Only six parameters are indicated at a time.

Note: This command is only available in time measurement mode and with R&S NRP-Z81 power sensors.

Parameters:

<State> 0 | 1 | OFF | ON
*RST: 0

Example:

TRAC:SWE:MEAS:PULS:ALL:DISP:ANN OFF
Switches the indication of all pulse data off.

Options:

Option R&S SMAB-K28

:TRACe<ch>[:POWer]:SWEep:PULSe:THReshold:BASE?

Queries how the threshold parameters are calculated.

Note: This parameter is only available in time measurement mode and R&S NRP-Z81 power sensors.

Return values:

<Base> VOLTage | POWer
*RST: VOLTage

- Example:** TRAC1 : SWE : PULS : THR : BAS ?
Queries the threshold base of pulse data calculation.
- Usage:** Query only
- Manual operation:** See " [Base](#) " on page 245

:TRACe<ch>[:POWer]:SWEep:PULSe:THReshold:POWer:HREFerence
<HReference>

Queries the upper threshold level of the overall pulse level. The distal power defines the end of the rising edge and the start of the falling edge of the pulse.

Note: This parameter is only available in time measurement mode and R&S NRP-Z81 power sensors.

Parameters:

<HReference>	float
Range:	0.0 to 100.0
Increment:	0.01
*RST:	90.0

- Example:** TRAC2 : SWE : PULS : THR : POW : HREF ?
Queries the upper reference level of trace 2.

Manual operation: See " [Distal](#) " on page 245

:TRACe<ch>[:POWer]:SWEep:PULSe:THReshold:POWer:LREFerence
<LReference>

Queries the lower medial threshold level of the overall pulse level. The proximal power defines the start of the rising edge and the end of the falling edge of the pulse.

Note: This parameter is only available in time measurement mode and R&S NRP-Z81 power sensors.

Parameters:

<LReference>	float
Range:	0.0 to 100.0
Increment:	0.01
*RST:	10.0

- Example:** TRAC : SWE : PULS : THR : POW : LREF ?
Queries the medial threshold level of trace 1.

Manual operation: See " [Proximal](#) " on page 246

:TRACe<ch>[:POWer]:SWEep:PULSe:THReshold:POWer:REFerence <Reference>

Queries the medial threshold level of the overall pulse level. This level is used to define the pulse width and pulse period.

Note: This parameter is only available in time measurement mode and R&S NRP-Z81 power sensors.

Parameters:

<Reference> float
 Range: 0.0 to 100.0
 Increment: 0.01
 *RST: 50.0

Example:

TRAC3:SWE:PULS:THR:POW:REF?
 Queries the medial threshold level of trace 3.

Manual operation: See " [Mesial](#) " on page 246

:TRACe<ch>[:POWer]:SWEep:STATe <State>

Activates the selected trace.

Parameters:

<State> OFF | ON | HOLD
 *RST: The preset value for each trace is evaluated during runtime as follows: If a sensor is plugged into the generator whose number corresponds to the trace number, this sensor is used to feed the trace and the state of the trace is ON; If no sensor is found with a number corresponding to the trace number, the preset value of the trace is "Off".

Example:

TRAC2:SWE:COPY REF
 Stores trace2 as reference trace.
 TRAC1:SWE:FEED REF
 Assigns the reference trace to trace 1.
 TRAC1:SWE:STAT ON
 Assigns the reference trace to trace 1.
 SENS:SWE:RMOD SING
 Selects single measurement.
 SENS:SWE:INIT
 Starts the measurement.

Manual operation: See " [Indication - Trace Power Analysis](#)" on page 231

:TRACe[:POWer]:SWEep:MEASurement:FULLscreen:DISPlay:ANNOtation[:STATe] <State>

Selects fullscreen display of the measurement diagram on the display and in the hard-copy file.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 1

- Example:** TRAC:SWE:MEAS:FULL:DISP:ANN ON
The display only shows the diagram.
- Options:** Option R&S SMAB-K28
- Manual operation:** See "[Full Screen](#)" on page 258

:TRACe[:POWer]:SWEep:MEASurement:GATE:DISPlay:ANNotation[:STATe]
<State>

Activates the indication of the time gate borders and values in the measurement diagram and in the hardcopy file. The gate settings are performed with the CALC:POW:SWE:TIME:GATE:... commands.

Parameters:
<State> 0 | 1 | OFF | ON
*RST: 1

- Example:** TRAC:SWE:MEAS:GATE:DISP:ANN ON
The diagram also shows the gate information.
- Options:** Option R&S SMAB-K28
- Manual operation:** See "[State - Gate](#)" on page 255

:TRACe[:POWer]:SWEep:MEASurement:MARKer:DISPlay:ANNotation[:STATe]
<State>

Activates the indication of the markers and the marker list in the measurement diagram and in the hardcopy file.

Parameters:
<State> 0 | 1 | OFF | ON
*RST: 1

- Example:** TRAC:SWE:MEAS:MARK:DISP:ANN ON
The diagram also shows the marker information.
- Options:** Option R&S SMAB-K28
- Manual operation:** See "[Marker View](#)" on page 257

:TRACe[:POWer]:SWEep:MEASurement:PULSe:DISPlay:ANNotation[:STATe]
<State>

Activates the indication of the pulse data below the measurement diagram and storing the data in the hardcopy file. The parameters to be indicated can be selected with the following TRAC:SWE:MEAS:... commands. Only six parameters are indicated at one time.

Note: This command is only available in time measurement mode and with R&S NRPZ81 power sensors.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 1

Example:

TRAC:SWE:MEAS:PULS:DISP:ANN ON
 Activates indication of the selected pulse data.

Options:

Option R&S SMAB-K28

Manual operation: See "[Pulse Data View](#)" on page 257

:TRACe[:POWer]:SWEep:MEASurement:STANdard:DISPlay:ANNotation[:STATe]
 <State>

Selects the standard view, i.e. diagram and buttons but no lists are displayed and also stored in the hardcopy file.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 1

Example:

TRAC:SWE:MEAS:STAN:DISP:ANN ON
 Activates indication of the selected pulse data.

Options:

Option R&S SMAB-K28

Manual operation: See "[Standard View](#)" on page 256

14.15 SENSE, READ, INITiate and SLISt Subsystems

These subsystems contain the commands for configuring the power measurements with R&S NRP power sensor connected to the R&S SMA100B.



The local state is set with the `INIT` command. Switching off the local state enhances the measurement performance. Measurements results can be retrieved in local state on or off.

Sensor parameters are set with the `SENSe` commands.

To start the measurement and retrieve the result, use the `:READ<ch>[:POWer]?` command.

Suffix	Value range	Description
SENSe<ch>	[1] to 4	Indicates the sensor Sensor mapping: <ul style="list-style-type: none"> SENSe[1] - default mapping for sensors connected to the [Sensor] connector SENSe2 - sensor connected to a [USB] connector SENSe3 4 - further connected sensors to [USB] connectors, in the connection order Use the :SLISt commands to change the sensor mapping
READ<ch>	[1] to 4	Sensor assignment
INIate<hw>	[1] to 4	Sensor assignment
ELEMent<ch>	[1] to 25	Sensor mapping list

Programming examples

Example: Detecting and assigning a power sensor

```
SLISt:LIST?
// Response: "NRP33SN-V-900007-USB Legacy", "NRP-Z211-900001-USB Legacy"
// list of automatically detected sensors

SLISt:SCAN:STATe 1
// searches for sensors connected in the LAN or via the USBTMC protocol

SLISt:LIST?
// Response:
// "NRP33SN-V-900007-USB Legacy", "NRP-Z211-900001-USB Legacy",
// "NRP33SN-V-900005-USBTMC", "NRP33SN-V-900011-LAN"
// list of automatically detected sensors
// the list can contain more entries

SLISt:ELEMent3:MAPPing SENS1
// maps the third sensor from the list to the first sensor channel

SLISt:SENSor:MAP "NRPS18S-100654-USB Legacy", SENS3
// maps the sensor directly to channel 3
```

Example: Performing a simple power measurement

Prerequisite: The sensor is connected to the instrument and mapped to the first sensor channel.

```
:INITiate1:CONTinuous ON
//Switches the continous power measurement on

:READ1?
// Triggers the measurement and displays the results
```

Example: Performing a power measurement with a fixed filter

Prerequisite: The sensor is connected to the instrument and mapped to the first sensor channel.

```

SENSe1:SOURce RF
//Sensor measures the power of the RF signal

SENSe1:FILTer:TYPE NSRatio
//Selects fixed noise filter mode

SENSe1:FILTer:NSRatio 0.02 DB
//Sets the maximum noise component in the result to 0.02 DB

SENSe1:FILTer:NSRatio:MTIME 10
//Limits the settling time to 10 seconds.

:SENSe1:APERTure:DEFault:STATe 0
// Deactivates the default aperture time of the sensor

:SENSe1:APERTure:TIME 10e-6
// Sets the aperture time to 10 us

SENSe1:UNIT DBM
//Selects unit dBm for the measured value

:INITiate:CONTinuous ON
//Switches the continous power measurement on

:READ?
//Triggers the measurement and displays the results

```

:SLISt[:LIST]?.....	506
:SLISt:SCAN[:STATe].....	506
:SLISt:ELEMent<ch>:MAPPing.....	506
:SLISt:SENSor:MAP.....	507
:INITiate<hw>[:POWer]:CONTinuous.....	507
:READ<ch>[:POWer]?.....	507
:SENSe<ch>:UNIT[:POWer].....	508
:SENSe<ch>[:POWer]:APERTure:DEFault:STATe.....	508
:SENSe<ch>[:POWer]:APERTure:TIME.....	509
:SENSe<ch>[:POWer]:CORRection:SPDevice:SElect.....	509
:SENSe<ch>[:POWer]:CORRection:SPDevice:STATe.....	509
:SENSe<ch>[:POWer]:CORRection:SPDevice:LIST?.....	510
:SENSe<ch>[:POWer]:DISPlay:PERManent:PRlority.....	510
:SENSe<ch>[:POWer]:DISPlay:PERManent:STATe.....	510
:SENSe<ch>[:POWer]:FILTer:LENGth:AUTO?.....	510
:SENSe<ch>[:POWer]:FILTer:LENGth[:USER].....	511
:SENSe<ch>[:POWer]:FILTer:NSRatio.....	511
:SENSe<ch>[:POWer]:FILTer:NSRatio:MTIME.....	512
:SENSe<ch>[:POWer]:FILTer:SONCe.....	512

:SENSe<ch>[:POWer]:FILTer:TYPE.....	512
:SENSe<ch>[:POWer]:FREQUency.....	513
:SENSe<ch>[:POWer]:LOGGing:STATe.....	513
:SENSe<ch>[:POWer]:OFFSet.....	514
:SENSe<ch>[:POWer]:OFFSet:STATe.....	514
:SENSe<ch>[:POWer]:SNUMber?.....	514
:SENSe<ch>[:POWer]:SOURce.....	514
:SENSe<ch>[:POWer]:STATus[:DEVice]?.....	515
:SENSe<ch>[:POWer]:SVERsion?.....	515
:SENSe<ch>[:POWer]:TYPE?.....	515
:SENSe<ch>[:POWer]:ZERO.....	516

:SLISt[:LIST]?

Returns a list of all detected sensors in a comma-separated string.

Return values:

<SensorList> String of comma-separated entries
 Each entry contains information on the sensor type, serial number and interface.
 The order of the entries does not correspond to the order the sensors are displayed in the "NRP Sensor Mapping" dialog.

Example: See [Example "Detecting and assigning a power sensor"](#) on page 504.

Usage: Query only

Manual operation: See "[Sensor Mapping List](#)" on page 216

:SLISt:SCAN[:STATe] <State>

Starts the search for R&S NRP power sensors, connected in the LAN or via the USBTMC protocol.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 0

Example: See [Example "Detecting and assigning a power sensor"](#) on page 504.

Manual operation: See "[Scan](#)" on page 217

:SLISt:ELEMent<ch>:MAPPING <Mapping>

Assigns an entry from the [:SLISt\[:LIST\]?](#) to one of the four sensor channels.

Parameters:

<Mapping> SENS1 | SENSor1 | SENS2 | SENSor2 | SENS3 | SENSor3 |
SENS4 | SENSor4 | UNMapped

Sensor channel.

*RST: UNMapped

Example:

See [Example "Detecting and assigning a power sensor"](#) on page 504.

Manual operation: See "[Sensor Mapping List](#)" on page 216

:SLISt:SENSor:MAP <SensorId>, <Mapping>

Assigns a sensor directly to one of the sensor channels, using the sensor name and serial number.

To find out the the sensor name and ID, you can get it from the label of the R&S NRP, or using the command `:SLISt:SCAN[:STATe]`. This command detects all R&S NRP power sensors connected in the LAN or via 'USBTMC' protocol.

Setting parameters:

<SensorId> string

<Mapping> enum

Example:

See [Example "Detecting and assigning a power sensor"](#) on page 504.

Usage:

Setting only

Manual operation: See "[Sensor Mapping List](#)" on page 216

:INITiate<hw>[:POWER]:CONTInuous <Continuous>

Switches the local state of the continuous power measurement by R&S NRP power sensors on and off. Switching off local state enhances the measurement performance during remote control.

The remote measurement is triggered with `:READ<ch>[:POWER]?`. This command also returns the measurement results. The local state is not affected, measurement results can be retrieved with local state on or off.

Parameters:

<Continuous> 0 | 1 | OFF | ON

*RST: 0

Example:

INIT1:CONT ON

Switches local state of continuous power measurement on.

Manual operation: See "[State](#)" on page 221

:READ<ch>[:POWER]?

Triggers power measurement and displays the results.

Note: This command does not affect the local state, i.e. you can get results with local state on or off. For long measurement times, we recommend that you use an SRQ for command synchronization (MAV bit).

Suffix:

<ch> 1 to 3

Return values:

<Power> float or float,float

The sensor returns the result in the unit set with command :

[SENSe<ch>:UNIT\[:POWER\]](#)

Certain power sensors, such as the R&S NRP-Z81, return two values, first the value of the average level and - separated by a comma - the peak value.

Example:

SENS1:UNIT DBM

Selects unit dBm for presentation of measurement result.

READ1?

Queries the measurement result of the sensor.

-45.6246576745440230

-45.6 dBm were measured at the given frequency.

Example:

R&S NRP-Z81

READ1?

-55.62403263352178, -22.419472478812476

-55.6 dBm is the measured average level, -22.4 dBm is the measured peak level at the given frequency.

Usage:

Query only

Manual operation: See "[Level \(Peak\) / Level \(Average\)](#)" on page 221

:SENSe<ch>:UNIT[:POWER] <Power>

Selects the unit (Watt, dBm or dBµV) of measurement result display, queried with :

[READ<ch>\[:POWER\]?](#)

Parameters:

<Power> DBM | DBUV | WATT

*RST: DBM

Example:

SENS2:UNIT DBM

Selects dBm as unit for the measured value returned by command READ.

READ2?

Response: 7.34

7.34 dBm are measured by sensor 2.

Manual operation: See "[Level \(Peak\) / Level \(Average\)](#)" on page 221

:SENSe<ch>[:POWER]:APERTure:DEFault:STATe <UseDefAp>

Deactivates the default aperture time of the respective sensor.

To specify a user-defined value, use the command `:SENSe<ch>[:POWer]:APERTure:TIME` on page 509.

Parameters:

`<UseDefAp>` 0 | 1 | OFF | ON
`*RST:` 1

Example: See [Example "Performing a power measurement with a fixed filter"](#) on page 505.

Manual operation: See ["Default Aperture Time"](#) on page 224

`:SENSe<ch>[:POWer]:APERTure:TIME <ApTime>`

Defines the aperture time (size of the acquisition interval) for the corresponding sensor.

Parameters:

`<ApTime>` float
 Range: depends on connected power sensor
 Increment: 1E-9
`*RST:` depends on connected power sensor

Example: See [Example "Performing a power measurement with a fixed filter"](#) on page 505.

Manual operation: See ["Aperture Time"](#) on page 224

`:SENSe<ch>[:POWer]:CORRection:SPDevice:SElect <Select>`

Several S-parameter tables can be stored in a sensor. The command selects a loaded data set for S-parameter correction for the corresponding sensor.

Parameters:

`<Select>` float
`*RST:` 0

Manual operation: See [" S-Parameter "](#) on page 224

`:SENSe<ch>[:POWer]:CORRection:SPDevice:STATe <State>`

Activates the use of the S-parameter correction data.

Note: If you use power sensors with attenuator, the instrument automatically activates the use of S-parameter data.

Parameters:

`<State>` 0 | 1 | OFF | ON
`*RST:` 0

Example: `SENSe1:POWer:CORRection:SPDevice:STATe 1`
 Activates the use of the S-parameters correction data.

Manual operation: See [" S-Parameter "](#) on page 224

:SENSe<ch>[:POWer]:CORRection:SPDevice:LIST?

Queries the list of the S-parameter data sets that have been loaded to the power sensor.

Return values:

<List> string list
*RST: 0

Usage: Query only

Manual operation: See " [S-Parameter](#) " on page 224

:SENSe<ch>[:POWer]:DISPlay:PERMANent:PRiority <Priority>

Selects average or peak power for permanent display.

Parameters:

<Priority> AVERAge | PEAK
*RST: AVERAge

Example:

SENS1:DISP:PERM:STAT ON
The permanent viewer is switched on.
SENS1:DISP:PERM:PRI AVER
The measured average power is indicated.

Manual operation: See " [Display](#) " on page 222

:SENSe<ch>[:POWer]:DISPlay:PERMANent:STATe <State>

Activates the permanent display of the measured power level results. The instrument also indicates the sensor type, the connection, the measurement source and the offset if set.

Parameters:

<State> 0 | 1 | OFF | ON
*RST: 0

Example:

SENS1:POW:DISP:PERM:STAT ON
The permanent viewer is switched on.

Manual operation: See " [Permanent](#) " on page 221

:SENSe<ch>[:POWer]:FILTer:LENGth:AUTO?

Queries the current filter length in filter mode AUTO (:SENSe<ch>[:POWer]:FILTer:TYPE)

Return values:

<Auto> float
Range: 1 to 65536

Example: SENS1:FILT:TYPE AUTO
 Selects auto filter.
 SENS1:FILT:LENG:AUTO?
 Queries the automatically set filter length.
 Response: 1024

Usage: Query only

Manual operation: See ["Filter Length"](#) on page 223

:SENSe<ch>[:POWer]:FILTer:LENGth[:USER] <User>

Selects the filter length for `SENS:POW:FILT:TYPE USER`. As the filter length works as a multiplier for the time window, a constant filter length results in a constant measurement time (see also ["About the measuring principle, averaging filter, filter length, and achieving stable results"](#) on page 217).

The R&S NRP power sensors provide different resolutions for setting the filter length, depending on the used sensor type:

- Resolution = 1 for R&S NRPxx power sensors
- Resolution = 2ⁿ for sensors of the R&S NRP-Zxx family, with n = 1 to 16

Parameters:

<User> float
 Range: 1 to 65536
 *RST: 1

Example: SENS1:FILT:TYPE USER
 Selects user filter mode.
 SENS1:FILT:LENG 16
 Sets a filter length of 16. E.g. using a sensor with 20 ms time window, the resulting measurement time is 640 ms (2x16x20 ms)

Manual operation: See ["Filter Length"](#) on page 223

:SENSe<ch>[:POWer]:FILTer:NSRatio <NSRatio>

Sets an upper limit for the relative noise content in fixed noise filter mode (`:SENSe<ch>[:POWer]:FILTer:TYPE`). This value determines the proportion of intrinsic noise in the measurement results.

Parameters:

<NSRatio> float
 Range: 0.001 to 1
 Increment: 0.001
 *RST: 0.01

Example: See [Example "Performing a power measurement with a fixed filter"](#) on page 505.

Manual operation: See ["Noise/Signal Ratio"](#) on page 223

:SENSe<ch>[:POWer]:FILTer:NSRatio:MTIME <MTime>

Sets an upper limit for the settling time of the auto-averaging filter in the `NSRatio` mode and thus limits the length of the filter. The filter type is set with command `:SENSe<ch>[:POWer]:FILTer:TYPE`.

Parameters:

<MTime> float
 Range: 1 to 999.99
 Increment: 0.01
 *RST: 4

Example: See [Example "Performing a power measurement with a fixed filter"](#) on page 505.

Manual operation: See ["Timeout"](#) on page 223

:SENSe<ch>[:POWer]:FILTer:SONCe

Starts searching the optimum filter length for the current measurement conditions. You can check the result with command `:SENS1:POW:FILT:LENG:USER?` in filter mode `USER (:SENSe<ch>[:POWer]:FILTer:TYPE)`.

Example:

```
SENS1:FILT:TYPE USER
Selects user filter mode.
SENS1:FILT:SONC
Activates the search for the optimum filter length.
SENS1:FILT:LENG?
Returns the found optimum filter length.
Response: 128
```

Usage: Event

Manual operation: See ["Auto Once"](#) on page 223

:SENSe<ch>[:POWer]:FILTer:TYPE <Type>

Selects the filter mode. The filter length is the multiplier for the time window and thus directly affects the measurement time.

Parameters:

<Type> AUTO | USER | NSRatio

AUTO
 Automatically selects the filter length, depending on the measured value. The higher the power, the shorter the filter length, and vice versa.

USER
 Allows you to set the filter length manually. As the filter-length takes effect as a multiplier of the measurement time, you can achieve constant measurement times.

NSRatio

Selects the filter length (averaging factor) according to the criterion that the intrinsic noise of the sensor (2 standard deviations) does not exceed the specified noise content. You can define the noise content with command `:SENSe<ch>[:POWer]:FILTer:NSRatio`.

Note: To avoid long settling times when the power is low, you can limit the averaging factor limited with the "timeout" parameter (`:SENSe<ch>[:POWer]:FILTer:NSRatio:MTIME`).

*RST: AUTO

Example: See [Example "Performing a power measurement with a fixed filter"](#) on page 505.

Manual operation: See ["Filter"](#) on page 222

:SENSe<ch>[:POWer]:FREQUency <Frequency>

Sets the RF frequency of the signal, if signal source "USER" is selected (`:SENSe<ch>[:POWer]:SOURce`).

Parameters:

<Frequency> float
*RST: 1 GHz

Example: `SENS1:SOUR USER`
Selects user-defined source.
`SENS1:FREQ 2.44GHz`
Sets the RF frequency of the source which is 2.44 GHz.

Manual operation: See ["Frequency"](#) on page 222

:SENSe<ch>[:POWer]:LOGGing:STATe <State>

Activates the recording of the power values, measured by a connected R&S NRP power sensor.

Parameters:

<State> 0 | 1 | OFF | ON
*RST: 0

Example: `SENS:LOGG:STAT ON`
Activates recording of the power measurement of the first sensor.

Manual operation: See ["Enable Logging"](#) on page 224

:SENSe<ch>[:POWer]:OFFSet <Offset>

Sets a level offset which is added to the measured level value after activation with command `:SENSe<ch>[:POWer]:OFFSet:STATe`. The level offset allows, e.g. to consider an attenuator in the signal path.

Parameters:

<Offset> float
 Range: -100.0 to 100.0
 *RST: 0
 Default unit: dB

Example: `SENS1:POW:OFFS 10.0`
 Sets a level offset of 10 dB

Manual operation: See "[Level Offset State,Level Offset](#)" on page 222

:SENSe<ch>[:POWer]:OFFSet:STATe <State>

Activates the addition of the level offset to the measured value. The level offset value is set with command `:SENSe<ch>[:POWer]:OFFSet`.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 0

Example: `SENS1:POW:OFFS 0.4dB`
 Sets a level offset of 0.4 dB
`SENS1:POW:OFFS:STAT ON`
 A level offset of 0.4 dB is added to the measured value.

Manual operation: See "[Level Offset State,Level Offset](#)" on page 222

:SENSe<ch>[:POWer]:SNUMber?

Queries the serial number of the sensor.

Return values:

<SNumber> string

Example: `SENS1:SNUM?`
 Queries the serial number.

Usage: Query only

Manual operation: See "[Sensor type and serial number](#)" on page 221

:SENSe<ch>[:POWer]:SOURce <Source>

Determines the signal to be measured.

Note: When measuring the RF signal, the sensor considers the corresponding correction factor at that frequency, and uses the level setting of the instrument as reference level.

Parameters:

<Source> A | USER | RF
*RST: A

Example: See [Example "Performing a power measurement with a fixed filter"](#) on page 505.

Manual operation: See "[Use Frequency Of](#)" on page 222

:SENSe<ch>[:POWer]:STATus[:DEVice]?

Queries if a sensor is connected to the instrument.

Return values:

<Status> 0 | 1 | OFF | ON
*RST: 0

Example: SENS1:STAT?
Response: 1
A sensor is connected.

Usage: Query only

Manual operation: See "[State](#)" on page 221

:SENSe<ch>[:POWer]:SVERsion?

Queries the software version of the connected R&S NRP power sensor.

Return values:

<SVersion> string

Example: SENS1:POW:SVER?
Queries the software version of the power sensor.

Usage: Query only

:SENSe<ch>[:POWer]:TYPE?

Queries the sensor type. The type is automatically detected.

Return values:

<Type> string

Example: SENS1:TYPE?
Queries the type of sensor.
Response: NRP-Z21
The R&S NRP-Z21 sensor is used.

Usage: Query only

Manual operation: See "[Sensor type and serial number](#)" on page 221

:SENSe<ch>[:POWer]:ZERO

Performs zeroing of the sensor.

Zeroing is required after warm-up, i.e. after connecting the sensor.

Note: Switch off or disconnect the RF power source from the sensor before zeroing.

We recommend that you zero in regular intervals (at least once a day), if:

- The temperature has varied more than about 5 °C.
- The sensor has been replaced.
- You want to measure very low power.

Example: SENS1 : ZERO
 Executes zeroing.

Usage: Event

Manual operation: See "[Zero](#)" on page 221

14.16 SOURce Subsystem

The SOURce subsystem contains the commands for configuring the digital and analog signals.

Common suffixes

The following common suffixes are used in remote commands:

Suffix	Value range	Description
SOURce<hw>	[1]	<ul style="list-style-type: none"> • SOURce[1] = RF output (optional keyword) • LF output = SOURce:LFOutput (SOURce is optional keyword)

- [Analog Modulation Subsystems](#).....517
- [Avionic Standards Subsystems](#).....544
- [SOURce:CORRection Subsystem](#).....586
- [SOURce:FREQuency Subsystem](#).....594
- [SOURce:INPut Subsystem](#).....602
- [SOURce:LFOutput Subsystem](#).....603
- [SOURce:LIST Subsystem](#).....616
- [SOURce:NOISe Subsystem](#).....629
- [SOURce:PGEN Subsystem](#).....630
- [SOURce:PHASe Subsystem](#).....632
- [SOURce:POWer Subsystem](#).....633
- [SOURce:ROSCillator Subsystem](#).....642
- [SOURce:SWEep Subsystem](#).....647

14.16.1 Analog Modulation Subsystems

Option: see [Chapter 5.1, "Required Options"](#), on page 74.

The subsystems in this section describe all commands for analog modulation of the RF signal. Divided in separate sections, you can configure amplitude modulation (AM), frequency modulation (FM), phase modulation (PhiM) and pulse modulation (PULM).

You can perform each of the modulations either with an internally generated modulation signal or with an externally applied signal.

To configure the internal signal, use the commands listed in [Chapter 14.16.6, "SOURce:LFOutput Subsystem"](#), on page 603.

For more information:

See [Chapter 5, "Analog Modulations"](#), on page 74.

14.16.1.1 SOURce:MODulation Subsystem

The command in this subsystem allows you to disable all active modulations at once, and, vice versa, to restore the last active ones.

[:SOURce<hw>]:MODulation[:ALL][:STATe] <State>

Activates all modulations that were active before the last switching off.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 0

Example:

```
SOURce1:AM1:DEPTh 30
SOURce1:AM1:SOURce LF1
SOURce1:AM1:STATe 1
SOURce1:FM1:DEVIation 1000
SOURce1:FM1:STATe 1
// disable both modulation
SOURce1:MODulation:ALL:STATe 0
SOURce1:AM1:STATe?
// 0
SOURce1:FM1:STATe?
// 0
// enable both modulation
SOURce1:MODulation:ALL:STATe 1
SOURce1:AM1:STATe?
// 1
SOURce1:FM1:STATe?
// 1
```

Manual operation: See "[\[Mod on/off\]](#)" on page 76

14.16.1.2 SOURce:AM Subsystem

Option: R&S SMAB-K720

The AM subsystem contains the commands for setting the amplitude modulation and also the broadband amplitude modulation.

The following examples show some variants for generating AM signals.

Example: Creating an amplitude modulated RF signal

Using the internal LF generator, the following command sequence configures an amplitude modulated signal.

```
// Reset the instrument to start from a defined state
*RST

// Set RF frequency and amplitude
SOURce1:FREQuency:CW 6000000000
SOURce1:POWer:LEVel:IMMediate:AMPLitude -25

// Configure the modulation signal
SOURce1:LFOutput1:SHAPE SINE
SOURce1:LFOutput1:FREQuency 20000

// Configure the amplitude modulation settings and switch AM on
SOURce1:AM1:SOURce LF1
SOURce1:AM1:DEPTh 30
SOURce1:AM:RATio 40
SOURce1:AM1:DEVIation:MODE UNC
SOURce1:AM1:STATE 1
```

Example: Using combined LF signals

Using the internal LF generators of both paths, the following command sequences configure an amplitude modulated signal with determined deviations depths.

```
// Configure the AM modulation settings with combined LF signal sources
SOURce1:AM1:SOURce LF1
SOURce1:AM1:DEPTh:LINear 32
// Select the modulation signal source for the second path
SOURce1:AM2:SOURce LF2
// Combine the signals of both paths with fixed total deviation depth
SOURce1:AM1:DEVIation:MODE TOT
SOURce1:AM1:DEPTh:SUM 60

// Query the deviation depth of modulation signal in the second path
SOURce1:AM2:DEPTh:LINear?
// Response: 28

// Combine the signals of both paths with fixed ratio
SOURce1:AM1:DEVIation:MODE RAT
```

```

SOURcel:AM1:RATio 100
SOURcel:AM2:DEPTh:LINear 25

// Query the deviation depth of modulation signal in the first path
SOURcel:AM1:DEPTh:LINear?
// Response: 25

SOURcel:AM1:STATe 1
SOURcel:AM2:STATe 1

```

Example: Using an external signal source

Using an external signal source, you can additionally determine whether you want to use only the AC component of the external modulation signal.

```

// Reset the instrument to start from a defined state
*RST

// Set frequency and amplitude
SOURcel:FREQuency:CW 6000000000
SOURcel:POWer:LEVel:IMMediate:AMPLitude -25

// Configure the amplitude modulation settings and turn on AM
SOURcel:AM1:SOURce EXT1
SOURcel:AM1:DEPTh 40

// Query the input sensitivity at the external modulation input
SOURcel:AM1:SENSitivity?
// Response: 40
// Since the voltage value for full modulation is 1V,
// the resulting sensitivity is precisely 50%/V.
// This value is assigned to the voltage value for full
// modulation of the input.

// Select the coupling mode AC for external amplitude modulation
SOURcel:INPut:MODext:COUPling1 AC

// For external AM signal input, adjust the sensitivity
SOURcel:AM1:TYPE EXP
SOURcel:AM1:SOURce EXT1
SOURcel:AM1:SENSitivity 25
SOURcel:AM1:SENSitivity?
Response: 25

// Alternatively use the scan mode for the level behavior of rotating antennas
// SCAN automatically sets the modulation type to exponential
SOURcel:AM1:MODE SCAN
SOURcel:AM1:SOURce EXT2
SOURcel:AM1:DEPTh:EXPOntial 12
SOURcel:AM1:DEPTh:EXPOntial?
Response: 12

```

```
// Activating the external exponential AM changes the coupling
// in this example for EXT2
INPut:MODext:COUPling2 DC

// Configure the modulation settings

// Switch on AM and RF signal output
SOURce1:AM1:STATe 1
OUTPut1:STATe 1
```

The following commands are available:

<code>[SOURce<hw>]:AM<ch>:STATe</code>	520
<code>[SOURce<hw>]:AM<ch>:SOURce</code>	520
<code>[SOURce<hw>]:AM<ch>[:DEPTH]</code>	521
<code>[SOURce<hw>]:AM<ch>:DEPTH:LINear</code>	521
<code>[SOURce<hw>]:AM<ch>:DEPTH:EXPonential</code>	522
<code>[SOURce<hw>]:AM:MODE</code>	522
<code>[SOURce<hw>]:AM:DEPTH:SUM</code>	522
<code>[SOURce<hw>]:AM:DEVIation:MODE</code>	523
<code>[SOURce<hw>]:AM:RATio</code>	523
<code>[SOURce<hw>]:AM<ch>:SENSitivity:EXPonential</code>	523
<code>[SOURce<hw>]:AM<ch>:SENSitivity[:LINear]</code>	524
<code>[SOURce<hw>]:AM:TYPE</code>	524

`[SOURce<hw>]:AM<ch>:STATe <State>`

Activates amplitude modulation.

Suffix:

`<ch>` 1 to 2
Modulation signal channel

Parameters:

`<State>` 0 | 1 | OFF | ON
*RST: 0

Example: See [Example "Creating an amplitude modulated RF signal"](#) on page 518.

Manual operation: See ["State"](#) on page 80

`[SOURce<hw>]:AM<ch>:SOURce <Source>`

Selects the modulation source for amplitude modulation.

Suffix:

`<ch>` 1 to 2
Modulation signal channel

Parameters:

`<Source>` LF1 | LF2 | NOISe | EXT1 | EXT2 | EXTernal | INTernal

LF1|LF2

Uses an internally generated LF signal.

EXT1|EXT2

Uses an externally supplied LF signal.

NOISe

Uses the internally generated noise signal.

INTernal

Uses the internally generated signal of LF1.

EXTernal

Uses an external LF signal (EXT1).

*RST: LF1 <AM1>; LF2 <AM2>

Example: See [Example "Creating an amplitude modulated RF signal"](#) on page 518.

Manual operation: See ["Source"](#) on page 80

[:SOURce<hw>]:AM<ch>[:DEPTH] <Depth>

Sets the depth of the amplitude modulation in percent.

Suffix:

<ch> 1...2
Modulation signal channel

Parameters:

<Depth> float
Range: 0 to 100
Increment: 0.01
*RST: 30

Example: See [Example "Creating an amplitude modulated RF signal"](#) on page 518.

[:SOURce<hw>]:AM<ch>:DEPTH:LINear <DepthLin>

Sets the depth of the linear amplitude modulation in percent / volt.

Parameters:

<DepthLin> float
Range: 0 to 100
Increment: 0.01
*RST: 30

Example: See [Example "Creating an amplitude modulated RF signal"](#) on page 518. Similar to DEPTH.

Manual operation: See ["Depth"](#) on page 84

[:SOURce<hw>]:AM<ch>:DEPTH:EXPONENTIAL <DepthExp>

Sets the depth of the exponential amplitude modulation in dB/volt.

Parameters:

<DepthExp> float
 Range: 0 to 100
 Increment: 0.01
 *RST: 10

Example: See [Example "Creating an amplitude modulated RF signal"](#) on page 518. Similar to DEPTH.

Manual operation: See ["Depth"](#) on page 84

[:SOURce<hw>]:AM:MODE <AmMode>

Selects the mode of the amplitude modulation.

`[:SOURce<hw>]:AM:MODE > SCAN sets [:SOURce<hw>]:AM:TYPE > EXPONENTIAL.`

For active external exponential AM, automatically sets `[:SOURce<hw>]:INPUT:MODExt:COUPling<ch> > DC.`

Parameters:

<AmMode> SCAN | NORMAl
 *RST: NORMAl

Example: See [Example "Using an external signal source"](#) on page 519.

Options: R&S SMAB-K721

Manual operation: See ["Mode"](#) on page 84

[:SOURce<hw>]:AM:DEPTH:SUM <AmDepthSum>

Sets the total depth of the LF signal when using combined signal sources in amplitude modulation.

Parameters:

<AmDepthSum> float
 Range: 0 to 100
 Increment: 0.01
 *RST: 30

Example: See [Example "Using combined LF signals"](#) on page 518.

Manual operation: See ["Total Depth"](#) on page 85

[:SOURce<hw>]:AM:DEVIation:MODE <AmDevMode>

Selects the coupling mode. The coupling mode parameter also determines the mode for fixing the total depth.

Parameters:

<AmDevMode> UNCOupled | TOTal | RATio

UNCOupled

Does not couple the LF signals.

The deviation depth values of both paths are independent.

TOTal

Couples the deviation depth of both paths.

RATio

Couples the deviation depth ratio of both paths

*RST: UNCOupled

Example: See [Example "Using combined LF signals"](#) on page 518.

Manual operation: See ["Deviation Mode"](#) on page 84

[:SOURce<hw>]:AM:RATio <Ratio>

Sets the deviation ratio (path#2 to path#1) in percent.

Parameters:

<Ratio> float
 Range: 0 to 100
 Increment: 0.01
 *RST: 100

Example: See [Example "Creating an amplitude modulated RF signal"](#) on page 518.

Manual operation: See ["Ratio Path2/Path1"](#) on page 85

[:SOURce<hw>]:AM<ch>:SENSitivity:EXPOntial <Sensitivity>

For [:SOURce<hw>]:AM:TYPEEXP, sets the sensitivity of the external signal source for amplitude modulation.

Parameters:

<Sensitivity> float
 Range: 0 to 100
 Increment: 0.01
 *RST: 10

Example: See [Example "Using an external signal source"](#) on page 519.

Manual operation: See ["Sensitivity"](#) on page 84

[:SOURce<hw>]:AM<ch>:SENSitivity[:LINear] <Sensitivity>

For [:SOURce<hw>] :AM:TYPE LIN, sets the sensitivity of the external signal source for amplitude modulation.

Parameters:

<Sensitivity> float
 Range: 0 to 100
 Increment: 0.1
 *RST: 30

Example: See [Example "Using an external signal source"](#) on page 519.

Manual operation: See ["Sensitivity"](#) on page 84

[:SOURce<hw>]:AM:TYPE <AmType>

Selects the type of amplitude modulation.

For [:SOURce<hw>] :AM:MODE SCAN, only EXPonential is available.

For active external exponential AM, automatically sets [:SOURce<hw>] :INPut : MODext:COUPling<ch>DC.

Parameters:

<AmType> LINear | EXPonential
 *RST: LINear

Example: See [Example "Using an external signal source"](#) on page 519.

Options: R&S SMAB-K721

Manual operation: See ["Type"](#) on page 84

14.16.1.3 SOURce:FM Subsystem

Option: R&S SMAB-K720

The FM subsystem contains the commands for setting the frequency modulation.

Example: Creating a frequency modulated RF signal

Using the internal LF generator, the following command sequence configures a frequency modulated signal.

```
// Reset the instrument to start from a defined state
*RST

// Set RF frequency and amplitude
SOURce1:FREQuency:CW 6000000000
SOURce1:POWer:LEVel:IMMediate:AMPLitude -25

// Configure the modulation signal
SOURce1:LFOutput1:SHAPE SINE
```



```
SOURcel:LFOutput1:FREQuency 20000

// Configure the frequency modulation settings and switch FM on
SOURcel:FM1:SOURce LF1
SOURcel:FM1:DEVIation 1000
SOURcel:FM:RATio 40
SOURcel:FM:MODE LNOise
SOURcel:FM1:STATe 1

// Switch on LF and RF signal output
SOURcel:LFOutput1:STATe 1
OUTPut1:STATe 1
```

Example: Using combined LF signals

Using the internal LF generators of both paths, the following command sequences configure a frequency modulated signal with determined deviations.

```
// Configure the FM modulation settings with combined LF signal sources
SOURcel:FM1:SOURce LF1
SOURcel:FM1:DEVIation 1000
// Select the modulation signal source for the second path
SOURcel:FM2:SOURce LF2
// Combine the signals of both paths with fixed total deviation depth
SOURcel:FM1:DEVIation:MODE TOT
SOURcel:FM1:DEVIation:SUM 5000

// Query the deviation depth of modulation signal in the second path
SOURcel:FM2:DEVIation?
// Response: 4000

// Combine the signals of both paths with fixed ratio
SOURcel:FM1:DEVIation:MODE RAT
SOURcel:FM1:RATio 100
SOURcel:FM2:DEVIation 10000

// Query the deviation depth of modulation signal in the first path
SOURcel:AM1:DEVIation?
// Response: 1000

SOURcel:FM1:STATe 1
SOURcel:FM2:STATe 1
```

Example: Using an external signal source

Alternatively configure the frequency modulation settings with an external modulation signal.

```
// Reset the instrument to start from a defined state
*RST
```

```
// Set RF frequency and amplitude
SOURce1:FREQuency:CW 6000000000
SOURce1:POWer:LEVel:IMMediate:AMPLitude -25

// Configure the frequency modulation settings and switch FM on
SOURce1:FM1:SOURce EXT1
SOURce1:FM1:DEVIation 5000

// Query the input sensitivity at the external modulation input
:SOURce1:FM1:SENSitivity?
// Response: 1000
// since the voltage value for full modulation is 1V,
// the resulting sensitivity is precisely 5000 Hz/V.

// Switch on FM and RF signal output
SOURce1:FM1:STATe 1
OUTPut1:STATe 1
```

The following commands are available:

[:SOURce<hw>]:FM<ch>:STATe	526
[:SOURce<hw>]:FM<ch>[:DEVIation]	526
[:SOURce<hw>]:FM<ch>:SOURce	527
[:SOURce<hw>]:FM:DEVIation:MODE	527
[:SOURce<hw>]:FM:DEVIation:SUM	528
[:SOURce<hw>]:FM:RATio	528
[:SOURce<hw>]:FM:MODE	528
[:SOURce<hw>]:FM:SENSitivity?	529

[\[:SOURce<hw>\]:FM<ch>:STATe <State>](#)

Activates frequency modulation.

Suffix:

FM<ch> 1..2
determines the modulation signal channel.

Parameters:

<State> 0 | 1 | OFF | ON
*RST: 0

Example: See [Example "Creating a frequency modulated RF signal"](#)
on page 524.

Manual operation: See ["State"](#) on page 80

[\[:SOURce<hw>\]:FM<ch>\[:DEVIation\] <Deviation>](#)

Sets the modulation deviation of the frequency modulation in Hz.

Suffix:

FM<ch> 1|2
Modulation signal channel

Parameters:

<Deviation> float

The maximum deviation depends on the RF frequency and the selected modulation mode (see data sheet).

Range: 0 to max

Increment: 0.01

*RST: 1E3

Example:

See [Example "Creating a frequency modulated RF signal"](#) on page 524.

Manual operation: See ["Deviation"](#) on page 80

[:SOURce<hw>]:FM<ch>:SOURce <Source>

Selects the modulation source for frequency modulation.

Suffix:

FM<ch> 1|2
Modulation signal channel.

Parameters:

<Source> LF1 | LF2 | NOISe | EXT1 | INTernal | EXTernal | EXT2

LF1|LF2

Uses an internally generated LF signal.

INTernal = LF1

Works like LF1

EXTernal

Works like EXT1

EXT1|EXT2

Uses an externally supplied LF signal.

NOISe

Uses the internally generated noise signal.

*RST: LF1 <FM1>; LF2 <FM2>

Example:

See [Example "Creating a frequency modulated RF signal"](#) on page 524.

Manual operation: See ["Source"](#) on page 80

[:SOURce<hw>]:FM:DEVIation:MODE <FmDevMode>

Selects the coupling mode. The coupling mode parameter also determines the mode for fixing the total deviation.

Parameters:

<FmDevMode> UNCOupled | TOTal | RATio

UNCOupled

Does not couple the LF signals.

The deviation values of both paths are independent.

TOTal

Couples the deviation of both paths.

RATio

Couples the deviation ratio of both paths

*RST: UNCOupled

Example: See [Example "Using combined LF signals"](#) on page 525.

Manual operation: See ["Deviation Mode"](#) on page 81

[:SOURce<hw>]:FM:DEVIation:SUM <FmDevSum>

Sets the total deviation of the LF signal when using combined signal sources in frequency modulation.

Parameters:

<FmDevSum> float
 Range: 0 to 40E6
 Increment: 0.01
 *RST: 1E3

Example: See [Example "Using combined LF signals"](#) on page 525.

Manual operation: See ["Total Deviation"](#) on page 81

[:SOURce<hw>]:FM:RATio <Ratio>

Sets the deviation ratio (path2 to path1) in percent.

Parameters:

<Ratio> float
 Range: 0 to 100
 Increment: 0.01
 *RST: 100

Example: See [Example "Creating a frequency modulated RF signal"](#) on page 524.

Manual operation: See ["Ratio Path2/Path1"](#) on page 81

[:SOURce<hw>]:FM:MODE <Mode>

Selects the mode for the frequency modulation.

Parameters:

<Mode> HBANdwidth | LNOise

HBANdwidth

Selects maximum range for modulation bandwidth.

LNOise

Selects optimized phase noise and spurious characteristics with reduced modulation bandwidth and FM deviation.

*RST: HBANdwidth

Example: See [Example "Creating a frequency modulated RF signal"](#) on page 524.

Manual operation: See ["Mode"](#) on page 81

[:SOURce<hw>]:FM:SENSitivity?

Queries the sensitivity of the externally supplied signal for frequency modulation. The sensitivity depends on the set modulation deviation.

Return values:

<Sensitivity> float
Sensitivity in Hz/V.
It is assigned to the voltage value for full modulation of the input.
Range: 0 to max
Increment: 0.01

Example: See [Example "Using an external signal source"](#) on page 525.

Usage: Query only

14.16.1.4 SOURce:PM Subsystem

Option: R&S SMAB-K720

The PM subsystem contains the commands for setting the phase modulation. You can configure the internal modulation source (LF generator) with the commands listed in [Chapter 14.16.6, "SOURce:LFOutput Subsystem"](#), on page 603 .

Example: Performing phase modulation

The following example shows a command sequence to perform phase modulation.

```
// Reset the instrument to start from an initial state
*RST; *CLS

// Set the RF signal frequency and level
SOURce:FREQuency:CW 4000000000
SOURce:POWer:LEVel:IMMediate:AMPLitude -25

// Configure the phase modulation settings
SOURce1:LFOutput1:SHAPE SINE
SOURce1:LFOutput1:FREQuency 1000

// Select the LF signal generated by the internal modulation generator
// or the internally generated noise signal
SOURce1:PM1:DEVIation 1
SOURce1:PM1:SOURce LF1
// SOURce1:PM1:SOURce INTernal
// SOURce1:PM1:SOURce NOISe
```

```

SOURcel:PM1:RATio 40
SOURcel:PM1:MODE HBAN

// Alternatively configure the phase modulation settings for an
// external modulation source and query the input sensitivity.
SOURcel:PM1:SOURce EXT1
// SOURcel:PM1:SOURce EXTernal
SOURcel:PM1:DEVIation 1
SOURcel:PM1:SENSitivity?
// Response: 1
// since the voltage value for full modulation is 1V,
// the resulting sensitivity is precisely 1RAD/V.

// Activate the signal output
SOURcel:PM1:STATe 1
OUTPut1:STATe 1

```

Example: Using combined LF signals

Using the internal LF generators of both paths, the following command sequences configure an phase modulated signal with determined deviations.

```

// Configure the Phase modulation settings with combined LF signal sources
SOURcel:PM1:SOURce LF1
SOURcel:PM1:DEVIation 1.5
// Select the modulation signal source for the second path
SOURcel:PM2:SOURce LF2
// Combine the signals of both paths with fixed total deviation depth
SOURcel:PM1:DEVIation:MODE TOT
SOURcel:PM1:DEVIation:SUM 2

// Query the deviation depth of the modulation signal in the second path
SOURcel:PM2:DEVIation?
// Response: 0.5

// Combine the signals of both paths with fixed ratio
SOURcel:PM1:DEVIation:MODE RAT
SOURcel:PM1:RATio 80
SOURcel:PM2:DEVIation?
// Response: 1.2

// Query the deviation depth of modulation signal in the first path
SOURcel:PM1:DEVIation?
// Response: 1.5

SOURcel:FM1:STATe 1
SOURcel:FM2:STATe 1

```

The following commands are available:

[:SOURce<hw>]:PM<ch>:STATe	531
[:SOURce<hw>]:PM<ch>:SOURce	531
[:SOURce<hw>]:PM:MODE	532
[:SOURce<hw>]:PM:DEVIation:MODE	532
[:SOURce<hw>]:PM:DEVIation:SUM	532
[:SOURce<hw>]:PM:RATio	533
[:SOURce<hw>]:PM:SENSitivity?	533
[:SOURce]:PM<ch>[:DEVIation]	533

[:SOURce<hw>]:PM<ch>:STATe <State>

Activates phase modulation.

Activation of phase modulation deactivates frequency modulation.

Suffix:

PM<ch> 1|2
Sets the modulation signal channel.

Parameters:

<State> 0 | 1 | OFF | ON
*RST: 0

Example: See [Example "Performing phase modulation"](#) on page 529.

Manual operation: See ["State"](#) on page 80

[:SOURce<hw>]:PM<ch>:SOURce <Source>

Selects the modulation source for phase modulation signal.

Suffix:

PM<ch> 1|2
Sets the modulation signal channel.

Parameters:

<Source> LF1 | LF2 | NOISe | EXT1 | EXT2 | INTernal | EXTernal

LF1|LF2

Uses an internally generated LF signal.

EXT1|EXT2

Uses an externally supplied LF signal.

NOISe

Uses the internally generated noise signal.

INTernal

Uses the internally generated signal of LF1.

EXTernal

Uses an external LF signal (EXT1).

*RST: LF1 <PM1>; LF2 <PM2>

Example: See [Example "Performing phase modulation"](#) on page 529.

Manual operation: See ["Source"](#) on page 80

[[:SOURce<hw>]:PM:MODE <Mode>

Selects the mode for the phase modulation.

Parameters:

<Mode> HBANdwidth | HDEVIation | LNOise

HBANdwidth

Sets the maximum available bandwidth.

HDEVIation

Sets the maximum range for Φ M deviation.

LNOise

Selects a phase modulation mode with phase noise and spurious characteristics close to CW mode.

*RST: HBANdwidth

Example: See [Example "Performing phase modulation"](#) on page 529.

Manual operation: See ["Mode"](#) on page 83

[[:SOURce<hw>]:PM:DEVIation:MODE <PmDevMode>

Selects the coupling mode. The coupling mode parameter also determines the mode for fixing the total deviation.

Parameters:

<PmDevMode> UNCOupled | TOTal | RATio

UNCOupled

Does not couple the LF signals.

The deviation values of both paths are independent.

TOTal

Couples the deviation of both paths.

RATio

Couples the deviation ratio of both paths

*RST: UNCOupled

Example: See [Example "Using combined LF signals"](#) on page 530

Manual operation: See ["Deviation Mode"](#) on page 82

[[:SOURce<hw>]:PM:DEVIation:SUM <PmDevSum>

Sets the total deviation of the LF signal when using combined signal sources in phase modulation.

Parameters:

<PmDevSum> float
Range: 0 to 20
Increment: 1E-6
*RST: 1

Example: See [Example "Using combined LF signals"](#) on page 530

Manual operation: See ["Total Deviation"](#) on page 82

[:SOURce<hw>]:PM:RATio <Ratio>

Sets the deviation ratio (path2 to path1) in percent.

Parameters:

<Ratio>	float
Range:	0 to 100
Increment:	0.01
*RST:	100

Example: See [Example "Performing phase modulation"](#) on page 529.

Manual operation: See ["Ratio Path2/Path1"](#) on page 82

[:SOURce<hw>]:PM:SENSitivity?

Queries the sensitivity of the externally applied signal for phase modulation.

The returned value reports the sensitivity in RAD/V. It is assigned to the voltage value for full modulation of the input.

Return values:

<Sensitivity>	float
---------------	-------

Example: See [Example "Performing phase modulation"](#) on page 529.

Usage: Query only

[:SOURce]:PM<ch>[:DEViation] <Deviation>

Sets the modulation deviation of the phase modulation in RAD.

Parameters:

<Deviation>	float
	The maximal deviation depends on the RF frequency and the selected modulation mode (see data sheet).
Range:	0 to max
Increment:	1
*RST:	1
	Default unit: RAD

Example: See [Example "Performing phase modulation"](#) on page 529.

Manual operation: See ["Deviation"](#) on page 82

14.16.1.5 SOURce:PULM Subsystem

Option: see [Chapter 5.1, "Required Options"](#), on page 74.

The PULM subsystem contains the commands for setting the pulse modulation.

- [Pulse Modulation Settings](#).....534
- [Pulse Train Settings](#)..... 539
- [Pulse Train Data Exchange](#)..... 542

Pulse Modulation Settings

With the commands described in this section, you can configure the settings for pulse modulation, select the trigger mode and determine delay times for the pulse modulation signal.

Example: Perform pulse modulation

The example shows a command sequence to perform pulse modulation.

```
// Reset the instrument to start from an initial state
*RST; *CLS

// Set the RF signal frequency and level
SOURce:FREQuency:CW 4000000000
SOURce:POWer:LEVel:IMMediate:AMPLitude -25

// Configure the pulse modulation settings
// Select the internal modulation generator,
// set trigger mode, select pulse mode, transition type

// Trigger a single pulse

SOURce:PULM:SOURce INT
SOURce:PULM:TRIGger:MODE SING
SOURce:PULM:MODE DOUB
SOURce:PULM:TTYPe SMO

SOURce:PULM:TRIG:IMM

// Alternatively configure the pulse modulation settings for
// external modulation source
// Select the source, set the polarity of the external signal,
// select the impedance for the external pulse modulation input/
// for the external pulse modulation trigger input
SOURce:PULM:SOURce EXT
SOURce:PULM:POLarity NORMal
SOURce:PULM:IMPedance G1K

// Configure the pulse generator settings
// Set pulse period, width, and delay
SOURce:PULM:PERiod 10 us
SOURce:PULM:WIDth 8 us
SOURce:PULM:DOUBle:WIDTh 0.0000012
SOURce:PULM:DOUBle:DELay 0.0000045

// Activate the signal output
SOURce:PGENERator:OUTPut:STATe 1
SOURce:PULM:STATe 1
OUTPut1:STATe 1
```

The following commands are available:

<code>[:SOURce<hw>]:PULM:MODE</code>	535
<code>[:SOURce<hw>]:PULM:TRIGger:MODE</code>	535
<code>[:SOURce]:PULM[:INTernal][:TRAIIn]:TRIGger:IMMEDIATE</code>	536
<code>[:SOURce<hw>]:PULM:PERiod</code>	536
<code>[:SOURce<hw>]:PULM:WIDTh</code>	536
<code>[:SOURce<hw>]:PULM:DELay</code>	536
<code>[:SOURce<hw>]:PULM:DOUBle:DELay</code>	537
<code>[:SOURce<hw>]:PULM:DOUBle:WIDTh</code>	537
<code>[:SOURce<hw>]:PULM:DOUBle:STATe</code>	537
<code>[:SOURce<hw>]:PULM:STATe</code>	537
<code>[:SOURce<hw>]:PULM:SOURce</code>	537
<code>[:SOURce<hw>]:PULM:TTYPe</code>	538
<code>[:SOURce<hw>]:PULM:POLarity</code>	538
<code>[:SOURce<hw>]:PULM:IMPedance</code>	538
<code>[:SOURce<hw>]:PULM:THReshold</code>	539

`[:SOURce<hw>]:PULM:MODE <Mode>`

Selects the mode for the pulse modulation.

Parameters:

<Mode> SINGle | DOUBle | PTRain

SINGle

Generates a single pulse.

DOUBle

Generates two pulses within one pulse period.

PTRain

Generates a user-defined pulse train.

Specify the pulse sequence with the commands:

`[:SOURce<hw>]:PULM:TRAIIn:ONTime`

`[:SOURce<hw>]:PULM:TRAIIn:OFFTime`

`[:SOURce<hw>]:PULM:TRAIIn:REPetition`

*RST: SINGle

Example: See [Example "Perform pulse modulation"](#) on page 534.

Options: PTRain requires R&S SMAB-K27

Manual operation: See ["Pulse Mode"](#) on page 87

`[:SOURce<hw>]:PULM:TRIGger:MODE <Mode>`

Selects a trigger mode - auto, single, external, external single or external gated - for generating the modulation signal.

Parameters:

<Mode> AUTO | EXTernal | EGATe | SINGle | ESINGle

*RST: AUTO

Example: See [Example "Perform pulse modulation"](#) on page 534.

Manual operation: See ["Trigger Mode"](#) on page 87

[[:SOURce]:PULM[:INTernal][:TRAIIn]:TRIGger:IMMEDIATE

If [[:SOURce<hw>]:PULM:TRIGger:MODE SINGLE, triggers the pulse generator.

Example: See [Example "Perform pulse modulation"](#) on page 534.

Manual operation: See ["Execute Single Trigger"](#) on page 90

[[:SOURce<hw>]:PULM:PERiod <Period>

Sets the period of the generated pulse, that means the repetition frequency of the internally generated modulation signal.

Parameters:

<Period> float
 The minimum value depends on the installed options
 R&S SMAB-K22 or R&S SMAB-K23
 Range: 20E-9 to 100
 Increment: 5E-9
 *RST: 10E-6

Example: See [Example "Perform pulse modulation"](#) on page 534.

Manual operation: See ["Pulse Period"](#) on page 89

[[:SOURce<hw>]:PULM:WIDTh <Width>

Sets the width of the generated pulse, that means the pulse length. It must be at least 20ns less than the set pulse period.

Parameters:

<Width> float
 Range: 20E-9 to 100
 Increment: 10E-9
 *RST: 2E-6

Example: See [Example "Perform pulse modulation"](#) on page 534.

Manual operation: See ["Pulse Width"](#) on page 89

[[:SOURce<hw>]:PULM:DELay <Delay>

Sets the pulse delay.

Parameters:

<Delay> float
 *RST: 1ms

Example: See [Example "Perform pulse modulation"](#) on page 534.

Manual operation: See ["Pulse Delay"](#) on page 90

[:SOURce<hw>]:PULM:DOUBLE:DELay <Delay>

Sets the delay from the start of the first pulse to the start of the second pulse.

Parameters:

<Delay> float
*RST: 1E-6

Example: See [Example "Perform pulse modulation"](#) on page 534.

Manual operation: See ["Double Pulse Delay"](#) on page 90

[:SOURce<hw>]:PULM:DOUBLE:WIDTh <Width>

Sets the width of the second pulse.

Parameters:

<Width> float
Increment: 5E-9

Example: See [Example "Perform pulse modulation"](#) on page 534.

Manual operation: See ["Double Pulse Width"](#) on page 90

[:SOURce<hw>]:PULM:DOUBLE:STATe <State>

Provided for backward compatibility with former Rohde & Schwarz signal generators.

Works like the command `[:SOURce<hw>] :PULM:MODE DOUBle`.

Parameters:

<State> 0 | 1 | OFF | ON
*RST: 0

[:SOURce<hw>]:PULM:STATe <State>

Activates pulse modulation.

Parameters:

<State> 0 | 1 | OFF | ON
*RST: 0

Example: See [Example "Perform pulse modulation"](#) on page 534.

Manual operation: See ["State"](#) on page 78

[:SOURce<hw>]:PULM:SOURce <Source>

Selects between the internal (pulse generator) or an external pulse signal for the modulation.

Parameters:

<Source> INTernal | EXTernal
 *RST: INTernal

Example: See [Example "Perform pulse modulation"](#) on page 534.

Manual operation: See ["Source"](#) on page 78

[:SOURce<hw>]:PULM:TTYPe <Source>

Sets the transition mode for the pulse signal.

Parameters:

<Source> SMOothed | FAST
SMOothed
 flattens the slew rate, resulting in longer rise/fall times.
FAST
 enables fast transitions with shortest rise and fall times.
 *RST: FAST

Example: See [Example "Perform pulse modulation"](#) on page 534.

Manual operation: See ["Transition Type"](#) on page 78

[:SOURce<hw>]:PULM:POLarity <Polarity>

Sets the polarity of the externally applied modulation signal.

Parameters:

<Polarity> NORMal | INVerted
NORMal
 Suppresses the RF signal during the pulse pause.
INVerted
 Suppresses the RF signal during the pulse.
 *RST: NORMal

Example: See [Example "Perform pulse modulation"](#) on page 534.

Manual operation: See ["Polarity"](#) on page 98

[:SOURce<hw>]:PULM:IMPedance <Impedance>

Sets the impedance for the external pulse trigger and pulse modulation input.

Parameters:

<Impedance> G50 | G10K
 *RST: G50

Example: See [Example "Perform pulse modulation"](#) on page 534.

Manual operation: See ["Impedance"](#) on page 98

[[:SOURce<hw>]:PULM:THReshold <Threshold>

Sets the threshold for the input signal at the [Pulse Ext] connector.

Parameters:

<Threshold> float
 Range: 0 to 2
 Increment: 0.1
 *RST: 1
 Default unit: V

Example: SOURce:PULM:THReshold 1

Manual operation: See "[Threshold](#)" on page 99

Pulse Train Settings

Option: R&S SMAB-K27

This section describes the commands for the pulse train modulation and the associated file handling. For background information, see [Chapter 5.4.3.2, "Pulse Generator > Pulse Train Settings"](#), on page 90.

Example: Generating a pulse train signal

The following settings are required to perform pulse train modulation.



Always create and select pulse train data list first before you activate the pulse train mode.

Otherwise, an error is displayed

```
*RST; *CLS

// Set the RF signal frequency and level
SOURce:FREQuency:CW 4000000000
SOURce:POWer:LEVel:IMMediate:AMPLitude -25

// Create a pulse train data list
// Select the directory
MMEM:CDIR '/var/user/'
SOURce1:PULM:TRain:CATalog?
// my_pt
// Create and/or select the pulse train data file
SOURce1:PULM:TRain:SElect "/var/user/pt"
// Enter the pulse train data
SOURce:PULM:TRain:ONTime 0.0001,0.00025,0.0001
SOURce:PULM:TRain:OFFTime 500us,500us,300us
SOURce:PULM:TRain:REPetition 2,0,3
// the second pulse is ignored

// Select pulse train mode
```

```
// Select the internal modulation generator and the pulse mode
SOURce1:PULM:SOURce INT
SOURce1:PULM:MODE PTR
SOURce1:PULM:TRIGger:MODE EXT
SOURce1:PGENerator:OUTPut:STATe 1
SOURce1:PGENerator:OUTPut:POLarity NORM
SOURce:PGENerator:OUTPut:STATe 1
SOURce:PULM:STATe 1
OUTPut1:STATe 1

// SOURce1:PULM:TRAI:n:CATalog?
// my_pt, pt
// SOURce1:PULM:TRAI:n:DEL "/var/user/my_pt"
```

The following commands are available:

[:SOURce<hw>]:PULM:TRAI:n:CATalog?	540
[:SOURce<hw>]:PULM:TRAI:n:DELete	540
[:SOURce<hw>]:PULM:TRAI:n:ONTime	541
[:SOURce<hw>]:PULM:TRAI:n:OFFTime	541
[:SOURce<hw>]:PULM:TRAI:n:REPetition:POINts?	541
[:SOURce<hw>]:PULM:TRAI:n:ONTime:POINts?	541
[:SOURce<hw>]:PULM:TRAI:n:OFFTime:POINts?	541
[:SOURce<hw>]:PULM:TRAI:n:REPetition	541
[:SOURce<hw>]:PULM:TRAI:n:SELect	542

[\[:SOURce<hw>\]:PULM:TRAI:n:CATalog?](#)

Queries the available pulse train files in the specified directory.

Return values:

<Catalog> string
 List of list filenames, separated by commas

Example: See [Example "Generating a pulse train signal"](#) on page 539.

Usage: Query only

Manual operation: See ["Pulse Train Data"](#) on page 92

[\[:SOURce<hw>\]:PULM:TRAI:n:DELete](#) <Filename>

Deletes the specified pulse train file.

Setting parameters:

<Filename> string
 Filename or complete file path; file extension is optional.

Example: See [Example "Generating a pulse train signal"](#) on page 539.

Usage: Setting only

Manual operation: See ["Pulse Train Data"](#) on page 92

```
[:SOURce<hw>]:PULM:TRAI:n:ONTime <OnTime>
[:SOURce<hw>]:PULM:TRAI:n:OFFTime <OffTime>
```

Enters the pulse on/off times values in the selected list.

Parameters:

<OffTime> Offtime#1{, Offtime#2, ...} | binary block data
 List of comma-separated numeric values or binary block data, where:
 The list of numbers can be of any length.
 In binary block format, 8 (4) bytes are always interpreted as a floating-point number with double accuracy.
 See :FORMat [:DATA] on page 444 for details.
 The maximum length is 2047 values.
 Range: 0 ns to 5 ms

Example: See [Example "Generating a pulse train signal"](#) on page 539.

Manual operation: See ["Edit Pulse Train Data"](#) on page 93

```
[:SOURce<hw>]:PULM:TRAI:n:REPetition:POINts?
[:SOURce<hw>]:PULM:TRAI:n:ONTime:POINts?
[:SOURce<hw>]:PULM:TRAI:n:OFFTime:POINts?
```

Queries the number of on and off time entries and repetitions in the selected list.

Return values:

<Points> integer
 Range: 0 to INT_MAX
 *RST: 0

Example: See [Example "Generating a pulse train signal"](#) on page 539.

Usage: Query only

```
[:SOURce<hw>]:PULM:TRAI:n:REPetition <Repetition>
```

Sets the number of repetitions for each pulse on/off time value pair.

Parameters:

<Repetition> Repetition#1{, Repetition#2, ...}
 0 = ignore value pair
 Set "Repetition = 0" to skip a particular pulse without deleting the pulse on/off time value pair
 Range: 0 to 65535

Example: See [Example "Generating a pulse train signal"](#) on page 539.

Manual operation: See ["Edit Pulse Train Data"](#) on page 93

[:SOURce<hw>]:PULM:TRAI:n:SElect <Filename>

Selects or creates a data list in pulse train mode.

If the list with the selected name does not exist, a new list is created.

Parameters:

<Filename> string
Filename or complete file path; file extension can be omitted.

Example: See [Example "Generating a pulse train signal"](#) on page 539.

Manual operation: See ["Pulse Train Data"](#) on page 92

Pulse Train Data Exchange

Option: R&S SMAB-K27

With the following commands, you can configure pulse trains in ASCII format and export or import them accordingly.

```
SOURce1:PULM:SOURce INT
SOURce1:PULM:MODE PTR
SOURce1:PULM:TRAI:n:SElect "/var/user/pt"
SOURce1:PULM:STATe 1

SOURce1:PULM:TRAI:n:DEXChange:MODE EXP
SOURce1:PULM:TRAI:n:DEXChange:AFILe:EXTension TXT
SOURce1:PULM:TRAI:n:DEXChange:AFILe:SEParator:DECimal DOT
SOURce1:PULM:TRAI:n:DEXChange:AFILe:SEParator:COLumn SEM
SOURce1:PULM:TRAI:n:DEXChange:AFILe:SEParator:COLumn COMM
SOURce1:PULM:TRAI:n:DEXChange:SElect "/var/user/pt.pulstrn"
SOURce1:PULM:TRAI:n:DEXChange:AFILe:SElect "/var/user/pt_script.txt"
SOURce1:PULM:TRAI:n:DEXChange:EXECute
```

The following commands are available:

[:SOURce<hw>]:PULM:TRAI:n:DEXChange:MODE	542
[:SOURce<hw>]:PULM:TRAI:n:DEXChange:AFILe:EXTension	543
[:SOURce<hw>]:PULM:TRAI:n:DEXChange:AFILe:SEParator:DECimal	543
[:SOURce<hw>]:PULM:TRAI:n:DEXChange:AFILe:SEParator:COLumn	543
[:SOURce<hw>]:PULM:TRAI:n:DEXChange:AFILe:CATalog?	543
[:SOURce<hw>]:PULM:TRAI:n:DEXChange:AFILe:SElect	544
[:SOURce<hw>]:PULM:TRAI:n:DEXChange:SElect	544
[:SOURce<hw>]:PULM:TRAI:n:DEXChange:EXECute	544

[:SOURce<hw>]:PULM:TRAI:n:DEXChange:MODE <Mode>

Determines the import or export of a list.

Specify the source or destination file with the command [\[:SOURce<hw>\]:PULM:TRAI:n:DEXChange:SElect](#).

Parameters:

<Mode> IMPort | EXPort
 *RST: IMPort

Example: See ["Pulse Train Data Exchange"](#) on page 542.

Manual operation: See [" Mode "](#) on page 95

[:SOURce<hw>]:PULM:TRAI:n:DEXChange:AFILe:EXTension <Extension>

Determines the extension of the ASCII file for import or export, or to query existing files.

Parameters:

<Extension> TXT | CSV
 *RST: TXT

Example: See ["Pulse Train Data Exchange"](#) on page 542.

Manual operation: See ["ASCII File Settings"](#) on page 95

[:SOURce<hw>]:PULM:TRAI:n:DEXChange:AFILe:SEParator:DECimal <Decimal>

Sets "." (decimal point) or "," (comma) as the decimal separator used in the ASCII data with floating-point numerals.

Parameters:

<Decimal> DOT | COMMa
 *RST: DOT

Example: See ["Pulse Train Data Exchange"](#) on page 542.

Manual operation: See ["ASCII File Settings"](#) on page 95

[:SOURce<hw>]:PULM:TRAI:n:DEXChange:AFILe:SEParator:COLumn <Column>

Selects the separator between the frequency and level column of the ASCII table.

Parameters:

<Column> TABulator | SEMicolon | COMMa | SPACe
 *RST: COMMa

Example: See ["Pulse Train Data Exchange"](#) on page 542.

Manual operation: See ["ASCII File Settings"](#) on page 95

[:SOURce<hw>]:PULM:TRAI:n:DEXChange:AFILe:CATalog?

Queries the available ASCII files in the current or specified directory.

Return values:

<Catalog> string
 List of ASCII files *.txt or *.csv, separated by commas.

- Example:** See ["Pulse Train Data Exchange"](#) on page 542.
- Usage:** Query only
- Manual operation:** See ["Select \(ASCII\) Source/Select \(ASCII\) Destination"](#) on page 96

[:SOURce<hw>]:PULM:TRAI:n:DEXChange:AFILe:SElect <Filename>

Selects the ASCII file to be imported or exported.

Parameters:

<Filename> string
Filename or complete file path; file extension can be omitted.

- Example:** See ["Pulse Train Data Exchange"](#) on page 542.
- Manual operation:** See ["Select \(ASCII\) Source/Select \(ASCII\) Destination"](#) on page 96

[:SOURce<hw>]:PULM:TRAI:n:DEXChange:SElect <Filename>

Selects the ASCII file for import or export, containing a pulse train list.

Parameters:

<Filename> string
Filename or complete file path; file extension can be omitted.

- Example:** See ["Pulse Train Data Exchange"](#) on page 542.
- Manual operation:** See ["Select Source/Select ASCII Destination"](#) on page 96

[:SOURce<hw>]:PULM:TRAI:n:DEXChange:EXECute

Usage: Event

Manual operation: See ["Import / Export"](#) on page 96

Executes the import or export of the selected list file, according to the transfer direction set with command [\[:SOURce<hw>\]:PULM:TRAI:n:DEXChange:MODE](#).

14.16.2 Avionic Standards Subsystems

Option: see [Chapter 6.1, "Required Options"](#), on page 113.

The following subsections describe all commands for avionic standard modulation of the RF signal. Divided into separate avionic subsystem command sections, you can configure ADF, ILS and VOR modulation.

Programming examples are given for general configuration and avionic standard-specific configuration tasks.

Placeholder <Subsystem>

To simplify the description of the remote control commands, the placeholder <Subsystem> is introduced. Depending on the avionic standard used as an entry standard, replace this placeholder <Subsystem> with for example SOURce:ADF for ADF.



The replacement of the place holder <Subsystem> is mandatory, i.e. remote control commands containing this placeholder are not recognized and accepted by the instrument.

Example:

SCPI command <subsystem>:STATe:

- Entry Standard = ADF
SOURce:ADF:STATe
- Entry Standard = ILS
SOURce:ILS:STATe
- Entry Standard = VOR
SOURce:VOR:STATe
- Invalid command
<Subsystem>:STAT

Contents

• Programming Examples	545
• General Commands	549
• SOURce:ADF Subsystem	552
• SOURce:ILS Subsystem	555
• SOURce:VOR Subsystem	578

14.16.2.1 Programming Examples**Example: Save/Recall a configuration**

This example shows how to query and load settings files, stored with the save/recall function for the ADF standard.

For other avionic standards, replace ADF by ILS or VOR.

```
SOURce1:ADF:PRESet
// Go to the "settings" directory.
MMEM:CDIR "/var/user/settings"
// List all files in the directory with extension *.adf.
SOURce1:ADF:SETTING:CATalog?
// adf_general, adf_comid

// Store the ADF configuration in the file "adf_general_latest.adf".
SOURce1:ADF:SETTING:STORe "/var/user/settings/adf_general_latest"
// Delete the file "adf_general.adf".
```

```

SOURcel:ADF:SETTING:DELeTe "/var/user/settings/adf_general"
SOURcel:ADF:SETTING:CATalog?
// adf_general_latest, adf_comid

// Load the file "adf_general_latest.adf".
SOURcel:ADF:SETTING:LOAD "/var/user/settings/adf_general_latest"

SOURcel:ADF:STATe 1

```

Example: Configure and generate a ADF signal

```

SOURcel:ADF:PRESet

// Configure ADF COM/ID settings.
SOURcel:ADF:COMid:PERiod 9
SOURcel:ADF:COMid:FREQuency 1020
SOURcel:ADF:COMid:DEPTh 11
SOURcel:ADF:COMid:TSCHEMA USER
SOURcel:ADF:COMid:DOT 0.11
SOURcel:ADF:COMid:DASH 0.29
SOURcel:ADF:COMid:SYMBOL 0.11
SOURcel:ADF:COMid:LETTER 0.29
SOURcel:ADF:COMid:STATe 1

SOURcel:ADF:STATe 1

```

Example: Configure and generate an ILS glide slope signal

```

SOURcel:BB:ILS:PRESet

// Configure ILS localizer general settings.
SOURcel:ILS:TYPE GS
SOURcel:ILS:GS:FREQuency:MODE USER
SOURcel:ILS:GS:FREQuency 334700000
SOURcel:ILS:GS:FREQuency:MODE ICAO
SOURcel:ILS:GS:ICAO:CHANnel?
// CH18X
SOURcel:ILS:GS:FREQuency:SYNChronize 1
SOURcel:ILS:LOCALizer:ICAO:CHANnel?
// CH18X
SOURcel:ILS:LOCALizer:FREQuency?
// 108100000
SOURcel:ILS:GSLope:SOURce?
// INT

// Configure ILS glide slope signal settings.
SOURcel:ILS:GS:MODE NORM
SOURcel:ILS:GS:DDM:POLarity P90_150
SOURcel:ILS:GS:ULObE:FREQuency 90
SOURcel:ILS:GS:LLObE:FREQuency 150
SOURcel:ILS:GS:PHASe 0

```

```
// Configure ILS glide slope amplitude settings.
SOURcel:ILS:GS:DDM:DIRection UP
SOURcel:ILS:GS:SDM 80
SOURcel:ILS:GS:DDM:COUPling FIX
SOURcel:ILS:GS:DDM:STEP DEC
SOURcel:ILS:GS:DDM:CURRent 0
SOURcel:ILS:GS:DDM:DEPTh 0
SOURcel:ILS:GS:DDM:LOGarithmic 0
SOURcel:ILS:GS:DDM:PCT 0

SOURcel:ILS:STATe 1
```

Example: Configure and generate an ILS localizer signal

```
SOURcel:ILS:PRESet

// Configure ILS localizer general settings.
SOURcel:ILS:TYPE LOC
SOURcel:ILS:LOCalizer:FREQuency:MODE USER
SOURcel:ILS:LOCalizer:FREQuency 108100000
SOURcel:ILS:LOCalizer:FREQuency:SYNChronize 1
SOURcel:ILS:GS:FREQuency?
// 108100000
SOURcel:ILS:LOCalizer:FREQuency:MODE ICAO
SOURcel:ILS:LOCalizer:ICAO:CHANnel CH26Y
SOURcel:ILS:GS:ICAO:CHANnel?
// CH26Y
SOURcel:ILS:GS:FREQuency?
// 108950000
SOURcel:ILS:LOCalizer:SOURce?
// INT

// Configure ILS localizer signal settings.
SOURcel:ILS:LOCalizer:MODE NORM
SOURcel:ILS:LOCalizer:DDM:POLarity P90_150
SOURcel:ILS:LOCalizer:LLOBe:FREQuency 90
SOURcel:ILS:LOCalizer:RLOBe:FREQuency 150
SOURcel:ILS:LOCalizer:PHASe 0

// Configure ILS localizer amplitude settings.
SOURcel:ILS:LOCalizer:DDM:DIRection LEFT
SOURcel:ILS:LOCalizer:SDM 40
SOURcel:ILS:LOCalizer:DDM:COUPling FIX
SOURcel:ILS:LOCalizer:DDM:STEP DEC
SOURcel:ILS:LOCalizer:DDM:CURRent 0
SOURcel:ILS:LOCalizer:DDM:DEPTh 0
SOURcel:ILS:LOCalizer:DDM:LOGarithmic 0
SOURcel:ILS:LOCalizer:DDM:PCT 0

// Configure ILS localizer COM/ID settings.
SOURcel:ILS:LOCalizer:COMid:CODE "MUC"
SOURcel:ILS:LOCalizer:COMid:PERiod 9
```

```

SOURCE1:ILS:LOCALizer:COMid:FREQuency 1020
SOURCE1:ILS:LOCALizer:COMid:DEPTh 10
SOURCE1:ILS:LOCALizer:COMid:TSCHEMA USER
SOURCE1:ILS:LOCALizer:COMid:DOT 0.11
SOURCE1:ILS:LOCALizer:COMid:DASH 0.29
SOURCE1:ILS:LOCALizer:COMid:SYMBOL 0.11
SOURCE1:ILS:LOCALizer:COMid:LETTER 0.29
SOURCE1:ILS:LOCALizer:COMid:STATE 1

SOURCE1:ILS:STATE 1

```

Example: Configure and generate an ILS marker beacons signal

```

SOURCE1:ILS:PRESet

// Configure ILS marker beacons general settings.
SOURCE1:ILS:TYPE MBE
SOURCE1:ILS:MBEacon:FREQuency:MODE USER
SOURCE1:ILS:MBEacon:FREQuency 75000000
SOURCE1:ILS:MBEacon:MARKer:FREQuency 400
SOURCE1:ILS:MBEacon:MARKer:DEPTh 95
SOURCE1:ILS:MBEacon:MARKer:PULSed?
// 0

// Configure ILS marker beacons COM/ID settings.
SOURCE1:ILS:MBEacon:COMid:CODE "MUC"
SOURCE1:ILS:MBEacon:COMid:PERiod 9
SOURCE1:ILS:MBEacon:COMid:FREQuency 1020
SOURCE1:ILS:MBEacon:COMid:DEPTh 5
SOURCE1:ILS:MBEacon:COMid:TSCHEMA USER
SOURCE1:ILS:MBEacon:COMid:DOT 0.11
SOURCE1:ILS:MBEacon:COMid:DASH 0.29
SOURCE1:ILS:MBEacon:COMid:SYMBOL 0.11
SOURCE1:ILS:MBEacon:COMid:LETTER 0.29
SOURCE1:ILS:MBEacon:COMid:STATE 1

SOURCE1:BB:ILS:STATE 1

```

Example: Configure and generate a VOR signal

```

SOURCE1:VOR:PRESet

// Configure VOR general settings.
SOURCE1:VOR:FREQuency:MODE USER
SOURCE1:VOR:FREQuency 108000000
SOURCE1:VOR:FREQuency:MODE ICAO
SOURCE1:VOR:ICAO:CHANnel?
// CH17X
SOURCE1:VOR:SOURce?
// INT

```



```

// Configure VOR signal settings.
SOURcel:VOR:MODE NORM
SOURcel:VOR:VAR:FREQuency 30
SOURcel:VOR:VAR:DEPTh 30
SOURcel:VOR:SUBCarrier:FREQuency 9960
SOURcel:VOR:SUBCarrier:DEPTh 30
SOURcel:VOR:REFerence:DEVIation 480

// Configure VOR position settings.
SOURcel:VOR:BANGLe 1
SOURcel:VOR:BANGLe:DIRection FROM

// Configure VOR COM/ID settings.
SOURcel:VOR:COMid:PERiod 9
SOURcel:VOR:COMid:FREQuency 1020
SOURcel:VOR:COMid:DEPTh 11
SOURcel:VOR:COMid:TSCHEMA USER
SOURcel:VOR:COMid:DOT 0.11
SOURcel:VOR:COMid:DASH 0.29
SOURcel:VOR:COMid:SYMBOL 0.11
SOURcel:VOR:COMid:LETTer 0.29
SOURcel:VOR:COMid:STATe 1

SOURcel:VOR:STATe 1

```

14.16.2.2 General Commands

<subsystem>:PRESet.....	550
[:SOURce<hw>]:ADF:PRESet.....	550
[:SOURce<hw>]:ILS:PRESet.....	550
[:SOURce<hw>]:VOR:PRESet.....	550
<subsystem>:SETTing:CATalog.....	550
[:SOURce<hw>]:ADF:SETTing:CATalog.....	550
[:SOURce<hw>]:ILS:SETTing:CATalog?.....	550
[:SOURce<hw>]:VOR:SETTing:CATalog?.....	550
<subsystem>:SETTing:DELeTe.....	550
[:SOURce<hw>]:ADF:SETTing:DELeTe.....	550
[:SOURce<hw>]:ILS:SETTing:DELeTe.....	550
[:SOURce<hw>]:VOR:SETTing:DELeTe.....	550
<subsystem>:SETTing:LOAD.....	550
[:SOURce<hw>]:ADF:SETTing:LOAD.....	550
[:SOURce<hw>]:ILS:SETTing:LOAD.....	551
[:SOURce<hw>]:VOR:SETTing:LOAD.....	551
<subsystem>:SETTing:STORe.....	551
[:SOURce<hw>]:ADF:SETTing:STORe.....	551
[:SOURce<hw>]:ILS:SETTing:STORe.....	551
[:SOURce<hw>]:VOR:SETTing:STORe.....	551
<subsystem>:STATe.....	551
[:SOURce<hw>]:ADF:STATe.....	551
[:SOURce<hw>]:ILS:STATe.....	551

<code>[:SOURce<hw>]:VOR:STATe</code>	551
<code><subsystem>:FREQuency:SYNChronize:STATe</code>	551
<code>[:SOURce<hw>]:ILS[:GS GSLope]:FREQuency:SYNChronize[:STATe]</code>	551
<code>[:SOURce<hw>]:ILS:LOCalizer:FREQuency:SYNChronize[:STATe]</code>	551

<subsystem>:PRESet
[:SOURce<hw>]:ADF:PRESet
[:SOURce<hw>]:ILS:PRESet
[:SOURce<hw>]:VOR:PRESet

Sets the parameters of the digital standard to their default values (*RST values specified for the commands).

Not affected is the state set with the command `SOURce<hw>:VOR:STATe`.

Example: See [Example "Save/Recall a configuration"](#) on page 545.

<subsystem>:SETTing:CATalog
[:SOURce<hw>]:ADF:SETTing:CATalog
[:SOURce<hw>]:ILS:SETTing:CATalog?
[:SOURce<hw>]:VOR:SETTing:CATalog?

Queries the files with settings in the default directory. Listed are files with the file extension `*.adf/*.ils/*.vor`.

Return values:

`<FileNames>` `<filename1>,<filename2>,...`

Returns a string of filenames separated by commas.

Example: See [Example "Save/Recall a configuration"](#) on page 545.

Usage: Query only

<subsystem>:SETTing:DELeTe
[:SOURce<hw>]:ADF:SETTing:DELeTe <Filename>
[:SOURce<hw>]:ILS:SETTing:DELeTe <Filename>
[:SOURce<hw>]:VOR:SETTing:DELeTe <Filename>

Deletes the selected file from the default or the specified directory. Deleted are files with extension `*.adf/*.ils/*.vor`.

Setting parameters:

`<Filename>` "`<filename>`"

Filename or complete file path; file extension can be omitted

Example: See [Example "Save/Recall a configuration"](#) on page 545.

Usage: Setting only

<subsystem>:SETTing:LOAD
[:SOURce<hw>]:ADF:SETTing:LOAD <Filename>

**[[:SOURce<hw>]:ILS:SETTING:LOAD <Filename>
[:SOURce<hw>]:VOR:SETTING:LOAD <Filename>**

Loads the selected file from the default or the specified directory. Loaded are files with extension *.adf/*.ils/*.vor.

Parameters:

<Filename> "<filename>"
Filename or complete file path; file extension can be omitted

Example: See [Example "Save/Recall a configuration"](#) on page 545.

Usage: Setting only

**<subsystem>:SETTING:STORe
[:SOURce<hw>]:ADF:SETTING:STORe <Filename>
[:SOURce<hw>]:ILS:SETTING:STORe <Filename>
[:SOURce<hw>]:VOR:SETTING:STORe <Filename>**

Saves the current settings into the selected file; the file extension (*.adf/*.ils/*.vor) is assigned automatically.

Parameters:

<Filename> "<filename>"
Filename or complete file path

Example: See [Example "Save/Recall a configuration"](#) on page 545.

Usage: Setting only

**<subsystem>:STATe
[:SOURce<hw>]:ADF:STATe <State>
[:SOURce<hw>]:ILS:STATe <State>
[:SOURce<hw>]:VOR:STATe <State>**

Activates/deactivates the VOR modulation.

Parameters:

<State> 0 | 1 | OFF | ON
*RST: 0

Example: See [Example "Save/Recall a configuration"](#) on page 545.

**<subsystem>:FREQuency:SYNChronize:STATe
[:SOURce<hw>]:ILS[:GS[GSLope]:FREQuency:SYNChronize[:STATe] <Mode>
[:SOURce<hw>]:ILS:LOCalizer:FREQuency:SYNChronize[:STATe] <Mode>**

Activates synchronization of the ILS localizer ICAO channel with the ILS glide slope ICAO channel.

The ILS glide slope/localizer frequency of the ICAO channel ([Table 6-2](#)) is set automatically.

Parameters:

<Mode> 0 | 1 | OFF | ON
 *RST: 0

Example:

See [Example "Configure and generate an ILS localizer signal"](#) on page 547.

14.16.2.3 SOURce:ADF Subsystem

Option: R&S SMAB-K25

The SOURce:ADF subsystem contains all commands for configuring the ADF signal.

Characteristics which are valid for all modulations and the LF output are configured in the SOURce:LFOutput subsystem. The signal is output at the LF connector.

Commands

[:SOURce<hw>]:ADF:COMid:CODE	552
[:SOURce<hw>]:ADF:COMid:DASH	552
[:SOURce<hw>]:ADF:COMid:DEPT	553
[:SOURce<hw>]:ADF:COMid:DOT	553
[:SOURce<hw>]:ADF:COMid:FREQuency	553
[:SOURce<hw>]:ADF:COMid:LETTer	554
[:SOURce<hw>]:ADF:COMid:PERiod	554
[:SOURce<hw>]:ADF:COMid:SYMBol	554
[:SOURce<hw>]:ADF:COMid:TSCHEMA	555
[:SOURce<hw>]:ADF:COMid[:STATe]	555

[\[:SOURce<hw>\]:ADF:COMid:CODE](#) <Code>

Sets the coding of the COM/ID signal by the international short name of the airport (e.g. MUC for the Munich airport).

The COM/ID tone is sent according to the selected code, see [Chapter D, "Morse Code Settings"](#), on page 745.

If no coding is set, the COM/ID tone is sent uncoded (key down).

Parameters:

<Code> string

Example:

See [Example "Configure and generate a ADF signal"](#) on page 546.

Manual operation: See ["Code"](#) on page 154

[\[:SOURce<hw>\]:ADF:COMid:DASH](#) <Dash>

Sets the length of a Morse code dash.

Parameters:

<Dash> float
 Range: 50E-3 to 1
 Increment: 1E-4
 *RST: 300E-3

Example: See [Example "Configure and generate a ADF signal"](#) on page 546.

Manual operation: See "[Dash Length](#)" on page 155

[:SOURce<hw>]:ADF:COMid:DEPTh <Depth>

Sets the AM modulation depth of the COM/ID signal.

Parameters:

<Depth> float
 Range: 0 to 100
 Increment: 0.1
 *RST: 95

Example: See [Example "Configure and generate a ADF signal"](#) on page 546.

Manual operation: See "[Depth](#)" on page 155

[:SOURce<hw>]:ADF:COMid:DOT <Dot>

Sets the length of a Morse code dot.

Parameters:

<Dot> float
 Range: 50E-3 to 1
 Increment: 1E-4
 *RST: 100E-3

Example: See [Example "Configure and generate a ADF signal"](#) on page 546.

Manual operation: See "[Dot Length](#)" on page 155

[:SOURce<hw>]:ADF:COMid:FREQuency <Frequency>

Sets the frequency of the COM/ID signal.

Parameters:

<Frequency> float
 Range: 0.1 to 20E3
 Increment: 0.01
 *RST: 1020

Example: See [Example "Configure and generate a ADF signal"](#) on page 546.

Manual operation: See ["Frequency"](#) on page 155

[:SOURce<hw>]:ADF:COMid:LETTer <Letter>

Sets the length of a Morse code letter space.

Parameters:

<Letter>	float
	Range: 50E-3 to 1
	Increment: 1E-4
	*RST: 300E-3

Example: See [Example "Configure and generate a ADF signal"](#) on page 546.

Manual operation: See [" Letter Space "](#) on page 156

[:SOURce<hw>]:ADF:COMid:PERiod <Period>

Sets the period of the COM/ID signal.

Parameters:

<Period>	float
	Range: 0 to 120
	Increment: 1E-3
	*RST: 9

Example: See [Example "Configure and generate a ADF signal"](#) on page 546.

Manual operation: See ["Period"](#) on page 155

[:SOURce<hw>]:ADF:COMid:SYMBol <Symbol>

Sets the length of the Morse code symbol space.

Parameters:

<Symbol>	float
	Range: 50E-3 to 1
	Increment: 1E-4
	*RST: 100E-3

Example: See [Example "Configure and generate a ADF signal"](#) on page 546.

Manual operation: See [" Symbol Space "](#) on page 155

[:SOURce<hw>]:ADF:COMid:TSCHEMA <TSCHEMA>

Sets the time schema of the Morse code for the COM/ID signal.

Parameters:

<TSCHEMA> STD | USER
*RST: STD

Example: See [Example "Configure and generate a ADF signal"](#) on page 546.

Manual operation: See ["Time Schema"](#) on page 155

[:SOURce<hw>]:ADF:COMid[:STATE] <State>

Enables/disables the COM/ID signal.

Parameters:

<State> 0 | 1 | OFF | ON
*RST: 0

Example: See [Example "Configure and generate a ADF signal"](#) on page 546.

Manual operation: See ["COM/ID State"](#) on page 154

14.16.2.4 SOURce:ILS Subsystem

Option: R&S SMAB-K25

The SOURce:BB:ILS subsystem contains all commands for configuring the ILS signal.

Characteristics which are valid for all modulations and the LF output are configured in the SOURce:LFOutput subsystem. The signal is output at the LF connector.

Commands

[:SOURce<hw>]:ILS:TYPE.....	557
[:SOURce<hw>]:ILS[:GS GSLope]:DDM:COUPling.....	557
[:SOURce<hw>]:ILS[:GS GSLope]:DDM:CURRent.....	557
[:SOURce<hw>]:ILS[:GS GSLope]:DDM:DIRection.....	558
[:SOURce<hw>]:ILS[:GS GSLope]:DDM:LOGarithmic.....	558
[:SOURce<hw>]:ILS[:GS GSLope]:DDM:PCT.....	558
[:SOURce<hw>]:ILS[:GS GSLope]:DDM:POLarity.....	559
[:SOURce<hw>]:ILS[:GS GSLope]:DDM:STEP.....	559
[:SOURce<hw>]:ILS[:GS GSLope]:DDM[:DEPTH].....	559
[:SOURce<hw>]:ILS[:GS GSLope]:FREQUency.....	560
[:SOURce<hw>]:ILS[:GS GSLope]:FREQUency:MODE.....	560
[:SOURce<hw>]:ILS[:GS GSLope]:FREQUency:SYNChronize[:STATE].....	560
[:SOURce<hw>]:ILS[:GS GSLope]:ICAO:CHANnel.....	561
[:SOURce<hw>]:ILS[:GS GSLope]:LLOBe[:FREQUency].....	561
[:SOURce<hw>]:ILS[:GS GSLope]:MODE.....	561
[:SOURce<hw>]:ILS[:GS GSLope]:PHASe.....	562

[SOURce<hw>]:ILS:GS GSLope:PRESet.....	562
[SOURce<hw>]:ILS[:GS GSLope]:SDM.....	562
[SOURce<hw>]:ILS[:GS GSLope]:SOURce.....	563
[SOURce<hw>]:ILS[:GS GSLope]:ULOBef[:FREQUENCY].....	563
[SOURce<hw>]:ILS:LOCALizer:COMid:CODE.....	563
[SOURce<hw>]:ILS:LOCALizer:COMid:DASH.....	564
[SOURce<hw>]:ILS:LOCALizer:COMid:DEPTh.....	564
[SOURce<hw>]:ILS:LOCALizer:COMid:DOT.....	564
[SOURce<hw>]:ILS:LOCALizer:COMid:FREQUENCY.....	565
[SOURce<hw>]:ILS:LOCALizer:COMid:LETTer.....	565
[SOURce<hw>]:ILS:LOCALizer:COMid:PERiod.....	565
[SOURce<hw>]:ILS:LOCALizer:COMid:SYMBol.....	565
[SOURce<hw>]:ILS:LOCALizer:COMid:TSCHEMA.....	566
[SOURce<hw>]:ILS:LOCALizer:COMid[:STATE].....	566
[SOURce<hw>]:ILS:LOCALizer:DDM:COUPLing.....	566
[SOURce<hw>]:ILS:LOCALizer:DDM:CURRent.....	567
[SOURce<hw>]:ILS:LOCALizer:DDM:DIRection.....	567
[SOURce<hw>]:ILS:LOCALizer:DDM:LOGarithmic.....	568
[SOURce<hw>]:ILS:LOCALizer:DDM:PCT.....	568
[SOURce<hw>]:ILS:LOCALizer:DDM:POLarity.....	568
[SOURce<hw>]:ILS:LOCALizer:DDM:STEP.....	569
[SOURce<hw>]:ILS:LOCALizer:DDM[:DEPTh].....	569
[SOURce<hw>]:ILS:LOCALizer:FREQUENCY.....	569
[SOURce<hw>]:ILS:LOCALizer:FREQUENCY:MODE.....	570
[SOURce<hw>]:ILS:LOCALizer:FREQUENCY:SYNChronize[:STATE].....	570
[SOURce<hw>]:ILS:LOCALizer:ICAO:CHANnel.....	570
[SOURce<hw>]:ILS:LOCALizer:LLOBef[:FREQUENCY].....	571
[SOURce<hw>]:ILS:LOCALizer:MODE.....	571
[SOURce<hw>]:ILS:LOCALizer:PHASe.....	571
[SOURce<hw>]:ILS:LOCALizer:PRESet.....	572
[SOURce<hw>]:ILS:LOCALizer:RLOBef[:FREQUENCY].....	572
[SOURce<hw>]:ILS:LOCALizer:SDM.....	572
[SOURce<hw>]:ILS:LOCALizer:SOURce.....	573
[SOURce<hw>][:ILS]:MBEacon:COMid:CODE.....	573
[SOURce<hw>][:ILS]:MBEacon:COMid:DASH.....	573
[SOURce<hw>][:ILS]:MBEacon:COMid:DEPTh.....	574
[SOURce<hw>][:ILS]:MBEacon:COMid:DOT.....	574
[SOURce<hw>][:ILS]:MBEacon:COMid:FREQUENCY.....	574
[SOURce<hw>][:ILS]:MBEacon:COMid:LETTer.....	575
[SOURce<hw>][:ILS]:MBEacon:COMid:PERiod.....	575
[SOURce<hw>][:ILS]:MBEacon:COMid:SYMBol.....	575
[SOURce<hw>][:ILS]:MBEacon:COMid:TSCHEMA.....	576
[SOURce<hw>][:ILS]:MBEacon:COMid[:STATE].....	576
[SOURce<hw>][:ILS]:MBEacon:FREQUENCY.....	576
[SOURce<hw>][:ILS]:MBEacon:FREQUENCY:MODE.....	576
[SOURce<hw>][:ILS]:MBEacon:MARKer:FREQUENCY.....	577
[SOURce<hw>][:ILS]:MBEacon[:MARKer]:DEPTh.....	577
[SOURce<hw>][:ILS]:MBEacon:PRESet.....	577
[SOURce<hw>][:ILS]:MBEacon[:MARKer]:PULSed.....	577

[:SOURce<hw>]:ILS:TYPE <Type>

Selects the ILS modulation type.

Parameters:

<Type> GS | LOCALize | GSLOpe | MBEacon
*RST: GS

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 546.

Manual operation: See ["ILS Component"](#) on page 129

[:SOURce<hw>]:ILS[:GS|GSLOpe]:DDM:COUPling <Coupling>

Selects if the DDM value is fixed or is changed with a change of sum of modulation depths (SDM, see [\[:SOURce<hw>\]:ILS\[:GS|GSLOpe\]:SDM](#) on page 562).

Parameters:

<Coupling> FIXed | SDM
*RST: FIXed

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 546.

Manual operation: See ["DDM - SDM Coupling"](#) on page 137

[:SOURce<hw>]:ILS[:GS|GSLOpe]:DDM:CURREnt <Current>

Sets the DDM value alternatively as a current by means of the ILS indicating instrument. The instrument current is calculated according to:

$$\text{DDM Current } \mu\text{A} = \text{DDM Depth } [\%] \times 857,125 \mu\text{A}$$

A variation of the instrument current automatically leads to a variation of the DDM value and the DDM value in dB.

Parameters:

<Current> float
Range: -8.57125E-4 to 8.57125E-4
Increment: 1E-7
*RST: 0

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 546.

Manual operation: See ["DDM Current"](#) on page 136

[:SOURce<hw>]:ILS[:GS|GSLope]:DDM:DIRection <Direction>

Sets the simulation mode for the ILS glide slope modulation signal. A change of the setting automatically changes the sign of the DDM value.

Parameters:

<Direction> UP | DOWN

UP

The 150-Hz modulation signal is predominant, the DDM value is negative (the airplane is too low, it must climb).

DOWN

The 90-Hz modulation signal is predominant, the DDM value is positive (the airplane is too high, it must descend).

*RST: UP

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 546.

Manual operation: See ["FlyMode"](#) on page 135

[:SOURce<hw>]:ILS[:GS|GSLope]:DDM:LOGarithmic <Logarithmic>

Sets the depth of modulation value for ILS glide slope modulation in dB.

See also [\[:SOURce<hw> \] : ILS \[:GS | GSLope \] : DDM \[:DEPTh \]](#) on page 559.

Parameters:

<Logarithmic> float
 Range: -999.9 to 999.9
 Increment: 1E-4
 *RST: 0

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 546.

Manual operation: See ["DDM Logarithmic"](#) on page 136

[:SOURce<hw>]:ILS[:GS|GSLope]:DDM:PCT <Pct>

Sets the difference in depth of modulation between the signal of the upper lobe (90 Hz) and the lower lobe (150 Hz). The maximum value equals the sum of the modulation depths of the 90 Hz and the 150 Hz tone.

See also [\[:SOURce<hw> \] : ILS \[:GS | GSLope \] : DDM \[:DEPTh \]](#) on page 559.

Parameters:

<Pct> float
 Range: -80.0 to 80.0
 Increment: 0.01
 *RST: 0

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 546.

Manual operation: See "DDM Percent" on page 136

[:SOURce<hw>] : ILS [:GS | GSLOpe] : DDM : POLarity <Polarity>

Sets the polarity for DDM calculation (see [:SOURce<hw>] : ILS [:GS | GSLOpe] : DDM [: DEPT h] on page 559).

The DDM depth calculation depends on the selected polarity:

- Polarity 90 Hz - 150 Hz (default setting):
DDM = [AM(90 Hz) - AM (150 Hz)] / 100%
- Polarity 150 Hz - 90 Hz:
DDM = [AM(150 Hz) - AM (90 Hz)] / 100%

Parameters:

<Polarity> P90_150 | P150_90
*RST: P90_150

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 546.

Manual operation: See "DDM Polarity" on page 134

[:SOURce<hw>] : ILS [:GS | GSLOpe] : DDM : STEP <DdmStep>

Sets the variation of the difference in depth of modulation via the rotary knob.

Parameters:

<DdmStep> DECimal | PREDeFined
*RST: DECimal

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 546.

Manual operation: See "DDM Step" on page 136

[:SOURce<hw>] : ILS [:GS | GSLOpe] : DDM [: DEPT h] <Depth>

Sets the difference in depth of modulation between the signal of the upper/left lobe (90 Hz) and the lower/right lobe (150 Hz). The maximum value equals the sum of the modulation depths of the 90 Hz and the 150 Hz tone. The following is true:

$$\text{ILS : GS | GSL : DDM : DEPT h} = (\text{AM}(90\text{Hz}) - \text{AM}(150\text{Hz})) / 100\%$$

A variation of the DDM value automatically leads to a variation of the DDM value in dB and the value of the instrument current.

Parameters:

<Depth> float
Range: -0.8 to 0.8
Increment: 1E-4
*RST: 0

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 546.

Manual operation: See ["DDM Depth"](#) on page 136

[[:SOURce<hw>]:ILS[:GS[GSLope]:FREQuency <CarrierFreq>

Sets the carrier frequency of the signal.

Parameters:

<CarrierFreq> float
 Range: 100E3 to 6E9
 Increment: 0.01
 *RST: 334.7E6

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 546.

Manual operation: See ["Carrier Frequency"](#) on page 131

[[:SOURce<hw>]:ILS[:GS[GSLope]:FREQuency:MODE <Mode>

Sets the mode for the carrier frequency of the signal.

Parameters:

<Mode> USER | ICAO
DECimal
 Activates user-defined variation of the carrier frequency.
ICAO
 Activates variation in predefined steps according to standard ILS transmitting frequencies (see [Table 6-2](#)).
 *RST: DECimal

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 546.

Manual operation: See ["Carrier Frequency Mode"](#) on page 131

[[:SOURce<hw>]:ILS[:GS[GSLope]:FREQuency:SYNChronize[:STATe] <Mode>

Activates synchronization of the ILS glide slope ICAO channel with the ILS localizer ICAO channel.

The ILS glide slope/localizer frequency of the ICAO channel ([Table 6-2](#)) is set automatically.

Parameters:

<Mode> 0 | 1 | OFF | ON
 *RST: 0

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 546.

[:SOURce<hw>] : ILS : GS [GSLope] : ICAO : CHANnel <Channel>

Sets the ICAO channel and the corresponding transmitting frequency.

If avionic standard modulation is activated and you change the "RF Frequency", the frequency value of the closest ICAO channel is applied automatically. The "ICAO Channel" is also updated.

The ICAO channel settings for ILS glide slope/localizer components are coupled. For an overview of the ILS ICAO channel frequencies, see [Table 6-2](#).

Parameters:

<Channel> CH18X | CH18Y | CH20X | CH20Y | CH22X | CH22Y | CH24X | CH24Y | CH26X | CH26Y | CH28X | CH28Y | CH30X | CH30Y | CH32X | CH32Y | CH34X | CH34Y | CH36X | CH36Y | CH38X | CH38Y | CH40X | CH40Y | CH42X | CH42Y | CH44X | CH44Y | CH46X | CH46Y | CH48X | CH48Y | CH50X | CH50Y | CH52X | CH52Y | CH54X | CH54Y | CH56X | CH56Y

*RST: CH18X

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 546.

Manual operation: See ["ICAO Channel"](#) on page 132

[:SOURce<hw>] : ILS : GS [GSLope] : LLOBe : FREQuency <Frequency>

Sets the modulation frequency of the antenna lobe arranged at the bottom viewed from the air plane for the ILS glide slope modulation signal.

Parameters:

<Frequency> float

Range: 100 to 200

Increment: 0.05

*RST: 150

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 546.

Manual operation: See ["Down Frequency"](#) on page 134

[:SOURce<hw>] : ILS : GS [GSLope] : MODE <Mode>

Sets the operating mode for the ILS glide slope modulation signal.

Parameters:

<Mode> NORM | ULOBe | LLOBe

NORM
ILS glide slope modulation is active.

ULOBe
Amplitude modulation of the output signal with the upper lobe (90Hz) signal component of the ILS glide slope signal is active.

LLOBe

Amplitude modulation of the output signal with the lower lobe (150Hz) signal component of the ILS glide slope signal is active.

*RST: NORM

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 546.

Manual operation: See ["Operating Mode"](#) on page 133

[:SOURce<hw>] : ILS : GS [GSLOpe] : PHASe <Phase>

Sets the phase between the modulation signals of the upper and lower antenna lobe of the ILS glide slope signal.

Zero crossing of the lower lobe (150Hz) signal serves as a reference. The angle refers to the period of the signal of the right antenna lobe.

Parameters:

<Phase> float
 Range: -60 to 120
 Increment: 0.01
 *RST: 0.0

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 546.

Manual operation: See ["Up/Down Phase"](#) on page 134

[:SOURce<hw>] : ILS : GS [GSLOpe] : PRESet

Sets the parameters of the ILS glide slope component to their default values (*RST values specified for the commands).

For other ILS preset commands, see [\[:SOURce<hw> \] : ILS : PRESet](#) on page 550.

Example: SOURce1 : ILS : GS : PRESet

Usage: Event

[:SOURce<hw>] : ILS : GS [GSLOpe] : SDM <Sdm>

Sets the arithmetic sum of the modulation depths of the upper lobe (90 Hz) and lower lobe (150 Hz) for the ILS glide slope signal contents.

The RMS modulation depth of the sum signal depends on the phase setting of both modulation tones.

Parameters:

<Sdm> float
 Range: 0 to 100
 Increment: 0.1
 *RST: 80

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 546.

Manual operation: See ["Sum of Depth"](#) on page 135

[:SOURce<hw>]:ILS[:GS|GSLope]:SOURce <IlsGsSource>

Sets the modulation source for the avionic standard modulation.

If external modulation source is set, the external signal is added to the internal signal. Switching off the internal modulation source is not possible.

Parameters:

<IlsGsSource> INT | INT,EXT | EXT

INT

Internal modulation source is used.

EXT|INT,EXT

An external modulation source is used, additional to the internal modulation source.

The external signal is input at the Ext connector.

*RST: INT

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 546.

Manual operation: See ["EXT AM"](#) on page 132

[:SOURce<hw>]:ILS[:GS|GSLope]:ULOBe[:FREQUENCY] <Frequency>

Parameters:

<Frequency> float
 Range: 60 to 120
 Increment: 0.03
 *RST: 90

Example: See [Example "Configure and generate an ILS glide slope signal"](#) on page 546.

Manual operation: See ["Up Frequency"](#) on page 134

[:SOURce<hw>]:ILS:LOCalizer:COMid:CODE <Code>

Sets the coding of the COM/ID signal by the international short name of the airport (e.g. MUC for the Munich airport).

The COM/ID tone is sent according to the selected code, see [Chapter D, "Morse Code Settings"](#), on page 745.

If no coding is set, the COM/ID tone is sent uncoded (key down).

Parameters:

<Code> string

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 547.

Manual operation: See ["Code"](#) on page 145

[:SOURce<hw>]:ILS:LOCAlizer:COMid:DASH <Dash>

Sets the length of a Morse code dash.

Parameters:

<Dash>	float
	Range: 0.05 to 1
	Increment: 1E-4
	*RST: 0.3

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 547.

Manual operation: See [" Dash Length "](#) on page 146

[:SOURce<hw>]:ILS:LOCAlizer:COMid:DEPTH <Depth>

Sets the AM modulation depth of the COM/ID signal.

Parameters:

<Depth>	float
	Range: 0 to 100
	Increment: 0.1
	*RST: 10

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 547.

Manual operation: See ["Depth"](#) on page 145

[:SOURce<hw>]:ILS:LOCAlizer:COMid:DOT <Dot>

Sets the length of a Morse code dot.

Parameters:

<Dot>	float
	Range: 0.05 to 1
	Increment: 1E-4
	*RST: 0.1

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 547.

Manual operation: See ["Dot Length"](#) on page 146

[[:SOURce<hw>]:ILS:LOCAlizer:COMid:FREQuency <Frequency>

Sets the frequency of the COM/ID signal.

Parameters:

<Frequency> float
 Range: 0.1 to 20E3
 Increment: 0.01
 *RST: 1020

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 547.

Manual operation: See ["Frequency"](#) on page 145

[[:SOURce<hw>]:ILS:LOCAlizer:COMid:LETTer <Letter>

Sets the length of a Morse code letter space.

Parameters:

<Letter> float
 Range: 0.05 to 1
 Increment: 1E-4
 *RST: 0.3

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 547.

Manual operation: See [" Letter Space "](#) on page 146

[[:SOURce<hw>]:ILS:LOCAlizer:COMid:PERiod <Period>

Sets the period of the COM/ID signal.

Parameters:

<Period> float
 Range: 0 to 120
 Increment: 1E-3
 *RST: 9

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 547.

Manual operation: See ["Period"](#) on page 145

[[:SOURce<hw>]:ILS:LOCAlizer:COMid:SYMBol <Symbol>

Sets the length of the Morse code symbol space.

Parameters:

<Symbol> float
 Range: 0.05 to 1
 Increment: 1E-4
 *RST: 0.1

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 547.

Manual operation: See "[Symbol Space](#)" on page 146

[:SOURce<hw>]:ILS:LOCalizer:COMid:TSCHEMA <TSchema>

Sets the time schema of the Morse code for the COM/ID signal.

Parameters:

<TSchema> STD | USER
STD
 Activates the standard time schema of the Morse code.
 The set [dot length](#) determines the [dash length](#), which is 3 times the dot length.
USER
 Activates the user-defined time schema of the Morse code.
 Dot and dash length, as well as [symbol](#) and [letter space](#) can be set separately.
 *RST: STD

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 547.

Manual operation: See "[Time Schema](#)" on page 146

[:SOURce<hw>]:ILS:LOCalizer:COMid[:STATe] <State>

Enables/disables the COM/ID signal.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 0

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 547.

Manual operation: See "[COM/ID State](#)" on page 145

[:SOURce<hw>]:ILS:LOCalizer:DDM:COUPling <Coupling>

Selects if the DDM value is fixed or is changed with a change of sum of modulation depths (SDM, see [\[:SOURce<hw>\]:ILS:LOCalizer:SDM](#) on page 572).

Parameters:

<Coupling> FIXed | SDM
 *RST: FIXed

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 547.

Manual operation: See ["DDM - SDM Coupling"](#) on page 143

[:SOURce<hw>]:ILS:LOCalizer:DDM:CURRent <Current>

Sets the DDM value alternatively as a current by means of the ILS indicating instrument. The instrument current is calculated according to:

$$\text{DDM } \mu\text{A} = \text{DDM} \times 857,1 \mu\text{A}$$

A variation of the instrument current automatically leads to a variation of the DDM value and the DDM value in dB.

Parameters:

<Current> float
 Range: -9.6775E-4 to 9.6775E-4
 Increment: 1E-7
 *RST: 0

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 547.

Manual operation: See ["DDM Current"](#) on page 143

[:SOURce<hw>]:ILS:LOCalizer:DDM:DIRection <Direction>

Sets the simulation mode for the ILS-LOC modulation signal. A change of the setting automatically changes the sign of the DDM value.

Parameters:

<Direction> LEFT | RIGHT

LEFT

The 150 Hz modulation signal is predominant, the DDM value is negative (the airplane is too far to the right, it must turn to the left).

RIGHT

The 90 Hz modulation signal is predominant, the DDM value is positive (the airplane is too far to the left, it must turn to the right).

*RST: LEFT

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 547.

Manual operation: See ["FlyMode"](#) on page 142

[:SOURce<hw>] : ILS : LOCALizer : DDM : LOGarithmic <Logarithmic>

Sets the modulation depth in dB for ILS localizer modulation.

See also [\[:SOURce<hw> \] : ILS : LOCALizer : DDM \[:DEPTh \]](#) on page 569.

Parameters:

<Logarithmic> float
 Range: -999.9 to 999.9
 Increment: 1E-4
 *RST: 0

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 547.

Manual operation: See ["DDM Logarithmic"](#) on page 144

[:SOURce<hw>] : ILS : LOCALizer : DDM : PCT <Pct>

Sets the difference in depth of modulation between the signal of the left lobe (90 Hz) and the right lobe (150 Hz). The maximum value equals the sum of the modulation depths of the 90 Hz and the 150 Hz tone.

See also [\[:SOURce<hw> \] : ILS : LOCALizer : DDM \[:DEPTh \]](#) on page 569.

Parameters:

<Pct> float
 Range: -80.0 to 80.0
 Increment: 0.01
 *RST: 0

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 547.

Manual operation: See ["DDM Percent"](#) on page 144

[:SOURce<hw>] : ILS : LOCALizer : DDM : POLarity <Polarity>

Sets the polarity for DDM calculation (see [\[:SOURce<hw> \] : ILS : LOCALizer : DDM \[:DEPTh \]](#)).

The DDM depth calculation depends on the selected polarity:

- Polarity 90 Hz - 150 Hz (default setting):
 $DDM = [AM(90\text{ Hz}) - AM(150\text{ Hz})] / 100\%$
- Polarity 150 Hz - 90 Hz:
 $DDM = [AM(150\text{ Hz}) - AM(90\text{ Hz})] / 100\%$

Parameters:

<Polarity> P90_150 | P150_90
 *RST: P90_150

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 547.

Manual operation: See ["DDM polarity"](#) on page 141

[[:SOURce<hw>]:ILS:LOCALizer:DDM:STEP <DdmStep>

Sets the variation step of the DDM values.

Parameters:

<DdmStep> DECimal | PREDefined
 *RST: DECimal

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 547.

Manual operation: See ["DDM Step"](#) on page 143

[[:SOURce<hw>]:ILS:LOCALizer:DDM[:DEPTH] <Depth>

Sets the difference in depth of modulation between the signal of the upper/left lobe (90 Hz) and the lower/right lobe (150 Hz). The maximum value equals the sum of the modulation depths of the 90 Hz and the 150 Hz tone. The following is true:

$$\text{ILS:LOC:DDM:DEPTH} = (\text{AM}(90\text{Hz}) - \text{AM}(150\text{Hz})) / 100\%$$

A variation of the DDM value automatically leads to a variation of the DDM value in dB and the value of the instrument current.

Parameters:

<Depth> float
 Range: -0.4 to 0.4
 Increment: 1E-4
 *RST: 0

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 547.

Manual operation: See ["DDM Depth"](#) on page 143

[[:SOURce<hw>]:ILS:LOCALizer:FREQUENCY <CarrierFreq>

Sets the carrier frequency of the signal.

Parameters:

<CarrierFreq> float
 Range: 100E3 to 6E9
 Increment: 0.01
 *RST: 108.1E6

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 547.

Manual operation: See ["Carrier Frequency"](#) on page 138

[:SOURce<hw>]:ILS:LOCALizer:FREQUENCY:MODE <IlsLocFreqMode>

Sets the mode for the carrier frequency of the signal.

Parameters:

<Mode> DECimal | ICAO

DECimal

Activates user-defined variation of the carrier frequency.

ICAO

Activates variation in predefined steps according to standard ILS transmitting frequencies (see [Table 6-2](#)).

*RST: DECimal

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 547.

Manual operation: See ["Carrier Frequency Mode"](#) on page 138

[:SOURce<hw>]:ILS:LOCALizer:FREQUENCY:SYNChronize[:STATe] <Mode>

Activates synchronization of the ILS localizer ICAO channel with the ILS glide slope ICAO channel.

The ILS glide slope/localizer frequency of the ICAO channel ([Table 6-2](#)) is set automatically.

Parameters:

<Mode> 0 | 1 | OFF | ON

*RST: 0

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 547.

[:SOURce<hw>]:ILS:LOCALizer:ICAO:CHANnel <SellcaoChan>

Sets the ICAO channel and the corresponding transmitting frequency.

If avionic standard modulation is activated and you change the "RF Frequency", the frequency value of the closest ICAO channel is applied automatically. The "ICAO Channel" is also updated.

The ICAO channel settings for ILS glide slope/localizer components are coupled. For an overview of the ILS ICAO channel frequencies, see [Table 6-2](#).

Parameters:

<SellcaoChan> CH18X | CH18Y | CH20X | CH20Y | CH22X | CH22Y | CH24X | CH24Y | CH26X | CH26Y | CH28X | CH28Y | CH30X | CH30Y | CH32X | CH32Y | CH34X | CH34Y | CH36X | CH36Y | CH38X | CH38Y | CH40X | CH40Y | CH42X | CH42Y | CH44X | CH44Y | CH46X | CH46Y | CH48X | CH48Y | CH50X | CH50Y | CH52X | CH52Y | CH54X | CH54Y | CH56X | CH56Y

*RST: CH18X

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 547.

Manual operation: See ["ICAO Channel"](#) on page 139

[[:SOURce<hw>]:ILS:LOCalizer:LLOBe[:FREQUENCY] <Frequency>

Sets the modulation frequency of the antenna lobe arranged at the bottom viewed from the air plane for the ILS localizer modulation signal.

Parameters:

<Frequency> float
 Range: 60 to 120
 Increment: 0.03
 *RST: 90

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 547.

Manual operation: See ["Left Frequency"](#) on page 141

[[:SOURce<hw>]:ILS:LOCalizer:MODE <Mode>

Sets the operating mode for the ILS localizer modulation signal.

Parameters:

<Mode> NORM | LLOBe | RLOBe
NORM
 ILS localizer modulation is active.
LLOBe
 Amplitude modulation of the output signal with the left lobe (90Hz) signal component of the ILS localizer signal is active.
RLOBe
 Amplitude modulation of the output signal with the right lobe (150Hz) signal component of the ILS localizer signal is active.
 *RST: NORM

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 547.

Manual operation: See ["Operating Mode"](#) on page 140

[[:SOURce<hw>]:ILS:LOCalizer:PHASe <Phase>

Sets the phase between the modulation signals of the left and right antenna lobe of the ILS localizer signal.

The zero crossing of the right lobe (150Hz) signal serves as a reference. The angle refers to the period of the signal of the right antenna lobe.

Parameters:

<Phase> float
 Range: -60 to 120
 Increment: 0.01
 *RST: 0

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 547.

Manual operation: See ["Left/Right Phase"](#) on page 141

[:SOURce<hw>]:ILS:LOCAlizer:PRESet

Sets the parameters of the ILS localizer component to their default values (*RST values specified for the commands).

For other ILS preset commands, see [\[:SOURce<hw>\]:ILS:PRESet](#) on page 550.

Example: SOURce1:ILS:LOCAlizer:PRESet

Usage: Event

[:SOURce<hw>]:ILS:LOCAlizer:RLOBe[:FREQuency] <Frequency>

Sets the modulation frequency of the antenna lobe arranged at the right viewed from the air plane.

Parameters:

<Frequency> float
 Range: 100 to 200
 Increment: 0.05
 *RST: 150

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 547.

Manual operation: See ["Right Frequency"](#) on page 141

[:SOURce<hw>]:ILS:LOCAlizer:SDM <Sdm>

Sets the arithmetic sum of the modulation depths of the left lobe (90 Hz) and right lobe (150 Hz) for the ILS localizer signal contents.

The RMS modulation depth of the sum signal depends on the phase setting of both modulation tones.

Parameters:

<Sdm> float
 Range: 0 to 100
 Increment: 0.1
 *RST: 40

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 547.

Manual operation: See ["Sum of Depth"](#) on page 142

[[:SOURce<hw>]:ILS:LOCALizer:SOURce <IlsLocSource>

Sets the modulation source for the avionic standard modulation.

If external modulation source is set, the external signal is added to the internal signal. Switching off the internal modulation source is not possible.

Parameters:

<IlsLocSource> INT | INT,EXT | EXT

INT

Internal modulation source is used.

EXT|INT,EXT

An external modulation source is used, additional to the internal modulation source.

The external signal is input at the Ext connector.

*RST: INT

Example: See [Example "Configure and generate an ILS localizer signal"](#) on page 547.

Manual operation: See ["EXT AM"](#) on page 139

[[:SOURce<hw>]:[:ILS]:MBEacon:COMid:CODE <Code>

Sets the coding of the COM/ID signal by the international short name of the airport (e.g. MUC for the Munich airport).

The COM/ID tone is sent according to the selected code, see [Chapter D, "Morse Code Settings"](#), on page 745.

If no coding is set, the COM/ID tone is sent uncoded (key down).

Parameters:

<Code> string

Example: See [Example "Configure and generate an ILS marker beacons signal"](#) on page 548.

Manual operation: See ["Code"](#) on page 150

[[:SOURce<hw>]:[:ILS]:MBEacon:COMid:DASH <Dash>

Sets the length of a Morse code dash.

Parameters:

<Dash> float
 Range: 0.05 to 1
 Increment: 1E-4
 *RST: 0.3

Example: See [Example "Configure and generate an ILS marker beacons signal"](#) on page 548.

Manual operation: See ["Dash Length"](#) on page 151

[:SOURce<hw>][:ILS]:MBEacon:COMid:DEPTh <Depth>

Sets the AM modulation depth of the COM/ID signal.

Parameters:

<Depth> float
 Range: 0 to 100
 Increment: 0.1
 *RST: 5

Example: See [Example "Configure and generate an ILS marker beacons signal"](#) on page 548.

Manual operation: See ["Depth"](#) on page 150

[:SOURce<hw>][:ILS]:MBEacon:COMid:DOT <Dot>

Sets the length of a Morse code dot.

Parameters:

<Dot> float
 Range: 0.05 to 1
 Increment: 1E-4
 *RST: 0.1

Example: See [Example "Configure and generate an ILS marker beacons signal"](#) on page 548.

Manual operation: See ["Dot Length"](#) on page 151

[:SOURce<hw>][:ILS]:MBEacon:COMid:FREQuency <Frequency>

Sets the frequency of the COM/ID signal.

Parameters:

<Frequency> float
 Range: 0.1 to 20E3
 Increment: 0.01
 *RST: 1020

Example: See [Example "Configure and generate an ILS marker beacons signal"](#) on page 548.

Manual operation: See ["Frequency"](#) on page 150

[[:SOURce<hw>][:ILS]:MBEacon:COMid:LETter <Letter>

Sets the length of a Morse code letter space.

Parameters:

<Letter> float
 Range: 0.05 to 1
 Increment: 1E-4
 *RST: 0.3

Example: See [Example "Configure and generate an ILS marker beacons signal"](#) on page 548.

Manual operation: See [" Letter Space "](#) on page 151

[[:SOURce<hw>][:ILS]:MBEacon:COMid:PERiod <Period>

Sets the period of the COM/ID signal.

Parameters:

<Period> float
 Range: 0 to 120
 Increment: 1E-3
 *RST: 9

Example: See [Example "Configure and generate an ILS marker beacons signal"](#) on page 548.

Manual operation: See ["Period"](#) on page 150

[[:SOURce<hw>][:ILS]:MBEacon:COMid:SYMBol <Symbol>

Sets the length of the Morse code symbol space.

Parameters:

<Symbol> float
 Range: 0.05 to 1
 Increment: 1E-4
 *RST: 0.1

Example: See [Example "Configure and generate an ILS marker beacons signal"](#) on page 548.

Manual operation: See [" Symbol Space "](#) on page 151

```
[[:SOURce<hw>]:[:ILS]:MBEacon:COMid:TSCHEMA <Tschema>
```

Sets the time schema of the Morse code for the COM/ID signal.

Parameters:

<Tschema> STD | USER

STD

Activates the standard time schema of the Morse code.

The set `dot length` determines the `dash length`, which is 3 times the dot length.

USER

Activates the user-defined time schema of the Morse code.

Dot and dash length, as well as `symbol` and `letter space` can be set separately.

*RST: STD

Example: See [Example "Configure and generate an ILS marker beacons signal"](#) on page 548.

Manual operation: See ["Time Schema"](#) on page 150

```
[[:SOURce<hw>]:[:ILS]:MBEacon:COMid[:STATe] <State>
```

Enables/disables the COM/ID signal.

Parameters:

<State> 0 | 1 | OFF | ON

*RST: 0

Example: See [Example "Configure and generate an ILS marker beacons signal"](#) on page 548.

Manual operation: See ["COM/ID State"](#) on page 150

```
[[:SOURce<hw>]:[:ILS]:MBEacon:FREQuency <CarrierFreq>
```

Sets the carrier frequency for the ILS marker beacon signal.

Parameters:

<CarrierFreq> float

Range: 100E3 to 6E9

Increment: 0.01

*RST: 75E6

Example: See [Example "Configure and generate an ILS marker beacons signal"](#) on page 548.

Manual operation: See ["Carrier Frequency"](#) on page 147

```
[[:SOURce<hw>]:[:ILS]:MBEacon:FREQuency:MODE <Mode>
```

Sets the carrier frequency mode of the ILS marker beacon signal.

Parameters:

<Mode> USER | PREDefined
 *RST: USER

Example: See [Example "Configure and generate an ILS marker beacons signal"](#) on page 548.

Manual operation: See ["Carrier Frequency Mode"](#) on page 147

[:SOURce<hw>] [:ILS] :MBEacon :MARKer :FREQUency <Frequency>

Sets the modulation frequency of the marker signal for the ILS marker beacon modulation signal.

Parameters:

<Frequency> 400 | 1300 | 3000
 *RST: 400
 Default unit: Hz

Example: See [Example "Configure and generate an ILS marker beacons signal"](#) on page 548.

Manual operation: See ["Marker Frequency"](#) on page 148

[:SOURce<hw>] [:ILS] :MBEacon [:MARKer] :DEPTH <Depth>

Sets the modulation depth of the marker signal for the ILS marker beacon signal.

Parameters:

<Depth> float
 Range: 0 to 100
 Increment: 0.1
 *RST: 95

Example: See [Example "Configure and generate an ILS marker beacons signal"](#) on page 548.

Manual operation: See ["Marker Depth"](#) on page 148

[:SOURce<hw>] [:ILS] :MBEacon :PRESet

Sets the parameters of the ILS marker beacons component to their default values (*RST values specified for the commands).

For other ILS preset commands, see [\[:SOURce<hw> \] :ILS :PRESet](#) on page 550.

Example: SOURce1 : ILS : MBEacon : PRESet

Usage: Event

[:SOURce<hw>] [:ILS] :MBEacon [:MARKer] :PULSed <Pulsed>

Activates the modulation of a pulsed marker signal (morse coding).

Parameters:

<Pulsed> 0 | 1 | OFF | ON
 *RST: 0

Example:

See [Example "Configure and generate an ILS marker beacons signal"](#) on page 548.

Manual operation: See ["Pulsed Marker"](#) on page 148

14.16.2.5 SOURce:VOR Subsystem

Option: R&S SMAB-K25

The SOURce:VOR subsystem contains all commands for configuring the VOR signal.

Characteristics which are valid for all modulations and the LF output are configured in the SOURce:LFOutput subsystem. The signal is output at the LF connector.

Commands

[SOURce<hw>]:VOR:SOURce.....	578
[SOURce<hw>]:VOR[:BANGLE].....	579
[SOURce<hw>]:VOR[:BANGLE]:DIRection.....	579
[SOURce<hw>]:VOR:COMid:CODE.....	580
[SOURce<hw>]:VOR:COMid:DASH.....	580
[SOURce<hw>]:VOR:COMid:DEPT.....	580
[SOURce<hw>]:VOR:COMid:DOT.....	580
[SOURce<hw>]:VOR:COMid:FREQuency.....	581
[SOURce<hw>]:VOR:COMid:LETter.....	581
[SOURce<hw>]:VOR:COMid:PERiod.....	581
[SOURce<hw>]:VOR:COMid:SYMBol.....	582
[SOURce<hw>]:VOR:COMid:TSCHEMA.....	582
[SOURce<hw>]:VOR:COMid[:STATE].....	582
[SOURce<hw>]:VOR:FREQuency.....	583
[SOURce<hw>]:VOR:FREQuency:MODE.....	583
[SOURce<hw>]:VOR:ICAO:CHANnel.....	583
[SOURce<hw>]:VOR:MODE.....	584
[SOURce<hw>]:VOR:REFerence[:DEViation].....	585
[SOURce<hw>]:VOR:SUBCarrier:DEPT.....	585
[SOURce<hw>]:VOR:SUBCarrier[:FREQuency].....	585
[SOURce<hw>]:VOR:VAR:FREQuency.....	586
[SOURce<hw>]:VOR:VAR[:DEPT].....	586

[SOURce<hw>]:VOR:SOURce <VorSourceSel>

Sets the modulation source for the avionic standard modulation.

If external modulation source is set, the external signal is added to the internal signal. Switching off the internal modulation source is not possible.

Parameters:

<VorSourceSel> INT | INT,EXT | EXT

INT

Internal modulation source is used.

EXT|INT,EXT

An external modulation source is used, additional to the internal modulation source.

The external signal is input at the Ext connector.

*RST: INT

Example: See [Example "Configure and generate a VOR signal"](#) on page 548.

Manual operation: See ["EXT AM"](#) on page 122

[:SOURce<hw>]:VOR[:BANGLe] <BAngle>

Sets the bearing angle between the VAR signal and the reference signal.

The orientation of the angle can be set with [\[:SOURce<hw>\]:VOR\[:BANGLe\]:DIRection](#).

Parameters:

<BAngle> float
 Range: 0 to 360
 Increment: 0.01
 *RST: 0

Example: See [Example "Configure and generate a VOR signal"](#) on page 548.

Manual operation: See ["Bearing Angle"](#) on page 124

[:SOURce<hw>]:VOR[:BANGLe]:DIRection <Direction>

Sets the reference position of the phase information.

Parameters:

<Direction> FROM | TO

FROM

The bearing angle is measured between the geographic north and the connection line from beacon to airplane.

TO

The bearing angle is measured between the geographic north and the connection line from airplane to beacon.

*RST: FROM

Example: See [Example "Configure and generate a VOR signal"](#) on page 548.

Manual operation: See ["Direction"](#) on page 124

[[:SOURce<hw>]:VOR:COMid:CODE <Code>

Sets the coding of the COM/ID signal by the international short name of the airport (e.g. MUC for the Munich airport).

The COM/ID tone is sent according to the selected code, see [Chapter D, "Morse Code Settings"](#), on page 745.

If no coding is set, the COM/ID tone is sent uncoded (key down).

Parameters:

<Code> string

Example: See [Example "Configure and generate a VOR signal"](#) on page 548.

Manual operation: See ["Code"](#) on page 126

[[:SOURce<hw>]:VOR:COMid:DASH <Dash>

Sets the length of a Morse code dash.

Parameters:

<Dash> float
 Range: 0.05 to 1
 Increment: 1E-4
 *RST: 0.3

Example: See [Example "Configure and generate a VOR signal"](#) on page 548.

Manual operation: See ["Dash Length"](#) on page 126

[[:SOURce<hw>]:VOR:COMid:DEPTH <Depth>

Sets the AM modulation depth of the COM/ID signal.

Parameters:

<Depth> float
 Range: 0 to 100
 Increment: 0.1
 *RST: 10

Example: See [Example "Configure and generate a VOR signal"](#) on page 548.

Manual operation: See ["Depth"](#) on page 126

[[:SOURce<hw>]:VOR:COMid:DOT <Dot>

Sets the length of a Morse code dot.

If the `time schema` is set to standard, the dash length (= 3 times dot length), symbol space (= dot length) and letter space (= 3 times dot length) is also determined by this entry.

Parameters:

<Dot> float
 Range: 0.05 to 1
 Increment: 1E-4
 *RST: 0.1

Example: See [Example "Configure and generate a VOR signal"](#) on page 548.

Manual operation: See ["Dot Length"](#) on page 126

[[:SOURce<hw>]:VOR:COMid:FREQuency <Frequency>

Sets the frequency of the COM/ID signal.

Parameters:

<Frequency> float
 Range: 0.1 to 20E3
 Increment: 0.01
 *RST: 1020

Example: See [Example "Configure and generate a VOR signal"](#) on page 548.

Manual operation: See ["Frequency"](#) on page 126

[[:SOURce<hw>]:VOR:COMid:LETTer <Letter>

Sets the length of a Morse code letter space.

Parameters:

<Letter> float
 Range: 0.05 to 1
 Increment: 1E-4
 *RST: 0.3
 Default unit: s

Example: See [Example "Configure and generate a VOR signal"](#) on page 548.

Manual operation: See [" Letter Space "](#) on page 127

[[:SOURce<hw>]:VOR:COMid:PERiod <Period>

Sets the period of the COM/ID signal.

Parameters:

<Period> float
 Range: 0 to 120
 Increment: 1E-3
 *RST: 9

Example: See [Example "Configure and generate a VOR signal"](#) on page 548.

Manual operation: See ["Period"](#) on page 126

[:SOURce<hw>]:VOR:COMid:SYMBOL <Symbol>

Sets the length of the Morse code symbol space.

Parameters:

<Symbol> float
 Range: 0.05 to 1
 Increment: 1E-4
 *RST: 0.1

Example: See [Example "Configure and generate a VOR signal"](#) on page 548.

Manual operation: See ["Symbol Space"](#) on page 127

[:SOURce<hw>]:VOR:COMid:TSCHEMA <Tschema>

Sets the time schema of the Morse code for the COM/ID signal.

Parameters:

<Tschema> STD | USER

STD

Activates the standard time schema of the Morse code.

The set [dot length](#) determines the [dash length](#), which is 3 times the dot length.

USER

Activates the user-defined time schema of the Morse code.

Dot and dash length, as well as [symbol](#) and [letter space](#) can be set separately.

*RST: STD

Example: See [Example "Configure and generate a VOR signal"](#) on page 548.

Manual operation: See ["Time Schema"](#) on page 126

[:SOURce<hw>]:VOR:COMid[:STATE] <State>

Enables/disables the COM/ID signal.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 0

Example: See [Example "Configure and generate a VOR signal"](#) on page 548.

Manual operation: See ["COM/ID State"](#) on page 125

[[:SOURce<hw>]:VOR:FREQuency <CarrierFreq>

Sets the carrier frequency of the signal.

Parameters:

<CarrierFreq> float
 Range: 100E3 to 6E9
 Increment: 0.01
 *RST: 108E6

Example: See [Example "Configure and generate a VOR signal"](#) on page 548.

Manual operation: See ["Carrier Frequency"](#) on page 121

[[:SOURce<hw>]:VOR:FREQuency:MODE <Mode>

Sets the mode for the carrier frequency of the signal.

Parameters:

<Mode> DECimal | ICAO

DECimal

Activates user-defined variation of the carrier frequency.

ICAO

Activates variation in predefined steps according to standard VOR transmitting frequencies (see [Table 6-1](#)).

*RST: DECimal

Example: See [Example "Configure and generate a VOR signal"](#) on page 548.

Manual operation: See ["Carrier Frequency Mode"](#) on page 121

[[:SOURce<hw>]:VOR:ICAO:CHANnel <Channel>

Sets the ICAO channel and the corresponding transmitting frequency.

If avionic standard modulation is activated and you change the "RF Frequency", the frequency value of the closest ICAO channel is applied automatically. The "ICAO Channel" is also updated.

The carrier frequency is set automatically to the value of the ICAO channel. For an overview of the VOR ICAO channel frequencies, see [Table 6-1](#).

Parameters:

<Channel> CH17X | CH17Y | CH19X | CH19Y | CH21X | CH21Y | CH23X | CH23Y | CH25X | CH25Y | CH27X | CH27Y | CH29X | CH29Y | CH31X | CH31Y | CH33X | CH33Y | CH35X | CH35Y | CH37X | CH37Y | CH39X | CH39Y | CH41X | CH41Y | CH43X | CH43Y | CH45X | CH45Y | CH47X | CH47Y | CH49X | CH49Y | CH51X | CH51Y | CH53X | CH53Y | CH55X | CH55Y | CH57X | CH57Y | CH58X | CH58Y | CH59X | CH59Y | CH70X | CH70Y | CH71X | CH71Y | CH72X | CH72Y | CH73X | CH73Y | CH74X | CH74Y | CH75X | CH75Y | CH76X | CH76Y | CH77X | CH77Y | CH78X | CH78Y | CH79X | CH79Y | CH80X | CH80Y | CH81X | CH81Y | CH82X | CH82Y | CH83X | CH83Y | CH84X | CH84Y | CH85X | CH85Y | CH86X | CH86Y | CH87X | CH87Y | CH88X | CH88Y | CH89X | CH89Y | CH90X | CH90Y | CH91X | CH91Y | CH92X | CH92Y | CH93X | CH93Y | CH94X | CH94Y | CH95X | CH95Y | CH96X | CH96Y | CH97X | CH97Y | CH98X | CH98Y | CH99X | CH99Y | CH100X | CH100Y | CH101X | CH101Y | CH102X | CH102Y | CH103X | CH103Y | CH104X | CH104Y | CH105X | CH105Y | CH106X | CH106Y | CH107X | CH107Y | CH108X | CH108Y | CH109X | CH109Y | CH110X | CH110Y | CH111X | CH111Y | CH112X | CH112Y | CH113X | CH113Y | CH114X | CH114Y | CH115X | CH115Y | CH116X | CH116Y | CH117X | CH117Y | CH118X | CH118Y | CH119X | CH119Y | CH120X | CH120Y | CH121X | CH121Y | CH122X | CH122Y | CH123X | CH123Y | CH124X | CH124Y | CH125X | CH125Y | CH126X | CH126Y

*RST: CH17X

Example: See [Example "Configure and generate a VOR signal"](#) on page 548.

Manual operation: See ["ICAO Channel"](#) on page 121

[:SOURce<hw>]:VOR:MODE <Mode>

Sets the operating mode for the VOR modulation signal.

Parameters:

<Mode> NORM | VAR | SUBCarrier | FMSubcarrier

NORM

VOR modulation is active.

VAR

Amplitude modulation of the output signal with the variable signal component (30Hz signal content) of the VOR signal.

The modulation depth of the 30 Hz signal can be set with [:SOURce<hw>]:VOR:VAR[:DEPTH].

SUBCarrier

Amplitude modulation of the output signal with the unmodulated FM carrier (9960Hz) of the VOR signal.

The modulation depth of the 30 Hz signal can be set with [:SOURce<hw>]:VOR:SUBCarrier:DEPTh.

FMSubcarrier

Amplitude modulation of the output signal with the frequency modulated FM carrier (9960Hz) of the VOR signal.

The modulation depth of the 30 Hz signal can be set with [:SOURce<hw>]:VOR:SUBCarrier:DEPTh.

The frequency deviation can be set with [:SOURce<hw>]:VOR:REFerence[:DEViation].

*RST: NORM

Example: See [Example "Configure and generate a VOR signal"](#) on page 548.

Manual operation: See ["Mode"](#) on page 123

[[:SOURce<hw>]:VOR:REFerence[:DEViation] <Deviation>

Sets the frequency deviation of the reference signal on the FM carrier.

Parameters:

<Deviation> integer
 Range: 0 to 960
 *RST: 480

Example: See [Example "Configure and generate a VOR signal"](#) on page 548.

Manual operation: See ["REF Deviation"](#) on page 124

[[:SOURce<hw>]:VOR:SUBCarrier:DEPTh <Depth>

Sets the AM modulation depth of the FM carrier.

Parameters:

<Depth> float
 Range: 0 to 100
 Increment: 0.1
 *RST: 30

Example: See [Example "Configure and generate a VOR signal"](#) on page 548.

Manual operation: See [" Subcarrier Depth "](#) on page 123

[[:SOURce<hw>]:VOR:SUBCarrier[:FREQUENCY] <Frequency>

Sets the frequency of the FM carrier.

Parameters:

<Frequency> float
 Range: 5E3 to 15E3
 Increment: 0.01
 *RST: 9.96E3

Example: See [Example "Configure and generate a VOR signal"](#) on page 548.

Manual operation: See ["Subcarrier Frequency"](#) on page 123

[:SOURce<hw>]:VOR:VAR:FREQuency <Frequency>

Sets the frequency of the variable and the reference signal. As the two signals must have the same frequency, the setting is valid for both signals.

Parameters:

<Frequency> float
 Range: 10 to 60
 Increment: 0.01
 *RST: 30

Example: See [Example "Configure and generate a VOR signal"](#) on page 548.

Manual operation: See ["VAR/REF Frequency"](#) on page 123

[:SOURce<hw>]:VOR:VAR[:DEPTh] <Depth>

Sets the AM modulation depth of the 30Hz variable signal.

Parameters:

<Depth> float
 Range: 0 to 100
 Increment: 0.1
 *RST: 30

Example: See [Example "Configure and generate a VOR signal"](#) on page 548.

Manual operation: See ["VAR Depth"](#) on page 123

14.16.3 SOURce:CORRection Subsystem

The SOURce:CORRection subsystem contains the commands for defining correction values for external test assemblies.

You can acquire the correction values any time, regardless of the modulation settings of the generator. The correction is performed by adding the correction values to the output level of the respective RF frequency.

Determine the correction values in one of the following ways:

- Measure the RF output level at several frequency points and enter the value pairs manually in a table
- Connect an R&S NRP to the generator output signal and send the command [: SOURce<hw>] : CORRection : CSET : DATA [: SENSor<ch>] [: POWer] : SONCe to fill the table automatically.

Correction values can be stored in files with the predefined file extension *.uco.

Refer to [Chapter 14.5.2, "Accessing Files in the Default or in a Specified Directory"](#), on page 420 for general information on file handling in the default and in a specific directory.

Programming example

The examples in this section assume that:

- The files are stored in the default directory.
- *RST does not affect data lists.

Example: Create a table with user-defined correction values for the RF level

The following example shows a command sequence to create and activate a list for assigning level correction values to arbitrary RF frequencies. Further hardware settings are not considered.

```
// Reset the instrument to start from an initial state
// Query the available user correction list files in the default directory
// Select a file or create a new one
// *****
*RST; *CLS
SOURcel:CORRection:CSET:CATalog?
// Response: shows the name of available user correction files (if applicable)
// Select a file
SOURcel:CORRection:CSET:SElect "/var/user/ucor1"
// Create a new file (if not existing)
SOURcel:CORRection:CSET:SElect "/var/user/ucor2"

// Enter the frequency/level value pairs in the table;
// existing data is overwritten
// Query the number of frequency/power entries in the selected list
SOURcel:CORRection:CSET:DATA:FREQuency 100MHz,110MHz,120MHz,130MHz,140MHz,150MHz
SOURcel:CORRection:CSET:DATA:POWer -10,-7.5,-5.0,-2.5,0,2.5
SOURcel:CORRection:CSET:DATA:FREQuency:POINTs?
// 6
SOURcel:CORRection:CSET:DATA:POWer:POINTs?
// 6

// Enable user correction mode and RF output
SOURcel:CORRection:STATe 1
OUTPut1:STATe ON
```

```
// Query the currently used correction value
SOURcel:CORRection:VALue?
// -2.5

// Delete a user correction file
SOURcel:CORRection:CSET:DELEte "/var/user/ucor1.uco"
```

Example: Fill user correction data with sensor

The following example shows a command sequence to fill a user correction list automatically supported by a connected R&S NRP.

```
// Fill a user correction list with the level values
// measured by an R&S NRP,
// store the data in a file and enable user correction.

*RST; *CLS

SOURcel:CORRection:CSET:SElect "/var/user/Ucor1_AutoFill.uco"
SOURcel:CORRection:CSET:DATA:FREQuency 100MHz,110MHz,120MHz,130MHz,140MHz,150MHz
SOURcel:CORRection:ZERoing:STATe 1
SOURcel:CORRection:CSET:DATA:SENSor1:POWer:SONce
// Query the number of automatically filled correction level values
SOURcel:CORRection:CSET:DATA:POWer:POINTs?
// 6
SOURcel:CORRection:STATe 1

// Query the correction value at a certain frequency
FREQ 120000000
SOURcel:CORRection:VALue?
// -52.13
```

Example: User correction data exchange

The following example shows a command sequence to export a user correction list (here the list created with the example before) into an ASCII file. Further hardware settings are not considered.

```
// Select a user correction file for exporting to file in ASCII format
// Set ASCII data parameters
// Set the ASCII file extension, the decimal separator
// and the column separator for the ASCII data
SOURcel:CORRection:DEXChange:AFILe:CATalog?
// my_ucor
SOURcel:CORRection:CSET:CATalog?
// ucor1,Ucor1_AutoFill
SOURcel:CORRection:CSET:SElect "/var/user/Ucor1_AutoFill.uco"
SOURcel:CORRection:DEXChange:AFILe:EXTension CSV
SOURcel:CORRection:DEXChange:AFILe:SEParator:DECimal DOT
SOURcel:CORRection:DEXChange:AFILe:SEParator:COLumn COMMa
```



```
// Select source and destination
SOURce1:CORRection:DEXChange:AFILe:SElect "/var/user/ucor2ASCII"

// Export the user correction data into the ASCII file
SOURce1:CORRection:DEXChange:MODE EXPort
SOURce1:CORRection:DEXChange:EXECute

// Query the available ASCII files with extension .csv
SOURce1:CORRection:DEXChange:AFILe:CATalog?
// ucor2ASCII,my_ucor

// Import a user correction ASCII file
SOURce1:CORRection:DEXChange:MODE IMPort
SOURce1:CORRection:DEXChange:AFILe:SElect "/var/user/my_ucor"
SOURce1:CORRection:DEXChange:EXECute
```

- [Correction Settings](#).....589
- [Correction Data Exchange](#).....592

14.16.3.1 Correction Settings

[:SOURce<hw>]:CORRection:CSET:DATA:FREQuency <Frequency>

Enters the frequency value in the table selected with [\[:SOURce<hw>\]:CORRection:CSET\[:SElect\]](#).

Parameters:

<Frequency> Frequency#1[, Frequency#2, ...]
String of values with default unit Hz.

Example: See [Example "Create a table with user-defined correction values for the RF level"](#) on page 587 .

Manual operation: See ["Edit List Mode Data"](#) on page 193

[:SOURce<hw>]:CORRection:CSET:DATA:POWer <Power>

Enters the level values to the table selected with [\[:SOURce<hw>\]:CORRection:CSET\[:SElect\]](#).

Parameters:

<Power> Power#1[, Power#2, ...]
String of values with default unit dB.
*RST: 0

Example: See [Example "Create a table with user-defined correction values for the RF level"](#) on page 587 .

Manual operation: See ["Edit List Mode Data"](#) on page 193

[[:SOURce<hw>]:CORRection:CSET:DATA:FREQUency:POINts?

[[:SOURce<hw>]:CORRection:CSET:DATA:POWer:POINts?

Queries the number of frequency/level values in the selected table.

Return values:

<Points> integer
 Range: 0 to 10000
 *RST: 0

Example: See [Example "Create a table with user-defined correction values for the RF level"](#) on page 587 .

Usage: Query only

[[:SOURce<hw>]:CORRection:CSET:DATA[:SENSor<ch>][:POWer]:SONCe

Fills the selected user correction table with the level values measured by the power sensor for the given frequencies.

To select the used power sensor set the suffix in key word `SENSe`.

Example: See [Example "Fill user correction data with sensor"](#) on page 588.

Usage: Event

Manual operation: See "[Fill User Correction Data with Sensor](#)" on page 210

[[:SOURce<hw>]:CORRection:CSET[:SELEct] <Filename>

Selects or creates a file for the user correction data.

If the file with the selected name does not exist, a new file is created.

Parameters:

<Filename> string
 Filename or complete file path; file extension can be omitted.

Example: See [Example "Create a table with user-defined correction values for the RF level"](#) on page 587 .

Manual operation: See "[UCOR Data](#)" on page 206

[[:SOURce<hw>]:CORRection:VALue?

Queries the current value for user correction.

Return values:

<Value> float
 Range: -100 to 100
 Increment: 0.01
 *RST: 0

Example: See [Example "Create a table with user-defined correction values for the RF level"](#) on page 587 .

Usage: Query only

Manual operation: See ["User Correction"](#) on page 206

[:SOURce<hw>]:CORRection:ZERoing:STATe <State>

Activates the zeroing procedure before filling the user correction data acquired by a sensor.

Parameters:

<State> 0 | 1 | OFF | ON

*RST: 1

Example: See [Example "Fill user correction data with sensor"](#) on page 588.

Manual operation: See [" Fill User Correction Data with Sensor"](#) on page 210

[:SOURce<hw>]:CORRection:CSET:DATA[:SENSor<ch>][:POWER]:SONCe

Fills the selected user correction list with the level values measured by the power sensor for the given frequencies.

Suffix:

SENSor<ch> Defines the used power sensor, i.e. the sensor whose values are used.

Example: See [Example "Fill user correction data with sensor"](#) on page 588.

Usage: Event

[:SOURce<hw>]:CORRection[:STATe] <State>

Activates user correction with the currently selected table.

Parameters:

<State> 0 | 1 | OFF | ON

*RST: 0

Example: See [Example "Create a table with user-defined correction values for the RF level"](#) on page 587 .

Manual operation: See ["State"](#) on page 206

[:SOURce]:CORRection:CSET:CATalog?

Queries a list of available user correction tables.

Return values:

<Catalog> string
List of list filenames, separated by commas

Example: See [Example "Create a table with user-defined correction values for the RF level"](#) on page 587 .

Usage: Query only

Manual operation: See ["UCOR Data"](#) on page 206

[:SOURce]:CORRection:CSET:DELeTe <Filename>

Deletes the specified user correction list file.

Setting parameters:

<Filename> string
Filename or complete file path; file extension is optional.

Example: See [Example "Create a table with user-defined correction values for the RF level"](#) on page 587 .

Usage: Setting only

Manual operation: See ["UCOR Data"](#) on page 206

14.16.3.2 Correction Data Exchange

With the following commands, you can configure user correction lists and export or import them accordingly.

[:SOURce<hw>]:CORRection:DEXChange:AFILe:CATalog?

Queries the available ASCII files for export or import of user correction data in the current or specified directory.

Return values:

<Catalog> string
List of ASCII files *.txt or *.csv, separated by commas.

Example: See [Example "Create a table with user-defined correction values for the RF level"](#) on page 587 .

Usage: Query only

Manual operation: See ["Select \(ASCII\) Source/Select \(ASCII\) Destination"](#) on page 96

[:SOURce<hw>]:CORRection:DEXChange:AFILe:EXTension <Extension>

Determines the extension of the ASCII files for file import or export, or to query existing files.

Parameters:

<Extension> TXT | CSV
 *RST: TXT

Example: See [Example "User correction data exchange"](#) on page 588 .

Manual operation: See ["ASCII File Settings"](#) on page 95

[[:SOURce<hw>]:CORRection:DEXChange:AFILe:SElect <Filename>

Selects the ASCII file to be imported or exported.

Parameters:

<Filename> string
 Filename or complete file path; file extension can be omitted.

Example: See [Example "User correction data exchange"](#) on page 588 .

Manual operation: See ["Select \(ASCII\) Source/Select \(ASCII\) Destination"](#)
 on page 96

[[:SOURce<hw>]:CORRection:DEXChange:AFILe:SEParator:COLumn <Column>

Selects the separator between the frequency and level column of the ASCII table.

Parameters:

<Column> TABulator | SEMicolon | COMMa | SPACe
 *RST: COMMa

Example: See [Example "User correction data exchange"](#) on page 588 .

Manual operation: See ["ASCII File Settings"](#) on page 95

[[:SOURce<hw>]:CORRection:DEXChange:AFILe:SEParator:DECimal <Decimal>

Sets the decimal separator used in the ASCII data between '.' (decimal point) and ',' (comma) with floating-point numerals.

Parameters:

<Decimal> DOT | COMMa
 *RST: DOT

Example: See [Example "User correction data exchange"](#) on page 588 .

Manual operation: See ["ASCII File Settings"](#) on page 95

[[:SOURce<hw>]:CORRection:DEXChange:EXECute

Executes the import or export of the selected correction list, according to the previously set transfer direction with command [\[:SOURce<hw>\]:CORRection:DEXChange:MODE](#).

Example: See [Example "User correction data exchange"](#) on page 588 .

Usage: Event

Manual operation: See ["Import / Export"](#) on page 96

[:SOURce<hw>]:CORRection:DEXChange:MODE <Mode>

Determines import or export of a user correction list.

Specify the source or destination file with the command `[:SOURce<hw>] :CORRection:DEXChange:SElect`.

Parameters:

<Mode> IMPort | EXPort
*RST: IMPort

Example: See [Example "User correction data exchange"](#) on page 588 .

Manual operation: See [" Mode "](#) on page 95

[:SOURce<hw>]:CORRection:DEXChange:SElect <Filename>

Selects the ASCII file for import or export, containing a user correction list.

Parameters:

<Filename> string
Filename or complete file path; file extension can be omitted.

Example: See [Example "User correction data exchange"](#) on page 588 .

Manual operation: See ["Select Source/Select ASCII Destination"](#) on page 96

14.16.4 SOURce:FREQuency Subsystem

The `SOURce:FREQuency` subsystem contains the commands used to define the frequency settings for the RF sources and sweeps.

Example: Frequency configuration

```
SOURce1:FREQuency:MODE CW
SOURce1:FREQuency:CW 6000000000
SOURce1:FREQuency:OFFSet 2000000000
SOURce1:FREQuency:MULTIplier 1.5
SOURce1:FREQuency:CW?
// 11000000000

// SOURce1:FREQuency:STEP:MODE USER
// SOURce1:FREQuency:STEP:INCRement 1000000
// SOURce1:FREQuency:CW UP

SOURce1:PHASe 2
SOURce1:PHASe:REFerence
```

Example: Setting a phase continuous frequency range

```

SOURce1:FREQuency:CW 502000000
SOURce1:FREQuency:PHASE:MODE NARR
SOURce1:FREQuency:PHASe:CONTInuous:STATe 1
*****
// Query the frequency range
SOURce1:FREQuency:PHASe:CONTInuous:LOW?
// Response: 494062500
SOURce1:FREQuency:PHASe:CONTInuous:HIGH?
// Response: 503750000
*****
// Vary the frequency. Within the specified range the signal is phase continuous.
SOURce1:FREQuency:CW 499000000
SOURce1:FREQuency:CW 500000000
SOURce1:FREQuency:CW 501000000
SOURce1:FREQuency:CW 503000000

```

[:SOURce<hw>]:FREQuency:MODE.....	595
[:SOURce<hw>]:FREQuency[:CW FIXed].....	596
[:SOURce<hw>]:FREQuency[:CW FIXed]:RCL.....	597
[:SOURce<hw>]:FREQuency:MANual.....	597
[:SOURce<hw>]:FREQuency:MUlTIplier.....	598
[:SOURce<hw>]:FREQuency:OFFSet.....	598
[:SOURce<hw>]:FREQuency:CENTer.....	598
[:SOURce<hw>]:FREQuency:SPAN.....	599
[:SOURce<hw>]:FREQuency:STARt.....	599
[:SOURce<hw>]:FREQuency:STOP.....	599
[:SOURce<hw>]:FREQuency:STEP:MODE.....	600
[:SOURce<hw>]:FREQuency:STEP[:INCRement].....	600
[:SOURce<hw>]:FREQuency:PLL:MODE.....	601
[:SOURce<hw>]:FREQuency:PHASe:CONTInuous:HIGH?.....	601
[:SOURce<hw>]:FREQuency:PHASe:CONTInuous:LOW?.....	601
[:SOURce<hw>]:FREQuency:PHASe:CONTInuous:MODE.....	601
[:SOURce<hw>]:FREQuency:PHASe:CONTInuous:STATe.....	602

[:SOURce<hw>]:FREQuency:MODE <Mode>

Sets the frequency mode for generating the RF output signal. The selected mode determines the parameters to be used for further frequency settings.

Parameters:

<Mode> CW | FIXed | SWEep | LIST

CW|FIXed

Sets the fixed frequency mode. CW and FIXed are synonyms. The instrument operates at a defined frequency, set with command `[:SOURce<hw>]:FREQuency[:CW|FIXed]`.

SWEep

Sets sweep mode.

The instrument processes frequency (and level) settings in defined sweep steps.

Set the range and current frequency with the commands:

[:SOURce<hw>] :FREQuency:STARt on page 599 and [:SOURce<hw>] :FREQuency:STOP on page 599,
[:SOURce<hw>] :FREQuency:CENTer on page 598,
[:SOURce<hw>] :FREQuency:SPAN on page 599,
[:SOURce<hw>] :FREQuency:MANual on page 597

LIST

Sets list mode.

The instrument processes frequency and level settings by means of values loaded from a list.

To configure list mode settings, use the commands of the [Chapter 14.16.7, "SOURce:LIST Subsystem"](#), on page 616.

*RST: CW

Example: See [Example "Frequency configuration"](#) on page 594

Example: See [Example "Setup an RF frequency or power sweep"](#) on page 647

Manual operation: See ["State \(RF frequency sweep\)"](#) on page 174

[:SOURce<hw>] :FREQuency [:CW | FIXed] <Fixed>

Sets the frequency of the RF output signal in the selected path.

The effect depends on the selected mode:

- In CW mode (`FREQ:MODE CW | FIXed`), the instrument operates at a fixed frequency.
- In sweep mode (`FREQ:MODE SWE`), the value applies to the sweep frequency. The instrument processes the frequency settings in defined sweep steps.
- In user mode (`FREQ:STEP:MODE USER`), you can vary the current frequency step by step.

Parameters:

<Fixed> float

The following settings influence the value range:

An offset set with the command [:SOURce<hw>] :FREQuency:OFFSet

Numerical value

Sets the frequency in CW and sweep mode

UP|DOWN

Varies the frequency step by step in user mode.

The frequency is increased or decreased by the value set with the command [:SOURce<hw>] :FREQuency:STEP [:INCRement].

Range: (RFmin + OFFSet) to (RFmax + OFFSet)
 *RST: 100 MHz

Example: See [Example "Frequency configuration"](#) on page 594

Example: See [Example "Setup an RF frequency or power sweep"](#) on page 647

Options: RFmax depends on the installed options, for example 3 GHz with R&S SMAB-B103

Manual operation: See ["Frequency"](#) on page 66

[:SOURce<hw>]:FREQuency[:CW|FIXed]:RCL <Rcl>

Set whether the RF frequency value is retained or taken from a loaded instrument configuration, when you recall instrument settings with command *RCL.

Parameters:

<Rcl> INCLude | EXCLude

INCLude

Takes the frequency value of the loaded settings.

EXCLude

Retains the current frequency when an instrument configuration is loaded.

*RST: INCLude

Example: SOURce1:FREQuency:CW:RCL INCLude

Manual operation: See ["Exclude Frequency"](#) on page 298

[:SOURce<hw>]:FREQuency:MANual <Manual>

Sets the frequency and triggers a sweep step manually if [SWEep:MODE MAN](#).

Parameters:

<Manual> float

You can select any frequency within the setting range, where:

START is set with [:SOURce<hw>] :FREQuency:START

STOP is set with [:SOURce<hw>] :FREQuency:STOP

OFFSet is set with [:SOURce<hw>] :FREQuency:OFFSet

Range: (START + OFFSet) to (STOP + OFFSet)

Increment: 0.01Hz

*RST: 100 MHz

Default unit: Hz

Example: See [Example "Setup an RF frequency or power sweep"](#) on page 647

Manual operation: See ["Current Frequency"](#) on page 175

[SOURce<hw>]:FREQUENCY:MULTIPLIER <Multiplier>

Sets the multiplication factor $N_{\text{FREQ:MULT}}$ of a subsequent downstream instrument.

The parameters offset $f_{\text{FREQ:OFFSer}}$ and multiplier $N_{\text{FREQ:MULT}}$ affect the frequency value set with the command `FREQ`.

The query `FREQ?` returns the value corresponding to the formula:

$$f_{\text{FREQ}} = f_{\text{RFout}} * N_{\text{FREQ:MULT}} + f_{\text{FREQ:OFFSer}}$$

See "RF frequency and level display with a downstream instrument" on page 64.

Parameters:

<Multiplier>	float
	Range: -10000 to 10000
	Increment: 0.001
	*RST: 1

Example: See [Example "Frequency configuration"](#) on page 594

Manual operation: See ["Multiplier"](#) on page 66

[SOURce<hw>]:FREQUENCY:OFFSET <Offset>

Sets the frequency offset $f_{\text{FREQ:OFFSet}}$ of a downstream instrument.

The parameters offset $f_{\text{FREQ:OFFSer}}$ and multiplier $N_{\text{FREQ:MULT}}$ affect the frequency value set with the command `FREQ`.

The query `FREQ?` returns the value corresponding to the formula:

$$f_{\text{FREQ}} = f_{\text{RFout}} * N_{\text{FREQ:MULT}} + f_{\text{FREQ:OFFSer}}$$

See "RF frequency and level display with a downstream instrument" on page 64.

Note: The offset also affects RF frequency sweep.

Parameters:

<Offset>	float
	Increment: 0.01
	*RST: 0

Example: See [Example "Frequency configuration"](#) on page 594

Manual operation: See ["Offset"](#) on page 66

[SOURce<hw>]:FREQUENCY:CENTER <Center>

Sets the center frequency of the sweep.

See [Chapter 7.2.1, "Correlating Parameters in Sweep Mode"](#), on page 167.

Parameters:

<Center> float
 Range: 300 kHz to RFmax
 Increment: 0.01 Hz
 *RST: 300E6
 Default unit: Hz

Example: See [Example "Setup an RF frequency or power sweep"](#) on page 647

Manual operation: See "[Center Frequency](#)" on page 179

**[:SOURce<hw>]:FREQUENCY:SPAN **

Sets the span of the frequency sweep range.

See [Chapter 7.2.1, "Correlating Parameters in Sweep Mode"](#), on page 167.

Parameters:

 float
 Full frequency range
 Increment: 0.01
 *RST: 400E6

Example: See [Example "Setup an RF frequency or power sweep"](#) on page 647

Manual operation: See "[Span](#)" on page 179

[:SOURce<hw>]:FREQUENCY:START <Start>

Sets the start frequency for the RF sweep.

See [Chapter 7.2.1, "Correlating Parameters in Sweep Mode"](#), on page 167.

Parameters:

<Start> float
 Range: 300kHz to RFmax
 Increment: 0.01Hz
 *RST: 100 MHz

Example: See [Example "Setup an RF frequency or power sweep"](#) on page 647

Manual operation: See "[Start Frequency/Stop Frequency](#)" on page 179

[:SOURce<hw>]:FREQUENCY:STOP <Stop>

Sets the stop frequency range for the RF sweep.

See [Chapter 7.2.1, "Correlating Parameters in Sweep Mode"](#), on page 167.

Parameters:

<Stop> float
 Range: 300kHz to RFmax
 Increment: 0.01Hz
 *RST: 500 MHz
 Default unit: Hz

Example: See [Example "Setup an RF frequency or power sweep"](#) on page 647

Manual operation: See "[Start Frequency/Stop Frequency](#)" on page 179

[[:SOURce<hw>]:FREQuency:STEP:MODE <Mode>

Defines the type of step size to vary the RF frequency at discrete steps with the commands [FREQ UP](#) or [FREQ DOWN](#).

Parameters:

<Mode> DECimal | USER
DECimal
 Increases or decreases the level in steps of ten.
USER
 Increases or decreases the level in increments, set with the command [FREQ:STEP\[:INCR\]](#).
 *RST: DECimal

Example:

```
// increasing the RF frequency with a step size of 50 KHz
SOURce1:FREQuency:STEP 50E3
SOURce1:FREQuency:STEP:MODE USER
SOURce1:FREQuency:CW UP
```

Manual operation: See "[Variation Active](#)" on page 67

[[:SOURce<hw>]:FREQuency:STEP[:INCRement] <Increment>

Sets the step width.

You can use this value to vary the RF frequency with command [FREQ UP](#) or [FREQ DOWN](#), if you have activated [FREQ:STEP:MODE USER](#).

Note: This value also applies to the step width of the rotary knob on the instrument and, in user-defined step mode, increases or decreases the frequency.

Parameters:

<Increment> float
 Range: 0 Hz to RFmax - 100 kHz
 Increment: 0.01 Hz
 *RST: 1E6

Example: See [Example "Frequency configuration"](#) on page 594

Manual operation: See "[Variation Step](#)" on page 67

[[:SOURce<hw>]:FREQUENCY:PLL:MODE <Mode>

Selects the PLL (Phase Locked Loop) bandwidth of the main synthesizer.

Parameters:

<Mode> NORMal | NARRow

NORMal
Maximum modulation bandwidth and FM/PhiM deviation.

NARRow
Narrow PLL bandwidth

*RST: NORMal

Example: SOURce:FREQUENCY:PLL:MODE NORMal

Manual operation: See "[Main PLL Bandwidth](#)" on page 66

[[:SOURce<hw>]:FREQUENCY:PHASE:CONTInuous:HIGH?

[[:SOURce<hw>]:FREQUENCY:PHASE:CONTInuous:LOW?

Queries the minimum frequency of the frequency range for phase continuous settings.

The minimum frequency of the frequency range depends on the mode selected with the command `[[:SOURce<hw>]:FREQUENCY:PHASE:CONTInuous:MODE`.

Return values:

<Low> float

Range: 1E5 to 6E9

Increment: 0.01

*RST: 1E9

Default unit: Hz

Example: SOURce:FREQUENCY:PHASE:CONTInuous:MODE NARR
SOURce:FREQUENCY:PHASE:CONTInuous:STATE 1
SOURce:FREQUENCY:PHASE:CONTInuous:LOW?
998 720 930.20

Usage: Query only

[[:SOURce<hw>]:FREQUENCY:PHASE:CONTInuous:MODE <Mode>

Selects the mode that determines the frequency range for the phase continuity.

To query the frequency range, use the commands `[[:SOURce<hw>]:FREQUENCY:PHASE:CONTInuous:HIGH?` and `[[:SOURce<hw>]:FREQUENCY:PHASE:CONTInuous:LOW?`

Parameters:

<Mode> NARRow | WIDE

NARRow
Small frequency range, asymmetrically around the RF frequency.

WIDE

Large frequency range, symmetrically around the RF frequency.

*RST: NARRow

Example: See [:SOURce<hw>]:FREQuency:PHASe:CONTInuous:LOW? on page 601

[:SOURce<hw>]:FREQuency:PHASe:CONTInuous:STATe <State>

Activates phase continuity of the RF frequency.

The frequency range is limited and varies depending on the set RF frequency. You can query the range with the commands [:SOURce<hw>]:FREQuency:PHASe:CONTInuous:HIGH? on page 601 and [:SOURce<hw>]:FREQuency:PHASe:CONTInuous:LOW? on page 601.

Note: Restricted structure of command line.

In phase continuous mode, the R&S SMA100B only processes the first command of a command line and ignores further commands if they are on the same line.

Parameters:

<State> 0 | 1 | OFF | ON

*RST: 0

Example: See [:SOURce<hw>]:FREQuency:PHASe:CONTInuous:LOW? on page 601

14.16.5 SOURce:INPut Subsystem

The SOURce:INPut subsystem contains the commands for configuring the inputs for external modulation signals. The instrument trigger setting influences all sweeps and is effective in the List mode (Instrument Trigger).

[:SOURce<hw>]:INPut:MODext:COUPling<ch>.....	602
[:SOURce<hw>]:INPut:MODext:IMPedance<ch>.....	603
[:SOURce]:INPut:TRIGger:SLOPe.....	603

[:SOURce<hw>]:INPut:MODext:COUPling<ch> <Coupling>

Selects the coupling mode for an externally applied modulation signal.

Parameters:

<Coupling> AC | DC

AC

Passes the AC signal component of the modulation signal.

DC

Passes the modulation signal with both components, AC and DC.

For active external exponential AM, automatically sets [:SOURce<hw>]:INPut:MODext:COUPling<ch>DC.

*RST: AC

Example: INP:MOD:COUP AC
Selects the coupling mode AC for an externally applied modulation signal.

Manual operation: See "[Coupling \(AC/DC\)](#)" on page 104

[:SOURce<hw>]:INPut:MODext:IMPedance<ch> <Impedance>

Sets the impedance for the externally supplied modulation signal.

Parameters:

<Impedance> G50 | G600 | HIGH
G50 = 50 Ohm to ground
G600 = 600 Ohm to ground
HIGH = 100 kOhm to ground
*RST: HIGH

Example: See [\[:SOURce<hw>\]:INPut:MODext:COUPling<ch>](#) on page 602.

Manual operation: See "[Impedance](#)" on page 104

[:SOURce]:INPut:TRIGger:SLOPe <Slope>

Sets the polarity of the active slope of an applied instrument trigger.

Parameters:

<Slope> NEGative | POSitive
*RST: POSitive

Example: INP:TRIG:SLOP NEG
Activates the falling slope of the external trigger signal at the trigger input.

Manual operation: See "[Trigger Slope](#)" on page 178

14.16.6 SOURce:LFOutput Subsystem

The SOURce:LFOutput subsystem contains the commands for setting the LF signal source in CW and Sweep mode and for analog modulation.

Example: Setup an LF sweep

The following example shows a command sequence to set up an LF sweep.

```
// Reset the instrument to start from an initial state
*RST; *CLS

// Set the trigger mode, the sweep mode and the sweep range
TRIGger1:LFFSweep:SOURce SINGLE
```

```

SOURcel:LFOutput1:SWEep:FREQuency:MODE AUTO
SOURcel:LFOutput1:FREQuency:START 1 kHz
SOURcel:LFOutput1:FREQuency:STOP 7 kHz

// Select linear spacing
// Select the waveform shape for the frequency sweep cycle
// Set the step width and the dwell time.
SOURcel:LFOutput1:SWEep:FREQuency:SPACing LINear
SOURcel:LFOutput1:SWEep:FREQuency:SHApe SAWtooth
SOURcel:LFOutput1:SWEep:FREQuency:STEP:LINear 100 Hz
SOURcel:LFOutput1:SWEep:FREQuency:DWELl 150 ms
// Alternatively to the step width set the number of steps
SOURcel:LFOutput1:SWEep:FREQuency:POINts 61

// Activate change to start frequency while waiting for next trigger
// Prerequisites: sweep mode single and sweep waveform sawtooth
SOURcel:LFOutput:SWEep:FREQuency:RETRace 1

// Activate the LF frequency sweep
SOURcel:LFOutput:FREQuency:MODE SWE

// Trigger the sweep(depending on the set mode) and query the status
// Perform a one-off LF sweep
SOURcel:LFOutput1:SWEep:FREQuency:EXECute
SOURcel:LFOutput1:SWEep:FREQuency:RUNning?
// 1
// the sweep is running

// *****
// For manual step LF sweep use the following commands
*RST; *CLS
SOURcel:LFOutput:SWEep:FREQuency:MODE MANual
// Activate the LF frequency sweep
SOURcel:LFOutput:FREQuency:MODE SWEep
// Activate LF Output1.
SOURcel:LFOutput1:STATE 1
// Input the frequency manually for each step
SOURcel:LFOutput1:FREQuency:MANual 2 kHz
SOURcel:LFOutput1:FREQuency:MANual 2.1 kHz
// Alternatively use UP or DOWN parameter with set step width.
SOURcel:LFOutput1:SWEep:FREQuency:STEP:LINear 500 Hz
SOURcel:LFOutput1:FREQuency:MANual UP

```

Example: Configuring the LF generator

The following is a simple example on how to configure the LF generator and output the generated signal.

```

// configure the signal of the LF1 generator
SOURcel:LFOutput1:SHApe SQU
SOURcel:LFOutput1:SHApe:PULSe:PERiod 0.001

```



```

SOURce1:LFOutput1:SHApe:PULSe:WIDTh 0.0005
SOURce1:LFOutput1:SHApe:PULSe:DCYCLe 0.5
// configure the signal of the LF1 generator
SOURce1:LFOutput2:SHApe SINE
SOURce1:LFOutput2:FREQuency 1000000
SOURce1:LFOutput2:PERiod?
// 0.000001

// changing the LF signal shape
// SOURce1:LFOutput2:SHApe TRAP
// SOURce1:LFOutput2:SHApe:PULSe:PERiod 0.2
// SOURce1:LFOutput2:SHApe:TRAPeZe:RISE 0.0001
// SOURce1:LFOutput2:SHApe:TRAPeZe:FALL 0.001
// SOURce1:LFOutput2:SHApe:TRAPeZe:FALL 0.0001
// SOURce1:LFOutput2:SHApe:TRAPeZe:HIGH 0.0005
// SOURce1:LFOutput2:SHApe TRI
// SOURce1:LFOutput2:SHApe:PULSe:PERiod 0.1
// SOURce1:LFOutput2:SHApe:TRIangle:RISE 0.0001

// activate the LF output and select the LF1 as signal source
// configure the LF output signal
SOURce1:LFOutput1:FREQuency:MODE CW
SOURce1:LFOutput1:STATe 1
SOURce1:LFOutput1:SOURce LF1
SOURce1:LFOutput1:INTernal:VOLTagE 1
SOURce1:LFOutput1:OFFSet 0.001

```

- [LF Generator Settings](#).....605
- [LF Sweep Settings](#).....613

14.16.6.1 LF Generator Settings

With the commands described in this section, you can configure the LF signal source.

[:SOURce]:LFOutput<ch>:BANDwidth?	606
[:SOURce]:LFOutput<ch>:FREQuency	606
[:SOURce<hw>]:LFOutput<ch>:PERiod?	606
[:SOURce<hw>]:LFOutput:FREQuency:MANual	607
[:SOURce<hw>]:LFOutput:FREQuency:MODE	607
[:SOURce<hw>]:LFOutput:FREQuency:STOP	608
[:SOURce<hw>]:LFOutput:FREQuency:START	608
[:SOURce]:LFOutput<ch>[:STATe]	608
[:SOURce]:LFOutput<ch>:INTernal:VOLTagE	608
[:SOURce]:LFOutput:OFFSet	609
[:SOURce]:LFOutput<ch>:SOURce	609
[:SOURce]:LFOutput<ch>:SOURce:PATH	609
[:SOURce]:LFOutput:VOLTagE	610
[:SOURce<hw>]:LFOutput<ch>:SHApe	610
[:SOURce<hw>]:LFOutput<ch>:SHApe:PULSe:DCYCLe	610
[:SOURce<hw>]:LFOutput<ch>:SHApe:PULSe:PERiod	610

<code>[:SOURce<hw>]:LFOutput<ch>:SHAPE:PULSE:WIDTH</code>	611
<code>[:SOURce<hw>]:LFOutput<ch>:SHAPE:TRAPeZe:FALL</code>	611
<code>[:SOURce<hw>]:LFOutput<ch>:SHAPE:TRAPeZe:HIGH</code>	611
<code>[:SOURce<hw>]:LFOutput<ch>:SHAPE:TRAPeZe:PERiod</code>	611
<code>[:SOURce<hw>]:LFOutput<ch>:SHAPE:TRAPeZe:RISE</code>	612
<code>[:SOURce<hw>]:LFOutput<ch>:SHAPE:TRiangle:PERiod</code>	612
<code>[:SOURce<hw>]:LFOutput<ch>:SHAPE:TRiangle:RISE</code>	612

`[:SOURce]:LFOutput<ch>:BANDwidth?`

Queries the bandwidth of the external LF signal.

Return values:

<Bandwidth> BW0M2 | BW10m
 *RST: BW10m

Example:

```
LFO:BAND?
// BW10m
// the bandwidth of the externally supplied LF signal is 10 MHz
```

Usage: Query only

Manual operation: See "[Bandwidth](#)" on page 105

`[:SOURce]:LFOutput<ch>:FREQuency <Frequency>`

Sets the frequency of the LF signal in `[:SOURce<hw>]:LFOutput:FREQuency:MODE` CW | FIXed mode.

Note

- If signal source "Internal" is set, the instrument performs the analog modulations (AM/FM/PhiM/PM) with this frequency.
- In sweep mode (`[:SOURce<hw>]:LFOutput:FREQuency:MODE` SWE), the frequency is coupled with the sweep frequency.

Parameters:

<Frequency> float
 Range: depends on the installed options
 *RST: 1000
 Default unit: Hz

Example:

```
SOURce1:LFOutput1:FREQuency 5 kHz
// sets the LF frequency
```

Manual operation: See "[Frequency](#)" on page 102

`[:SOURce<hw>]:LFOutput<ch>:PERiod?`

Queries the repetition frequency of the sine signal.

Return values:

<LfSinePeriod> float
 Range: 1E-6 to 100
 Increment: 10E-9
 *RST: 0.001
 Default unit: s

Example: See [Example "Configuring the LF generator"](#) on page 604.

Usage: Query only

[:SOURce<hw>]:LFOutput:FREQUENCY:MANual <Manual>

Sets the frequency of the subsequent sweep step if [LFO:SWE:MODE MAN](#).

Use a separate command for each sweep step.

Parameters:

<Manual> float
 You can select any value within the setting range, where:
 START is set with [\[:SOURce<hw> \]:LFOutput:FREQUENCY:START](#)
 STOP is set with [\[:SOURce<hw> \]:LFOutput:FREQUENCY:STOP](#)
 Range: START to STOP
 Increment: 0.1
 *RST: 1000

Example: See [Example "Setup an LF sweep"](#) on page 603.

Manual operation: See [" Current Frequency"](#) on page 175

[:SOURce<hw>]:LFOutput:FREQUENCY:MODE <Mode>

Sets the mode for the output of the LF generator frequency, and determines the commands to be used for frequency settings.

Parameters:

<Mode> CW | FIXed | SWEep
CW|FIXed
 Sets the fixed-frequency mode. CW and FIXed are synonyms.
 To set the output frequency, use command [\[:SOURce \]:LFOutput<ch>:FREQUENCY](#)
SWEep
 Sets sweep mode.
 To set the frequency, use the commands:
[\[:SOURce<hw> \]:LFOutput:FREQUENCY:START](#) and [\[:SOURce<hw> \]:LFOutput:FREQUENCY:STOP](#)
 Or [\[:SOURce<hw> \]:LFOutput:FREQUENCY:MANual](#)
 *RST: CW

Example: See [Example "Setup an LF sweep"](#) on page 603.

Manual operation: See ["State \(LF frequency sweep\)"](#) on page 100

[:SOURce<hw>]:LFOutput:FREQuency:STOP <Stop>

[:SOURce<hw>]:LFOutput:FREQuency:STARt <Start>

Sets the start/stop frequency for [\[:SOURce<hw>\]:LFOutput:FREQuency:MODE](#) SWEep.

Parameters:

<Start> float
 Range: 0.1 Hz to 1 MHz
 Increment: 0.1
 *RST: 1 KHz

<Stop> float
 Range: 0.1 Hz to 1 MHz
 Increment: 0.1 Hz
 *RST: 100 KHz

Example: See [Example "Setup an LF sweep"](#) on page 603.

Manual operation: See [" Start Frequency/Stop Frequency "](#) on page 179

[:SOURce]:LFOutput<ch>[:STATe] <State>

Activates LF signal output.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 0

Example: See [Example "Configuring the LF generator"](#) on page 604.

Manual operation: See ["State"](#) on page 107

[:SOURce]:LFOutput<ch>:INTernal:VOLTage <Voltage>

Sets the output voltage for the LF generators.

The sum of both values must not exceed the overall output voltage, set with command [\[:SOURce\]:LFOutput:VOLTage](#).

Suffix:

<ch> [1]2
 LF1 and LF2

Parameters:

<Voltage> float
 Range: 0 to 4
 Increment: 0.001
 *RST: 1

Example: See [Example "Configuring the LF generator"](#) on page 604.

Manual operation: See ["Output Voltage"](#) on page 107

[[:SOURce]:LFOutput:OFFSet <Offset>

Sets a DC offset at the LF Output.

Parameters:

<Offset> float
 Range: depends on lfo voltage
 Increment: 0.001
 *RST: 0

Example: See [Example "Configuring the LF generator"](#) on page 604.

Manual operation: See ["DC-Offset"](#) on page 107

[[:SOURce]:LFOutput<ch>:SOURce <Source>

Determines the LF signal to be synchronized, when monitoring is enabled.

Parameters:

<Source> LF1 | LF2 | NOISe | AM | FMPM | EXT1 | | EXT2
LF1|LF2
 Selects an internally generated LF signal.
NOISe
 Selects an internally generated noise signal.
EXT1|EXT2
 Selects an externally supplied LF signal
AM
 Selects the AM signal.
FMPM
 Selects the signal also used by the frequency or phase modulations.
 *RST: LF1

Example: See [Example "Configuring the LF generator"](#) on page 604.

Manual operation: See ["Source"](#) on page 107

[[:SOURce]:LFOutput<ch>:SOURce:PATH <SourPath>

Determines the path of the LF output source.

Parameters:

<SourPath> A | B
 *RST: A

Example: LFO:SOUR:PATH?
 Queries the currently set path for the LF output signal source.

[[:SOURce]:LFOutput:VOLTage <Voltage>

Sets the voltage of the LF output.

Parameters:

<Voltage> float
 Range: dynamic (see data sheet)
 Increment: 0.001
 *RST: 1

Example: SOURce:LFOutput:VOLTage 1.5

[[:SOURce<hw>]:LFOutput<ch>:SHAPE <Shape>

Selects the waveform shape of the LF signal.

Parameters:

<Shape> SINE | SQUARE | TRIangle | TRAPEze | PULS
 *RST: SINE

Example: See [Example "Configuring the LF generator"](#) on page 604.

Options: TRIangle|TRAPEze require R&S SMAB-K24

Manual operation: See ["Shape"](#) on page 101

[[:SOURce<hw>]:LFOutput<ch>:SHAPE:PULSE:DCYCLE <DCycle>

Sets the duty cycle for the shape pulse.

Parameters:

<DCycle> float
 Range: 1E-6 to 100
 Increment: 1E-6
 *RST: 50
 Default unit: PCT

Example: See [Example "Configuring the LF generator"](#) on page 604.

Manual operation: See ["Pulse Duty Cycle"](#) on page 103

[[:SOURce<hw>]:LFOutput<ch>:SHAPE:PULSE:PERIOD <Period>

Sets the period of the generated pulse. The period determines the repetition frequency of the internal signal.

Parameters:

<Period> float
 Range: 1E-6 to 100
 Increment: 1E-8
 *RST: 1E-3

Example: See [Example "Configuring the LF generator"](#) on page 604.

Manual operation: See ["Period"](#) on page 102

[:SOURce<hw>]:LFOuTput<ch>:SHAPE:PULSe:WIDTh <Width>

Sets the pulse width of the generated pulse.

Parameters:

<Width>	float
Range:	1E-6 to 100
Increment:	1E-8
*RST:	5E-4

Example: See [Example "Configuring the LF generator"](#) on page 604.

Manual operation: See ["Pulse Width"](#) on page 102

[:SOURce<hw>]:LFOuTput<ch>:SHAPE:TRAPeZe:FALL <Fall>

Selects the fall time for the trapezoid shape of the LF generator.

Parameters:

<Fall>	float
Range:	1E-6 to 100
Increment:	10E-9
*RST:	250E-6

Example: See [Example "Configuring the LF generator"](#) on page 604.

Manual operation: See ["Trapezoid Rise / Fall"](#) on page 103

[:SOURce<hw>]:LFOuTput<ch>:SHAPE:TRAPeZe:HIGh <High>

Sets the high time for the trapezoid signal of the LF generator.

Parameters:

<High>	float
Range:	1E-6 to 100
Increment:	10E-9
*RST:	250E-6

Example: See [Example "Configuring the LF generator"](#) on page 604.

Manual operation: See ["Trapezoid High"](#) on page 103

[:SOURce<hw>]:LFOuTput<ch>:SHAPE:TRAPeZe:PERiod <Period>

Sets the period of the generated trapezoid shape. The period determines the repetition frequency of the internal signal.

Parameters:

<Period> float
 Range: 1E-6 to 100
 Increment: 1E-8
 *RST: 1E-3

Example: See [Example "Configuring the LF generator"](#) on page 604.

Manual operation: See ["Period"](#) on page 102

[:SOURce<hw>]:LFOutput<ch>:SHAPE:TRAPeZe:RISE <Rise>

Selects the rise time for the trapezoid shape of the LF generator.

Parameters:

<Rise> float
 Range: 1E-6 to 100
 Increment: 10E-9
 *RST: 250E-6

Example: See [Example "Configuring the LF generator"](#) on page 604.

Manual operation: See ["Trapezoid Rise / Fall"](#) on page 103

[:SOURce<hw>]:LFOutput<ch>:SHAPE:TRlangle:PERiod <Period>

Sets the period of the generated pulse. The period determines the repetition frequency of the internal signal.

Parameters:

<Period> float
 Range: 1E-6 to 100
 Increment: 10E-9
 *RST: 0.001

Example: See [Example "Configuring the LF generator"](#) on page 604.

Manual operation: See ["Period"](#) on page 102

[:SOURce<hw>]:LFOutput<ch>:SHAPE:TRlangle:RISE <Rise>

Selects the rise time for the triangle single of the LF generator.

Parameters:

<Rise> float
 Range: 1E-6 to 100
 Increment: 10E-9
 *RST: 0.5E-3

Example: See [Example "Configuring the LF generator"](#) on page 604.

Manual operation: See ["Triangle Rise"](#) on page 103

14.16.6.2 LF Sweep Settings

With the commands described in this section, you can configure the sweep of the LF signal.

<code>[:SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:DWEll</code>	613
<code>[:SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:EXECute</code>	613
<code>[:SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:MODE</code>	613
<code>[:SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:POINts</code>	614
<code>[:SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:RETRace</code>	614
<code>[:SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:RUNNing?</code>	615
<code>[:SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:SHAPE</code>	615
<code>[:SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:SPACing</code>	615
<code>[:SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:STEP:LOGarithmic</code>	615
<code>[:SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:STEP:LINear</code>	616

`[:SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:DWEll <Dwell>`

Sets the dwell time for each frequency step of the sweep.

Parameters:

<code><Dwell></code>	float
	Range: 0.001 to 100
	Increment: 100E-6
	*RST: 0.01
	Default unit: s

Example: See [Example "Setup an LF sweep"](#) on page 603.

Manual operation: See [" Dwell Time "](#) on page 177

`[:SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:EXECute`

Immediately starts an LF sweep.

`[:SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:MODE` determines which sweep is executed, e.g. `SOURce:LFOutput:SWEep:FREQUENCY:MODE STEP`.

Example: See [Example "Setup an LF sweep"](#) on page 603.

Usage: Event

Manual operation: See [" Execute Single Sweep "](#) on page 178

`[:SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:MODE <Mode>`

Sets the cycle mode of the LF sweep.

Parameters:

<code><Mode></code>	AUTO MANual STEP
---------------------------	----------------------

AUTO

Performs a complete sweep cycle from the start to the end value when a trigger event occurs.

The dwell time determines the time period until the signal switches to the next step.

MANual

Performs a single sweep step when a manual trigger event occurs.

The trigger system is not active. To trigger each frequency step of the sweep individually, use the command `[:SOURce<hw>] :LFOutput:FREQuency:MANual` on page 607.

STEP

Each trigger command triggers one sweep step only.

The frequency increases by the value set with the coammnds:

`[:SOURce<hw>] :LFOutput:SWEep [:FREQuency] :STEP [:LINear]` (linear spacing)

`[:SOURce<hw>] :LFOutput:SWEep [:FREQuency] :STEP :LOGarithmic` (logarithmic spacing)

*RST: AUTO

Example: See [Example "Setup an LF sweep"](#) on page 603.

Manual operation: See ["Mode"](#) on page 175

[:SOURce<hw>] :LFOutput:SWEep [:FREQuency] :POINts <Points>

Sets the number of steps in an LF sweep.

For information on how the value is calculated and the interdependency with other parameters, see [Chapter 7.2.1, "Correlating Parameters in Sweep Mode"](#), on page 167

Parameters:

<Points> integer
 Range: 2 to POINTs
 *RST: 50

Example: See [Example "Setup an LF sweep"](#) on page 603.

[:SOURce<hw>] :LFOutput:SWEep [:FREQuency] :RETRace <State>

Activates that the signal changes to the start frequency value while it is waiting for the next trigger event.

You can enable this feature, when you are working with sawtooth shapes in sweep mode "Single" or "External Single".

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 0

Manual operation: See ["Retrace"](#) on page 176

[[:SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:RUNNING?

Queries the current status of the LF frequency sweep mode.

Return values:

<State> 0 | 1 | OFF | ON

Example: See [Example "Setup an LF sweep"](#) on page 603.

Usage: Query only

[[:SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:SHAPE <Shape>

Sets the cycle mode for a sweep sequence (shape).

Parameters:

<Shape> SAWTooth | TRIangle
*RST: SAWTooth

Example: See [Example "Setup an LF sweep"](#) on page 603.

Manual operation: See "[Shape](#)" on page 176

[[:SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:SPACING <Spacing>

Selects linear or logarithmic sweep spacing.

Parameters:

<Spacing> LINear | LOGarithmic
*RST: LINear

Example: See [Example "Setup an LF sweep"](#) on page 603.

Manual operation: See "[Spacing](#)" on page 177

**[[:SOURce<hw>]:LFOutput:SWEep[:FREQUENCY]:STEP:LOGarithmic
<Logarithmic>**

Sets the step width factor for logarithmic sweeps to calculate the frequencies of the steps.

For information on how the value is calculated and the interdependency with other parameters, see [Chapter 7.2.1, "Correlating Parameters in Sweep Mode"](#), on page 167

Parameters:

<Logarithmic> float
The unit is mandatory
Range: 0.01 to 100
Increment: 0.01
*RST: 1
Default unit: PCT

Example: See [Example "Setup an LF sweep"](#) on page 603.

Manual operation: See " [Step Linear/Step Logarithmic](#) " on page 180

[:SOURce<hw>]:LFOutput:SWEep[:FREQuency]:STEP[:LINear] <Linear>

Sets the step width for the linear sweep.

For information on how the value is calculated and the interdependency with other parameters, see [Chapter 7.2.1, "Correlating Parameters in Sweep Mode"](#), on page 167

Parameters:

<Linear>	float
	Range: 0.1 to STOP-START
	Increment: 0.1
	*RST: 1000

Example: See [Example "Setup an LF sweep"](#) on page 603.

Manual operation: See " [Step Linear/Step Logarithmic](#) " on page 180

14.16.7 SOURce:LIST Subsystem

The SOURce:LIST subsystem contains all commands for defining lists and for handling of list files.

List files have the predefined file extension *.lsw.

Refer to [Chapter 14.5.2, "Accessing Files in the Default or in a Specified Directory"](#), on page 420 for general information on file handling in the default and in a specific directory.



- *RST does not affect data lists.
 - SCPI refers to the individual lists as segments.
-

Example: Create an RF list and activate the list mode

The following example shows a command sequence to create an RF list and to activate the list mode. Further hardware settings are not considered.

```
// Reset the instrument to start from an initial state
// Query the available list files in the default
// directory /var/user
// Select the list file or create it (if not existing)
*RST; *CLS
SOUR1:LIST:CAT?
// Response:- shows the name of available list files (if applicable)
SOUR1:LIST:SEL "/var/user/list1.lsw"

// Write the frequency/level/dwell time values in the selected list file
// existing data is overwritten
// Query the number of frequency/power/dwell time entries in the selected list
```

```

// Query the amount of free memory (in bytes) for list mode lists
SOUR1:LIST:FREQ 58 MHz, 61 MHz, 73 MHz, 86 MHz, 91 MHz, 92 MHz, 98 MHz
SOUR1:LIST:POW 13 dBm, 12 dBm, 5 dBm, 3 dBm, 0 dBm, 4 dBm, 6 dBm
SOUR1:LIST:DWEL:LIST 10000, 100000, 200000, 19000, 10000, 150000, 220000
SOUR1:LIST:FREQ:POIN?
// 7
SOUR1:LIST:POW:POINT?
// 7
SOUR1:LIST:DWEL:LIST:POIN?
// 7
SOUR1:LIST:FREE?
// 2147483647 (bytes of free memory)

// Use dwell times from list
// Configure the list mode parameters
// Enable RF output
SOUR1:LIST:MODE AUTO
SOUR1:LIST:TRIG:SOUR AUTO
SOUR1:LIST:DWEL:MODE "LIST"

OUTP1:STAT ON

// Use global dwell time
// Set only a part of the list (value pairs 3 to 5) to be processed
// Configure the list mode parameters using global dwell time
// Enable RF output
SOUR1:LIST:IND:START 2
SOUR1:LIST:IND:STOP 4
SOUR1:LIST:MODE AUTO
SOUR1:LIST:TRIG:SOUR AUTO
SOUR1:LIST:DWEL:LIST 500 ms
OUTP1:STAT ON

// Enable the list mode
// Trigger the list (depending on the mode, not needed with trigger
// mode AUTO); query the current index
// Reset the list to the starting point
SOUR1:FREQ:MODE LIST
SOUR1:LIST:TRIG:EXEC
SOUR1:LIST:RUNN?
SOUR1:LIST:IND?
// 3
// value changes when the value is queried again
SOUR1:LIST:RES

// For list mode STEP use the following commands
*RST; *CLS
// Change list mode to STEP
SOUR1:LIST:MODE STEP
// Activate RF Output1
OUTP1:STAT 1

```

```

// Activate the list mode
SOUR1:FREQ:MODE LIST
// For each step: select frequency/powerlevel pair as index from the list
SOUR1:LIST:IND 2
SOUR1:LIST:IND 3
SOUR1:LIST:IND 4

// Use the selected list for path B (with List Mode B default settings)
SOUR2:LIST:SEL "/var/user/list1.lsw"
OUTP2:STAT ON
SOUR2:FREQ:MODE LIST
SOUR2:LIST:IND?
// 2
// value changes when the value is queried again

// Deactivate the list mode
SOUR1:FREQ:MODE CW

```

Example: List mode data exchange

The following example shows a command sequence to export a list (here the RF list created with the example before) into an ASCII file. Further hardware settings are not considered.

```

*RST; *CLS
LIST:DEXC:MODE EXP

// Set ASCII data parameters
// Set the ASCII file extension, the decimal separator
// and the column separator for the ASCII data
SOUR1:LIST:DEXC:AFIL:EXT CSV
SOUR1:LIST:DEXC:AFIL:SEP:DEC DOT
SOUR1:LIST:DEXC:AFIL:SEP:COL COMM

// Select source and destination path/directory
// Query available listfiles in default directory "/var/user"
SOUR1:LIST:CAT?
// list1
SOUR1:LIST:DEXC:AFIL:SEL "/var/user/list1ASCII"
SOUR1:LIST:DEXC:SEL "/var/user/list1"

// Export the list file data into the ASCII file
SOUR1:LIST:DEXC:EXEC

// Query the available ASCII files with extension .csv
SOUR1:LIST:DEXC:AFIL:CAT?
// Response: "list1ASCII"

// Deactivate the list mode
SOUR1:FREQ:MODE CW

```

- [List Mode Settings](#).....619
- [List Mode File Operation](#).....624
- [List Mode Data Exchange](#).....626

14.16.7.1 List Mode Settings

With the following commands, you can create list mode data, select the trigger mode and determine the dwell time.

[:SOURce<hw>]:LIST:DWELL	619
[:SOURce<hw>]:LIST:DWELL:MODE	619
[:SOURce<hw>]:LIST:DWELL:LIST	620
[:SOURce<hw>]:LIST:DWELL:LIST:POINts?	620
[:SOURce<hw>]:LIST:FREQUency	620
[:SOURce<hw>]:LIST:FREQUency:POINts?	621
[:SOURce<hw>]:LIST:INDex	621
[:SOURce<hw>]:LIST:INDex:START	621
[:SOURce<hw>]:LIST:INDex:STOP	621
[:SOURce<hw>]:LIST:MODE	622
[:SOURce<hw>]:LIST:POWEr	622
[:SOURce<hw>]:LIST:POWEr:POINts?	623
[:SOURce<hw>]:LIST:TRIGGer:EXECute	623
[:SOURce<hw>]:LIST:TRIGGer:SOURce	623
[:SOURce<hw>]:LIST:RUNNing?	624

[:SOURce<hw>]:LIST:DWELL <Dwell>

Sets the global dwell time. The instrument generates the signal with the frequency / power value pairs of each list entry for that particular period.

See also [Significant Parameters and Functions](#).

Parameters:

<Dwell>	float
	Range: 1E-3 to 100
	Increment: 1E-6
	*RST: 0.01

Example: See [Example "Create an RF list and activate the list mode"](#) on page 616.

Manual operation: See ["Global Dwell Time"](#) on page 187

[:SOURce<hw>]:LIST:DWELL:MODE <DwellMode>

Selects the dwell time mode.

Parameters:

<DwellMode>	LIST GLOBal
-------------	---------------

LIST

Uses the dwell time, specified in the data table for each value pair individually.

GLOBAL

Uses a constant dwell time, set with command [:

[SOURce<hw>\]:LIST:DWELL](#).

*RST: GLOBAL

Example: See [Example "Create an RF list and activate the list mode"](#) on page 616.

Manual operation: See ["Dwell Time Mode"](#) on page 187

[:SOURce<hw>]:LIST:DWELL:LIST <Dwell>

Enters the dwell time values in the selected list in μ s.

Parameters:

<Dwell> <Dwell#1>{, <Dwell#2>, ...} | block data

You can either enter the data as a list of numbers, or as binary block data. The list of numbers can be of any length, with the list entries separated by commas.

In binary block format, 8 (4) bytes are always interpreted as a floating-point number with double accuracy. See also :

[FORMat \[:DATA\]](#) on page 444 for more details.

Example: See [Example "Create an RF list and activate the list mode"](#) on page 616.

Manual operation: See ["Edit List Mode Data"](#) on page 193

[:SOURce<hw>]:LIST:DWELL:LIST:POINTS?

Queries the number (points) of dwell time entries in the selected list.

Return values:

<Points> integer

Range: 0 to INT_MAX

*RST: 0

Example: See [Example "Create an RF list and activate the list mode"](#) on page 616.

Usage: Query only

[:SOURce<hw>]:LIST:FREQUENCY <Frequency>

Enters the frequency values in the selected list.

Parameters:

<Frequency> <Frequency#1>{, <Frequency#2>, ...} | block data

You can either enter the data as a list of numbers, or as binary block data.

The list of numbers can be of any length, with the list entries separated by commas.

In binary block format, 8 (4) bytes are always interpreted as a floating-point number with double accuracy.

See also :FORMat [:DATA] .

Range: 300 kHz to RFmax (depends on the installed options)

Example: See [Example "Create an RF list and activate the list mode"](#) on page 616.

Manual operation: See ["Edit List Mode Data"](#) on page 193

[:SOURce<hw>]:LIST:FREQuency:POINts?

Queries the number (points) of frequency entries in the selected list.

Return values:

<Points> integer
 Range: 0 to INT_MAX
 *RST: 0

Example: See [Example "Create an RF list and activate the list mode"](#) on page 616.

Usage: Query only

[:SOURce<hw>]:LIST:INDex <Index>

Sets the list index in [LIST:MODE STEP](#).

After the trigger signal, the instrument processes the frequency and level settings of the selected index.

Parameters:

<Index> integer
 *RST: 0

Example: See [Example "Create an RF list and activate the list mode"](#) on page 616.

Manual operation: See ["Current Index"](#) on page 186

[:SOURce<hw>]:LIST:INDex:STARt <Start>

[:SOURce<hw>]:LIST:INDex:STOP <Stop>

Sets the start and stop index of the index range which defines a subgroup of frequency/level value pairs in the current list.

Parameters:

<Start>/<Stop> integer
 Index range
 Only values inside this range are processed in list mode
 Range: 0 to list length
 *RST: 0

Example: See [Example "Create an RF list and activate the list mode"](#) on page 616.

Manual operation: See "[List Range from/to](#)" on page 189

[:SOURce<hw>]:LIST:MODE <Mode>

Sets the list mode.

The instrument processes the list according to the selected mode and trigger source, see [LIST:TRIG:SOUR AUTO](#), [SING](#) or [EXT](#).

Parameters:

<Mode> AUTO | STEP
AUTO
 Each trigger event triggers a complete list cycle.
STEP
 Each trigger event triggers only one step in the list processing cycle. The list is processed in ascending order.
 In this mode, you can select between [LIST:TRIG:SOUR SING](#) or [EXT](#).
 *RST: AUTO

Example: See [Example "Create an RF list and activate the list mode"](#) on page 616.

Manual operation: See "[Mode](#)" on page 187

[:SOURce<hw>]:LIST:POWer <Power>

Enters the level values in the selected list. The number of level values must correspond to the number of frequency values. Existing data is overwritten.

Parameters:

<Power> <Power#1>{, <Power#2>, ...} | block data
 You can either enter the data as a list of numbers, or as binary block data.
 The list of numbers can be of any length, with the list entries separated by commas.
 In binary block format, 8 (4) bytes are always interpreted as a floating-point number with double accuracy.
 See also [:FORMat \[:DATA \]](#).
 Range: depends on the installed options

Default unit: dBm

Example: See [Example "Create an RF list and activate the list mode"](#) on page 616.

Manual operation: See ["Edit List Mode Data"](#) on page 193

[:SOURce<hw>]:LIST:POWer:POINts?

Queries the number (points) of level entries in the selected list.

Return values:

<Points> integer
 Range: 0 to INT_MAX
 *RST: 0

Example: See [Example "Create an RF list and activate the list mode"](#) on page 616.

Usage: Query only

[:SOURce<hw>]:LIST:TRIGger:EXECute

Starts the processing of a list in list mode.

Example: See [Example "Create an RF list and activate the list mode"](#) on page 616.

Usage: Event

Manual operation: See ["Execute Single"](#) on page 188

[:SOURce<hw>]:LIST:TRIGger:SOURce <Source>

Selects the trigger source for processing lists.

The names of the parameters correspond to those in sweep mode. SCPI standard uses other names for the parameters; these names are also accepted by the instrument. The SCPI names should be used if compatibility is an important consideration. For an overview, see the following table:

Rohde & Schwarz name	SCPI name	Command in manual control
AUTO	IMMEDIATE	MODE AUTO
SINGLE	BUS	MODE SINGLE or STEP
EXTernal	EXTernal	MODE EXT TRIG SINGLE or EXT TRIG STEP

Parameters:

<Source> SINGLE | BUS | AUTO | EXTernal | IMMEDIATE

AUTO|IMMEDIATE

The trigger is free-running, i.e. the trigger condition is fulfilled continuously. The selected list is restarted as soon as it is finished.

SINGLE|BUS

The list is triggered by the command `[:SOURce<hw>] :LIST:TRIGger:EXECute`. The list is executed once.

EXTERNAL

The list is triggered externally and executed once.

*RST: AUTO

Example: See [Example "Create an RF list and activate the list mode"](#) on page 616.

Manual operation: See ["Mode"](#) on page 187

[:SOURce<hw>] :LIST:RUNNING?

Queries the current state of the list mode.

Return values:

<State> 0 | 1 | OFF | ON

1

Signal generation based on the list mode is active.

Example: See [Example "Create an RF list and activate the list mode"](#) on page 616.

Usage: Query only

14.16.7.2 List Mode File Operation

The following section covers basic commands to file handling in list mode.

<code>[:SOURce<hw>] :LIST:CATalog?</code>	624
<code>[:SOURce<hw>] :LIST:DELeTe</code>	625
<code>[:SOURce<hw>] :LIST:DELeTe:ALL</code>	625
<code>[:SOURce<hw>] :LIST:FREE?</code>	625
<code>[:SOURce<hw>] :LIST:RESet</code>	626
<code>[:SOURce<hw>] :LIST:SElect</code>	626

[:SOURce<hw>] :LIST:CATalog?

Queries the available list files in the specified directory.

Return values:

<Catalog> string

List of list filenames, separated by commas

Example: See [Example "Create an RF list and activate the list mode"](#) on page 616.

Usage: Query only

Manual operation: See " [List Mode Data](#) " on page 188

[:SOURce<hw>]:LIST:DELeTe <Filename>

Deletes the specified list.

Setting parameters:

<Filename> string
Filename or complete file path; file extension is optional.

Example: See `[:SOURce<hw>] :LIST:DELeTe:ALL` on page 625.

Usage: Setting only

Manual operation: See " [List Mode Data](#) " on page 188

[:SOURce<hw>]:LIST:DELeTe:ALL

Deletes all lists in the set directory.

This command can only be executed, if:

- No list file is selected.
- List mode is disabled.

Example:

```
SOUR1:LIST:CAT?
// list,my_list
SOUR1:LIST:DEL "/var/user/list1"
SOUR1:LIST:CAT?
// my_list
SOUR1:FREQ:MODE?
// LIST
SOUR1:LIST:SEL?
// /var/user/my_list.lsw
//deactivate list mode
SOUR1:FREQ:MODE CW
SOUR1:LIST:DELeTe:ALL
SOUR1:LIST:CAT?
// -
// all list files are deleted
```

Usage: Event

Manual operation: See " [List Mode Data](#) " on page 188

[:SOURce<hw>]:LIST:FREE?

Queries the amount of free memory (in bytes) for list mode lists.

Return values:

<Free> integer
 Range: 0 to INT_MAX
 *RST: 0

Example: See [Example "Create an RF list and activate the list mode"](#) on page 616.

Usage: Query only

[:SOURce<hw>]:LIST:RESet

Jumps to the beginning of the list.

Example: See [Example "Create an RF list and activate the list mode"](#) on page 616.

Usage: Event

Manual operation: See "[Reset](#)" on page 188

[:SOURce<hw>]:LIST:SElect <Filename>

Selects or creates a data list in list mode.

If the list with the selected name does not exist, a new list is created.

Parameters:

<Filename> string
 Filename or complete file path; file extension can be omitted.

Example: See [Example "Create an RF list and activate the list mode"](#) on page 616.

Manual operation: See "[List Mode Data](#)" on page 188

14.16.7.3 List Mode Data Exchange

With the following commands, you can configure lists in ASCII format and export or import them accordingly.

[:SOURce<hw>]:LIST:DEXChange:AFILe:CATalog?	627
[:SOURce<hw>]:LIST:DEXChange:EXECute	627
[:SOURce<hw>]:LIST:DEXChange:AFILe:EXTension	627
[:SOURce<hw>]:LIST:DEXChange:AFILe:SElect	627
[:SOURce<hw>]:LIST:DEXChange:AFILe:SEParator:COLumn	628
[:SOURce<hw>]:LIST:DEXChange:AFILe:SEParator:DECimal	628
[:SOURce<hw>]:LIST:DEXChange:MODE	628
[:SOURce<hw>]:LIST:DEXChange:SElect	628

[:SOURce<hw>]:LIST:DEXChange:AFILe:CATalog?

Queries the available ASCII files for export or import of list mode data in the current or specified directory.

Return values:

<Catalog> string
List of ASCII files *.txt or *.csv, separated by commas.

Example: See [Example "List mode data exchange"](#) on page 618.

Usage: Query only

Manual operation: See ["Select \(ASCII\) Source/Select \(ASCII\) Destination"](#) on page 96

[:SOURce<hw>]:LIST:DEXChange:EXECute

Executes the import or export of the selected list file, according to the previously set transfer direction with command [:SOURce<hw>]:LIST:DEXChange:MODE

Example: See [Example "List mode data exchange"](#) on page 618.

Usage: Event

Manual operation: See ["Import / Export"](#) on page 96

[:SOURce<hw>]:LIST:DEXChange:AFILe:EXTension <Extension>

Determines the extension of the ASCII file for import or export, or to query existing files.

Parameters:

<Extension> TXT | CSV
*RST: TXT

Example: See [Example "List mode data exchange"](#) on page 618.

Manual operation: See ["ASCII File Settings"](#) on page 95

[:SOURce<hw>]:LIST:DEXChange:AFILe:SELect <Filename>

Selects the ASCII file to be imported or exported.

Parameters:

<Filename> string
Filename or complete file path; file extension can be omitted.

Example: See [Example "List mode data exchange"](#) on page 618.

Manual operation: See ["Select \(ASCII\) Source/Select \(ASCII\) Destination"](#) on page 96

[:SOURce<hw>]:LIST:DEXChange:AFILe:SEParator:COLumn <Column>

Selects the separator between the frequency and level column of the ASCII table.

Parameters:

<Column> TABulator | SEMicolon | COMMa | SPACe
 *RST: COMMa

Example: See [Example "List mode data exchange"](#) on page 618.

Manual operation: See ["ASCII File Settings"](#) on page 95

[:SOURce<hw>]:LIST:DEXChange:AFILe:SEParator:DECimal <Decimal>

Sets "." (decimal point) or "," (comma) as the decimal separator used in the ASCII data with floating-point numerals.

Parameters:

<Decimal> DOT | COMMa
 *RST: DOT

Example: See [Example "List mode data exchange"](#) on page 618.

Manual operation: See ["ASCII File Settings"](#) on page 95

[:SOURce<hw>]:LIST:DEXChange:MODE <Mode>

Determines the import or export of a list.

Specify the source or destination file with the command [\[:SOURce<hw> \]:LIST:DEXChange:SElect](#).

Parameters:

<Mode> IMPort | EXPort
 *RST: IMPort

Example: See [Example "List mode data exchange"](#) on page 618.

Manual operation: See [" Mode "](#) on page 95

[:SOURce<hw>]:LIST:DEXChange:SElect <Filename>

Selects the ASCII file for import or export, containing a list.

Parameters:

<Filename> string
 Filename or complete file path; file extension can be omitted.

Example: See [Example "List mode data exchange"](#) on page 618.

Manual operation: See ["Select Source/Select ASCII Destination"](#) on page 96

14.16.8 SOURce:NOISe Subsystem

The SOURce:NOISe subsystem contains the commands for:

- Setting the noise modulation signal. The noise generator is optional.

Example: Configuring the noise generator

```
SOURce1:NOISe:DISTRibution GAUSS
SOURce1:NOISe:BANDwidth 10000000
SOURce1:NOISe:BANDwidth:STATe 1
```

```
SOURce1:LFOutput1:SOURce NOIS
SOURce1:LFOutput1:STATe 1
```

```
SOURce1:NOISe:LEVel:RELative?
// -83.86
SOURce1:NOISe:LEVel:ABSolute?
// -13.86
```

- [Noise Generator](#).....629

14.16.8.1 Noise Generator

[:SOURce<hw>]:NOISe:BANDwidth BWIDth	629
[:SOURce<hw>]:NOISe:BWIDth:STATe	629
[:SOURce<hw>]:NOISe:DISTRibution	630
[:SOURce<hw>]:NOISe:LEVel:RELative?	630
[:SOURce<hw>]:NOISe:LEVel[:ABSolute]?	630

[:SOURce<hw>]:NOISe:BANDwidth|BWIDth <BWidth>

Sets the noise level in the system bandwidth when bandwidth limitation is enabled.

Parameters:

<BWidth>	float
Range:	100E3 to 10E6
Increment:	100E3
*RST:	100E3

Example: See [Example "Configuring the noise generator"](#) on page 629.

Manual operation: See ["Bandwidth"](#) on page 105

[:SOURce<hw>]:NOISe:BWIDth:STATe <State>

Activates noise bandwidth limitation.

Parameters:

<State>	0 1 OFF ON
*RST:	0

Example: See [Example "Configuring the noise generator"](#) on page 629.

Manual operation: See ["Bandwidth"](#) on page 105

[:SOURce<hw>]:NOISe:DISTRibution <Distribution>

Sets the distribution of the noise power density.

Parameters:

<Distribution> GAUSs | EQUal
 *RST: GAUSs

Example: See [Example "Configuring the noise generator"](#) on page 629.

Manual operation: See ["Distribution"](#) on page 105

[:SOURce<hw>]:NOISe:LEVel:RELative?

Queries the level of the noise signal per Hz in the total bandwidth.

Return values:

<Relative> float
 Range: -149.18 to -52.67
 Increment: 0.1
 *RST: -69.84

Example: See [Example "Configuring the noise generator"](#) on page 629.

Usage: Query only

Manual operation: See ["Noise Density"](#) on page 108

[:SOURce<hw>]:NOISe:LEVel[:ABSolute]?

Queries the level of the noise signal in the system bandwidth within the enabled bandwidth limitation.

Return values:

<Absolute> float
 Noise level within the bandwidth limitation
 *RST: 3.84 MHz

Example: See [Example "Configuring the noise generator"](#) on page 629.

Usage: Query only

Manual operation: See ["Noise Level"](#) on page 108

14.16.9 SOURce:PGEN Subsystem

The PGEN subsystem contains the commands for setting output of the pulse modulation signal.

Example: Using pulse generator as source for pulse modulation

```
// select pulse generator as source for pulse modulation
// enable pulse modulation
SOURce1:PULM:SOURce INT
SOURce1:PULM:STATe 1
// pulse generator and signal output are also activated
SOURce1:PGENerator:STATe?
// 1
SOURce1:PGENerator:OUTPut:STATe?
// 1
PGENerator:OUTPut:POLarity NORMal
// to disable pulse generator
SOURce1:PGENerator:STATe 0
// activate the pulse modulation of the RF carrier
SOURce1:PULM:STATe 1
```

[:SOURce<hw>]:PGENerator:OUTPut:POLarity	631
[:SOURce<hw>]:PGENerator:OUTPut[:STATe]	631
[:SOURce<hw>]:PGENerator:STATe	632

[:SOURce<hw>]:PGENerator:OUTPut:POLarity <Polarity>

Sets the polarity of the pulse output signal.

Parameters:

<Polarity> NORMal | INVerted

NORMal

Outputs the pulse signal during the pulse width, that means during the high state.

INVerted

Inverts the pulse output signal polarity. The pulse output signal is suppressed during the pulse width, but provided during the low state.

*RST: NORMal

Example: See [Example "Using pulse generator as source for pulse modulation"](#) on page 631.

Manual operation: See ["Pulse Output Polarity"](#) on page 90

[:SOURce<hw>]:PGENerator:OUTPut[:STATe] <State>

Activates the output of the pulse modulation signal.

Parameters:

<State> 0 | 1 | OFF | ON

*RST: 0

Example: See [Example "Using pulse generator as source for pulse modulation"](#) on page 631.

Manual operation: See ["Pulse Output State"](#) on page 90

[:SOURce<hw>]:PGENERator:STATe <State>

Enables the output of the video/sync signal.

If the pulse generator is the current modulation source, activating the pulse modulation automatically activates the signal output and the pulse generator.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 0

Example: See [Example "Using pulse generator as source for pulse modulation"](#) on page 631.

14.16.10 SOURce:PHASe Subsystem

This subsystem contains the commands for adjusting the phase of the RF output signal relative to a reference signal of the same frequency.

Example: Programming Example

```
// change the phase relative to the current phase
SOURce1:PHASe 2 DEG
// adopt the setting as the current phase
SOURce1:PHASe:REFerence
```

The following commands are available:

[:SOURce<hw>]:PHASe	632
[:SOURce<hw>]:PHASe:REFerence	632

[:SOURce<hw>]:PHASe <Phase>

Sets the phase variation relative to the current phase.

Parameters:

<Phase> float
 Range: -36000 to 36000
 Increment: 0.001
 *RST: 0
 Default unit: DEG

Example: See [Example "Programming Example"](#) on page 632.

Manual operation: See ["Delta Phase"](#) on page 73

[:SOURce<hw>]:PHASe:REFerence

Assigns the value set with command [\[:SOURce<hw>\]:PHASe](#) as the reference phase.

- Example:** See [Example "Programming Example"](#) on page 632.
- Usage:** Event
- Manual operation:** See ["Reset Delta Phase Display"](#) on page 73

14.16.11 SOURce:POWer Subsystem

The SOURce:POWer subsystem contains the commands for setting the output level, level control and level correction of the RF signal.

The default units are dBm. To change the units, perform one of the following:

- Enter the unit after the numerical value
Example: :POW 0.5V
- Set the unit with the command :UNIT:POWer.

[:SOURce<hw>]:POWer:ALC[:STATe]	633
[:SOURce<hw>]:POWer:ALC:DSENSitivity	634
[:SOURce<hw>]:POWer:ALC:SONCe	634
[:SOURce<hw>]:POWer:ATTenuation:PATTenuator	635
[:SOURce<hw>]:POWer:ATTenuation:RFOFF:MODE	635
[:SOURce<hw>]:POWer:EMF:STATe	635
[:SOURce<hw>]:POWer:LBEHaviour	636
[:SOURce<hw>]:POWer:LIMit[:AMPLitude]	636
[:SOURce<hw>]:POWer:LMOde	636
[:SOURce<hw>]:POWer:MANual	637
[:SOURce<hw>]:POWer:MODE	637
[:SOURce<hw>]:POWer:POWer	638
[:SOURce<hw>]:POWer:START	638
[:SOURce<hw>]:POWer:STOP	638
[:SOURce<hw>]:POWer:STEP:MODE	639
[:SOURce<hw>]:POWer:STEP[:INCRement]	639
[:SOURce<hw>]:POWer[:LEVel][:IMMEDIATE]:OFFSet	639
[:SOURce<hw>]:POWer[:LEVel][:IMMEDIATE]:RCL	640
[:SOURce<hw>]:POWer[:LEVel][:IMMEDIATE][:AMPLitude]	640
[:SOURce<hw>]:POWer:RANGe:LOWer?	641
[:SOURce<hw>]:POWer:RANGe:UPPer?	641
[:SOURce]:POWer:WIGNore	641

[\[:SOURce<hw>\]:POWer:ALC\[:STATe\] <State>](#)

Parameters:

<State> 0 | OFF | AUTO | 1 | ON | ONTable | PRESet | OFFTable

AUTO

Adjusts the output level to the operating conditions automatically.

1|ON

Activates internal level control permanently.

OFFTable

Controls the level using attenuation values of the internal ALC table.

0|OFF

Provided only for backward compatibility with other Rohde & Schwarz signal generators.

The R&S SMA100B accepts these values and maps them automatically as follows:

0|OFF = OFFTable

ONTable

Starts with the attenuation setting from the table and continues with automatic level control.

*RST: AUTO

Example:

POW:ALC ON

Activates internal level control.

Manual operation: See ["State"](#) on page 201

[:SOURce<hw>]:POWer:ALC:DSENSitivity <Sensitivity>

Sets the sensitivity of the ALC detector.

Parameters:

<Sensitivity> AUTO | FIXed

AUTO

Selects the optimum sensitivity automatically.

FIXed

Fixes the internal level detector.

*RST: AUTO

Example:

POW:ALC:DSEN FIX

Manual operation: See ["Detector Sensitivity"](#) on page 202

[:SOURce<hw>]:POWer:ALC:SONCe

Activates level control for correction purposes temporarily.

Example:

POW:ALC OFF

Deactivates automatic level control at the RF output.

POW:ALC:SONC

Executes level control (once).

Usage:

Event

Manual operation: See ["Readjust"](#) on page 72

[[:SOURce<hw>]:POWER:ATTenuation:PATTenuator <StepAttSel>

Selects the type of step attenuator used below 20 GHz.

Parameters:

<StepAttSel> MECHanical | ELECTronic

MECHanical

Uses the mechanical step attenuator over the all frequencies.

ELECTronic

Uses the electronic step attenuator up to 20 GHz.

Options: R&S SMAB-B35/-B37/-B39

Manual operation: See "[Step Attenuator below 20 GHz](#)" on page 199

[[:SOURce<hw>]:POWER:ATTenuation:RFOff:MODE <Mode>

Selects the state the attenuator is to assume if the RF signal is switched off.

Parameters:

<Mode> UNCHanged | FATTenuation

FATTenuation

The step attenuator switches to maximum attenuation

UNCHanged

Retains the current setting and keeps the output impedance constant during RF off.

*RST: n.a. (factory preset: FATTenuation)

Example:

```
SOURce1:POWER:ATTenuation:RFOff:MODE
FATTenuation
```

uses maximum attenuation when the RF output is turned off.

Manual operation: See "[RF OFF Mode](#)" on page 199

[[:SOURce<hw>]:POWER:EMF:STATE <State>

Displays the signal level as voltage of the EMF. The displayed value represents the voltage over a 50 Ohm load.

Parameters:

<State> 0 | 1 | OFF | ON

*RST: n.a. (factory preset: 0)

Example:

```
POW:EMF:STAT 1
```

Activates voltage level display.

Manual operation: See "[Display Level as Voltage of EMF](#)" on page 325

[[:SOURce<hw>]:POWER:LBEHaviour <Behaviour>**Parameters:**

<Behaviour> AUTO | UNINterrupted | MONotone | CVSWr | HDUN

UNINterrupted|MONotone
Uninterrupted level settings and strictly monotone modes.

CVSWr
Constant VSWR

HDUN
High dynamic uninterrupted level settings.

*RST: AUTO

Example: SOURce1:POWER:LBEHaviour AUTO

Options: R&S SMAB-K724

Manual operation: See " [Setting Characteristics](#) " on page 70

[[:SOURce<hw>]:POWER:LIMit[:AMPLitude] <Amplitude>

Limits the maximum RF output level in CW and sweep mode.

It does not influence the "Level" display or the response to the query [[:SOURce<hw>]:POWER[:LEVel] [:IMMediate] [:AMPLitude].

Parameters:

<Amplitude> float

Range: depends on the installed options

Increment: 0.01

*RST: n.a. (factory preset: 30)

Example: SOURce1:POWER:LIMit:AMPLitude 10

Manual operation: See " [Limit](#) " on page 70

[[:SOURce<hw>]:POWER:LMODe <LevMode>

Sets the RF level mode.

Parameters:

<LevMode> NORMal | LOWNoise | LOWDistortion

NORMal
Supplies the RF signal with the standard power level of the instrument.

LOWNoise
Supplies a very low noise sinewave signal.

LOWDistortion
Supplies a very pure sinewave signal.

*RST: NORMal

Example: `SOURce1:POWer:LMODe LOWD`
Sets low distortion mode. The instrument reduces distortions of the RF signal to a minimum.

Manual operation: See " [Mode](#) " on page 71

`[:SOURce<hw>]:POWer:MANual <Manual>`

Sets the level for the subsequent sweep step if `SWE:POW:MODE MAN`.

Use a separate command for each sweep step.

Parameters:

<Manual> float

You can select any level within the setting range, where:

`START` is set with `[:SOURce<hw>] :POWer:STARt`

`STOP` is set with `[:SOURce<hw>] :POWer:STOP`

`OFFSet` is set with `[:SOURce<hw>] :POWer [:LEVel] [:IMMediate] :OFFSet`

Range: (START + OFFSet) to (STOP + OFFSet)

Increment: 0.01

Default unit: dBm

Example: See [Example "Setup an RF frequency or power sweep"](#) on page 647

Manual operation: See " [Current Level](#) " on page 175

`[:SOURce<hw>]:POWer:MODE <Mode>`

Selects the operating mode of the instrument to set the output level.

Parameters:

<Mode> CW | FIXed | SWEep

CW|FIXed

Operates at a constant level.

CW and FIXed are synonyms.

To set the output level value, use the command `[:SOURce<hw>] :POWer [:LEVel] [:IMMediate] [:AMPLitude]`.

SWEep

Sets sweep mode.

Set the range and current level with the commands:

`[:SOURce<hw>] :POWer:STARt` and `[:SOURce<hw>] :POWer:STOP`,

`[:SOURce<hw>] :POWer:MANual`.

*RST: CW

Example: See [Example "Setup an RF frequency or power sweep"](#) on page 647

Manual operation: See ["State \(RF level sweep\)"](#) on page 174

[:SOURce<hw>]:POWER:POWER <Power>

Sets the level **at the RF output** connector.

This value does not consider a specified offset.

The command `[:SOURce<hw>]:POWER[:LEVel][:IMMediate][:AMPLitude]` sets the level of the "Level" display, that means the level containing offset.

See ["RF frequency and level display with a downstream instrument"](#) on page 64.

Parameters:

<Power> float
 Level at the RF output, without level offset
 Range: See data sheet
 Increment: 0.01
 Default unit: dBm

Example: `SOURce1:POWER:POWER 15`
 Sets the level at RF output

Manual operation: See ["Amplitude"](#) on page 69

[:SOURce<hw>]:POWER:START <Start>

[:SOURce<hw>]:POWER:STOP <Stop>

Sets the RF start/stop level in sweep mode.

Parameters:

<Stop> float
 Sets the setting range calculated as follows:
 $(Level_min + OFFSET)$ to $(Level_max + OFFSET)$
 Where the values are set with the commands:
`[:SOURce<hw>]:POWER[:LEVel][:IMMediate]:OFFSet`
`[:SOURce<hw>]:POWER:START`
`[:SOURce<hw>]:POWER:STOP`
 Range: Minimum level to maximum level
 *RST: -30 (Start)/ -10 (Stop)
 Default unit: dBm

Example: See [Example "Setup an RF frequency or power sweep"](#) on page 647

Manual operation: See [" Start Level / Stop Level "](#) on page 181

[:SOURce<hw>]:POWER:STEP:MODE <Mode>

Defines the type of step width to vary the RF output power step-by-step with the commands `POW UP` or `POW DOWN`.

Parameters:

<Mode> DECimal | USER

DECimal

Increases or decreases the level in steps of ten.

USER

Increases or decreases the level in increments, determined with the command `[:SOURce<hw>]:POWER:STEP[:INCRement]`.

*RST: DECimal

Example:

```
SOURce1:POWER:STEP:INCRement 2
SOURce1:POWER:STEP:MODE USER
SOURce1:POWER:LEVel:IMMediate:AMPLitude UP
Increasing the RF level with a step size of 2 dB
```

Manual operation: See "[Variation Active](#)" on page 67

[:SOURce<hw>]:POWER:STEP[:INCRement] <Increment>

Specifies the step width in the appropriate path for `POW:STEP:MODE USER`.

To adjust the level step-by-step with this increment value, use the command `POW UP`, or `POW DOWN`.

Note: The command also sets "Variation Step" in the manual control, that means the user-defined step width for setting the level with the rotary knob or the [Up/Down] arrow keys.

Parameters:

<Increment> float
 Range: 0 to 200
 Increment: 0.01
 *RST: 1
 Default unit: dB

Example: See `[:SOURce<hw>]:POWER:STEP:MODE` on page 639.

Manual operation: See "[Variation Step](#)" on page 67

[:SOURce<hw>]:POWER[:LEVel][:IMMediate]:OFFSet <Offset>

Sets the level offset of a downstream instrument.

The level at the RF output is not changed.

To query the resulting level, as it is at the output of the downstream instrument, use the command `[:SOURce<hw>]:POWER[:LEVel][:IMMediate][:AMPLitude]`.

See "[RF frequency and level display with a downstream instrument](#)" on page 64.

Note: The level offset also affects the RF level sweep.

Parameters:

<Offset> float
 Range: -100 to 100
 Increment: 0.01
 *RST: 0
 Default unit: dB
 Level offset is always expressed in dB; linear units (V, W, etc.) are not supported

Example: POWer:OFFSet 10
 Sets the RF level offset to 10 dB

Manual operation: See "Offset" on page 70

[[:SOURce<hw>]:POWER[:LEVel]][:IMMediate]:RCL <Rcl>

Determines whether the current level is retained or if the stored level setting is adopted when an instrument configuration is loaded.

Parameters:

<Rcl> INCLUDE | EXCLUDE
INCLUDE
 Takes the current level when an instrument configuration is loaded.
EXCLUDE
 Retains the current level when an instrument configuration is loaded.
 *RST: INCLUDE

Example: POW:RCL INCL
 Takes the level value from an instrument configuration loaded with command *RCL.

Manual operation: See "Exclude Level" on page 299

[[:SOURce<hw>]:POWER[:LEVel]][:IMMediate][:AMPLitude] <Amplitude>

Sets the RF level applied to the DUT.

To activate the RF output use command :OUTPut<hw>[:STATe] ("RF On"/"RF Off").

The following applies $POWER = RF \text{ output level} + OFFSet$, where:

- POWER is the values set with [[:SOURce<hw>]:POWER[:LEVel]][:IMMediate][:AMPLitude]
- RF output level is set with [[:SOURce<hw>]:POWER:POWER
- OFFSet is set with [[:SOURce<hw>]:POWER[:LEVel]][:IMMediate]:OFFSet

Parameters:

<Amplitude> float

The following settings influence the value range:

OFFSet set with the command `[:SOURce<hw>] :POWer [:LEVel] [:IMMediate] :OFFSet`

Numerical value

Sets the level

UP|DOWN

Varies the level step by step.

The level is increased or decreased by the value set with the command `[:SOURce<hw>] :POWer:STEP [:INCRement]`.

Range: (Level_min + OFFSet) to (Level_max + OFFSet)

*RST: -30

Default unit: dBm

Example: `POWer -30`
Sets the RF level

Example: See also `[:SOURce<hw>] :POWer:STEP:MODE` on page 639.

Manual operation: See "Amplitude" on page 69

`[:SOURce<hw>] :POWer:RANGe:LOWer?`

`[:SOURce<hw>] :POWer:RANGe:UPPer?`

Queries the current interruption-free range of the level.

Return values:

<Upper> float
Increment: 0.01
Default unit: dBm

Example: `SOURce1:POWer:RANGe:UPPer?`
`// -15`
`SOURce1:POWer:RANGe:LOW?`
`// -50`

Usage: Query only

Manual operation: See "Level Range" on page 71

`[:SOURce] :POWer:WIGNore <State>`

Ignores level range warnings.

Parameters:

<State> 0 | 1 | OFF | ON
*RST: n.a. (factory preset: 0)

Example: `SOURce:POWer:WIGNore 1`

14.16.12 SOURce:ROSCillator Subsystem

The SOURce:ROSCillator subsystem contains the commands for setting the external and internal reference frequency.



The commands of this subsystem are not affected by an instrument reset ([*RST](#) on page 415).

Example: Configuring the reference oscillator

```
// Using 100 MHz external reference source
SOURce:ROSCillator:PRESet
SOURce:ROSCillator:SOURce EXT
SOURce:ROSCillator:EXTernal:RFOFf:STATe 1
SOURce:ROSCillator:EXTernal:FREQuency 100MHZ
SOURce:ROSCillator:EXTernal:SBANdwidth WIDE
// 100 MHz (loop thought) and 1 GHz output
SOURce:ROSCillator:OUTPut:FREQuency:MODE LOOP
SOURce:ROSCillator:OUTPut:ALternate:FREQuency:MODE DER1G
SOURce:ROSCillator:INTernal:ADJust:STATe 0

// Variable external reference frequency
// SOURce:ROSCillator:EXTernal:FREQuency VAR
// SOURce:ROSCillator:EXTernal:FREQuency:VARiable 100000000

// Using the internal reference frequency
SOURce:ROSCillator:SOURce INT
SOURce:ROSCillator:INTernal:TUNing:STATe 1
SOURce:ROSCillator:INTernal:TUNing:SLOPe LOW
// 10 MHz and 1 GHz output
SOURce:ROSCillator:OUTPut:FREQuency:MODE DER10M
SOURce:ROSCillator:OUTPut:ALternate:FREQuency:MODE DER1G

// Query calibration value
CALibration:ROSCillator?
// 32767
// Set an internal source
// Activate user-defined adjustment value of 1000
SOURce:ROSCillator:SOURce INT
SOURce:ROSCillator:INTernal:ADJust:STATe 1
SOURce:ROSCillator:INTernal:ADJust:VALue 1000

// to resume calibrated state
SOURce:ROSCillator:INTernal:ADJust:VALue 0
SOURce:ROSCillator:INTernal:ADJust:STATe 0
// or
// SYSTEM:FPRest
```

<code>[:SOURce]:ROSCillator:PRESet</code>	643
<code>[:SOURce]:ROSCillator:SOURce</code>	643
<code>[:SOURce]:ROSCillator:INTernal:TUNing[:STATe]</code>	643
<code>[:SOURce]:ROSCillator:INTernal:TUNing:SLOPe</code>	643
<code>[:SOURce]:ROSCillator:EXTernal:RFOFf[:STATe]</code>	644
<code>[:SOURce]:ROSCillator:EXTernal:FREQuency</code>	644
<code>[:SOURce]:ROSCillator:EXTernal:FREQuency:VARiable</code>	644
<code>[:SOURce]:ROSCillator:EXTernal:SBANdwidth</code>	645
<code>[:SOURce]:ROSCillator:EXTernal:MLRange?</code>	645
<code>[:SOURce]:ROSCillator:EXTernal:NSBandwidth?</code>	645
<code>[:SOURce]:ROSCillator:OUTPut:FREQuency:MODE</code>	645
<code>[:SOURce]:ROSCillator:OUTPut:ALTerNate:FREQuency:MODE</code>	646
<code>[:SOURce]:ROSCillator[:INTernal]:ADJust:VALue</code>	646
<code>[:SOURce]:ROSCillator[:INTernal]:ADJust[:STATe]</code>	647

`[:SOURce]:ROSCillator:PRESet`

Resets the reference oscillator settings.

Example: See [Example "Configuring the reference oscillator"](#) on page 642.

Usage: Event

Manual operation: See ["Set to Default"](#) on page 278

`[:SOURce]:ROSCillator:SOURce` <Source>

Selects between internal or external reference frequency.

Parameters:

<Source> INTernal | EXTernal
 *RST: n.a. (factory preset: INTernal)

Example: See [Example "Configuring the reference oscillator"](#) on page 642.

Manual operation: See ["Source"](#) on page 278

`[:SOURce]:ROSCillator:INTernal:TUNing[:STATe]` <State>

Activates the EFC (external frequency control).

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: n.a. (factory preset: 1)

Example: See [Example "Configuring the reference oscillator"](#) on page 642.

Manual operation: See ["External Tuning Active"](#) on page 279

`[:SOURce]:ROSCillator:INTernal:TUNing:SLOPe` <State>

Sets the sensitivity of the external tuning volatge.

Parameters:

<State> LOW | HIGH
 *RST: n.a. (factory preset: LOW)

Example: See [Example "Configuring the reference oscillator"](#) on page 642.

Manual operation: See ["External Tuning Slope"](#) on page 280

[[:SOURce]:ROSCillator:EXTernal:RFOFF[:STATe]] <State>

Determines that the RF output is turned off when the external reference signal is selected, but missing.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: n.a. (factory preset: 0)

Example: See [Example "Configuring the reference oscillator"](#) on page 642.

Manual operation: See ["Deactivate RF Output \(if external reference is missing\)"](#) on page 278

[[:SOURce]:ROSCillator:EXTernal:FREQuency] <Frequency>

Sets the frequency of the external reference.

Parameters:

<Frequency> 100MHZ | 1GHZ | VARiable | 10MHZ
 *RST: n.a. (factory preset: 10MHZ)

Example: See [Example "Configuring the reference oscillator"](#) on page 642.

Options: VARiable requires R&S SMAB-K704
 100MHZ|1GHZ require R&S SMAB-K703

Manual operation: See ["External Reference Frequency"](#) on page 278

[[:SOURce]:ROSCillator:EXTernal:FREQuency:VARiable] <Frequency>

Specifies the user-defined external reference frequency.

Parameters:

<Frequency> float
 Range: 1E6 to 100E6
 Increment: 0.1
 *RST: n.a. (factory preset: 1E7)
 Default unit: Hz

Example: See [Example "Configuring the reference oscillator"](#) on page 642.

Options: R&S SMAB-K704

Manual operation: See ["Variable Reference Frequency"](#) on page 279

[[:SOURce]:ROSCillator:EXTernal:SBANDwidth <SBandwidth>

Selects the synchronization bandwidth for the external reference signal.

For more information, see data sheet.

Parameters:

<SBandwidth> WIDE | NARRow

NARRow

The synchronization bandwidth is a few Hz.

Suitable for external reference sources with phase noise worse than the R&S SMA100B.

WIDE

Uses the widest possible synchronization bandwidth.

For more information, see data sheet.

*RST: n.a. (factory preset)

Example: See [Example "Configuring the reference oscillator"](#) on page 642.

Manual operation: See ["Synchronization Bandwidth"](#) on page 279

[[:SOURce]:ROSCillator:EXTernal:MLRange?

Queries the minimum locking range for the selected external reference frequency.

Return values:

<MinLockRange> string

Example: SOUR:ROSC:EXT:MLR?

Usage: Query only

Manual operation: See ["Minimum Locking Range"](#) on page 279

[[:SOURce]:ROSCillator:EXTernal:NSBandwidth?

Queries the nominal synchronization bandwidth for the selected external reference frequency and synchronization bandwidth.

Return values:

<NomBandwidth> string

Example: SOUR:ROSC:EXT:NSB?

Usage: Query only

Manual operation: See ["Nominal Synchronization Bandwidth"](#) on page 279

[[:SOURce]:ROSCillator:OUTPut:FREQuency:MODE <OutpFreqMode>

Sets the output reference frequency.

Parameters:

<OutpFreqMode> DER10M | DER100M | OFF | LOOPthrough

OFF

Disables the output.

DER10M|DER100M

Sets the output reference frequency to 10 MHz or 100 MHz. The reference frequency is derived from the internal reference frequency.

LOOPthrough

This option is unavailable for `ROSCillator:EXTernal:FREQuency 1GHZ`. Forwards the input reference frequency to the reference frequency output.

*RST: n.a. (factory preset: DER10M)

Example: See [Example "Configuring the reference oscillator"](#) on page 642.

Manual operation: See ["Reference Output/1GHz Reference Output"](#) on page 280

[:SOURce]:ROSCillator:OUTPut:ALTErnate:FREQuency:MODE <OutpFreqMode>

Sets the output reference frequency.

Parameters:

<OutpFreqMode> LOOPthrough | DER1G | OFF

OFF

Disables the output.

DER1G

Sets the output reference frequency to 1 GHz. The reference frequency is derived from the internal reference frequency.

LOOPthrough

If `[:SOURce] :ROSCillator:EXTernal:FREQuency1GHZ`, forwards the input reference frequency to the reference frequency output.

*RST: n.a. (factory preset: OFF)

Example: See [Example "Configuring the reference oscillator"](#) on page 642.

Manual operation: See ["Reference Output/1GHz Reference Output"](#) on page 280

[:SOURce]:ROSCillator[:INTernal]:ADJust:VALue <Value>

Specifies the frequency correction value (adjustment value).

Parameters:

<Value> integer

*RST: 0

Example: See `[:SOURce] :ROSCillator [:INTernal] :ADJust [:STATe]` on page 647

Manual operation: See ["Adjustment Value"](#) on page 281

[:SOURce]:ROSCillator[:INTernal]:ADJust[:STATe] <State>

Determines whether the calibrated (off) or a user-defined (on) **adjustment value** is used for fine adjustment of the frequency.

Parameters:

<State> 0 | 1 | OFF | ON

0
Fine adjustment with the calibrated frequency value

1
User-defined adjustment value.
The instrument is no longer in the calibrated state.
The calibration value is, however, not changed. The instrument resumes the calibrated state if you send
`SOURce:ROSCillator:INTernal:ADJust:STATe 0.`

*RST: n.a. (factory preset: 0)

Example: See [Example "Configuring the reference oscillator"](#) on page 642.

Manual operation: See ["Adjustment Active"](#) on page 281

14.16.13 SOURce:SWEep Subsystem

The `SOURce:SWEep` subsystem contains the commands for configuring RF sweep signals.



- The keyword `[:FREQuency]` can be omitted, then the commands are SCPI-compliant.
- To activate an RF sweep mode, use the following commands:
 - RF frequency sweep: `SOURce:FREQuency:MODE SWEep`
(`SOURce:FREQuency:MODE CW (off)`)
 - RF level sweep: `SOURce:POWer:MODE SWEep` (`SOURce:POWer:MODE CW (off)`)
- All sweeps, including the LF sweep, can be set independently of each other.

For detailed information on the sweep modes and the triggering, see [Chapter 7.1, "Signal Generation and Triggering in the Sweep and List Modes"](#), on page 159.

Example: Setup an RF frequency or power sweep

The following example shows a command sequence to set up an RF frequency sweep, triggered by the execute command. For an RF power sweep, replace `FREQuency` in the `SWEep` commands with `POWer`.

Exceptions are the power spacing (defined with `LINear` only) and the power step width (defined with `LOGarithmic` only).

```
// Reset the instrument to start from an initial state
// Switch off display update to improve performance
```

```

// (especially with short dwell times)
// Set the sweep mode (first two commands) and the sweep range
// Select linear spacing
// Select the waveform shape for the frequency sweep
*RST; *CLS
SYSTEM:DISPLAY:UPDATE OFF
TRIGGER1:FSWEEP:SOURCE SINGLE
SOURCE1:SWEEP:FREQUENCY:MODE AUTO
SOURCE1:FREQUENCY:SPAN 300 MHz
SOURCE1:FREQUENCY:CENTER 200 MHz
// Alternatively use
// SOURCE1:FREQUENCY:START 50 MHz
// SOURCE1:FREQUENCY:STOP 350 MHz
SOURCE1:SWEEP:FREQUENCY:SPACING LINear
SOURCE1:SWEEP:FREQUENCY:SHAPE SAWTooth

// Activate change to start frequency while waiting for next trigger
// Prerequisites: sweep mode single and sweep waveform sawtooth
SOURCE1:SWEEP:FREQUENCY:RETRACE 1
// Alternatively reset all sweeps to their initial value
SOURCE1:SWEEP:RESET:ALL

// Set the step width and dwell time
SOURCE1:SWEEP:FREQUENCY:STEP:LINear 1 MHz
// Alternatively set the number of steps, then the sweep step width is
// set automatically
SOURCE1:SWEEP:FREQUENCY:POINTS 301
SOURCE1:SWEEP:FREQUENCY:DWELL 500 ms
// With logarithmic spacing select the step width as follows
// (steps of 10 percent of the previous frequency in each instance)
SOURCE1:SWEEP:FREQUENCY:SPACING LOG
SOURCE1:SWEEP:FREQUENCY:STEP:LOGarithmic 10PCT

// Activate the sweep
// Trigger the sweep (depending on the set mode) and query the status
SOURCE1:FREQUENCY:MODE SWEep
// Perform a one-off RF frequency sweep
SOURCE1:SWEEP:FREQUENCY:EXECute
SOURCE1:SWEEP:FREQUENCY:RUNNING?
// 1
// the frequency sweep is running

// For manual step RF sweep use the following commands
*RST; *CLS
// Activate manual step RF sweep
SOURCE1:SWEEP:FREQUENCY:MODE MANual
// Activate the RF frequency sweep.
SOURCE1:FREQUENCY:MODE SWEep
// Activate RF Output1.
Output1:STATE 1

```

```

// Input the frequency manually for each step
SOURce1:FREQuency:MANual 200 MHz
SOURce1:FREQuency:MANual 201 MHz
// Alternatively use the UP or DOWN commands with the set step width.
SOURce1:SWEep:FREQuency:STEP:LINear 1 MHz
SOURce1:FREQuency:MANual UP

:SWEep:TYPE..... 649
[:SOURce<hw>]:SWEep:POWer:DWELI..... 649
[:SOURce<hw>]:SWEep:POWer:DWELI..... 650
[:SOURce<hw>]:SWEep:GENeration..... 650
[:SOURce<hw>]:SWEep:POWer:MODE..... 650
[:SOURce<hw>]:SWEep:POWer:POINts..... 651
[:SOURce<hw>]:SWEep:POWer:SPACing:MODE?..... 651
[:SOURce<hw>]:SWEep:POWer:STEP[:LOGarithmic]..... 651
[:SOURce<hw>]:SWEep[:FREQuency]:DWELI..... 652
[:SOURce<hw>]:SWEep[:FREQuency]:MODE..... 652
[:SOURce<hw>]:SWEep[:FREQuency]:POINts..... 653
[:SOURce<hw>]:SWEep[:FREQuency]:SPACing..... 653
[:SOURce<hw>]:SWEep:POWer:SHAPE..... 653
[:SOURce<hw>]:SWEep[:FREQuency]:SHAPE..... 653
[:SOURce<hw>]:SWEep:POWer:EXECute..... 654
[:SOURce<hw>]:SWEep[:FREQuency]:EXECute..... 654
[:SOURce<hw>]:SWEep:POWer:RETRace..... 654
[:SOURce<hw>]:SWEep[:FREQuency]:RETRace..... 654
[:SOURce<hw>]:SWEep:POWer:RUNNing?..... 654
[:SOURce<hw>]:SWEep[:FREQuency]:RUNNing?..... 654
[:SOURce<hw>]:SWEep[:FREQuency]:STEP:LOGarithmic..... 655
[:SOURce<hw>]:SWEep[:FREQuency]:STEP[:LINear]..... 655
[:SOURce<hw>]:SWEep:RESet[:ALL]..... 655
[:SOURce<hw>]:SWEep[:FREQuency]:TIME..... 655
[:SOURce<hw>]:SWEep:MARKer:OUTPut:POLarity..... 656
[:SOURce<hw>]:SWEep[:FREQuency]:MARKer:ACTive..... 656
[:SOURce<hw>]:SWEep[:FREQuency]:MARKer<ch>:FREQuency..... 656
[:SOURce<hw>]:SWEep[:FREQuency]:MARKer<ch>:FState..... 657

```

:SWEep:TYPE <SweepType>

Provided for compatibility between SCPI and Rohde & Schwarz commands.

Parameters:

<SweepType>	ADVanced STANdard
*RST:	n.a. (factory preset: STANdard)

[:SOURce<hw>]:SWEep:POWer:DWELI <Dwell>

Sets the dwell time for a level sweep step.

Parameters:

<Dwell> float
 Range: 3E-3 to 100
 Increment: 100E-6
 *RST: 10E-3
 Default unit: s

Example: See [Example "Setup an RF frequency or power sweep"](#) on page 647.

[:SOURce<hw>] :SWEep:POWer:DWELI <Dwell>

Sets the dwell time for a level sweep step.

Parameters:

<Dwell> float
 Range: 0.001 to 100
 Increment: 100E-6
 *RST: 0.01

Example: See [Example "Setup an RF frequency or power sweep"](#) on page 647.

Manual operation: See "[Dwell Time](#)" on page 177

[:SOURce<hw>] :SWEep:GENeration <SweepType>

Selects frequency sweep type.

Parameters:

<SweepType> STEPped | ANALog
STEPped
 Performs a frequency sweep.
ANALog
 Performs a continuous analog frequency sweep (ramp),
 synchronized with the sweep time [:SOURce<hw>] :SWEep [:
[FREQuency](#)] :TIME.
 *RST: STEPped

Manual operation: See "[Sweep Type](#)" on page 174

[:SOURce<hw>] :SWEep:POWer:MODE <Mode>

Sets the cycle mode for the level sweep.

Parameters:

<Mode> AUTO | MANual | STEP
AUTO
 Each trigger triggers exactly one complete sweep.

MANual

The trigger system is not active. You can trigger every step individually with the command `[:SOURce<hw>] :POWer:MANual`. The level value increases at each step by the value that you define with `[:SOURce<hw>] :POWer:STEP [:INCRement]`. Values directly entered with the command `[:SOURce<hw>] :POWer:MANual` are not taken into account.

STEP

Each trigger triggers one sweep step only. The level increases by the value entered with `[:SOURce<hw>] :POWer:STEP [:INCRement]`.

*RST: AUTO

Example: See [Example "Setup an RF frequency or power sweep"](#) on page 647.

Manual operation: See ["Mode"](#) on page 175

[:SOURce<hw>] :SWEep:POWer:POINts <Points>

Sets the number of steps within the RF level sweep range.

See [Chapter 7.2.1, "Correlating Parameters in Sweep Mode"](#), on page 167.

Parameters:

<Points> integer
Range: 2 to Max

Example: See [Example "Setup an RF frequency or power sweep"](#) on page 647.

[:SOURce<hw>] :SWEep:POWer:SPACing:MODE?

Queries the level sweep spacing. The sweep spacing for level sweeps is always linear.

Return values:

<Mode> LINear
*RST: LINear

Example: `SWE:POW:SPAC:MODE?`
queries the sweep spacing for a level sweep at RF output.
Result: "LIN"
linear spacing

Usage: Query only

[:SOURce<hw>] :SWEep:POWer:STEP[:LOGarithmic] <Logarithmic>

Sets a logarithmically determined step size for the RF level sweep. The level is increased by a logarithmically calculated fraction of the current level.

See [Chapter 7.2.1, "Correlating Parameters in Sweep Mode"](#), on page 167.

Parameters:

<Logarithmic> float
 The unit dB is mandatory.
 Range: 0.01 to 139 dB
 Increment: 0.01
 *RST: 1
 Default unit: dB

Example: See [Example "Setup an RF frequency or power sweep"](#) on page 647.

Manual operation: See " [Step](#) " on page 181

[:SOURce<hw>]:SWEep[:FREQuency]:DWELI <Dwell>

Sets the dwell time for a frequency sweep step.

Parameters:

<Dwell> float
 Range: 0.001 to 100
 Increment: 100E-6
 *RST: 0.01

Example: See [Example "Setup an RF frequency or power sweep"](#) on page 647.

Manual operation: See " [Dwell Time](#) " on page 177

[:SOURce<hw>]:SWEep[:FREQuency]:MODE <Mode>

Sets the cycle mode for the frequency sweep.

Parameters:

<Mode> AUTO | MANual | STEP

AUTO

Each trigger event triggers exactly one complete sweep.

MANual

The trigger system is not active. You can trigger every step individually by input of the frequencies with the command [:SOURce<hw>]:FREQuency:MANual.

STEP

Each trigger event triggers one sweep step. The frequency increases by the value entered with [:SOURce<hw>]:SWEep[:FREQuency]:STEP[:LINear] (linear spacing) or [:SOURce<hw>]:SWEep[:FREQuency]:STEP:LOGarithmic (logarithmic spacing).

*RST: AUTO

Example: See [Example "Setup an RF frequency or power sweep"](#) on page 647.

Manual operation: See "Mode" on page 175

[:SOURce<hw>]:SWEep[:FREQuency]:POINts <Points>

Sets the number of steps within the RF frequency sweep range.

See [Chapter 7.2.1, "Correlating Parameters in Sweep Mode"](#), on page 167.

Two separate POINTs values are used for linear or logarithmic sweep spacing ([:SOURce<hw>]:SWEep[:FREQuency]:SPACing LIN | LOG). The command always affects the currently set sweep spacing.

Parameters:

<Points> integer
Range: 2 to Max

Example: See [Example "Setup an RF frequency or power sweep"](#) on page 647.

[:SOURce<hw>]:SWEep[:FREQuency]:SPACing <Spacing>

Selects the mode for the calculation of the frequency intervals, with which the current frequency at each step is increased or decreased.

The keyword [:FREQuency] can be omitted; then the command is SCPI-compliant.

Parameters:

<Spacing> LINear | LOGarithmic

LINear

Sets a fixed frequency value as step width and adds it to the current frequency.

The linear step width is entered in Hz, see [:SOURce<hw>]:SWEep[:FREQuency]:STEP[:LINear].

LOGarithmic

Sets a constant fraction of the current frequency as step width and adds it to the current frequency.

The logarithmic step width is entered in %, see [:SOURce<hw>]:SWEep[:FREQuency]:STEP:LOGarithmic.

*RST: LINear

Example: See [Example "Setup an RF frequency or power sweep"](#) on page 647.

Manual operation: See "Spacing" on page 177

[:SOURce<hw>]:SWEep:POWer:SHAPE <Shape>

[:SOURce<hw>]:SWEep[:FREQuency]:SHAPE <Shape>

Determines the waveform shape for a frequency sweep sequence.

Parameters:

<Shape> SAWTooth | TRlangle
 *RST: SAWTooth

Example: See [Example "Setup an RF frequency or power sweep"](#) on page 647.

Manual operation: See "[Shape](#)" on page 176

[:SOURce<hw>]:SWEep:POWer:EXECute
[:SOURce<hw>]:SWEep[:FREQuency]:EXECute

Executes an RF frequency sweep.

The command performs a single sweep and is therefore only effective in manual sweep mode.

Example: See [Example "Setup an RF frequency or power sweep"](#) on page 647.

Usage: Event

Manual operation: See "[Execute Single Sweep](#)" on page 178

[:SOURce<hw>]:SWEep:POWer:RETRace <State>
[:SOURce<hw>]:SWEep[:FREQuency]:RETRace <State>

Activates that the signal changes to the start frequency value while it is waiting for the next trigger event.

You can enable this feature, when you are working with sawtooth shapes in sweep mode "Single" or "External Single".

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: 0

Example: See [Example "Setup an RF frequency or power sweep"](#) on page 647.

Manual operation: See "[Retrace](#)" on page 176

[:SOURce<hw>]:SWEep:POWer:RUNNing?
[:SOURce<hw>]:SWEep[:FREQuency]:RUNNing?

Queries the current sweep state.

Return values:

<State> 0 | 1 | OFF | ON

Example: See [Example "Setup an RF frequency or power sweep"](#) on page 647.

Usage: Query only

[[:SOURce<hw>]:SWEep[:FREQUENCY]:STEP:LOGarithmic <Logarithmic>

Sets a logarithmically determined step width for the RF frequency sweep. The value is added at each sweep step to the current frequency.

See [Chapter 7.2.1, "Correlating Parameters in Sweep Mode"](#), on page 167.

Parameters:

<Logarithmic> float
 The unit is mandatory.
 Range: 0.01 to 100
 Increment: 1E-3
 *RST: 1
 Default unit: PCT

Example: See [Example "Setup an RF frequency or power sweep"](#) on page 647.

Manual operation: See [" Step Linear/Step Logarithmic "](#) on page 180

[[:SOURce<hw>]:SWEep[:FREQUENCY]:STEP[:LINear] <Linear>

Sets the step width for linear sweeps.

See [Chapter 7.2.1, "Correlating Parameters in Sweep Mode"](#), on page 167.

Omit the optional keywords so that the command is SCPI-compliant.

Parameters:

<Linear> float
 Range: 0.001 Hz to (STOP - START)
 Increment: 0.01

Example: See [Example "Setup an RF frequency or power sweep"](#) on page 647.

Manual operation: See [" Step Linear/Step Logarithmic "](#) on page 180

[[:SOURce<hw>]:SWEep:RESet[:ALL]

Resets all active sweeps to the starting point.

Usage: Event

Manual operation: See [" Reset Sweep "](#) on page 178

[[:SOURce<hw>]:SWEep[:FREQUENCY]:TIME <Time>

Sets the duration of a frequency ramp sweep step.

Parameters:

<Time> float
 Range: 0.01 to 100
 Increment: 1E-4
 *RST: 0.015
 Default unit: s

Example:

```
SOURce1:SWEep:FREQuency:SPACing RAMP
SOURce1:SWEep:FREQuency:TIME 0.020
```

Options: R&S SMAB-B28

Manual operation: See " Sweep Time " on page 177

[:SOURce<hw>]:SWEep:MARKer:OUTPut:POLarity <Polarity>

Selects the polarity of the marker signal.

Parameters:

<Polarity> NORMal | INVerted
NORMal
 Marker level is high when after reaching the mark.
INVerted
 Marker level is low after reaching the mark.
 *RST: NORMal

Example: See [:SOURce<hw>] :SWEep [:FREQuency] :MARKer<ch> :FREQuency on page 656.

Options: R&S SMAB-B28

Manual operation: See "Marker Polarity" on page 185

[:SOURce<hw>]:SWEep[:FREQuency]:MARKer:ACTive <Active>

Defines the marker signal to be output with a higher voltage than all other markers.

Parameters:

<Active> NONE | M01 | M02 | M03 | M04 | M05 | M06 | M07 | M08 | M09 | M10
 *RST: NONE

Example: See [:SOURce<hw>] :SWEep [:FREQuency] :MARKer<ch> :FREQuency on page 656.

Options: R&S SMAB-B28

Manual operation: See " Active Marker " on page 185

[:SOURce<hw>]:SWEep[:FREQuency]:MARKer<ch>:FREQuency <Frequency>

Sets the frequency of the selected marker.

Suffix:	
<ch>	1 to 10 Marker
Parameters:	
<Frequency>	float Increment: 0.01 *RST: 100 + n* 100
Example:	<pre>SOURce1:SWEep:MARKer:OUTPut:POLarity NORMal three markers at 1 GHz, 2 GHz and 3 GHz SOURce1:SWEep:FREQuency:MARKer1:FREQuency 1000000000 SOURce1:SWEep:FREQuency:MARKer2:FREQuency 2000000000 SOURce1:SWEep:FREQuency:MARKer3:FREQuency 3000000000 SOURce1:SWEep:FREQuency:MARKer1:FState 1 SOURce1:SWEep:FREQuency:MARKer2:FState 1 SOURce1:SWEep:FREQuency:MARKer3:FState 1 SOURce1:SWEep:FREQuency:MARKer:ACTive M03</pre>
Options:	R&S SMAB-B28
Manual operation:	See " Frequency x " on page 184

[:SOURce<hw>]:SWEep[:FREQuency]:MARKer<ch>:FState <FState>

Activates the selected marker.

Suffix:	
<ch>	1 to 10 Marker
Parameters:	
<FState>	0 1 OFF ON *RST: 0
Example:	See [:SOURce<hw>] :SWEep [:FREQuency] :MARKer<ch> : FREQuency on page 656.
Options:	R&S SMAB-B28
Manual operation:	See " State " on page 184

14.17 SYSTem Subsystem

The SYSTem subsystem contains a series of commands for general functions which do not directly affect signal generation.

Example: Retrieving information on network-related settings

```
SYSTEM:COMMunicate:NETWork:STATus?
// 1
SYSTEM:PROTection1:STATe 0,123456

SYSTEM:COMMunicate:NETWork:IPADdress:MODE STAT
SYSTEM:COMMunicate:NETWork:IPADdress "10.113.0.104"
SYSTEM:COMMunicate:NETWork:IPADdress:DNS "10.0.2.166"
SYSTEM:COMMunicate:NETWork:COMMon:HOSTname?
// "SMA100B-102030"
SYSTEM:COMMunicate:NETWork:COMMon:WORKgroup "instrument"
SYSTEM:COMMunicate:NETWork:COMMon:DOMain "rsint.net"
SYSTEM:COMMunicate:NETWork:IPADdress:GATeway "10.113.0.1"
SYSTEM:COMMunicate:NETWork:IPADdress:SUBNet:MASK "255.255.252.0"
SYSTEM:COMMunicate:NETWork:MACaddress "08 00 27 a3 a1 70"
SYSTEM:PROTection1:STATe 1
```

Example: Finding out the used VISA ressource strings

```
SYSTEM:COMMunicate:NETWork:RESource?
// "TCPIP::10.113.0.104::inst0::INSTR"

SYSTEM:COMMunicate:HISLip:RESource?
// "TCPIP::10.113.0.104::hislip0::INSTR"

SYSTEM:COMMunicate:GPIB:RESource?
// "GPIB::28::INSTR"
SYSTEM:COMMunicate:GPIB:SELF:ADDRESS?
// 28
SYSTEM:COMMunicate:GPIB:LTERminator?
// STAN

SYSTEM:COMMunicate:SERial:RESource?
// "ASRL1::INSTR"
SYSTEM:COMMunicate:SERial:SBITS?
// 1
SYSTEM:COMMunicate:SERial:BAUD?
// 115200
SYSTEM:COMMunicate:SERial:PARity?
// NONE

SYSTEM:COMMunicate:SOCKET:RESource?
// "TCPIP::10.113.0.104::5025::SOCKET"
SYSTEM:COMMunicate:USB:RESource?
// "USB::0x0AAD::0x01DD::100001::INSTR"
```

Example: Querying the error queue

```
SYSTem:ERRor:STATic?
// -221,"Settings conflict", 153,"Input voltage out of range", ...
// returns all static errors that are collected in the error queue
```

```
SYSTem:ERRor:HISTory:CLear
// deletes the history entries
```

:SYSTem:ERRor:ALL?	660
:SYSTem:ERRor:CODE:ALL?	661
:SYSTem:ERRor:CODE[:NEXT]?	661
:SYSTem:ERRor:COUNT?	662
:SYSTem:ERRor[:NEXT]?	662
:SYSTem:ERRor:GNEXT?	663
:SYSTem:ERRor:HISTory:CLear	663
:SYSTem:ERRor:STATic?	663
:SYSTem:DLOCK	663
:SYSTem:KLOCK	664
:SYSTem:ULOCK	664
:SYSTem:LOCK:OWNer?	664
:SYSTem:LOCK:RELease:ALL	665
:SYSTem:LOCK:REQuest[:EXCLusive]?	665
:SYSTem:SAV	665
:SYSTem:RCL	665
:SYSTem:PROTect<ch>[:STATe]	666
:SYSTem:SECurity:VOLMode[:STATe]	666
:SYSTem:COMMunicate:GPIB:LTERminator	667
:SYSTem:COMMunicate:GPIB:RESource?	667
:SYSTem:COMMunicate:GPIB[:SELF]:ADDRes	667
:SYSTem:COMMunicate:HISlip:RESource?	668
:SYSTem:COMMunicate:NETWork:IPADdress	668
:SYSTem:COMMunicate:NETWork:IPADdress:MODE	668
:SYSTem:COMMunicate:NETWork:MACAddress	668
:SYSTem:COMMunicate:NETWork:RESource?	669
:SYSTem:COMMunicate:NETWork:REStart	669
:SYSTem:COMMunicate:NETWork:STATus?	669
:SYSTem:COMMunicate:NETWork[:COMMOn]:DOMain	669
:SYSTem:COMMunicate:NETWork[:COMMOn]:HOSTname	669
:SYSTem:COMMunicate:NETWork[:COMMOn]:WORKgroup	670
:SYSTem:COMMunicate:NETWork[:IPADdress]:DNS	670
:SYSTem:COMMunicate:NETWork[:IPADdress]:GATeway	670
:SYSTem:COMMunicate:NETWork[:IPADdress]:SUBNet:MASK	670
:SYSTem:COMMunicate:SERial:BAUD	671
:SYSTem:COMMunicate:SERial:PARity	671
:SYSTem:COMMunicate:SERial:RESource?	671
:SYSTem:COMMunicate:SERial:SBITs	671
:SYSTem:COMMunicate:SOCKet:RESource?	672
:SYSTem:COMMunicate:USB:RESource?	672
:SYSTem:HELP:EXPort	672
:SYSTem:IDENTification	672

:SYSTem:IDENtification:PRESet.....	673
:SYSTem:IRESpOse.....	673
:SYSTem:ORESpOse.....	673
:SYSTem:LANGUage.....	674
:SYSTem:INfOrMation:SCPI.....	674
:SYSTem:SECurity:SANitiz[e]:STATe].....	674
:SYSTem:SECurity:SUPolicy.....	674
:SYSTem:SPECification?.....	675
:SYSTem:SPECification:VERsion.....	676
:SYSTem:SPECification:IDENtification:CATalog?.....	676
:SYSTem:SPECification:PARAmeter?.....	677
:SYSTem:SPECification:VERsion:CATalog?.....	677
:SYSTem:SPECification:VERsion:FACTory?.....	677
:SYSTem:SRData?.....	678
:SYSTem:STARtup:COMPLete?.....	678
:SYSTem:DATE.....	678
:SYSTem:NTP:HOSTName.....	679
:SYSTem:NTP:STATe.....	679
:SYSTem:TIME.....	679
:SYSTem:TIME:ZONE.....	679
:SYSTem:TIME:ZONE:CATalog?.....	680
:SYSTem:UPTime?.....	680
:SYSTem:BIOS:VERsion?.....	680
:SYSTem:VERsion?.....	680
:SYSTem:OSYStem?.....	681
:SYSTem:MMEMory:PATH:USER?.....	681
:SYSTem:DFPR?.....	681
:SYSTem:REBoot.....	681
:SYSTem:RESart.....	681
:SYSTem:SHUTdown.....	682
:SYSTem:WAIT.....	682
:SYSTem:FILEs:TEMPorary:DELete.....	682

:SYSTem:ERRor:ALL?

Queries the error/event queue for all unread items and removes them from the queue.

Return values:

<All>	string
-------	--------

Error/event_number,"Error/event_description">[;Device-dependent info]"

A comma separated list of error number and a short description of the error in FIFO order.

If the queue is empty, the response is 0, "No error"

Positive error numbers are instrument-dependent. Negative error numbers are reserved by the SCPI standard.

Volatile errors are reported once, at the time they appear. Identical errors are reported repeatedly only if the original error has already been retrieved from (and hence not any more present in) the error queue.

Example: `SYST:ERR:ALL?`
 Queries all entries in the error queue.
 Response: 0, 'no error'
 No errors have occurred since the error queue was last read out.

Usage: Query only

Manual operation: See "[Clear History](#)" on page 712

:SYSTem:ERRor:CODE:ALL?

Queries the error numbers of all entries in the error queue and then deletes them.

Return values:

<All> string
 Returns the error numbers. To retrieve the entire error text, send the command `:SYSTem:ERRor:ALL?`.

0
 "No error", i.e. the error queue is empty

Positive value
 Positive error numbers denote device-specific errors

Negative value
 Negative error numbers denote error messages defined by SCPI.

Example: `SYST:ERR:CODE:ALL`
 Queries all entries in the error queue.
 Response: 0
 No errors have occurred since the error queue was last read out.

Usage: Query only

:SYSTem:ERRor:CODE[:NEXT]?

Queries the error number of the oldest entry in the error queue and then deletes it.

Return values:

<Next> string
 Returns the error number. To retrieve the entire error text, send the command `:SYSTem:ERRor:ALL?`.

0
 "No error", i.e. the error queue is empty

Positive value
 Positive error numbers denote device-specific errors

Negative value
 Negative error numbers denote error messages defined by SCPI.

Example: SYST:ERR:CODE
 Queries the oldest entry in the error queue.
 Response: 0
 No errors have occurred since the error queue was last read out.

Usage: Query only

:SYSTem:ERRor:COUNT?

Queries the number of entries in the error queue.

Return values:

<Count> integer

0

The error queue is empty.

Example: SYST:ERR:COUN
 Queries the number of entries in the error queue.
 Response: 1
 One error has occurred since the error queue was last read out.

Usage: Query only

:SYSTem:ERRor[:NEXT]?

Queries the error/event queue for the oldest item and removes it from the queue.

Return values:

<Next> string

Error/event_number,"Error/event_description>[;Device-dependent info]"

Error number and a short description of the error.

If the queue is empty, the response is 0, "No error"

Positive error numbers are instrument-dependent. Negative error numbers are reserved by the SCPI standard.

Volatile errors are reported once, at the time they appear. Identical errors are reported repeatedly only if the original error has already been retrieved from (and hence not any more present in) the error queue.

Example: SYST:ERR?
 Queries the oldest entry in the error queue.
 Response: 0, 'no error'
 No errors have occurred since the error queue was last read out.

Usage: Query only

Manual operation: See "[Static Errors/Error History](#)" on page 712

:SYSTem:ERRor:GNEXt?

Similar to `:SYSTem:ERRor[:NEXT]?`, but queries the next entry from the global persistent error/event queue.

Return values:

`<NextGlobalError>` string
 Error/event number, "Error/event description" [;Device dependent info]
 An error number and a short description of the error. Positive error numbers are instrument-dependent. Negative error numbers are reserved by the SCPI standard.

Example:

`SYST:ERR:GNEX?`
 Returns the next error message from the global error queue.

Usage: Query only

:SYSTem:ERRor:HISTory:CLEar

Clears the error history.

Example: See [Example "Querying the error queue"](#) on page 659

Usage: Event

Manual operation: See ["Clear History"](#) on page 712

:SYSTem:ERRor:STATic?

Returns a list of all errors existing at the time when the query is started. This list corresponds to the display on the info page under manual control.

Return values:

`<StaticErrors>` string

Example: See [Example "Querying the error queue"](#) on page 659

Usage: Query only

Manual operation: See ["Static Errors/Error History"](#) on page 712

:SYSTem:DLOCK <DispLockStat>

Disables the manual operation via the display, including the front panel keyboard of the instrument and the Local key.

Parameters:

`<DispLockStat>` 0 | 1 | OFF | ON
 *RST: n.a. (factory preset: 0)

Example:

`SYST:DLOC ON`
 Activates the display lock. The instrument cannot be operated via the display until it has been enabled with `SYST:DLOC OFF`.

Manual operation: See ["User Interface"](#) on page 343

:SYSTem:KLOCK <State>

Disables the front panel keyboard of the instrument including the Local key.

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: n.a. (factory preset: 0)

Example:

SYST:KLOC ON
 Locks the front panel and external controls.
 To enable the controls, send SYST:KLOC OFF.

Manual operation: See ["User Interface"](#) on page 343

:SYSTem:ULOCK <Mode>

Locks or unlocks the user interface of the instrument.

Parameters:

<Mode> ENABled | DONLy | DISabled | TOFF | VNConly

ENABled

Unlocks the display, the touchscreen and all controls for the manual operation.

DONLy

Locks the touchscreen and controls for the manual operation of the instrument. The display shows the current settings.

VNConly

Locks the touchscreen and controls for the manual operation, and enables remote operation over VNC. The display shows the current settings.

TOFF

Locks the touchscreen for the manual operation of the instrument. The display shows the current settings.

DISabled

Locks the display, the touchscreen and all controls for the manual operation.

*RST: n.a. (factory preset: ENABled)

Example:

:SYST:ULOC DIS
 Activates the user interface lock, including display and controls.

Manual operation: See ["User Interface"](#) on page 343

:SYSTem:LOCK:OWNer?

Queries the sessions that have locked the instrument currently.

If an exclusive lock is set, the query returns the owner of this exclusive lock, otherwise it returns `NONE`.

Return values:

<Owner> string

Example:

`SYST:LOCK:OWN?`

Returns the owner of locking.

Response: `NONE`

The instrument is not locked.

Usage:

Query only

:SYSTEM:LOCK:RELease:ALL

Revokes the exclusive access to the instrument.

Usage:

Setting only

:SYSTEM:LOCK:REQuest[:EXCLusive]?

Queries whether a lock for exclusive access to the instrument via ethernet exists. If successful, the query returns a 1, otherwise 0.

Return values:

<Success> integer

Example:

`SYST:LOCK:REQ?`

Queries the state of exclusive locking.

Response: 1

The exclusive locking is active.

Usage:

Query only

:SYSTEM:SAV <Pathname>

Saves the current instrument settings to a file with defined filename.

Setting parameters:

<Pathname> string

Example:

`SYSTEM:SAV`

`"/var/user/Instrument_settings.savrc1txt"`

Usage:

Setting only

:SYSTEM:RCL <Pathname>

Loads a file with previously saved instrument settings.

Setting parameters:

<Pathname> string

Example: SYSTEM:RCL
 "/var/user/Instrument_settings.savrcltxt"

Usage: Setting only

:SYSTEM:PROTECT<ch>[:STATE] <State>[, <Key>]

Activates and deactivates the specified protection level.

Suffix:

<ch> Indicates the protection level.
 See also "[Protection](#)" on page 337

Parameters:

<State> 0 | 1 | OFF | ON
 *RST: n.a. (factory preset: 1)

Setting parameters:

<Key> integer

The respective functions are disabled when the protection level is activated. No password is required for activation of a level. A password must be entered to deactivate the protection level. The default password for the first level is 123456. This protection level is required to unlock internal adjustments for example.

Example: To activate protection level:
 SYSTEM:PROTECT1:STATE 1
 Internal adjustments or hostname cannot be changed.
 To unlock protection level 1:
 SYSTEM:PROTECT1:STATE 0,123456
 Internal adjustments are accessible.

Manual operation: See "[Protection Level/Password](#)" on page 338

:SYSTEM:SECURITY:VOLMODE[:STATE] <SecPassWord>, <MmemProtState>

Activates volatile mode, so that no user data can be written to the internal memory permanently.

To enable volatile mode, reboot the instrument. Otherwise the change has no effect.

Parameters:

<MmemProtState> 0 | 1 | OFF | ON
 *RST: 0

Setting parameters:

<SecPassWord> string
 Current security password
 The default password is 123456.

Example: SYSTEM:SECURITY:VOLMODE:STATE "123456", 1
 SYSTEM:REBOOT

Manual operation: See ["Volatile Mode"](#) on page 341

:SYSTem:COMMunicate:GPIB:LTERminator <LTerminator>

Sets the terminator recognition for remote control via GPIB interface.

Parameters:

<LTerminator> STANdard | EOI

EOI

Recognizes an LF (Line Feed) as the terminator only when it is sent with the line message EOI (End of Line). This setting is recommended particularly for binary block transmissions, as binary blocks may coincidentally contain a character with value LF (Line Feed), although it is not determined as a terminator.

STANdard

Recognizes an LF (Line Feed) as the terminator regardless of whether it is sent with or without EOI.

*RST: n.a. (factory preset: STANdard)

Example: See [Example "Finding out the used VISA resource strings"](#) on page 658.

:SYSTem:COMMunicate:GPIB:RESource?

Queries the visa resource string for remote control via the GPIB interface.

To change the GPIB address, use the command `:SYSTem:COMMunicate:GPIB[:SELF]:ADDRes`.

Return values:

<Resource> string

Example: See [Example "Finding out the used VISA resource strings"](#) on page 658.

Usage: Query only

:SYSTem:COMMunicate:GPIB[:SELF]:ADDRes <Address>

Sets the GPIB address.

Parameters:

<Address> integer
 Range: 0 to 30
 *RST: 28

Example: See [Example "Finding out the used VISA resource strings"](#) on page 658.

:SYSTem:COMMunicate:HISLip:RESource?

Queries the VISA resource string . This string is used for remote control of the instrument with HiSLIP protocol.

Return values:

<Resource> string

Example: See [Example "Finding out the used VISA ressource strings"](#) on page 658.

Usage: Query only

:SYSTem:COMMunicate:NETWork:IPADdress <IpAddress>

Sets the IP address.

Parameters:

<IpAddress> string
Range: 0.0.0.0. to ff.ff.ff.ff

Example: See [Example "Retrieving information on network-related settings"](#) on page 658.

Manual operation: See ["IP Address"](#) on page 365

:SYSTem:COMMunicate:NETWork:IPADdress:MODE <Mode>

Selects manual or automatic setting of the IP address.

Parameters:

<Mode> AUTO | STATic
*RST: n.a. (factory preset: AUTO)

Example: See [Example "Retrieving information on network-related settings"](#) on page 658.

Example: SYSTem:COMMunicate:NETWork:IPADdress:MODE
STATic
SYSTem:COMMunicate:NETWork:IPADdress
"10.113.0.105"

Manual operation: See ["Address Mode"](#) on page 364

:SYSTem:COMMunicate:NETWork:MACAddress <MacAddress>

Queries the MAC address of the network adapter.

This is a password-protected function. Unlock the protection level 1 to access it.

Parameters:

<MacAddress> string

Example: See [Example "Retrieving information on network-related settings"](#) on page 658.

Manual operation: See ["MAC Address"](#) on page 366

:SYSTEM:COMMunicate:NETWork:RESource?

Queries the visa resource string for Ethernet instruments.

Return values:

<Resource> string

Example: See [Example "Finding out the used VISA resource strings"](#) on page 658.

Usage: Query only

:SYSTEM:COMMunicate:NETWork:REStart

Restarts the network.

Example: `SYSTEM:COMMunicate:NETWork:REStart`
 // Terminates the network connection and sets it up again

Usage: Event

Manual operation: See ["Restart Network"](#) on page 364

:SYSTEM:COMMunicate:NETWork:STATus?

Queries the network configuration state.

Return values:

<State> 0 | 1 | OFF | ON

Example: See [Example "Retrieving information on network-related settings"](#) on page 658.

Usage: Query only

Manual operation: See ["Network Status"](#) on page 363

:SYSTEM:COMMunicate:NETWork[:COMMON]:DOMain <Domain>

Determines the primary suffix of the network domain.

Parameters:

<Domain> string

Example: See [Example "Retrieving information on network-related settings"](#) on page 658.

Manual operation: See ["DNS Suffix"](#) on page 365

:SYSTEM:COMMunicate:NETWork[:COMMON]:HOSTname <Hostname>

Sets an individual hostname for the Signal Generator.

Note: We recommend that you do not change the hostname to avoid problems with the network connection. If you change the hostname, be sure to use a unique name.

This is a password-protected function. Unlock the protection level 1 to access it.

Parameters:

<Hostname> string

Example: See [Example "Retrieving information on network-related settings"](#) on page 658.

Manual operation: See ["Hostname"](#) on page 364

:SYSTEM:COMMunicate:NETWork[:COMMON]:WORKgroup <Workgroup>

Sets an individual workgroup name for the instrument.

Parameters:

<Workgroup> string

Example: See [Example "Retrieving information on network-related settings"](#) on page 658.

Manual operation: See ["Workgroup"](#) on page 364

:SYSTEM:COMMunicate:NETWork[:IPADdress]:DNS <DNS>

Determines or queries the network DNS server to resolve the name.

Parameters:

<DNS> string

Example: See [Example "Retrieving information on network-related settings"](#) on page 658.

Manual operation: See ["DNS Server"](#) on page 365

:SYSTEM:COMMunicate:NETWork[:IPADdress]:GATeway <Gateway>

Sets the IP address of the default gateway.

Parameters:

<Gateway> string

Range: 0.0.0.0 to ff.ff.ff.ff

Example: See [Example "Retrieving information on network-related settings"](#) on page 658.

Manual operation: See ["Default Gateway"](#) on page 365

:SYSTEM:COMMunicate:NETWork[:IPADdress]:SUBNet:MASK <Mask>

Sets the subnet mask.

Parameters:

<Mask> string

Example:

See [Example "Retrieving information on network-related settings"](#) on page 658.

Manual operation: See ["Subnet Mask"](#) on page 365

:SYSTEM:COMMunicate:SERial:BAUD <Baud>

Defines the baudrate for the serial remote control interface.

Parameters:

<Baud> 2400 | 4800 | 9600 | 19200 | 38400 | 57600 | 115200

*RST: n.a. (factory preset: 115200)

Example:

See [Example "Finding out the used VISA resource strings"](#) on page 658.

Manual operation: See ["Baud Rate"](#) on page 367

:SYSTEM:COMMunicate:SERial:PARity <Parity>

Enters the parity for the serial remote control interface.

Parameters:

<Parity> NONE | ODD | EVEN

*RST: n.a. (factory preset: NONE)

Example:

See [Example "Finding out the used VISA resource strings"](#) on page 658.

Manual operation: See ["Parity"](#) on page 368

:SYSTEM:COMMunicate:SERial:RESource?

Queries the visa resource string for the serial remote control interface. This string is used for remote control of the instrument.

Return values:

<Resource> string

Example:

See [Example "Finding out the used VISA resource strings"](#) on page 658.

Usage:

Query only

:SYSTEM:COMMunicate:SERial:SBITs <SBits>

Defines the number of stop bits for the serial remote control interface.

Parameters:

<SBits> 1 | 2
 *RST: n.a. (factory preset: 1)

Example: See [Example "Finding out the used VISA resource strings"](#) on page 658.

Manual operation: See ["Stop Bits"](#) on page 368

:SYSTEM:COMMunicate:SOCKet:RESource?

Queries the visa resource string for remote control via LAN interface, using TCP/IP socket protocol.

Return values:

<Resource> string

Example: See [Example "Finding out the used VISA resource strings"](#) on page 658.

Usage: Query only

:SYSTEM:COMMunicate:USB:RESource?

Queries the visa resource string for remote control via the USB interface.

Return values:

<Resource> string

Example: See [Example "Finding out the used VISA resource strings"](#) on page 658.

Usage: Query only

:SYSTEM:HELP:EXPort

Saves the online help as zip archive in the user directory.

Example:

```
:SYSTEM:HELP:EXPort
MMEM:CDIR?
// "/var/user"
MMEM:CAT?
// ..,"Log,DIR,4096","help.tgz,BIN,69836600"
// confirms that help zip archive is saved.
```

Usage: Event

Manual operation:: "Setup > Help > Export Help to User Path"

:SYSTEM:IDENTification <Identification>

Selects the mode to determine the "IDN String" and the "OPT String" for the instrument, selected with command `:SYSTEM:LANGuage`.

Note: While working in an emulation mode, the R&S SMA100B specific command set is disabled, that is, the SCPI command `SYST:IDEN` is discarded.

Parameters:

<Identification> AUTO | USER

AUTO
Automatically determines the strings.

USER
User-defined strings can be selected.

*RST: n.a. (factory preset: AUTO)

Example:

```
SYST:IDEN AUTO
```

Automatically assigns the OPT and IDN strings according to the selected instrument language.

Manual operation: See "[Mode](#)" on page 369

:SYSTEM:IDENTification:PRESet

Sets the *IDN and *OPT strings in user defined mode to default values.

Example:

```
SYST:IDEN USER
SYST:IDEN:PRES
```

Usage: Event

Manual operation: See "[Set to Default](#)" on page 369

:SYSTEM:IRESpouse <IdnResponse>

Defines the user defined identification string for *IDN.

Note: While working in an emulation mode, the instrument's specific command set is disabled, i.e. the SCPI command `SYST:IRES` is discarded.

Parameters:

<IdnResponse> string

Example:

```
SYST:IDEN USER
// Selects a user-defined identification
SYST:IRES "Test Device"
// Defines identification string 'test device'
*IDN?
// Response: 'test device'
```

Manual operation: See "[IDN String](#)" on page 369

:SYSTEM:ORESpouse <OResponse>

Defines the user defined response string for *OPT.

Note: While working in an emulation mode, the instrument's specific command set is disabled, i.e. the SCPI command `SYST:ORES` is discarded.

Parameters:**<OResponse>** string**Example:**

```

SYST:IDEN USER
// Selects a user-defined identification
SYST:ORES "Test Option"
// Defines the OPT string 'test option'
*OPT?
// Response: 'test option'

```

Manual operation: See "[OPT String](#)" on page 369**:SYSTem:LANGUage <Language>**

Sets the remote control command set.

Parameters:**<Language>** string**Example:**

```

SYSTem:LANGUage "SCPI"
// selects SCPI command set

```

Manual operation: See "[Language](#)" on page 368**:SYSTem:INFormation:SCPI <InfoString>**

Inserts system information in recorded SCPI command lists, for example information on a missing command.

Parameters:**<InfoString>** string**Example:**

```

SYST:INF:SCPI "missing command"

```

enters the information into a recorded SCPI command list.

:SYSTem:SECurity:SANitize[:STATe] <SecPassWord>, <MmemProtState>

Sanitizes the internal memory.

Parameters:

<MmemProtState> 0 | 1 | OFF | ON
***RST:** 0

Setting parameters:**<SecPassWord>** string**Example:**

```

SYSTem:SECurity:SANitize[:STATe] 1

```

Manual operation: See "[Sanitize](#)" on page 342**:SYSTem:SECurity:SUPolicy <SecPassWord>, <UpdatePolicy>**

Configures the automatic signature verification for firmware installation.

Parameters:

<UpdatePolicy> STRict | CONFirm | IGNore
*RST: n.a. (factory preset: CONFirm)

Setting parameters:

<SecPassWord> string

Manual operation: See "[Secure Update Policy](#)" on page 340

:SYSTEM:SPECification? <Id>

Retrieves data sheet information for a specific parameter.

Setting parameters:

<Id> string
Identifies the name of the entry in the data sheet, as queried with the command `:SYSTEM:SPECification:IDENTification:CATalog?` on page 676

Return values:

<ValList> float
Comma-separated list with the specified and, if available, the typical value of the parameter, as specified in the data sheet. See also "[Data Sheet](#)" on page 378.

Example:

Retrieving instruments specification

Note: The following values are merely an example.

Query the data sheet versions stored in the instrument:

```
:SYSTem:SPECification:VERSion:CATalog?
"04.03,04.02,04.01,04.00,03.04,03.03,03.02,
03.01,03.00,02.96,02.95,02.94,02.02,02.01,
02.00,01.03,01.02,01.01,01.00"
```

Query the data sheet version with that the instrument was delivered:

```
:SYSTem:SPECification:VERSion:FACTory?
"04.00"
```

Select a data sheet version:

```
:SYSTem:SPECification:VERSion?
"04.00"
:SYSTem:SPECification:VERSion "04.01"
```

Selects one particular data sheet version.

Queries regarding data sheet parameters (IDs) and their values
Refer to this particular data sheet

Query the IDs of all parameters listed in the **selected** data sheet version:

```
:SYSTem:SPECification:IDENtification:CATalog?
"ID_RF_FREQ_SETTING_TIME_ALC_ON_MS,
ID_RF_FREQ_SETTING_TIME_MS,..."
```

Query the data sheet information on a specific parameter, defined by its ID

```
:SYSTem:SPECification?
"ID_RF_FREQ_SETTING_TIME_ALC_ON_MS"
```

Returned is the specified and, if available, the typical value of the parameter

Usage:

Query only

:SYSTem:SPECification:VERSion <Version>

Selects a data sheet version from the data sheets saved on the instrument.

Further queries regarding the data sheet parameters (<Id>) and their values refer to the selected data sheet.

To query the list of data sheet versions, use the command `:SYSTem:SPECification:VERSion:CATalog?` on page 677.

Parameters:

<Version> string

Example: See `:SYSTem:SPECification?` on page 675.

:SYSTem:SPECification:IDENtification:CATalog?

Queries the parameter identifiers (<Id>) available in the data sheet.

Return values:

<IdList> string
Comma-separated string of the parameter identifiers (<Id>)

Example: See [:SYSTem:SPECification?](#) on page 675.

Usage: Query only

:SYSTem:SPECification:PARAmeter? <Id>[, <Parameter>]

Retrieves data sheet information for a specific parameter.

Setting parameters:

<Id> string
Identifies the name of the entry in the data sheet.
Query the data sheet parameters with the command [:SYSTem:SPECification:IDENTification:CATalog?](#).

<Parameter> float
An additional value the result (ValList) depends on.

Return values:

<ValList> float
Comma-separated list with the specified and, if available, the typical value of the parameter, as specified in the data sheet.

Example: **Note:** The following values are merely an example. Your instrument may not support the same parameters.

```
SYST:SPEC:PAR? "ID_RF_FREQ_SETTING_TIME_MS",0.1
SYST:SPEC:PAR? "ID_RF_LEVEL_MAX_GENERAL_DBM",
0.1
```

Usage: Query only

:SYSTem:SPECification:VERSion:CATalog?

Queries all data sheet versions stored in the instrument.

Return values:

<VersCatalog> string

Example: See [:SYSTem:SPECification?](#) on page 675.

Usage: Query only

:SYSTem:SPECification:VERSion:FACTory?

Queries the data sheet version of the factory setting.

Return values:

<Version> string

Example: See [:SYSTem:SPECification?](#) on page 675.

Usage: Query only
Manual operation: See "[Versions](#)" on page 706

:SYSTEM:SRData?

Queries the SCPI recording data from the internal file.

This feature enables you to transfer an instrument configuration to other test environments, as e.g. laboratory virtual instruments.

Return values:

<FileData> block data

Example:

```
SYSTEM:SRData?
// #3118:SOURce1:ROSCillator:SOURce EXT
// :SOURce1:FREQuency:CW 4000000000
// :SOURce1:FREQuency:OFFSet 1000000
// :SOURce1:AM1:STATe 1
// :OUTPut1:STATe 1
```

Usage: Query only

:SYSTEM:STARtup:COMPLete?

Queries if the startup of the instrument is completed.

Return values:

<Complete> 0 | 1 | OFF | ON
 *RST: 0

Example:

```
SYST:STAR:COMP?
Response: 1
the startup of the instrument is completed.
```

Usage: Query only

:SYSTEM:DATE <Year>, <Month>, <Day>

Queries or sets the date for the instrument-internal calendar.

This is a password-protected function. Unlock the protection level 1 to access it.

Parameters:

<Year> integer
 <Month> integer
 Range: 1 to 12
 <Day> integer
 Range: 1 to 31

Example:

```
:SYSTEM:DATE?
// 2016,05,01
```

Manual operation: See ["Date"](#) on page 695

:SYSTem:NTP:HOSTname <NTPName>

Sets the address of the NTP server. You can enter the IP address, or the hostname of the time server, or even set up an own vendor zone. See the Internet for more information on NTP.

Parameters:

<NTPName> string

Manual operation: See ["NTP Address"](#) on page 696

:SYSTem:NTP:STATe <UseNtpState>

Activates clock synchronization via NTP.

Parameters:

<UseNtpState> 0 | 1 | OFF | ON
 *RST: n.a. (factory preset: 0)

Example: SYSTem:NTP:STATe 1

Manual operation: See ["Use Time from NTP Server"](#) on page 696

:SYSTem:TIME <Hour>, <Minute>, <Second>

Queries or sets the time for the instrument-internal clock.

This is a password-protected function. Unlock the protection level 1 to access it.

Parameters:

<Hour> integer
 Range: 0 to 23
 <Minute> integer
 Range: 0 to 59
 <Second> integer
 Range: 0 to 59

Example: SYSTem:TIME?
 // 10,27,14

Manual operation: See ["Time"](#) on page 695

:SYSTem:TIME:ZONE <TimeZone>

Sets the timezone. You can query the list of the available timezones with [:SYSTem:TIME:ZONE:CATalog?](#).

Parameters:

<TimeZone> string

Manual operation: See "Timezone" on page 696

:SYSTem:TIME:ZONE:CATalog?

Queries the list of available timezones.

Return values:

<Catalog>

Usage: Query only

Manual operation: See "Timezone" on page 696

:SYSTem:UPTime?

Queries the up time of the operating system.

Return values:

<UpTime> "<ddd.hh:mm:ss>"

Example: SYSTem:UPTime?
Response: "0.08:11:00"

Usage: Query only

:SYSTem:BIOS:VERSion?

Queries the BIOS version of the instrument.

Return values:

<Version> string

Example: SYST:BIOS:VERS?
queries the BIOS version.
Response: 123456

Usage: Query only

:SYSTem:VERSion?

Queries the SCPI version the instrument's command set complies with.

Return values:

<Version> string

Example: SYST:VERS
queries the SCPI version.
Response: "1996"
The instrument complies with the SCPI version from 1996.

Usage: Query only

:SYSTEM:OSYSTEM?

Queries the operating system of the instrument.

Return values:

<OperSystem> string

Example: SYSTEM:OSYSTEM?
Response: "Linux"

Usage: Query only

:SYSTEM:MMEMORY:PATH:USER?

Queries the user directory, that means the directory the R&S SMA100B stores user files on.

Return values:

<PathUser> string

Example: SYSTEM:MMEMORY:PATH:USER?
Response: "/var/user/"

Usage: Query only

:SYSTEM:DFPR?

Queries the device footprint of the instrument. The retrieved information is in machine-readable form suitable for automatic further processing.

Return values:

<DeviceFootprint> string
Information on the instrument type, device identification and details on the installed FW version, hardware and software options.

Example: :SYSTEM:DFPR?

Usage: Query only

:SYSTEM:REBoot

Reboots the instrument including the operating system.

Usage: Event

:SYSTEM:REStart

Restarts the instrument without restarting the operating system.

Usage: Event

:SYSTem:SHUTdown

Shuts down the instrument.

Usage: Event

Manual operation: See "Shut down" on page 703

:SYSTem:WAIT <TimeMs>

Delays the execution of the subsequent remote command by the specified time.

This function is useful, for example to execute an SCPI sequence automatically but with a defined time delay between some commands.

See [Chapter 12.2.3, "Assigning Actions to the \[★ \(User\)\] Key"](#), on page 331.

Setting parameters:

<TimeMs> integer
 Wait time in ms
 Range: 0 to 10000
 *RST: 0

Example:

```
:SYSTem:WAIT 10000
// waits 10s before resetting the instrument
*RST
```

Usage: Setting only

:SYSTem:FILEs:TEMPorary:DELeTe

Deletes the temporary files from the internal memory or, if installed, from the SD card slot.

Example:

```
:SYSTem:FILEs:TEMPorary:DELeTe
// temporary files are removed
```

Usage: Event

14.18 STATus Subsystem

This system contains the commands for the status reporting system. See also [Chapter A.1.5, "Status Reporting System"](#), on page 727 for detailed information.

*RST on page 415 has no effect on the status registers.

Value ranges

- Queries return the current value of the respective register, which permits a check of the device status.
 Return values: A decimal value in the range 0 to 32767 ($=2^{15}-1$)

- The configuration commands set the respective register thus determining which status changes of the R&S SMA100B cause the status registers to be changed.
Setting values: A decimal value in the range 0 to 32767 ($=2^{15}-1$)

:STATus:OPERation:CONDition?	683
:STATus:OPERation:ENABLE	683
:STATus:OPERation[:EVENT]	683
:STATus:OPERation:NTRansition	684
:STATus:OPERation:PTRansition	684
:STATus:PRESet	684
:STATus:QUESTionable:CONDition	685
:STATus:QUESTionable:ENABLE	685
:STATus:QUESTionable[:EVENT]	685
:STATus:QUESTionable:NTRansition	685
:STATus:QUESTionable:PTRansition	686
:STATus:QUEue[:NEXT]?	686

:STATus:OPERation:CONDition?

Queries the content of the CONDition part of the STATus:OPERation register.

This part contains information on the action currently being performed in the instrument. The content is not deleted after being read out because it indicates the current hardware status.

Return values:

<Condition> string

Example: :STATus:OPERation:CONDition?

Usage: Query only

:STATus:OPERation:ENABLE <Enable>

Sets the bits of the ENABLE part of the STATus:OPERation register. This setting determines which events of the Status-Event part are forwarded to the sum bit in the status byte. These events can be used for a service request.

Parameters:

<Enable> string

Example: :STAT:OPER:ENAB 32767
all events are forwarded to the sum bit of the status byte.

:STATus:OPERation[:EVENT] <Event>

Queries the content of the EVENT part of the STATus:OPERation register. This part contains information on the actions performed in the instrument since the last readout. The content of the EVENT part is deleted after being read out.

Parameters:

<Event> string

Example: `:STAT:OPER:EVEN?`
queries the STATus:OPERation:EVENT register.

:STATus:OPERation:NTRansition <Ntransition>

Sets the bits of the NTRansition part of the STATus:OPERation register. If a bit is set, a transition from 1 to 0 in the condition part causes an entry to be made in the EVENT part of the register. The disappearance of an event in the hardware is thus registered, for example the end of an adjustment.

Parameters:

<Ntransition> string

Example: `:STAT:OPER:NTR 0`
a transition from 1 to 0 in the condition part of the Status:Operation register does not cause an entry to be made in the EVENT part.

:STATus:OPERation:PTRansition <Ptransition>

Sets the bits of the PTRansition part of the STATus:OPERation register. If a bit is set, a transition from 0 to 1 in the condition part causes an entry to be made in the EVENT part of the register. A new event in the hardware is thus registered, for example the start of an adjustment.

Parameters:

<Ptransition> string

Example: `:STAT:OPER:PTR 32767`
all transitions from 0 to 1 in the condition part of the Status:Operation register cause an entry to be made in the EVENT part.

:STATus:PRESet <Preset>

Resets the status registers. All PTRansition parts are set to FFFFh (32767), i.e. all transitions from 0 to 1 are detected. All NTRansition parts are set to 0, i.e. a transition from 1 to 0 in a CONDition bit is not detected. The ENABLE parts of STATus:OPERation and STATus:QUESTionable are set to 0, i.e. all events in these registers are not passed on.

Parameters:

<Preset> string

Example: `STAT:PRES`
resets the status registers.

:STATus:QUEStionable:CONDition <Condition>

Queries the content of the CONDition part of the STATus:QUEStionable register. This part contains information on the action currently being performed in the instrument. The content is not deleted after being read out since it indicates the current hardware status.

Parameters:

<Condition> string

Example:

`:STATus:QUEStionable:CONDition?`
queries the Status:Questionable:Condition register.

:STATus:QUEStionable:ENABle <Enable>

Sets the bits of the ENABle part of the STATus:QUEStionable register. The enable part determines which events of the STATus:EVENT part are enabled for the summary bit in the status byte. These events can be used for a service request.

If a bit in the ENABle part is 1, and the corresponding EVENT bit is true, a positive transition occurs in the summary bit. This transition is reported to the next higher level.

Parameters:

<Enable> string

Example:

`STAT:QUES:ENAB 1`
Problems when performing an adjustment cause an entry to be made in the sum bit.

:STATus:QUEStionable[:EVENT] <Event>

Queries the content of the EVENT part of the STATus:QUEStionable register. This part contains information on the actions performed in the instrument since the last readout. The content of the EVENT part is deleted after being read out.

Parameters:

<Event> string

Example:

`STAT:QUES:EVENT?`
queries the Status:Questionable:Event register.

:STATus:QUEStionable:NTRansition <Ntransition>

Sets the bits of the NTRansition part of the STATus:QUEStionable register. If a bit is set, a transition from 1 to 0 in the condition part causes an entry to be made in the EVENT part of the register.

Parameters:

<Ntransition> string

Example: `STAT:QUES:NTR 0`
 a transition from 1 to 0 in the condition part of the STATus:QUEStionable register does not cause an entry to be made in the EVENT part

:STATus:QUEStionable:PTRansition <PTransition>

Sets the bits of the NTRansition part of the STATus:QUEStionable register. If a bit is set, a transition from 1 to 0 in the condition part causes an entry to be made in the EVENT part of the register.

Parameters:

<PTransition> string

Example: `STAT:QUES:PTR 32767`
 all transitions from 0 to 1 in the condition part of the STATus:QUEStionable register cause an entry to be made in the EVENT part

:STATus:QUEue[:NEXT]?

Queries the oldest entry in the error queue and then deletes it. Positive error numbers denote device-specific errors, and negative error numbers denote error messages defined by SCPI. If the error queue is empty, 0 ("No error") is returned.

The command is identical to `:SYSTem:ERRor[:NEXT]?` on page 662.

Return values:

<Next> string

Example: `:STATus:QUEue?`
 queries the oldest entry in the error queue.
 Response: 0, 'no error'
 no errors have occurred since the error queue was last read out

Usage: Query only

14.19 TEST Subsystem

The TEST subsystem contains the commands for performing test routines directly at the hardware assemblies.

The selftest responses with a 0 if the test is performed successfully, otherwise a value other than 0 is returned. None of the commands of this system has a *RST value.

`:TEST<hw>:ALL:START`..... 686
`:TEST<hw>:ALL:RESult?`.....687

:TEST<hw>:ALL:START

Usage: Event

Starts the selftest. Use the command `:TEST<hw>:ALL:RESult?` to query the result.

:TEST<hw>:ALL:RESult?

Queries the result of the performed selftest. Start the selftest with `:TEST<hw>:ALL:START`.

Return values:

<Result> 0 | 1 | RUNning | STOPped
*RST: STOPped

Usage: Query only

14.20 TRIGger Subsystem

The TRIGger system contains the commands for selecting the trigger source for the RF and LF sweep.

You can work with an internal or with an externally applied trigger signal. In this case, use the commands in the `SOURCE:INPut` subsystem to configure the signal.

The trigger system of the R&S SMA100B is a simplified implementation of the SCPI trigger system. The TRIGger system differs from the SCPI system as follows:

- No `INITiate` command; the instrument behaves as if `INITiate:CONTinuous ON` were set.
- Under TRIGger several sweep subsystems exist.
- The trigger source names correspond directly to the various settings of manual control. SCPI uses different names which are also accepted by the instrument. The SCPI names should be used if compatibility is an important consideration.

In addition to these commands, see more trigger-related commands in the modulation and RF signal subsystems.

Table 14-1: Cross-reference between the manual and remote control

R&S proprietary value name	SCPI conform value name	Parameter in manual control
AUTO	IMMediate	"Auto" mode
SINGle	BUS	"Single" mode.
EXTernal	EXTernal	"Ext Single" and "Ext Step" mode. Use command <code>LFO:SWEep:MODE</code> to select between the two sweep modes.
EAUTO	-	"Ext Start/Stop" mode.

<code>:TRIGger<hw>:FSWweep:SOURce</code>	688
<code>:TRIGger<hw>:LFFSweep:SOURce</code>	688
<code>:TRIGger<hw>:PSWweep:SOURce</code>	688
<code>:TRIGger<hw>[:SWEep]:SOURce</code>	688

:TRIGger<hw>:FSweep[:IMMEDIATE].....	689
:TRIGger<hw>:PSweep[:IMMEDIATE].....	689
:TRIGger<hw>:LFFSweep:IMMEDIATE.....	689
:TRIGger<hw>[:SWEep][:IMMEDIATE].....	689
:TRIGger<hw>:LFFSweep.....	689

```

:TRIGger<hw>:FSweep:SOURce <Source>
:TRIGger<hw>:LFFSweep:SOURce <Source>
:TRIGger<hw>:PSweep:SOURce <Source>
:TRIGger<hw>[:SWEep]:SOURce <Source>

```

Selects the trigger source for the corresponding sweeps:

- FSweep - RF frequency
- LFFSweep - LF frequency
- PSweep - RF level
- SWEep - all sweeps

The source names of the parameters correspond to the values provided in manual control of the instrument. They differ from the SCPI-compliant names, but the instrument accepts both variants.

Use the SCPI name, if compatibility is an important issue. Find the corresponding SCPI-compliant commands in [Cross-reference between the manual and remote control](#).

Setting parameters:

<Source> AUTO | IMMEDIATE | SINGLE | BUS | EXTERNAL | EAUTO

AUTO [IMMEDIATE]

Executes a sweep automatically.

In this free-running mode, the trigger condition is met continuously. I.e. when a sweep is completed, the next one starts immediately.

SINGLE [BUS]

Executes one complete sweep cycle.

The following commands initiate a trigger event:

*TRG on page 416

```
[ :SOURce<hw> ] :SWEep:POWer:EXECute
```

```
[ :SOURce<hw> ] :SWEep [ :FREQuency ] :EXECute
```

```
:TRIGger<hw> [ :SWEep ] [ :IMMEDIATE ], :TRIGger<hw>:
```

```
PSweep [ :IMMEDIATE ] and :TRIGger<hw>:FSweep [ :
```

```
IMMEDIATE ].
```

Set the sweep mode with the commands:

```
[ :SOURce<hw> ] :SWEep:POWer:MODE AUTO | STEP
```

```
[ :SOURce<hw> ] :SWEep [ :FREQuency ] :MODE AUTO | STEP
```

```
[ :SOURce<hw> ] :LFOutput:SWEep [ :FREQuency ] :MODE
```

```
AUTO | STEP
```

In step mode (STEP), the instrument executes only one step.

EXTERNAL

An external signal triggers the sweep.

EAUTO

An external signal triggers the sweep. When one sweep is finished, the next sweep starts.

A second trigger event stops the sweep at the current frequency, a third trigger event starts the trigger at the start frequency, and so on.

*RST: AUTO

Example: See [Example "Setup an LF sweep"](#) on page 603

Usage: Setting only

Manual operation: See ["Mode"](#) on page 175

:TRIGger<hw>:FSweep[:IMMEDIATE]

:TRIGger<hw>:PSweep[:IMMEDIATE]

:TRIGger<hw>:LFFSweep:IMMEDIATE

:TRIGger<hw>[:SWEep][:IMMEDIATE]

Performs a single sweep and immediately starts the activated, corresponding sweep:

- FSWep - RF frequency
- PSWep - RF level
- LFFSweep - LF frequency
- SWEep - all sweeps

Effective in the following configuration:

- TRIG:FSW|LFFS|PSW|[:SWE]:SOUR **SING**
- SOUR:SWE:FREQ|POW:MODE **AUTO** or SOUR:LFO:SWE:[FREQ:]MODE **AUTO**

Alternatively, you can use the IMMEDIATE command instead of the respective SWEep : [FREQ:] | POW:EXECute command.

Example: TRIG
Starts all active sweeps.

Usage: Event

Manual operation: See ["Execute Single Sweep"](#) on page 178

:TRIGger<hw>:LFFSweep

Executes an LF frequency sweep in the following configuration:

- TRIG:LFFS:SOUR SING
- LFO:SWE:MODE AUTO

Example: LFO:SWE:MODE AUTO
TRIG:LFFS:SOUR SING
TRIG:LFFSweep

Usage: Event

14.21 UNIT Subsystem

The `UNIT` subsystem is used to set default units for parameters if no unit is indicated in a command. These settings are valid for the entire instrument.

Example: Setting default units for remote control

```
UNIT:POW V
UNIT:ANGL DEG
```

Sets V (volts) as unit of all power parameters, DEG (degrees) for the phase modulation angle and KMH for the speed.

```
:UNIT:ANGLE.....690
:UNIT:POWer.....690
```

:UNIT:ANGLE <Angle>

Sets the default unit for phase modulation angle. The command affects no other parameters, such as RF phase, or the manual control or display.

Parameters:

```
<Angle>          DEGREE | DEGREE | RADIAN
                  *RST:      RADIAN
```

:UNIT:POWer <Power>

Sets the default unit for all power parameters. This setting affects the GUI, as well as all remote control commands that determine power values.

Parameters:

```
<Power>          V | DBUV | DBM
                  *RST:      DBM
```

15 Maintenance

The instrument does not need periodic maintenance. Only the cleaning of the instrument is essential.

Follow the instructions in the service manual and the safety instructions when exchanging modules or ordering spares. The order no. for spare parts is included in the service manual. The service manual includes further information particularly on troubleshooting, repair, exchange of modules and alignment.

The address of our support center and a list of all Rohde & Schwarz service centers can be found at the beginning of this manual.

NOTICE

Risk of damage during shipment

Insufficient protection against mechanical and electrostatic effects during shipment can damage the instrument.

- When shipping an instrument, use the original packaging. If you do not have the original packaging, use sufficient padding to prevent the instrument from moving around inside the box.
- Pack the instrument in antistatic wrap to protect it from electrostatic charging.
- Secure the instrument to prevent any movement and other mechanical effects during transportation.

15.1 Cleaning

⚠ WARNING

Risk of electric shock

If moisture enters the casing, for example if you clean the instrument using a moist cloth, contact with the instrument can lead to electric shock. Before cleaning the instrument other than with a dry cloth, make sure that the instrument is switched off and disconnected from all power supplies.

NOTICE**Instrument damage caused by cleaning agents**

Cleaning agents contain substances such as solvents (thinners, acetone, etc.), acids, bases, or other substances. Solvents can damage the front panel labeling, plastic parts, or screens, for example.

Never use cleaning agents to clean the outside of the instrument. Use a soft, dry, lint-free dust cloth instead.

NOTICE**Risk of instrument damage due to obstructed fans**

If the instrument is operated in dusty areas, the fans become obstructed by dust or other particles over time. Check and clean the fans regularly to ensure that they always operate properly. If the instrument is run with obstructed fans for a longer period, the instrument overheats, which can disturb the operation and even cause damage.

1. Clean the outside of the instrument using a soft, dry, lint-free dust cloth.
2. Check and clean the fans regularly to ensure that they always operate properly.

15.2 Storing and Packing

The storage temperature range of the instrument is given in the data sheet. If the instrument is to be stored for a longer period of time, it must be protected against dust.

Repack the instrument as it was originally packed when transporting or shipping. The two protective foam plastic parts prevent the control elements and connectors from being damaged. The antistatic packing foil avoids any undesired electrostatic charging to occur.

If you do not use the original packaging, use a sturdy cardboard box of suitable size and provide for sufficient padding to prevent the instrument from slipping inside the package. Wrap antistatic packing foil around the instrument to protect it from electrostatic charging.

15.3 Performing Maintenance Tasks

The R&S SMA100B is accurate due to integrated adjustment procedures, which you can execute directly on the instrument.

Internal Adjustments

NOTICE


Risk of DUT damage

During internal adjustments, the instrument temporarily applies high power at the RF output. This high power can destroy a connected DUT (device under test).


Do not start internal adjustments if the DUT is connected.

Disconnect the DUT and replace it by a terminating resistor with adequate power rating.

Note: Before the internal adjustment starts, a warning message prompts you to make sure that you have terminated the RF output as specified in the message. The required power of the resistor varies depending on whether the instrument is equipped with a high power option.



If the termination resistor is missing, a second warning message appears.



NOTICE

Risk of invalid adjustment

Wait until the instrument has reached its operating temperature before you start the adjustment procedure. The warm-up time is 30 minutes.



Self-calibration routines that require additional (external) equipment are performed at an authorized Rohde & Schwarz service center.

See also "[Protection levels](#)" on page 337.

When to perform adjustments?

We recommend that you perform internal adjustments in the following cases:

- Before starting any application, that requires a maximum of level and frequency accuracy
- When a long period of time has passed since the last adjustments
- If the ambient temperature of the instrument significantly differs from the one of the last adjustments
- When changing the frequency setting

Additional Information to the Adjustments

During adjustments, a progress indicator shows the status of the process. If any error occurs, the process aborts and an error message appears in the info line.

The extent of the adjustments depends on the installed options.

15.3.1 Date and Time Settings

The R&S SMA100B uses an internal real-time clock to determine the date and time. It adjusts the time and date to the timezone of your location automatically, by providing a selection list of continents and cities.

The instrument records the time whenever you create or modify files on your instrument or you use timed licenses. By default, the instrument is set to the UTC timezone, but you can select the timezone according to your location.

Moreover, the instrument supports NTP protocol for synchronizing all connected instruments and computer systems to minimize time delays in the network.

Access:

- ▶ Select "System Config > Setup > Maintenance > Date / Time".

The "Date / Time" dialog contains the time and data settings of the operating system.

This function is password-protected. Unlock the protection level 1 to access it.

The required remote commands are described in [Chapter 14.17, "SYSTem Subsystem"](#), on page 657.

To select the timezone

1. Press the [Setup] key.
2. Select "Maintenance > Date /Time > Timezone".
3. Select continent and city of your location.
Tip: By typing the first letter, you can quickly navigate through the lists to find the desired destination.
4. Close the dialogs.

The instrument adjusts the time according to the selected location.

To set the date and time

1. Press the [Setup] key.
2. Select "Security > Protection".
3. Enable the "Protection Level 1".
The default password is *123456*.
4. Select "Setup > Maintenance > Date / Time".
5. Adjust the settings.
6. Close the dialogs.

The instrument adopts the new date and time.

Settings:

Date.....	695
Time.....	695
Timezone.....	696
NTP Address.....	696
Use Time from NTP Server.....	696

Date

Displays the date set in the operating system in the format [dd.mm.yyyy].

Remote command:

:SYSTem:DATE on page 678

Time

Displays the time set in the operating system in the format [hh.mm.ss].

The time setting corresponds to the selected [Use Time from NTP Server](#).

Remote command:

:SYSTem:TIME on page 679

Timezone

Selects the timezone.

You can select the timezone according to the major cities on the respective continents.

Note: By typing the first letter, you can quickly navigate through the lists to find the desired destination.

Remote command:

:SYSTem:TIME:ZONE on page 679

:SYSTem:TIME:ZONE:CATalog? on page 680

NTP Address

Sets the IP address or host name of the NTP server.

NTP is a network time protocol used for synchronizing all participating devices in a data network.

You can select a high-precision time server to reduce the impact of varying network delays.

Remote command:

:SYSTem:NTP:HOSTname on page 679

Use Time from NTP Server

Activates clock synchronization of the network via the NTP protocol.

Remote command:

:SYSTem:NTP:STATe on page 679

15.3.2 Check Front Panel

Within this dialog, you can verify the functionality of the control keys.

For Instructions on how to perform the tests and the expected results, see [Chapter 15.3.2.2, "How to Test the Front Panel"](#), on page 697

In case of malfunctions:

Contact the Rohde & Schwarz customer support, see [Chapter 16.6, "Collecting Information for Technical Support"](#), on page 713.

**Accessing the online help in the check front panel dialog or exiting via [Esc]**

During the test, the actual functions of all keys are disabled, including the [Help] and the [Esc] keys.

15.3.2.1 Check Front Panel Settings

Access:

- ▶ Select "System Config > Setup > Maintenance > Check Front Panel".



Reflecting the front panel, the "Check Front Panel" dialog contains all functions to test the operating elements of the instrument.

15.3.2.2 How to Test the Front Panel

How to perform the key panel test

To perform the key panel test, you operate the keys at the front panel, and check the response of the instrument in the "Check Front Panel" dialog. To perform this test properly, check each key of the front panel. The test is only completed, when you have verified all keys.

During the test, the actual functions of the keys are disabled.

1. Press the [Setup] key.
2. Select "Maintenance > Check Front Panel"
The "Check Front Panel" dialog opens.
3. Press a key on the front panel.
Check if the corresponding key in the "Check Front Panel" dialog turns green.
4. Press the same key a second time.
Check that the key in the dialog turns red.

Note: Pressing the same key again has no further effect, except for the [Esc] key, see [Press the ESC key a third time](#).

- Continue with the next key on the front panel and repeat [step 3](#) to [step 5](#) until all keys are tested.

The test is completed, when each key is verified successfully, confirmed by a "Test passed" message.

- ▶ Press the [Esc] key a third time.
Exits the "Check Front Panel" dialog.

Expected responses:


- Pressing a key once (green), pressing twice (red)
- Pressing the [Esc] key a third time exits the dialog.

If you detect a malfunction, for example, you press the front panel key the first time, and the color of the button in the dialog turns red (instead of green), the front panel key may be stuck.

Contact the Rohde & Schwarz customer support, see [Chapter 16.6, "Collecting Information for Technical Support"](#), on page 713.

How to perform the touchscreen test


- Press the [Setup] key.
- Select "Maintenance > Check Touch Panel"
The "Finger Paint" test window opens.




- Drag with your finger one or more lines, for example diagonally across the screen.
The test traces the movements of your finger on the screen.

The following results are expected:

- If the lines are uninterrupted, the touchscreen works properly.



- If there are any gaps, the touch-sensitive functionality is damaged.



- To return to the "Check Front Panel" dialog, press [Esc].


If there are malfunctions:

Contact the Rohde & Schwarz customer support, see [Chapter 16.6, "Collecting Information for Technical Support"](#), on page 713.

15.3.3 Internal Adjustment Settings

Access:

- ▶ Select "System Config > Setup > General > Internal Adjustments".



In this dialog, you can perform internal calibration routines and get information on the last performed calibration.

The remote commands required to define these settings are described in [Chapter 14.6, "CALibration Subsystem"](#), on page 428.



The background color of "Temperature Offset" depends on the deviation of the temperature at the beginning of the adjustment, compared to the last adjustment. We recommend that you perform internal adjustments if the instrument is warmed up, but depending on instrument usage, less than 30 minutes are sufficient.

Further functions and individually targeted calibration routines are also available but password-protected.

- Calibration routines
Self-calibration routines that require additional (external) equipment are performed in the Rohde & Schwarz service center.
These functions are password-protected and require higher-level protection password, see ["Protection levels"](#) on page 337

For more information, see R&S SMA100B Service Manual.

Adjust All


Performs all available internal calibration routines of the instrument.

NOTICE! Risk of DUT damage. During internal adjustments, the instrument temporarily applies high power at the RF output. This high power can destroy a connected DUT (device under test).


Do not start internal adjustments if the DUT is connected.

Disconnect the DUT and replace it by a terminating resistor with adequate power rating.

Note: Before the internal adjustment starts, a warning message prompts you to make sure that you have terminated the RF output as specified in the message. The required power of the resistor varies depending on whether the instrument is equipped with a high power option.



If the termination resistor is missing, a second warning message appears.



Remote command:

`:CALibration:ALL[:MEASure]?` on page 429

Last Full Adjustment

Displays the date of the last fully performed adjustment.

Remote command:

`:CALibration<hw>:ALL:DATE?` on page 429

Time Since Last Full Adjustment

Displays the elapsed time since the last full adjustment.

Remote command:

`:CALibration<hw>:ALL:TIME?` on page 430

Temperature Offset Since Last Full Adjustment

Displays the temperature difference, comparing the temperature at the beginning of the last adjustment to the temperature at the beginning of the present adjustment.

If the temperature deviates more than ± 5 K, the background of the parameter turns yellow.

Remote command:

`:CALibration<hw>:ALL:TEMP?` on page 430

Information

Displays information to the current adjustment state.

Remote command:

`:CALibration<hw>:ALL:INformation?` on page 429

Continue Adjustment on Error

Continues the calibration even though an error was detected. By default adjustments are aborted on error.

This function is password-protected. Unlock the protection level 1 to access it.


Remote command:

:CALibration<hw>:CONTinueonerror on page 431

15.3.4 FPGA/uC Update Settings

Access:

- ▶ Select "System Config > Setup > Maintenance > FPGA/μC Update".



This dialog enables you to check for and install internal assembly updates.

Settings:

Check For Updates.....	702
Assembly.....	702
Install.....	702
Shut down.....	703

Check For Updates

Check for updates of the FPGA/μC.

Remote command:

n.a.

Assembly

The table shows the installed assemblies and their states.

"Assembly" Assembly designation.

"State" Indicates the current state of installed assemblies.

Install

Install all available updates for the FPGA/μC.

Remote command:

n.a.

Shut down

For at least one assembly "State = Done" and no pending assemblies, shuts the instrument down to applies installed updates.

Remote command:

:SYSTem:SHUTdown on page 682

15.3.5 Requesting Instrument Configuration and Specifications

The R&S SMA100B is equipped with various hardware and software components. To get an overview of what your instrument is equipped with, you can request the assemblies, hardware and software options, and the firmware version. The components are structured according to the hardware configuration, software options, including the license management, and externally used Rohde & Schwarz equipment, like R&S NRP power sensors.



Software options purchased at a later stage can be activated with a keycode. The activation code is supplied with the software option. How to install options is described in chapter 4 of the R&S SMA100B service manual.

The installation of hardware options purchased at a later stage is also described in chapter 4 of the service manual. Most of the hardware options have to be installed at an authorized Rohde & Schwarz service center.

15.3.5.1 Hardware Configuration Settings

Access:

- ▶ Select "System Config > Setup > Instrument Assembly > Hardware Config".

Assembly	Part Number	Serial Number	Revision	Slot
SMA100B	1419.8888k02	0		
FRONT_AF	1419.9690.02	100000	01.00	PCI-E slot
PSU300	2118.2067.02	100000	01.00	
IFB.BV	1423.5009.02	100000	01.00	
MB2_AF	1420.1360.02	100000	01.00	
SMAF_COM			01.00	
ADAP_CPU_AF	1420.1960.02	100000	01.00	
DCDC2_AF	1420.1860.02	100000	01.00	
IPM21	1206.3122.02	100000	01.00	PCI-E slot
BIOS				

The "Hardware Config" dialog lists all installed assemblies and externally connected instruments with information on their part and serial numbers, and revision states. The BIOS version is also listed; firmware updates do not update the BIOS version.

The dialog is divided in tabs, according to the hardware components of the signal domains. The "Counter" tab provides information on the operation time and number of times the instrument was powered on.

The remote commands required to query the hardware configuration are described in [Chapter 14.8, "DIAGnostic Subsystem"](#), on page 436.

Assembly

The tables in the tabs show characteristics of the installed assemblies.

"Assembly"	Assembly designation.
"Part Number"	Part number of the assembly.
"Serial Number"	Serial number of the assembly.
"Revision"	Revision state of the assembly.
"Slot"	Indicates whether the assembly is connected to the serial bus or PCI bus.

Remote command:

`:DIAGnostic<hw>:BGInfo?` on page 437

Counter

Displays information on the operation times of the R&S SMA100B.

Operation Time / h ← Counter

Displays the operation time in hours.

Remote command:

n.a.

Power On Count ← Counter

Displays the number of power-on.

Remote command:

n.a.

Last Factory Calibration ← Counter

Displays the date of the last factory calibration.

Remote command:

`:CALibration:DATA:FACTory:DATE?` on page 430

15.3.5.2 Versions/Options Settings

Access:

- ▶ Select "System Config > Setup > Instrument Assembly > Versions / Options".

Firmware	Hardware Options	Software Options	Versions
Package	Version		
FW	4.20.044		
Service Pack	not installed		
Bios Version	VirtualBox		
Downgrade Info:			
Package	Version		
Factory Version	4.20.044		
Min. Version	4.00.016.00		
<p>The Min. Version is the first version supporting all hardware modules installed in this instrument. Please read release notes carefully before downgrading, some software options and features may get lost.</p>			
<input type="button" value="Show Open Source Acknowledgements"/>			

The "Versions/Options" dialog shows the version of the installed instrument firmware, the hardware and software options, the data sheet and the software components of the firmware. The BIOS version is also listed; firmware updates do not update the BIOS version.

The remote commands required to query the hardware configuration are described in [Chapter 14.8, "DIAGnostic Subsystem"](#), on page 436.

Firmware

Shows the firmware version and the version of the software platform.

Note: Your instrument is delivered with the latest firmware version available. You can download firmware updates and the "Release Notes" that describe the modifications and the firmware update procedure.

See www.rohde-schwarz.com/firmware/sma100b

Remote command:

n.a.

Downgrade Info

Shows downgrade information, like factory firmware version and minimum firmware version to that the instrument can be downgraded.

Remote command:

n.a.

Show Open Source Acknowledgments

Accesses the list of the used open source software packages and the corresponding verbatim license texts.

Hardware Options/Software Options

The tables in the "Hardware" and "Software" tabs list the installed hardware and software options.

"Option" Short name of option

"Designation" Name of option

"Expiration Date"

For regular options, "Permanent" is indicated in this column. Some options are available as trial versions. This column shows their expiration date. After this date, the option is no longer available on the instrument.

Remote command:

*[OPT?](#) on page 414

*[IDN?](#) on page 413

Versions

The "Versions" tab shows the versions of the technical specification of the R&S SMA100B and of the software components that comprise the firmware.

"Package" Name of the component.

"Version" Current issue of the component.

E.g. the data sheet covers the technical data of the hardware components of the factory settings.

See also "[Data Sheet](#)" on page 378.

Remote command:

:[SYSTEM:SPECification:VERSion:FACTory?](#) on page 677

15.3.5.3 Requesting the Data Sheet

You can access data sheet related information via the LXI web browser, see "[Data Sheet](#)" on page 378.

16 Troubleshooting and Error Messages

The R&S SMA100B distinguishes between various messages such as status messages, error messages, warnings, or information that are displayed in the "Info" line on the screen, and also entered in the error/event queue of the status reporting system.

This section describes the types of error messages and warnings. The status reporting system is described in detail in [Chapter A.1.5, "Status Reporting System"](#), on page 727.

You can also access an Info window with detailed information about all messages in a history list. For details, see [Chapter 16.4, "Querying Error Messages"](#), on page 710

16.1 Error Messages

Error messages indicate errors in the instrument. They are displayed in different colors depending on their importance and display duration. Errors (e.g. no calibration data) are displayed in red, information (e.g. file not found) and warnings in black. Warnings indicate less significant errors (e.g. the instrument operates outside specified data).

Some error messages require that the error must be eliminated before correct instrument operation can be ensured. To access the "Info" dialog with a list of current messages and a detailed description of each message, select "Info".

In the remote control mode, error messages are entered in the error/event queue of the status reporting system and can be queried with the command `SYSTem:ERRor?`. If the error queue is empty, 0 ("No error") is returned.

16.1.1 Volatile Messages

Volatile messages report automatic settings in the instrument (e.g. switching off incompatible types of modulation) or on illegal entries that are not accepted by the instrument (e.g. range violations). They are displayed in the info line on a yellow background. They are displayed on top of status information or permanent messages.

Volatile messages do not normally demand user actions and disappear automatically after a brief period of time. They are stored in the history, however.

Remote command:

```
:SYSTem:ERRor:ALL? or  
:SYSTem:ERRor:CODE[:NEXT]?
```

16.1.2 Permanent Messages

Permanent messages are displayed if an error occurs that impairs further instrument operation, e.g. a hardware fault. The error signaled by a permanent message must be eliminated before correct instrument operation can be continued.

The message is displayed until the error is eliminated. It covers the status display in the info line. After error elimination, the message automatically disappears and is also recorded in the history.

Remote command:

```
:SYSTem:ERRor:STATic?
```

16.2 SCPI-Error Messages


The SCPI error messages are the same in all SCPI instruments. Detailed information and an overview of all error messages as defined in SCPI standard can be found in the corresponding documentation.

SCPI errors have negative codes (numbers). The error text being entered into the error/event queue or being displayed is printed in bold face on the left together with the error code. Below the error text, there is an explanation as to the respective error.

16.3 Device-Specific Error Messages

Start-up error

If device-specific errors occur during operation, the R&S SMA100B issues corresponding error messages, as listed under [Errors during operation](#). However, problems can also occur during start-up.



If your instrument prompts this error message when starting up, some information during initialization is missing. This error can occur when the power supply was interrupted during the last boot-up, e.g. due to power failure.

Remedy

- ▶ Select "Reset this error".
 - If the operating system and the firmware boot successfully, the functionality is restored.
 - If the error message reappears, a hardware error has occurred. We recommend that you contact the Rohde & Schwarz customer support (<http://www.customersupport.rohdeschwarz.com>), or ship your R&S SMA100B directly to the service center experts for troubleshooting (<http://www.services.rohdeschwarz.com>).

Errors during operation

The following table contains all error messages specific for the instrument in alphabetical order, as well as an explanation of the error situation. The positive error codes mark the errors specific to the instrument.

The device-specific error messages set bit 3 in the ESR register.



The index provides a list of the error messages sorted according to their error codes.

Error Code	Error	Description	Remedy
50	Extern reference out of range or disconnected	External reference is selected but no external signal is applied or the signal is out of range.	<ul style="list-style-type: none"> Check the selected reference signal source (internal or external) in the "Setup > Reference Oscillator" dialog. Change setting to 'internal' if no appropriate external source is available.
140	This modulation forces other modulations off	A modulation has been switched on which cannot be used at the same time as an already active modulation. The previous modulation has been switched off.	
180	Adjustment failed	Adjustment could not be executed	Generate the adjustment data and load it into the device
182	Adjustment data missing	Adjustment data is missing.	Generate the adjustment data and load it into the device
183	Adjustment data invalid	Adjustment data is invalid and must be restored.	Generate the adjustment data and load it into the device
200	Cannot access hardware	The data transmission to a module was unsuccessful.	The module is not installed, not properly installed or missing.
201	Hardware revision out of date	A later version of certain parts of the instrument is necessary to execute the function selected.	The driver does not support the installed version of a module.
202	Cannot access the EEPROM	An error occurs when writing or reading a EEPROM.	The EEPROM is possibly defect. Replace it.
203	Invalid EEPROM data	Reading a EEPROM is possible, however the data are inconsistent.	
204	Driver initialization failed	Initialization of a driver fails when booting the instrument firmware.	The driver is not compatible with the hardware or software configuration of the instrument.
241	No current list	There is no list selected. To execute the required operation, a list has to be selected in the related dialog. If no list is available, a new list must be created.	
242	Unknown list type specified	The list type selected is not valid for the required operation.	Check the selected list type.
460	Cannot open the file	The selected file cannot be opened.	Check the path and file name.

Error Code	Error	Description	Remedy
461	Cannot write file	The file cannot be written.	Check if the file is read-only.
462	Cannot read file	The file cannot be read.	Check if the file contents are compatible with the file type.
463	Filename missing	The required operation cannot be executed because the file name is not specified.	Enter file name when creating list.
464	Invalid filename extension	The file extension is not valid for the required operation.	Check the file extension.
465	File contains invalid data	The selected file contains data that is not valid for the file type. The file extension determines the data that is valid for this file type. If the file extension is changed, the lists are no longer recognized and the data is therefore invalid.	Check the file extension.

16.4 Querying Error Messages


The R&S SMA100B monitors the functions performed and automatically detects errors and irregularities. The instrument displays the messages in the "Info" line and records them in the background with a detailed description.

Find details to the system messages in [Chapter 16, "Troubleshooting and Error Messages"](#), on page 707.

To display information on static errors and error history

1. In the taskbar, select the "Info" icon.
2. For some messages, the information line appears briefly on the home screen.


To open the dialog, in the "Info" line select the "Info" button.



- The "Static Errors" dialog lists the last monitored messages chronologically and displays additional information on the highlighted message.
- The "Error History" dialog lists the accumulated messages with a short description.
 Volatile errors are reported once, at the time they appear. If identical errors occur subsequently, they are not reported repeatedly.
 In the "Info" line, identical errors are displayed repeatedly only if the original error has already disappeared from the display. If queried by SCPI command, identical errors are only reported if the original error has already been retrieved from (and hence not any more present in) the error queue.



Indication and handling of permanent messages

If any critical error occurs, the R&S SMA100B automatically shows the  icon in the taskbar. Select the icon to obtain information on the error and the number of occurrences.

The icon is assigned to permanent messages. The message and icon are displayed until the error is eliminated.

Static Errors/Error History

Toggles between "Static" and "History" view of the info dialog.

Remote command:

`:SYSTem:ERRor[:NEXT]?` on page 662

Each time a `SYST:ERR:NEXT?` query is sent, the eldest entry in the error queue is returned and at the same time cleared in the list.

`:SYSTem:ERRor:STATic?` on page 663

Queries the list of all errors.

Clear History

Clears all messages in the "History" view.

Remote command:

`:SYSTem:ERRor:ALL?` on page 660

Each time a `SYST:ERR:ALL?` query is sent, the error queue is returned and at the same time cleared.

`:SYSTem:ERRor:HISTory:CLEar` on page 663

Clears the messages in the "History" view.

16.5 Resolving Network Connection Failures

Several issues may cause failures in the network connection to the instrument. This section lists the most likely reasons and the recommended solutions.

Common reasons for network connection failures

- Network connecting cables and cable connectors of poor quality
- Incompatibility between the network interface of the R&S SMA100B and certain switches or routers available on the market
- An invalid IP address assigned to the instrument

Possible solutions

NOTICE**Risk of network failure**

Consult your network administrator before performing the following tasks:

- Connecting the instrument to the network
- Configuring the network
- Changing IP addresses

Errors can affect the entire network.

-
- Check the network infrastructure. Exchange connecting cables if obvious damage is visible.

- Observe the link status LED on the R&S SMA100B or the connected network device. The link status LED is located next to the LAN connector. If a link failure is detected, connect the instrument to a different device port or to a different network device.
- Check whether the LAN interface and the required LAN services are enabled. See [Chapter 12.4.3, "Configuring LAN Services"](#), on page 345.
- Check whether the IP address of the instrument is within the network's address range.
(See also ["IP Address"](#) on page 365).
Check whether IP addresses that were set manually or obtained via the Zeroconf (APIPA) protocol are valid.

16.6 Collecting Information for Technical Support

If you encounter problems that you cannot solve yourself, contact your Rohde & Schwarz support center as listed at <http://www.customersupport.rohde-schwarz.com>. Our support center staff is optimally trained to assist you in solving problems.


The support center finds solutions more quickly and efficiently if you provide them with information on the instrument and an error description.

- The following dialog boxes in the "Setup > Instrument Assembly" menu provide useful information:
 - **Hardware Configuration:** hardware assemblies
 - **Software and Options:** the status of all software and hardware options installed on your instrument
- **System Messages:** displayed in the "Info" line and provide information on any errors that have occurred
- **Support file:** a special file (*.tar.gz file) with important support information that can be created automatically.
The support *.tar.gz file has a user definable name and contains the following files and information:
 - SgErrors.txt: chronological record of errors
 - SystemRestorationSMAB.savrcltxt: instrument settings at the last correct shutdown of the instrument
 - UndoHistSuppInfo.xml: list of the last user interactions
 - DeviceFootprint_<SerialNumber>_<Date>_<Time>.xml: service-related information on the instrument's configuration.
 - crashlog.txt, coredump: Postmortem debug info
 - Several files with information on the last performed adjustment and self-test.

See also the description of error messages [Chapter 16.1, "Error Messages"](#), on page 707.

To collect error information in a support file

1. Connect a USB device to the R&S SMA100B.
2. Select "System Config > Setup > Maintenance > Create R&S Support Information".
3. In the "Create R&S Support Information" dialog, navigate to the /usb directory. Enter the support filename, for example `RSSupport_DeviceInfo`.



The error information and further required data is collected automatically. The support file `RSSupport_DeviceInfo.tar.gz` is created and stored in the /usb directory.

Collect the error information and attach it to an email in which you describe the problem. Send the email to the customer support address for your region as listed on the Internet (<http://www.customersupport.rohde-schwarz.com>).

To remove sensitive data

- ▶ For information on how to handle or remove the sensitive data from your instrument, refer to the description "Resolving Security Issues when working with R&S SMA100B".

Packing and transporting the instrument

- ▶ If the instrument has to be transported or shipped, observe the notes described in [Chapter 3.1.1.2, "Unpacking and Checking the Instrument"](#), on page 23.

Annex

A Reference Information for Remote Control

A.1 Additional Basics on Remote Control

This section provides basic information using the remote control.

A.1.1 Messages

The messages transferred on the data lines are divided into the following categories:

- **Interface messages**
Interface messages are transmitted to the instrument on the data lines, with the attention line being active (LOW). They are used to communicate between the controller and the instrument. Interface messages can only be sent by instruments that have GPIB bus functionality. For details see the sections for the required interface.
- **Instrument messages**
Instrument messages are employed in the same way for all interfaces, if not indicated otherwise in the description. Structure and syntax of the instrument messages are described in [Chapter A.1.3, "SCPI Command Structure"](#), on page 716. A detailed description of all messages available for the instrument is provided in the chapter "Remote Control Commands".
There are different types of instrument messages, depending on the direction they are sent:
 - Commands
 - Instrument responses

Commands

Commands (program messages) are messages the controller sends to the instrument. They operate the instrument functions and request information. The commands are subdivided according to two criteria:

- According to the effect they have on the instrument:
 - **Setting commands** cause instrument settings such as a reset of the instrument or setting the frequency.
 - **Queries** cause data to be provided for remote control, e.g. for identification of the instrument or polling a parameter value. Queries are formed by directly appending a question mark to the command header.
- According to their definition in standards:
 - **Common commands:** their function and syntax are precisely defined in standard IEEE 488.2. They are employed identically on all instruments (if implemented). They refer to functions such as management of the standardized status registers, reset and self-test.

- **Instrument control commands** refer to functions depending on the features of the instrument such as frequency settings. Many of these commands have also been standardized by the SCPI committee. These commands are marked as "SCPI confirmed" in the command reference chapters. Commands without this SCPI label are device-specific; however, their syntax follows SCPI rules as permitted by the standard.

Instrument responses

Instrument responses (response messages and service requests) are messages the instrument sends to the controller after a query. They can contain measurement results, instrument settings and information on the instrument status.

A.1.2 LAN Interface Messages

In the LAN connection, the interface messages are called low-level control messages. These messages can be used to emulate interface messages of the GPIB bus.

Command	Long term	Effect on the instrument
&ABO	Abort	Aborts processing of the commands just received.
&DCL	Device Clear	Aborts processing of the commands just received and sets the command processing software to a defined initial state. Does not change the instrument setting.
>L	Go to Local	Transition to the "local" state (manual control). (The instrument automatically returns to remote state when a remote command is sent UNLESS &NREN was sent before.)
>R	Go to Remote	Enables automatic transition from local state to remote state by a subsequent remote command (after &NREN was sent).
&GET	Group Execute Trigger	Triggers a previously active instrument function (e.g. a sweep). The effect of the command is the same as with that of a pulse at the external trigger signal input.
&LLO	Local Lockout	Disables transition from remote control to manual control by means of the front panel keys.
&NREN	Not Remote Enable	Disables automatic transition from local state to remote state by a subsequent remote command. (To re-activate automatic transition use >R.)
&POL	Serial Poll	Starts a serial poll.

A.1.3 SCPI Command Structure

SCPI commands consist of a header and, in most cases, one or more parameters. The header and the parameters are separated by a "white space" (ASCII code 0 to 9, 11 to 32 decimal, e.g. blank). The headers may consist of several mnemonics (keywords). Queries are formed by appending a question mark directly to the header.

The commands can be either device-specific or device-independent (common commands). Common and device-specific commands differ in their syntax.

A.1.3.1 Syntax for Common Commands

Common (= device-independent) commands consist of a header preceded by an asterisk (*), and possibly one or more parameters.

Table A-1: Examples of common commands

*RST	RESET	Resets the instrument.
*ESE	EVENT STATUS ENABLE	Sets the bits of the event status enable registers.
*ESR?	EVENT STATUS QUERY	Queries the contents of the event status register.
*IDN?	IDENTIFICATION QUERY	Queries the instrument identification string.

A.1.3.2 Syntax for Device-Specific Commands



Not all commands used in the following examples are necessarily implemented in the instrument. For demonstration purposes only, assume the existence of the following commands for this section:

- DISPLAY[:WINDow<1...4>]:MAXimize <Boolean>
- FORMAT:READings:DATA <type>[,<length>]
- HCOpy:DEvice:COLor <Boolean>
- HCOpy:DEvice:CMAP:COLor:RGB <red>,<green>,<blue>
- HCOpy[:IMMediate]
- HCOpy:ITEM:ALL
- HCOpy:ITEM:LABel <string>
- HCOpy:PAGE:DIMensions:QUADrant [<N>]
- HCOpy:PAGE:ORientation LANDscape | PORTrait
- HCOpy:PAGE:SCALE <numeric value>
- MMEMory:COpy <file_source>,<file_destination>
- SENSE:BANDwidth|BWIDth[:RESolution] <numeric_value>
- SENSE:FREQuency:STOP <numeric value>
- SENSE:LIST:FREQuency <numeric_value>{,<numeric_value>}

- [Long and short form](#)..... 718
- [Numeric Suffixes](#)..... 718
- [Optional Mnemonics](#)..... 718

Long and short form

The mnemonics feature a long form and a short form. The short form is marked by upper case letters, the long form corresponds to the complete word. Either the short form or the long form can be entered; other abbreviations are not permitted.

Example:

HCOPY:DEVIce:COLor ON is equivalent to HCOP:DEV:COL ON.



Case-insensitivity

Upper case and lower case notation only serves to distinguish the two forms in the manual, the instrument itself is case-insensitive.

Numeric Suffixes

If a command can be applied to multiple instances of an object, e.g. specific channels or sources, the required instances can be specified by a suffix added to the command. Numeric suffixes are indicated by angular brackets (<1...4>, <n>, <i>) and are replaced by a single value in the command. Entries without a suffix are interpreted as having the suffix 1.

Example:

Definition: HCOpy:PAGE:DImentions:QUADrant [<N>]

Command: HCOP:PAGE:DIM:QUAD2

This command refers to the quadrant 2.



Different numbering in remote control

For remote control, the suffix may differ from the number of the corresponding selection used in manual operation. SCPI prescribes that suffix counting starts with 1. Suffix 1 is the default state and used when no specific suffix is specified.

Some standards define a fixed numbering, starting with 0. If the numbering differs in manual operation and remote control, it is indicated for the corresponding command.

Optional Mnemonics

Some command systems permit certain mnemonics to be inserted into the header or omitted. These mnemonics are marked by square brackets in the description. The instrument must recognize the long command to comply with the SCPI standard. Some commands are considerably shortened by these optional mnemonics.

Example:

Definition: HCOpy[:IMMediate]

Command: HCOP:IMM is equivalent to HCOP



Optional mnemonics with numeric suffixes

Do not omit an optional mnemonic if it includes a numeric suffix that is relevant for the effect of the command.

Example:

Definition: `DISPlay[:WINDow<1...4>]:MAXimize <Boolean>`

Command: `DISP:MAX ON` refers to window 1.

In order to refer to a window other than 1, you must include the optional `WINDow` parameter with the suffix for the required window.

`DISP:WIND2:MAX ON` refers to window 2.

A.1.3.3 SCPI Parameters

Many commands are supplemented by a parameter or a list of parameters. The parameters must be separated from the header by a "white space" (ASCII code 0 to 9, 11 to 32 decimal, e.g. blank).

The parameters required for each command and the allowed range of values are specified in the command description.

Allowed parameters are:

- [Numeric Values](#)..... 719
- [Special Numeric Values](#)..... 720
- [Boolean Parameters](#)..... 720
- [Text Parameters](#)..... 721
- [Character Strings](#)..... 721
- [Block Data](#)..... 721

Numeric Values

Numeric values can be entered in any form, i.e. with sign, decimal point and exponent. Values exceeding the resolution of the instrument are rounded up or down. The mantissa may comprise up to 255 characters, the exponent must lie inside the value range -32000 to 32000. The exponent is introduced by an "E" or "e". Entry of the exponent alone is not allowed.

Example:

`SENS:FREQ:STOP 1500000 = SENS:FREQ:STOP 1.5E6`

Units

For physical quantities, the unit can be entered. If the unit is missing, the basic unit is used. Allowed unit prefixes are:

- G (giga)
- MA (mega), MOHM, MHZ
- K (kilo)
- M (milli)
- U (micro)

- N (nano)

Example:

```
SENSe:FREQ:STOP 1.5GHz = SENSe:FREQ:STOP 1.5E9
```

Some settings allow relative values to be stated in percent. According to SCPI, this unit is represented by the `PCT` string.

Example:

```
HCOP:PAGE:SCAL 90PCT
```

Special Numeric Values

The following mnemonics are special numeric values. In the response to a query, the numeric value is provided.

- **MIN and MAX:** denote the minimum and maximum value.
- **DEF:** denotes a preset value which has been stored in the EPROM. This value conforms to the default setting, as it is called by the `*RST` command.
- **UP and DOWN:** increases or reduces the numeric value by one step. The step width can be specified via an allocated step command for each parameter which can be set via `UP` and `DOWN`.
- **INF and NINF:** INfinity and negative INfinity (NINF) represent the numeric values $9.9E37$ or $-9.9E37$, respectively. `INF` and `NINF` are only sent as instrument responses.
- **NAN:** Not A Number (NAN) represents the value $9.91E37$. `NAN` is only sent as a instrument response. This value is not defined. Possible causes are the division of zero by zero, the subtraction of infinite from infinite and the representation of missing values.

Example:

Setting command: `SENSe:LIST:FREQ MAXimum`

Query: `SENS:LIST:FREQ?`

Response: `3.5E9`

**Queries for special numeric values**

The numeric values associated to `MAXimum`/`MINimum`/`DEFault` can be queried by adding the corresponding mnemonic after the quotation mark.

Example: `SENSe:LIST:FREQ? MAXimum`

Returns the maximum numeric value as a result.

Boolean Parameters

Boolean parameters represent two states. The "ON" state (logically true) is represented by "ON" or a numeric value 1. The "OFF" state (logically untrue) is represented by "OFF" or the numeric value 0. The numeric values are provided as the response for a query.

Example:

Setting command: `HCOPY:DEV:COL ON`

Query: `HCOPY:DEV:COL?`

Response: 1

Text Parameters

Text parameters observe the syntactic rules for mnemonics, i.e. they can be entered using a short or long form. Like any parameter, they have to be separated from the header by a white space. In the response to a query, the short form of the text is provided.

Example:

Setting command: `HCOPY:PAGE:ORIENTATION LANDscape`

Query: `HCOPY:PAGE:ORI?`

Response: LAND

Character Strings

Strings must always be entered in quotation marks (' or ").

Example:

`HCOPY:ITEM:LABEL "Test1"`

`HCOPY:ITEM:LABEL 'Test1'`

Block Data

Block data is a format which is suitable for the transmission of large amounts of data. For example, a command using a block data parameter has the following structure:

```
FORMat:READings:DATA #45168xxxxxxxx
```

The ASCII character # introduces the data block. The next number indicates how many of the following digits describe the length of the data block. In the example the 4 following digits indicate the length to be 5168 bytes. The data bytes follow. During the transmission of these data bytes all end or other control signs are ignored until all bytes are transmitted.

#0 specifies a data block of indefinite length. The use of the indefinite format requires a `NL^END` message to terminate the data block. This format is useful when the length of the transmission is not known or if speed or other considerations prevent segmentation of the data into blocks of definite length.

A.1.3.4 Overview of Syntax Elements

The following tables provide an overview of the syntax elements and special characters.

Table A-2: Syntax elements

:	The colon separates the mnemonics of a command.
;	The semicolon separates two commands of a command line. It does not alter the path.
,	The comma separates several parameters of a command.
?	The question mark forms a query.
*	The asterisk marks a common command.
' '	Quotation marks introduce a string and terminate it (both single and double quotation marks are possible).
#	The hash symbol introduces binary, octal, hexadecimal and block data. <ul style="list-style-type: none"> • Binary: #B10110 • Octal: #O7612 • Hexa: #HF3A7 • Block: #21312
	A "white space" (ASCII-Code 0 to 9, 11 to 32 decimal, e.g. blank) separates the header from the parameters.

Table A-3: Special characters

	<p>Parameters</p> <p>A vertical stroke in parameter definitions indicates alternative possibilities in the sense of "or". The effect of the command differs, depending on which parameter is used.</p> <p>Example:</p> <p>Definition:HCOPY:PAGE:ORIENTATION LANDscape PORTRait</p> <p>Command HCOP:PAGE:ORI LAND specifies landscape orientation</p> <p>Command HCOP:PAGE:ORI PORT specifies portrait orientation</p> <p>Mnemonics</p> <p>A selection of mnemonics with an identical effect exists for several commands. These mnemonics are indicated in the same line; they are separated by a vertical stroke. Only one of these mnemonics needs to be included in the header of the command. The effect of the command is independent of which of the mnemonics is used.</p> <p>Example:</p> <p>DefinitionSENSE:BANDwidth BWIDth[:RESolution] <numeric_value></p> <p>The two following commands with identical meaning can be created:</p> <p>SENS:BAND:RES 1</p> <p>SENS:BWID:RES 1</p>
[]	<p>Mnemonics in square brackets are optional and may be inserted into the header or omitted.</p> <p>Example: HCOPY[:IMMEDIATE]</p> <p>HCOP: IMM is equivalent to HCOP</p>
{ }	<p>Parameters in curly brackets are optional and can be inserted once or several times, or omitted.</p> <p>Example: SENSE:LIST:FREQUENCY <numeric_value>{,<numeric_value>}</p> <p>The following are valid commands:</p> <p>SENS:LIST:FREQ 10</p> <p>SENS:LIST:FREQ 10,20</p> <p>SENS:LIST:FREQ 10,20,30,40</p>

A.1.3.5 Structure of a Command Line

A command line may consist of one or several commands. It is terminated by one of the following:

- <New Line>
- <New Line> with EOI
- EOI together with the last data byte

Several commands in a command line must be separated by a semicolon ";".

Example:

```
MMEM:COPY "Test1", "MeasurementXY";:HCOP:ITEM ALL
```

This command line contains two commands. The first command belongs to the MMEM system, the second command belongs to the HCOP system. If the next command belongs to a different command system, the semicolon is followed by a colon.

Example:

```
HCOP:ITEM ALL;:HCOP:IMM
```

This command line contains two commands. Both commands are part of the HCOP command system, i.e. they have one level in common.

If the successive commands belong to the same system, having one or several levels in common, the command line can be abbreviated. When abbreviating the command line, the second command begins with the level below HCOP. The colon after the semicolon is omitted. The abbreviated form of the command line reads as follows:

```
HCOP:ITEM ALL;IMM
```

Example:

```
HCOP:ITEM ALL
```

```
HCOP:IMM
```

A new command line always begins with the complete path.

A.1.3.6 Responses to Queries

A query is defined for each setting command unless explicitly specified otherwise. It is formed by adding a question mark to the associated setting command. According to SCPI, the responses to queries are partly subject to stricter rules than in standard IEEE 488.2.

- The requested parameter is transmitted without a header.
Example: `HCOP:PAGE:ORI?`, **Response:** `LAND`
- Maximum values, minimum values and all other quantities that are requested via a special text parameter are returned as numeric values.
Example: `SENSe:FREQuency:STOP? MAX`, **Response:** `3.5E9`
- Numeric values are output without a unit. Physical quantities are referred to the basic units or to the units set using the `Unit` command. The response `3.5E9` in the previous example stands for 3.5 GHz.

- Truth values (Boolean values) are returned as 0 (for OFF) and 1 (for ON).
Example:
 Setting command: `HCOPY:DEV:COL ON`
 Query: `HCOPY:DEV:COL?`
 Response: 1
- Text (character data) is returned in a short form.
Example:
 Setting command: `HCOPY:PAGE:ORIENTATION LANDscape`
 Query: `HCOP:PAGE:ORI?`
 Response: LAND
- Invalid numerical results
 In some cases, particularly when a result consists of multiple numeric values, invalid values are returned as 9.91E37 (not a number).

A.1.4 Command Sequence and Synchronization

IEEE 488.2 defines a distinction between overlapped and sequential commands:

- A sequential command always completes executing before the next command starts. Commands that are processed quickly are defined as sequential commands. They are not implemented in the instrument. However, the execution time of most of the commands is so short that they act as sequential commands, if they are sent in separate command lines.
- An overlapping command is still running when the next command starts. Usually, an overlapping command takes a certain time to process its task, and thus allows the program to execute other tasks, while it is still running. If overlapping commands have to follow a specific order, for example to avoid incorrect measurement readings, they must be executed in sequence. This is called synchronization between the controller and the instrument.

Several setting commands within a command line are not necessarily processed in the order they are received. Even if they are implemented as sequential commands. To follow a particular sequence, send each command in a separate line.



As a rule, send commands and queries in different program messages.

A.1.4.1 Preventing Overlapping Execution

To prevent an overlapping execution of commands, one of the commands `*OPC`, `*OPC?` or `*WAI` can be used. All three commands cause a certain action only to be carried out after the hardware has been set. The controller can be forced to wait for the corresponding action to occur.

Table A-4: Synchronization using *OPC, *OPC? and *WAI

Com- mand	Action	Programming the controller
*OPC	Sets the Operation Complete bit in the ESR after all previous commands have been executed.	<ul style="list-style-type: none"> Setting bit 0 in the ESE Setting bit 5 in the SRE Waiting for service request (SRQ)
*OPC?	Stops command processing until 1 is returned. This occurs when all pending operations are completed.	Send *OPC? directly after the command whose processing must be terminated before other commands can be executed.
*WAI	Stops further command processing until all commands sent before *WAI have been executed.	Send *WAI directly after the command whose processing must be terminated before other commands are executed.

Command synchronization using *WAI or *OPC? is a good choice if the overlapped command takes only little time to process. The two synchronization commands simply block overlapped execution of the command. Append the synchronization command to the overlapping command, for example:

```
SINGLE; *OPC?
```

For time consuming overlapped commands, you can allow the controller or the instrument to do other useful work while waiting for command execution. Use one of the following methods:

***OPC with a service request**

1. Set the OPC mask bit (bit no. 0) in the ESE: *ESE 1
2. Set bit no. 5 in the SRE: *SRE 32 to enable ESB service request.
3. Send the overlapped command with *OPC .
4. Wait for a service request.

The service request indicates that the overlapped command has finished.

***OPC? with a service request**

1. Set bit no. 4 in the SRE: *SRE 16 to enable MAV service request.
2. Send the overlapped command with *OPC?.
3. Wait for a service request.

The service request indicates that the overlapped command has finished.

Event status register (ESE)

1. Set the OPC mask bit (bit no. 0) in the ESE: *ESE 1
2. Send the overlapped command without *OPC, *OPC? or *WAI.

3. Poll the operation complete state periodically (with a timer) using the sequence:
*OPC; *ESR?

A return value (LSB) of 1 indicates that the overlapped command has finished.

A.1.4.2 Examples to Command Sequence and Synchronization

See the following examples to command sequences and synchronization. Some examples given illustrate possible constellations for overlapping tasks.

Example: Commands and queries in one message

The response to a query combined in a program message with commands that affect the queried value is not predictable.

The following commands always return the specified result:

```
:FREQ:STAR 1GHZ;SPAN 100 :FREQ:STAR?
```

Result:

```
1000000000 (1 GHz)
```

Whereas the result for the following commands is not specified by SCPI:

```
:FREQ:STAR 1GHZ;STAR?;SPAN 1000000
```

The result could be the value of `START` before the command was sent since the instrument might defer executing the individual commands until a program message terminator is received. The result could also be 1 GHz if the instrument executes commands as they are received.

Example: Overlapping command with *OPC

The instrument implements `*RST` as an overlapped command. Assuming that `*RST` takes longer to execute than `*OPC`, sending the following command sequence results in initiating a reset and, after some time, setting the `OPC` bit in the `ESR`:

```
*RST; *OPC
```

Sending the following commands still initiates a reset:

```
*RST; *OPC; *CLS
```

However, since the operation is still pending when the instrument executes `*CLS`, forcing it into the "Operation Complete Command Idle" State (OCIS), `*OPC` is effectively skipped. The `OPC` bit is not set until the instrument executes another `*OPC` command.

Example: Overlapped command followed by non-conflicting commands

Suppose that the instrument is switched on to provide a real time test signal that requires some calculation time. At the same time, some settings for the configuration of a different signal are made which do not interact with the generated signal (for example the signal may be used later on). The signal generation and the signal configuration are independent from each other, so there is no need to synchronize the following overlapped commands:

```
SOUR:BB:3GPP:STAT ON
```

```
SOUR:BB:GSM:FORM FSK2
```

Example: Overlapped command followed by conflicting commands

Suppose that the generator is switched on to provide a real time test signal that requires some calculation time. This signal is to be added to a waveform from the second baseband generator. In this case, the application program has to make sure that the real signal is available in the added signal before further action is started. This involves an appropriate synchronization technique for the first command (the following sequence assumes an appropriate routing):

```
SOUR:BB:3GPP:STAT ON
```

The instrument waits until command has finished.

```
SOUR2:BB:GSM:STAT ON
```

Depending on the selected synchronization techniques, non-conflicting commands can be executed while waiting until the synchronized overlapped command has finished.

Example: Polling the progress of the zeroing process

Suppose that you start the zeroing for a connected power sensor via the remote control command `SENS1:ZERO`. This process blocks the processing of further tasks during execution. The query for completeness is performed with the `*OPC?` command. It returns a 1 in the output buffer when the process is completed.

```
SENS:ZERO;*OPC?
```

Instead of waiting via `*OPC?`, you can perform alternative tasks while the zeroing is running, as for example updating the GUI or adjusting other instruments. Synchronize the commands by querying the progress of the zeroing process periodically via the event status register `*ESR?`:

```
*SRE 32
```

Sets the service request enable. The bit is set when an event in the event status register occurs.

```
*ESE 1
```

Configures the mask of the event status register to "Operation Complete".

```
SENS:ZERO;*OPC
```

Sets the evaluation via the status byte query. It uses `*OPC?` as the reference.

```
*CLS
```

Clears all status registers.

Even if the instrument is busy, you can perform this procedure, since the query is executed in a subchannel.

A.1.5 Status Reporting System

The status reporting system stores all information on the current operating state of the instrument, and on errors which have occurred. This information is stored in the status registers and in the error queue.

You can query both with the commands of the [STATus Subsystem](#).

A.1.5.1 Hierarchy of the Status Registers

The [Figure A-1](#) shows the hierarchical structure of information in the status registers (ascending from left to right).




Figure A-1: Graphical overview of the status registers hierarchy

- OPER = Operation Status Summary Bit
- RQS/MSS = Service Request Generation
- ESB = Standard Event Status Summary Bit
- MAV = Message Available in Output Queue
- QUES = Questionable Status Summary Bit
- 2 = Error- /Event-Queue
- 1, 0 = not used

Note: This legend explains the abbreviations to the Status Byte Register.

The R&S SMA100B uses the following status registers:

- **Status Byte (STB)** and **Service Request Enable (SRE)**, see [Chapter A.1.5.3, "Status Byte \(STB\) and Service Request Enable Register \(SRE\)"](#), on page 731.
- **Standard Event Status**, i.e. the Event status Register (ESR) and the Event Status Enable (ESE), see [Chapter A.1.5.4, "Event Status Register \(ESR\) and Event Status Enable Register \(ESE\)"](#), on page 732.
- **Questionable Status** and **Operation Status**, the (SCPI status registers, see [Chapter A.1.5.2, "Structure of a SCPI Status Register"](#), on page 729, [Chapter A.1.5.5, "Questionable Status Register \(STATus:QUESTionable\)"](#), on page 733 and [Chapter A.1.5.6, "Operation Status Register \(STATus:OPERation\)"](#), on page 733.
- **Output-Queue**
The output queue contains the messages the instrument returns to the controller. It is not part of the status reporting system but determines the value of the `MAV` bit in the `STB` and thus is represented in the overview.
- **Error- /Event-Queue**
The error-/event-queue contains all errors and events that have occurred in the past. When reading the queue, the instrument starts with the first occurred error/event.

All status registers have the same internal structure.



SRE, ESE

The service request enable register `SRE` can be used as `ENABLE` part of the `STB` if the `STB` is structured according to SCPI. By analogy, the `ESE` can be used as the `ENABLE` part of the `ESR`.

A.1.5.2 Structure of a SCPI Status Register

Each standard SCPI register consists of 5 parts. Each part has a width of 16 bits and has different functions. The individual bits are independent of each other, i.e. each hardware status is assigned a bit number which is valid for all five parts. Bit 15 (the most significant bit) is set to zero for all parts. Thus the contents of the register parts can be processed by the controller as positive integers.




Figure A-2: The status-register model

Description of the five status register parts

The five parts of a SCPI register have different properties and functions:

- **CONDition**

The **CONDition** part is written into directly by the hardware or the sum bit of the next lower register. Its contents reflect the current instrument status. This register part can only be read, but not written into or cleared. Its contents are not affected by reading.

- **PTRansition / NTRansition**

The two transition register parts define which state transition of the **CONDition** part (none, 0 to 1, 1 to 0 or both) is stored in the **EVENT** part.

The **Positive-TRansition** part acts as a transition filter. When a bit of the **CONDition** part is changed from 0 to 1, the associated **PTR** bit decides whether the **EVENT** bit is set to 1.

- **PTR** bit =1: the **EVENT** bit is set.
- **PTR** bit =0: the **EVENT** bit is not set.

This part can be written into and read as required. Its contents are not affected by reading.

The **Negative-TRansition** part also acts as a transition filter. When a bit of the **CONDition** part is changed from 1 to 0, the associated **NTR** bit decides whether the **EVENT** bit is set to 1.

- **NTR** bit =1: the **EVENT** bit is set.
- **NTR** bit =0: the **EVENT** bit is not set.

This part can be written into and read as required. Its contents are not affected by reading.

- **EVENT**

The **EVENT** part indicates whether an event has occurred since the last reading, it is the "memory" of the condition part. It only indicates events passed on by the transition filters. It is permanently updated by the instrument. This part can only be

read by the user. Reading the register clears it. This part is often equated with the entire register.

- **ENABLE**

The `ENABLE` part determines whether the associated `EVENT` bit contributes to the sum bit (see below). Each bit of the `EVENT` part is "ANDed" with the associated `ENABLE` bit (symbol '&'). The results of all logical operations of this part are passed on to the sum bit via an "OR" function (symbol '+').

`ENABLE` bit = 0: the associated `EVENT` bit does not contribute to the sum bit

`ENABLE` bit = 1: if the associated `EVENT` bit is "1", the sum bit is set to "1" as well.

This part can be written into and read by the user as required. Its contents are not affected by reading.

Sum bit

The sum bit is obtained from the `EVENT` and `ENABLE` part for each register. The result is then entered into a bit of the `CONDition` part of the higher-order register.

The instrument automatically generates the sum bit for each register. Thus an event can lead to a service request throughout all levels of the hierarchy.

A.1.5.3 Status Byte (STB) and Service Request Enable Register (SRE)

The `Status Byte` (STB) is already defined in IEEE 488.2. It provides a rough overview of the instrument status by collecting the pieces of information of the lower registers. A special feature is that bit 6 acts as the sum bit of the remaining bits of the status byte.

The STB is read using the command `*STB?` or a serial poll.

The `Status Byte` (STB) is linked to the `Service Request Enable` (SRE) register. Each bit of the STB is assigned a bit in the SRE. Bit 6 of the SRE is ignored. If a bit is set in the SRE and the associated bit in the STB changes from 0 to 1, a service request (SRQ) is generated. The SRE can be set using the command `*SRE` and read using the command `*SRE?`.

Table A-5: Meaning of the bits used in the status byte

Bit No.	Meaning
0...1	Not used
2	Error Queue not empty The bit is set when an entry is made in the error queue. If this bit is enabled by the SRE, each entry of the error queue generates a service request. Thus an error can be recognized and specified in greater detail by polling the error queue. The poll provides an informative error message. This procedure is to be recommended since it considerably reduces the problems involved with remote control.
3	QUESTIONable status register summary bit The bit is set if an <code>EVENT</code> bit is set in the <code>QUESTIONable</code> status register and the associated <code>ENABLE</code> bit is set to 1. A set bit indicates a questionable instrument status, which can be specified in greater detail by querying the <code>STATUS:QUESTIONable</code> status register.

Bit No.	Meaning
4	MAV bit (message available) The bit is set if a message is available in the output queue which can be read. This bit can be used to enable data to be automatically read from the instrument to the controller.
5	ESB bit Sum bit of the event status register. It is set if one of the bits in the event status register is set and enabled in the event status enable register. Setting of this bit indicates a serious error which can be specified in greater detail by polling the event status register.
6	MSS bit (master status summary bit) The bit is set if the instrument triggers a service request. This is the case if one of the other bits of this registers is set together with its mask bit in the service request enable register SRE.
7	STATUS:OPERation status register summary bit The bit is set if an EVENT bit is set in the OPERATION status register and the associated ENABLE bit is set to 1. A set bit indicates that the instrument is just performing an action. The type of action can be determined by querying the STATUS:OPERation status register.

A.1.5.4 Event Status Register (ESR) and Event Status Enable Register (ESE)

The ESR is defined in IEEE 488.2. It can be compared with the EVENT part of a SCPI register. The event status register can be read out using command *ESR?.

The ESE corresponds to the ENABLE part of a SCPI register. If a bit is set in the ESE and the associated bit in the ESR changes from 0 to 1, the ESB bit in the STB is set. The ESE register can be set using the command *ESE and read using the command *ESE?.

Table A-6: Meaning of the bits used in the event status register

Bit No.	Meaning
0	Operation Complete This bit is set on receipt of the command *OPC exactly when all previous commands have been executed.
1	Not used
2	Query Error This bit is set if either the controller wants to read data from the instrument without having sent a query, or if it does not fetch requested data and sends new instructions to the instrument instead. The cause is often a query which is faulty and hence cannot be executed.
3	Device-dependent Error This bit is set if a device-dependent error occurs. An error message with a number between -300 and -399 or a positive error number, which denotes the error in greater detail, is entered into the error queue.
4	Execution Error This bit is set if a received command is syntactically correct but cannot be performed for other reasons. An error message with a number between -200 and -300, which denotes the error in greater detail, is entered into the error queue.

Bit No.	Meaning
5	Command Error This bit is set if a command is received, which is undefined or syntactically incorrect. An error message with a number between -100 and -200, which denotes the error in greater detail, is entered into the error queue.
6	User Request This bit is set when the instrument is switched over to manual control.
7	Power On (supply voltage on) This bit is set on switching on the instrument.

A.1.5.5 Questionable Status Register (STATus:QUESTionable)

This register contains information on questionable instrument states. Such states may occur when the instrument is not operated in compliance with its specifications.

To read the register, use the query commands `STAT:QUEST:COND?` or `STAT:QUEST[:EVEN]?`.

Table A-7: Meaning of the bits used in the questionable status register

Bit No.	Meaning
0–15	Not used

A.1.5.6 Operation Status Register (STATus:OPERation)

This condition part contains information on the actions currently being performed by the instrument, while the event part contains information on the actions performed by the instrument since the last readout of the register.

To read the register, use the query commands `STAT:OPER:COND?` or `STAT:OPER[:EVEN]?`.

Table A-8: Meaning of the bits used in the operation status register

Bit No.	Meaning
0	Calibrating The bit is set during the calibration phase.
1–2	Not used
3	Sweeping This bit is set during a sweep in automatic or single mode.
4–15	Not used

A.1.5.7 Application of the Status Reporting System

The purpose of the status reporting system is to monitor the status of one or several devices in a measuring system. To do this and react appropriately, the controller must

receive and evaluate the information of all devices. The following standard methods are used:

- **Service request** (SRQ) initiated by the instrument
- **Serial poll** of all devices in the bus system, initiated by the controller to find out who sent an SRQ and why
- Query of a **specific instrument status** by commands
- Query of the **error queue**

Service Request

Under certain circumstances, the instrument can send a service request (SRQ) to the controller. Usually this service request initiates an interrupt at the controller, to which the control program can react appropriately. An SRQ is always initiated if one or several of bits 2, 4 or 5 of the status byte are set and enabled in the SRE. Each of these bits combines the information of the error queue or the output buffer. To use the possibilities of the service request effectively, all bits should be set to "1" in the enable registers SRE and ESE.

Example:

Use command `*OPC` to generate an SRQ .

`*ESE 1` - set bit 0 of ESE (Operation Complete)

`*SRE 32` - set bit 5 of SRE (ESB).

After its settings have been completed, the instrument generates an SRQ.

The SRQ is the only possibility for the instrument to become active on its own. Each controller program should set the instrument such that a service request is initiated in the case of malfunction. The program should react appropriately to the service request.

Serial Poll

In a serial poll, just as with command `*STB`, the status byte of an instrument is queried. However, the query is realized via interface messages and is thus clearly faster.

The serial poll method is defined in IEEE 488.1 and used to be the only standard possibility for different instruments to poll the status byte. The method also works for instruments which do not adhere to SCPI or IEEE 488.2.

The serial poll is mainly used to obtain a fast overview of the state of several instruments connected to the controller.

Query of an instrument status

Each part of any status register can be read using queries. There are two types of commands:

- The common commands `*ESR?`, `*IDN?`, `*IST?`, `*STB?` query the higher-level registers.
- The commands of the `STATus` system query the SCPI registers (`STATus:QUESTionable...`)

The returned value is always a decimal number that represents the bit pattern of the queried register. This number is evaluated by the controller program.

Queries are usually used after an SRQ in order to obtain more detailed information on the cause of the SRQ.

Error Queue

Each error state in the instrument leads to an entry in the error queue. The entries of the error queue are detailed plain text error messages that can be looked up in the Error Log or queried via remote control using `SYSTem:ERRor[:NEXT]?`. Each call of `SYSTem:ERRor[:NEXT]?` provides one entry from the error queue. If no error messages are stored there any more, the instrument responds with 0, "No error".

The error queue should be queried after every SRQ in the controller program as the entries describe the cause of an error more precisely than the status registers. Especially in the test phase of a controller program the error queue should be queried regularly since faulty commands from the controller to the instrument are recorded there as well.

A.1.5.8 Reset Values of the Status Reporting System

The following table contains the different commands and events causing the status reporting system to be reset. None of the commands, except of `*RST` and `SYSTem:PRESet` affect the functional instrument settings. In particular, `DCL` does not change the instrument settings.

Table A-9: Resetting the status reporting system

Event	Switching on supply voltage Power-On-Status-Clear		DCL, SDC (Device Clear, Selected Device Clear)	*RST or SYSTem: PRESet	STATus: PRESet	*CLS
	0	1				
Clear STB, ESR	-	Yes	-	-	-	Yes
Clear SRE, ESE	-	Yes	-	-	-	-
Clear PPE	-	Yes	-	-	-	-
Clear error queue	Yes	Yes	-	-	-	Yes
Clear output buffer	Yes	Yes	Yes	1)	1)	1)
Clear command processing and input buffer	Yes	Yes	Yes	-	-	-

1) The first command in a command line that immediately follows a <PROGRAM MESSAGE TERMINATOR> clears the output buffer.

A.1.6 General Programming Recommendations

Initial instrument status before changing settings

Manual operation is designed for maximum possible operating convenience. In contrast, the priority of remote control is the "predictability" of the instrument status. Thus, when a command attempts to define incompatible settings, the command is ignored and the instrument status remains unchanged, i.e. other settings are not automatically adapted. Therefore, control programs should always define an initial instrument status (e.g. using the *RST command) and then implement the required settings.

Command sequence

As a general rule, send commands and queries in different program messages. Otherwise, the result of the query may vary depending on which operation is performed first (see also Preventing Overlapping Execution).

Reacting to malfunctions

The service request is the only possibility for the instrument to become active on its own. Each controller program should instruct the instrument to initiate a service request in case of malfunction. The program should react appropriately to the service request.

Error queues

The error queue should be queried after every service request in the controller program as the entries describe the cause of an error more precisely than the status registers. Especially in the test phase of a controller program the error queue should be queried regularly since faulty commands from the controller to the instrument are recorded there as well.

A.2 Telnet program examples

The following program example shows a simple `TcpClient` class that is intended to explain on how to get started with programming of sockets.

The example sets up a socket communication to R&S SMA100B and opens a simple user interface, very similar to the telnet, which allows input of commands. To enable real automation, further development of the program is required.

TcpClient.h

```
#include <string>
//defines structs for socket handling
#include <netinet/in.h>
using namespace std;
typedef struct sockaddr_in SockAddrStruct;
typedef struct hostent      HostInfoStruct;
```

```

class TcpClient
{
public:
    TcpClient();
    ~TcpClient();
    void connectToServer( string &hostname, int port );
    void disconnect( );
    void transmit( string &txString );
    void receive( string &rxString );
    string getCurrentHostName( ) const;
    int    getCurrentPort( ) const;
private:
    string      currentHostName;
    int         currentPort;
    int         currentSocketDescr;
    SockAddrStruct  serverAddress;
    HostInfoStruct * currentHostInfo;
    bool        clientIsConnected;
    int         receiveBufferSize;
};

```

TcpClient.cpp

```

#include <string>
//defines structs for socket handling
#include <netinet/in.h>
using namespace std;
typedef struct sockaddr_in SockAddrStruct;
typedef struct hostent     HostInfoStruct;
class TcpClient
{
public:
    TcpClient();
    ~TcpClient();
    void connectToServer( string &hostname, int port );
    void disconnect( );
    void transmit( string &txString );
    void receive( string &rxString );
    string getCurrentHostName( ) const;
    int    getCurrentPort( ) const;
private:
    string      currentHostName;
    int         currentPort;
    int         currentSocketDescr;
    SockAddrStruct  serverAddress;
    HostInfoStruct * currentHostInfo;
    bool        clientIsConnected;
    int         receiveBufferSize;
};

```

```

#include <netdb.h>
#include <netinet/in.h>
#include <unistd.h>
#include "TcpClient.h"
TcpClient::TcpClient()
: currentHostName( "" )
, currentPort( 0 )
, currentSocketDescr( 0 )
, serverAddress ( )
, currentHostInfo( NULL )
, clientIsConnected( false )
, receiveBufferSize( 1024 )
{
}
TcpClient::~~TcpClient()
{
    currentHostInfo = NULL;
}

void TcpClient::connectToServer( string &hostname, int port )
{
    currentHostInfo = gethostbyname( hostname.c_str( ) );
    if( currentHostInfo == NULL )
    {
        currentHostName = "";
        currentPort = 0;
        currentHostInfo = NULL;
        clientIsConnected = false;
        printf("error connecting host\n" );
    }
    currentHostName = hostname;
    currentPort = port;
    currentSocketDescr = socket(AF_INET, SOCK_STREAM, 0);
    if( currentSocketDescr == 0 )
    {
        currentHostName = "";
        currentPort = 0;
        currentHostInfo = NULL;
        clientIsConnected = false;
        printf("can't create socket\n" );
    }
    serverAddress.sin_family = currentHostInfo->h_addrtype;
    serverAddress.sin_port = htons( currentPort );
    memcpy( (char *) &serverAddress.sin_addr.s_addr,
        currentHostInfo->h_addr_list[0], currentHostInfo->h_length );
    if( connect( currentSocketDescr, ( struct sockaddr *) &serverAddress,
        sizeof( serverAddress ) ) < 0 )
    {
        throw string("can't connect server\n" );
    }
}

```

```
        clientIsConnected = true;
    }
void TcpClient::disconnect( )
{
    if( clientIsConnected )
    {
        close( currentSocketDescr );
    }
    currentSocketDescr = 0;
    currentHostName    = "";
    currentPort        = 0;
    currentHostInfo    = NULL;
    clientIsConnected  = false;
}
void TcpClient::transmit( string &txString )
{
    if( !clientIsConnected )
    {
        throw string("connection must be established before any data can be sent\n");
    }
    char * transmitBuffer = new char[txString.length() +1];
    memcpy( transmitBuffer, txString.c_str(), txString.length() );
    transmitBuffer[txString.length()] = '\n'; //newline is needed!
    if( send( currentSocketDescr, transmitBuffer, txString.length() + 1, 0 ) < 0 )
    {
        throw string("can't transmit data\n");
    }
    delete [] transmitBuffer;
}
void TcpClient::receive( string &rxString )
{
    if( !clientIsConnected )
    {
        throw string("connection must be established before any data can be received\n");
    }
    char * receiveBuffer = new char[receiveBufferSize];
    memset( receiveBuffer, 0, receiveBufferSize );
    bool receiving = true;
    while( receiving )
    {
        int receivedByteCount = recv( currentSocketDescr,
            receiveBuffer, receiveBufferSize, 0 );
        if( receivedByteCount < 0 )
        {
            throw string("error while receiving data\n");
        }
        rxString += string( receiveBuffer );
        receiving = ( receivedByteCount == receiveBufferSize );
    }
    delete [] receiveBuffer;
}
```

```

}
string TcpClient::getCurrentHostName( ) const
{
    return currentHostName;
}
int TcpClient::getCurrentPort( ) const
{
    return currentPort;
}

```

TelnetClient.cpp

```

#include <iostream>
#include "TcpClient.h"
void printUsage()
{
    cout<<"usage: EthernetRawCommand <server-ip> [scpi-command]"<<endl;
}
int main( int argc, char *argv[] )
{
    int errorCode          = 0; //no error
    bool useSingleCommand = false;
    string singleCommand  = "";
    string hostname       = "";
    int    port           = 5025;
    string input          = "";
    TcpClient client;
    switch( argc )
    {
        case 3:
            useSingleCommand = true;
            singleCommand    = argv[2];
        case 2:
            hostname        = argv[1];
            break;
        default:
            printUsage();
            return(-1);
    }
    try
    {
        client.connectToServer( hostname, port );
        bool terminate = false;
        while( !terminate )
        {
            char buffer[1024];
            if( useSingleCommand )
            {
                input = singleCommand; //send string
            }

```



```
else
{
    cin.getline( buffer, 1024 );
    input = buffer;
    if( input == "end" )
    {
        terminate = true;
    }
}
if( !terminate)
{
    client.transmit( input ); //send string
    int qPos = input.find( "?", 0 );
    //receive string only when needed
    if( qPos > 0 )
    {
        string rcStr = "";
        client.receive( rcStr );
        cout << rcStr << endl;
    }
}
if( useSingleCommand )
{
    terminate = true;
}
}
}catch( const string errorString )
{
    cout<<errorString<<endl;
}
client.disconnect( );
return errorCode;
}
```

B Hardware Interfaces

This section covers hardware-related topics, like pin assignment of the IEC 625/IEEE 488 interface.

The remote control interfaces are described in details in [Chapter 13, "Network Operation and Remote Control"](#), on page 351.

All other interfaces are described in [Chapter 3.2, "Instrument Tour"](#), on page 32.

For specifications, refer to the data sheet.

B.1 GPIB-Bus Interface

Option: R&S SMAB-B86.

Pin assignment




Figure B-1: Pin assignment of GPIB-bus (IEEE 488) interface

Bus lines

- Data bus with 8 lines D0 to D7:
The transmission is bit-parallel and byte-serial in the ASCII/ISO code. D0 is the least significant bit, D7 the most significant bit.
- Control bus with five lines:
IFC (Interface Clear): active LOW resets the interfaces of the instruments connected to the default setting.
ATN (Attention): active LOW signals the transmission of interface messages, inactive HIGH signals the transmission of device messages.

SRQ (Service Request): active LOW enables the connected device to send a service request to the controller.

REN (Remote Enable): active LOW permits switchover to remote control.

EOI (End or Identify): has two functions in connection with ATN:

- ATN=HIGH active LOW marks the end of data transmission.
- ATN=LOW active LOW triggers a parallel poll.

- Handshake bus with three lines:

DAV (Data Valid): active LOW signals a valid data byte on the data bus.

NRFD (Not Ready For Data): active LOW signals that one of the connected devices is not ready for data transfer.

NDAC (Not Data Accepted): active LOW signals that the instrument connected is accepting the data on the data bus.

Interface functions

Instruments which can be controlled via GPIB-bus interface can be equipped with different interface functions. [Table B-1](#) lists the interface functions for the R&S SMA100B.

Table B-1: GPIB-bus interface functions

Control character	Interface function
SH1	Handshake source function (source handshake), full capability
AH1	Handshake sink function (acceptor handshake), full capability
L4	Listener function, full capability, de-addressed by MTA.
T6	Talker function, full capability, ability to respond to serial poll, deaddressed by MLA
SR1	Service request function (Service Request), full capability
PP1	Parallel poll function, full capability
RL1	Remote/Local switch over function, full capability
DC1	Reset function (Device Clear), full capability
DT1	Trigger function (Device Trigger), full capability

C Extensions for User Files

The [Table C-1](#) lists all available file extensions for user files. The currently available files on the instrument depend on the installed options.

Table C-1: List of the automatically assigned file extensions in the instrument

Function	List type	Contents	File suffix
Instrument State	Settings	Instrument settings	*.savrc1txt
License Key		License Key	*.xml
"User Correction"	List	User-defined level correction values	*.uco
"List Mode"	List	User-defined frequency/level value pairs	*.lsw
	Settings	Response file	*.txt
"Pulse Train"	Settings	Pulse train data	*.pulstrn
"NRP Settings"	Settings	R&S NRP Settings	*.nrp, *.rsu
SCPI command list	List	Export file containing list of SCPIs	*.iee
R&S Support Info Archive	Support File	Automatically collected support information	*.tar.gz
Tutorials	Tutorial files	Lists containing SCPIs and explanations	*.tut

D Morse Code Settings

The COM/ID tone is sent according to the selected code (see [Table D-1](#)). The length of the Morse code can be varied. For selected standard time scheme, the selected dot length determines the setting of all other length parameters of the Morse code (dash length, symbol space and letter space). For selected user time scheme, all length parameters of the code can be set independently. If no coding is entered, the COM/ID tone is sent uncoded (key down).



The following values are default values:

- A dot (.) has a tone duration of 100 ms
- A dash (-) has a tone duration of 300ms
- The time between two tones is 100ms
- The time between two letters is 300ms

After each word, a word space is entered. The word repetition rate is 7 words per minute. Since the word length can vary between 900 ms and 4500 ms, the word space between the words varies accordingly.

Example:

ID code = MUC

The word length =

$(300+100+300)+300+(100+100+100+100+300)+300+(300+100+100+100+300+100+100) = 3100$ ms

Table D-1: Morse code

Letter	Morse code	Letter	Morse code
A	.-	N	-.
B	-...	O	---
C	-...	P	..-.
D	-...	Q	--..
E	.	R	.-.
F	...-	S	...
G	--.	T	-
H	U	...-
I	..	V	...-
J-	W	..--
K	-.-	X	-...-
L	...-	Y	-...-
M	--	Z	---..

Glossary: List of the Often Used Terms and Abbreviations

Symbols

1MA193: 1MA193_0e Application Note, "Aeronautical radio navigation measurement solutions"

A

Absolute file path: [Complete file path](#)

B

Base unit: This term describes a R&S SMA100B equipped with the option R&S SMAB-B103.

C

Clock: A mandatory internal or an external reference clock signal for generating the timing pulse in the instrument.

Complete file path: The complete file path specifies the root directory and all subdirectories that contain a file or folder.

See also [Chapter 14.5.2, "Accessing Files in the Default or in a Specified Directory"](#), on page 420.

Computer name: An unambiguous indication of the instrument in a LAN that uses a [DNS](#) server.

The default computer name follows the syntax `SMA100B-<serial number>`, e.g. `SMA100B-102030`.

Synonym: [Hostname](#)

See [Serial number](#).

D

daisy chain: A connection scheme in which instruments are connected together in sequence, i.e. an output of the first one is connected to an input of the second one, etc.

DHCP: Dynamic host configuration protocol

DNS: Domain name system server

E

e.g.: For example

External mass memory: External memory, connected to the instrument via USB connector (Type A female). It can hold stored files with user data.

See also [System drive](#) and [SD card](#)

F

File transfer: The transmission of files from or to the instrument by a remote client. The instrument supports the standard methods [FTP](#) and file sharing according to [SAMBA/SMB](#).

FTP: File transfer protocol

Full file path: [Complete file path](#)

G

Glossary: List of the often used terms and abbreviations

GUI: Graphical user interface

H

HDD: Hard disk drive, see [System drive](#)

Hostname: [Computer name](#)

I

i.e.: That is

L

LF: Low frequency

LSB: Least significant bit

M

MIMO: Multiple input multiple output

MSB: Most significant bit

P

PC: Personal computer

Power: A term describing the signal level of the RF signal

product page: A designation of the R&S SMA100B product page <http://www.rohde-schwarz.com/product/SMA100B.html>

R

Remote access: [Remote operation](#)

Remote control: The operation of the R&S SMA100B by remote control commands or programs to perform automated tests.

The instrument is connected to a system controller via LAN/VXI-11, GPIB or USB using [VISA](#). The instrument is controlled directly or supported by instrument drivers.

Remote device: External device controls the R&S SMA100B in remote operation mode, see [Remote operation](#).

Synonyms: External controller, client device

Remote operation: Allows you to operate the R&S SMA100B from a remote device via VNC.

Both the R&S SMA100B and the remote device are connected in a LAN.

Synonym: Remote access

Removable memory: General term describing mass memory that can be unmounted from the instrument.

See also [SD card](#)

RF: Radio frequency

S

SAMBA/SMB: Server message protocol

SD card: Secure digital card is a type of removable memory storage, that can hold files with user data.

Support of this memory type is optional and requires option R&S SMAB-B85.

Throughout this description, the SD card is referred as a removable memory.

See also [System drive](#).

Serial number: Unique instrument identification, provided on the rear panel of the instrument and required to build the [Computer name](#).

The serial number are the last 6 digits in the string `<stock no.>-<serial number>`, e.g. SMA100B-102030

Smart device: A mobile, cordless device, such as a smartphone or tablet, capable of Internet browsing.

Synonyms: Smartphone, tablet

System drive: The system drive is a built-in internal memory that holds the operating system, the firmware, and the stored user data.

Throughout this description, the system drive is referred as an internal memory.

See also [SD card](#) and [Removable memory](#)

T

Trigger: Internally generated or externally supplied signal which starts signal generation at a particular point in time

Trigger event: A trigger event is caused by the received trigger signal or executed manual trigger.

U

UE: User equipment

USBTMC: (USB test & measurement class)

A protocol built on top of USB for communication with USB devices. Using [VISA](#) library, it supports service request, triggers, and other specific operations, similar to GPIB.

User directory: Describes the default file storage location for user data.

Depending on the installed options, the user directory is physically located on the [System drive](#) or on the [Removable memory](#)

In the file system, user directory is always indicated as `/var/user`

V

VISA: Virtual instrument software architecture

List of Commands

:CALCulate[:POWer]:SWEep:FREQuency:MATH<ch>:STATe.....	455
:CALCulate[:POWer]:SWEep:FREQuency:MATH<ch>:SUBTract.....	456
:CALCulate[:POWer]:SWEep:POWer:MATH<ch>:STATe.....	456
:CALCulate[:POWer]:SWEep:POWer:MATH<ch>:SUBTract.....	456
:CALCulate[:POWer]:SWEep:TIME:GATE<ch>:AVERAge?.....	457
:CALCulate[:POWer]:SWEep:TIME:GATE<ch>:FEED.....	457
:CALCulate[:POWer]:SWEep:TIME:GATE<ch>:MAXimum?.....	457
:CALCulate[:POWer]:SWEep:TIME:GATE<ch>:START.....	458
:CALCulate[:POWer]:SWEep:TIME:GATE<ch>:STATe.....	458
:CALCulate[:POWer]:SWEep:TIME:GATE<ch>:STOP.....	458
:CALCulate[:POWer]:SWEep:TIME:MATH<ch>:STATe.....	459
:CALCulate[:POWer]:SWEep:TIME:MATH<ch>:SUBTract.....	459
:CALibration:ALL[:MEASure]?.....	429
:CALibration:DATA:FACTory:DATE?.....	430
:CALibration<hw>:ALL:DATE?.....	429
:CALibration<hw>:ALL:INformation?.....	429
:CALibration<hw>:ALL:TEMP?.....	430
:CALibration<hw>:ALL:TIME?.....	430
:CALibration<hw>:CONTinueonerror.....	431
:CSYNthesis:FREQuency.....	432
:CSYNthesis:FREQuency:STEP.....	435
:CSYNthesis:FREQuency:STEP:MODE.....	435
:CSYNthesis:OFFSet.....	433
:CSYNthesis:OFFSet:STATe.....	433
:CSYNthesis:OTYPE.....	432
:CSYNthesis:PHASe.....	434
:CSYNthesis:PHASe:REFerence.....	434
:CSYNthesis:POWer.....	433
:CSYNthesis:POWer:STEP:MODE.....	435
:CSYNthesis:POWer:STEP[:INCRement].....	435
:CSYNthesis:STATe.....	432
:CSYNthesis:VOLTagE.....	434
:DEvice:PRESet.....	417
:DIAGnostic<hw>:BGInfo:CATalog?.....	436
:DIAGnostic<hw>:BGInfo?.....	437
:DIAGnostic<hw>:POINT:CATalog?.....	437
:DIAGnostic<hw>[:MEASure]:POINT?.....	438
:DISPlay:ANNotation:AMPLitude.....	440
:DISPlay:ANNotation:FREQuency.....	441
:DISPlay:ANNotation[:ALL].....	441
:DISPlay:BRIGhtness.....	440
:DISPlay:BUtTon:BRIGhtness.....	440
:DISPlay:DIALog:CLOSe.....	442
:DISPlay:DIALog:CLOSe:ALL.....	443
:DISPlay:DIALog:ID?.....	441
:DISPlay:DIALog:OPEN.....	442
:DISPlay:PSAVe:HOLDoff.....	439

:DISPlay:PSAVE[:STATe].....	439
:DISPlay:UPDate.....	440
:DISPlay[:WINDow][:POWer]:SWEep:BACKground:COLor.....	459
:DISPlay[:WINDow][:POWer]:SWEep:GRID:STATe.....	460
:FORMat:BORDER.....	443
:FORMat:SREGister.....	443
:FORMat[:DATA].....	444
:HCOPy:DATA?.....	446
:HCOPy:DEVIce:LANGuage.....	446
:HCOPy:FILE[:NAME].....	446
:HCOPy:FILE[:NAME]:AUTO:DIRectory.....	447
:HCOPy:FILE[:NAME]:AUTO:DIRectory:CLear.....	448
:HCOPy:FILE[:NAME]:AUTO:FILE?.....	448
:HCOPy:FILE[:NAME]:AUTO:STATe.....	448
:HCOPy:FILE[:NAME]:AUTO?.....	447
:HCOPy:FILE[:NAME]:AUTO[:FILE]:DAY:STATe.....	448
:HCOPy:FILE[:NAME]:AUTO[:FILE]:MONTH:STATe.....	448
:HCOPy:FILE[:NAME]:AUTO[:FILE]:NUMBER?.....	449
:HCOPy:FILE[:NAME]:AUTO[:FILE]:PREFIX.....	449
:HCOPy:FILE[:NAME]:AUTO[:FILE]:PREFIX:STATe.....	449
:HCOPy:FILE[:NAME]:AUTO[:FILE]:YEAR:STATe.....	448
:HCOPy:IMAGe:FORMat.....	446
:HCOPy:REGion.....	446
:HCOPy[:EXECute].....	447
:INITiate<hw>[:POWer]:CONTinuous.....	460
:INITiate<hw>[:POWer]:CONTinuous.....	507
:KBOARD:LAYOUT.....	449
:MEMory:HFRee?.....	428
:MMEMory:CATalog:LENGth?.....	423
:MMEMory:CATalog?.....	423
:MMEMory:CDIRectory.....	424
:MMEMory:COPY.....	424
:MMEMory:DATA.....	425
:MMEMory:DCATalog:LENGth?.....	426
:MMEMory:DCATalog?.....	425
:MMEMory:DELeTe.....	426
:MMEMory:LOAD:STATe.....	426
:MMEMory:MDIRectory.....	426
:MMEMory:MOVE.....	427
:MMEMory:MSIS.....	427
:MMEMory:RDIRectory.....	427
:MMEMory:STORe:STATe.....	427
:OUTPut:ALL[:STATe].....	450
:OUTPut:FPROportional:SCALE.....	452
:OUTPut:USER:MARKer.....	453
:OUTPut<hw>:AFIXed:RANGe:LOWer?.....	453
:OUTPut<hw>:AFIXed:RANGe:UPPer?.....	453
:OUTPut<hw>:AMODE.....	451
:OUTPut<hw>:FILTer:MODE.....	452
:OUTPut<hw>:IMPedance?.....	452

:OUTPut<hw>:PROTection:CLEar.....	453
:OUTPut<hw>:PROTection:TRIPped?.....	454
:OUTPut<hw>[:STATe].....	451
:OUTPut<hw>[:STATe]:PON.....	451
:READ<ch>[:POWer]?.....	507
:SENSe[:POWer]:SWEep:ABORT.....	471
:SENSe[:POWer]:SWEep:FREQuency:REFerence:DATA:COpy.....	471
:SENSe[:POWer]:SWEep:FREQuency:REFerence:DATA:POINts?.....	471
:SENSe[:POWer]:SWEep:FREQuency:REFerence:DATA:XVALues.....	471
:SENSe[:POWer]:SWEep:FREQuency:REFerence:DATA:YVALues.....	472
:SENSe[:POWer]:SWEep:FREQuency:RMODe.....	472
:SENSe[:POWer]:SWEep:FREQuency:SPACing[:MODe].....	472
:SENSe[:POWer]:SWEep:FREQuency:STARt.....	472
:SENSe[:POWer]:SWEep:FREQuency:STEPs.....	473
:SENSe[:POWer]:SWEep:FREQuency:STOP.....	473
:SENSe[:POWer]:SWEep:FREQuency:TIMing[:MODe].....	473
:SENSe[:POWer]:SWEep:FREQuency:YSCale:AUTO.....	474
:SENSe[:POWer]:SWEep:FREQuency:YSCale:AUTO:RESet.....	474
:SENSe[:POWer]:SWEep:FREQuency:YSCale:MAXimum.....	474
:SENSe[:POWer]:SWEep:FREQuency:YSCale:MINimum.....	475
:SENSe[:POWer]:SWEep:HCOPy:DATA?.....	475
:SENSe[:POWer]:SWEep:HCOPy:DEVIce.....	476
:SENSe[:POWer]:SWEep:HCOPy:DEVIce:LANGUage.....	477
:SENSe[:POWer]:SWEep:HCOPy:DEVIce:LANGUage:CSV:DPOint.....	477
:SENSe[:POWer]:SWEep:HCOPy:DEVIce:LANGUage:CSV:HEADer.....	477
:SENSe[:POWer]:SWEep:HCOPy:DEVIce:LANGUage:CSV:ORientation.....	478
:SENSe[:POWer]:SWEep:HCOPy:DEVIce:LANGUage:CSV[:COLumn]:SEPArator.....	478
:SENSe[:POWer]:SWEep:HCOPy:DEVIce:SIZE.....	478
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME].....	479
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO:DIRectory.....	479
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO:DIRectory:CLEar.....	479
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO:FILE?.....	480
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO:STATe.....	480
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:DAY:STATe.....	481
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:DAY?.....	480
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:MONTH:STATe.....	481
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:MONTH?.....	481
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:NUMBer?.....	482
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:PREFix.....	482
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:PREFix:STATe.....	482
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:YEAR:STATe.....	483
:SENSe[:POWer]:SWEep:HCOPy:FILE[:NAME]:AUTO[:FILE]:YEAR?.....	482
:SENSe[:POWer]:SWEep:HCOPy[:EXECute].....	483
:SENSe[:POWer]:SWEep:INITiate.....	483
:SENSe[:POWer]:SWEep:MODe.....	483
:SENSe[:POWer]:SWEep:POWer:REFerence:DATA:COpy.....	484
:SENSe[:POWer]:SWEep:POWer:REFerence:DATA:POINts?.....	484
:SENSe[:POWer]:SWEep:POWer:REFerence:DATA:XVALues.....	484
:SENSe[:POWer]:SWEep:POWer:REFerence:DATA:YVALues.....	484
:SENSe[:POWer]:SWEep:POWer:RMODe.....	485

:SENSe[:POWer]:SWEep:POWer:SPACing[:MODE].....	485
:SENSe[:POWer]:SWEep:POWer:START.....	485
:SENSe[:POWer]:SWEep:POWer:STEPS.....	485
:SENSe[:POWer]:SWEep:POWer:STOP.....	486
:SENSe[:POWer]:SWEep:POWer:TIMing[:MODE].....	486
:SENSe[:POWer]:SWEep:POWer:YSCale:AUTO.....	486
:SENSe[:POWer]:SWEep:POWer:YSCale:AUTO:RESet.....	487
:SENSe[:POWer]:SWEep:POWer:YSCale:MAXimum.....	487
:SENSe[:POWer]:SWEep:POWer:YSCale:MINimum.....	488
:SENSe[:POWer]:SWEep:RMODE.....	488
:SENSe[:POWer]:SWEep:TIME:AVERAge[:COUNT].....	488
:SENSe[:POWer]:SWEep:TIME:REFerence:DATA:COpy.....	489
:SENSe[:POWer]:SWEep:TIME:REFerence:DATA:POINts?.....	489
:SENSe[:POWer]:SWEep:TIME:REFerence:DATA:XVALues.....	489
:SENSe[:POWer]:SWEep:TIME:REFerence:DATA:YVALues.....	489
:SENSe[:POWer]:SWEep:TIME:RMODE.....	490
:SENSe[:POWer]:SWEep:TIME:SPACing[:MODE].....	490
:SENSe[:POWer]:SWEep:TIME:START.....	490
:SENSe[:POWer]:SWEep:TIME:STEPS.....	490
:SENSe[:POWer]:SWEep:TIME:STOP.....	491
:SENSe[:POWer]:SWEep:TIME:TEVents.....	491
:SENSe[:POWer]:SWEep:TIME:YSCale:AUTO.....	491
:SENSe[:POWer]:SWEep:TIME:YSCale:AUTO:RESet.....	492
:SENSe[:POWer]:SWEep:TIME:YSCale:MAXimum.....	492
:SENSe[:POWer]:SWEep:TIME:YSCale:MINimum.....	493
:SENSe<ch>:UNIT[:POWer].....	508
:SENSe<ch>[:POWer]:APERTure:DEFault:STATe.....	508
:SENSe<ch>[:POWer]:APERTure:TIME.....	509
:SENSe<ch>[:POWer]:CORRection:SPDeVice:LIST?.....	510
:SENSe<ch>[:POWer]:CORRection:SPDeVice:SElect.....	509
:SENSe<ch>[:POWer]:CORRection:SPDeVice:STATe.....	509
:SENSe<ch>[:POWer]:DISPlay:PERManent:PRiority.....	510
:SENSe<ch>[:POWer]:DISPlay:PERManent:STATe.....	510
:SENSe<ch>[:POWer]:FILTer:LENGth:AUTO?.....	510
:SENSe<ch>[:POWer]:FILTer:LENGth[:USER].....	511
:SENSe<ch>[:POWer]:FILTer:NSRatio.....	511
:SENSe<ch>[:POWer]:FILTer:NSRatio:MTIME.....	512
:SENSe<ch>[:POWer]:FILTer:SONCe.....	512
:SENSe<ch>[:POWer]:FILTer:TYPE.....	512
:SENSe<ch>[:POWer]:FREQuency.....	513
:SENSe<ch>[:POWer]:LOGGing:STATe.....	513
:SENSe<ch>[:POWer]:OFFSet.....	514
:SENSe<ch>[:POWer]:OFFSet:STATe.....	514
:SENSe<ch>[:POWer]:SNUMber?.....	514
:SENSe<ch>[:POWer]:SOURce.....	514
:SENSe<ch>[:POWer]:STATus[:DEVice]?.....	515
:SENSe<ch>[:POWer]:SVERsion?.....	515
:SENSe<ch>[:POWer]:SWEep:FREQuency[:SENSor]:OFFSet.....	462
:SENSe<ch>[:POWer]:SWEep:FREQuency[:SENSor]:OFFSet:STATe.....	463
:SENSe<ch>[:POWer]:SWEep:FREQuency[:SENSor]:SRANge:START.....	463

:SENSe<ch>[:POWer]:SWEep:FREQuency[:SENSor]:SRANge:STOP.....	463
:SENSe<ch>[:POWer]:SWEep:FREQuency[:SENSor]:SRANge[:STATe].....	464
:SENSe<ch>[:POWer]:SWEep:POWer[:SENSor]:OFFSet.....	464
:SENSe<ch>[:POWer]:SWEep:POWer[:SENSor]:OFFSet:STATe.....	465
:SENSe<ch>[:POWer]:SWEep:POWer[:SENSor]:SFRequency.....	465
:SENSe<ch>[:POWer]:SWEep:POWer[:SENSor]:SFRequency:STATe.....	465
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:OFFSet.....	466
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:OFFSet:STATe.....	466
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:STATe.....	466
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:THReshold:BASE.....	467
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:THReshold:POWer:HREFerence.....	467
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:THReshold:POWer:LREFerence.....	467
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:PULSe:THReshold:POWer:REFerence.....	468
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:SFRequency.....	468
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:SFRequency:STATe.....	468
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:TRIGger:AUTO.....	469
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:TRIGger:DTIME.....	469
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:TRIGger:HYSTEResis.....	469
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:TRIGger:LEVel.....	470
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:TRIGger:SLOPe.....	470
:SENSe<ch>[:POWer]:SWEep:TIME[:SENSor]:TRIGger:SOURce.....	470
:SENSe<ch>[:POWer]:TYPE?.....	515
:SENSe<ch>[:POWer]:ZERO.....	470
:SENSe<ch>[:POWer]:ZERO.....	516
:SLISt:ELEMent<ch>:MAPPing.....	506
:SLISt:SCAN[:STATe].....	506
:SLISt:SENSor:MAP.....	507
:SLISt[:LIST]?.....	506
:SOURce<hw>:PRESet.....	417
:STATus:OPERation:CONDition?.....	683
:STATus:OPERation:ENABLE.....	683
:STATus:OPERation:NTRansition.....	684
:STATus:OPERation:PTRansition.....	684
:STATus:OPERation[:EVENT].....	683
:STATus:PRESet.....	684
:STATus:QUESTionable:CONDition.....	685
:STATus:QUESTionable:ENABLE.....	685
:STATus:QUESTionable:NTRansition.....	685
:STATus:QUESTionable:PTRansition.....	686
:STATus:QUESTionable[:EVENT].....	685
:STATus:QUEEue[:NEXT]?.....	686
:SWEep:TYPE.....	649
:SYSTem:BIOS:VERSion?.....	680
:SYSTem:COMMunicate:GPIB:LTERminator.....	667
:SYSTem:COMMunicate:GPIB:RESource?.....	667
:SYSTem:COMMunicate:GPIB[:SELF]:ADDResS.....	667
:SYSTem:COMMunicate:HISLip:RESource?.....	668
:SYSTem:COMMunicate:NETWork:IPADdress.....	668
:SYSTem:COMMunicate:NETWork:IPADdress:MODE.....	668
:SYSTem:COMMunicate:NETWork:MACAddress.....	668

:SYSTem:COMMunicate:NETWork:RESource?	669
:SYSTem:COMMunicate:NETWork:REStart	669
:SYSTem:COMMunicate:NETWork:STATus?	669
:SYSTem:COMMunicate:NETWork[:COMMOn]:DOMain	669
:SYSTem:COMMunicate:NETWork[:COMMOn]:HOSTname	669
:SYSTem:COMMunicate:NETWork[:COMMOn]:WORKgroup	670
:SYSTem:COMMunicate:NETWork[:IPADdress]:DNS	670
:SYSTem:COMMunicate:NETWork[:IPADdress]:GATeway	670
:SYSTem:COMMunicate:NETWork[:IPADdress]:SUBNet:MASK	670
:SYSTem:COMMunicate:SERial:BAUD	671
:SYSTem:COMMunicate:SERial:PARity	671
:SYSTem:COMMunicate:SERial:RESource?	671
:SYSTem:COMMunicate:SERial:SBITs	671
:SYSTem:COMMunicate:SOCKet:RESource?	672
:SYSTem:COMMunicate:USB:RESource?	672
:SYSTem:DATE	678
:SYSTem:DFPR?	681
:SYSTem:DLOCK	663
:SYSTem:ERRor:ALL?	660
:SYSTem:ERRor:CODE:ALL?	661
:SYSTem:ERRor:CODE[:NEXT]?	661
:SYSTem:ERRor:COUNT?	662
:SYSTem:ERRor:GNEXt?	663
:SYSTem:ERRor:HISTory:CLear	663
:SYSTem:ERRor:STATic?	663
:SYSTem:ERRor[:NEXT]?	662
:SYSTem:FILEs:TEMPorary:DELeTe	682
:SYSTem:FPReset	418
:SYSTem:HELP:EXPort	672
:SYSTem:IDENtification	672
:SYSTem:IDENtification:PRESet	673
:SYSTem:INFormation:SCPI	674
:SYSTem:IRESpone	673
:SYSTem:KLOCK	664
:SYSTem:LANGuage	674
:SYSTem:LOCK:OWNer?	664
:SYSTem:LOCK:RELease:ALL	665
:SYSTem:LOCK:REQuest[:EXCLusive]?	665
:SYSTem:MMEMory:PATH:USER?	681
:SYSTem:NTP:HOSTname	679
:SYSTem:NTP:STATe	679
:SYSTem:ORESpone	673
:SYSTem:OSYSem?	681
:SYSTem:PRESet	418
:SYSTem:PROTect<ch>[:STATe]	666
:SYSTem:RCL	665
:SYSTem:REBoot	681
:SYSTem:REStart	681
:SYSTem:SAV	665
:SYSTem:SECurity:SANitize[:STATe]	674

:SYSTem:SECurity:SUPolicy.....	674
:SYSTem:SECurity:VOLMode[:STATe].....	666
:SYSTem:SHUTdown.....	682
:SYSTem:SPECification:IDENtification:CATalog?.....	676
:SYSTem:SPECification:PARAmeter?.....	677
:SYSTem:SPECification:VERSion.....	676
:SYSTem:SPECification:VERSion:CATalog?.....	677
:SYSTem:SPECification:VERSion:FACTory?.....	677
:SYSTem:SPECification?.....	675
:SYSTem:SRData?.....	678
:SYSTem:STARtup:COMPLete?.....	678
:SYSTem:TIME.....	679
:SYSTem:TIME:ZONE.....	679
:SYSTem:TIME:ZONE:CATalog?.....	680
:SYSTem:ULOCK.....	664
:SYSTem:UPTime?.....	680
:SYSTem:VERSion?.....	680
:SYSTem:WAIT.....	682
:TEST<hw>:ALL:RESult?.....	687
:TEST<hw>:ALL:STARt.....	686
:TRACe[:POWer]:SWEep:MEASurement:FULLscreen:DISPlay:ANNotation[:STATe].....	501
:TRACe[:POWer]:SWEep:MEASurement:GATE:DISPlay:ANNotation[:STATe].....	502
:TRACe[:POWer]:SWEep:MEASurement:MARKer:DISPlay:ANNotation[:STATe].....	502
:TRACe[:POWer]:SWEep:MEASurement:PULSe:DISPlay:ANNotation[:STATe].....	502
:TRACe[:POWer]:SWEep:MEASurement:STANdard:DISPlay:ANNotation[:STATe].....	503
:TRACe<ch>[:POWer]:SWEep:COLor.....	494
:TRACe<ch>[:POWer]:SWEep:COPIY.....	495
:TRACe<ch>[:POWer]:SWEep:DATA:POINts?.....	495
:TRACe<ch>[:POWer]:SWEep:DATA:XVALues?.....	495
:TRACe<ch>[:POWer]:SWEep:DATA:YSValue?.....	496
:TRACe<ch>[:POWer]:SWEep:DATA:YVALues?.....	496
:TRACe<ch>[:POWer]:SWEep:FEED.....	496
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:AVERage:DISPlay:ANNotation[:STATe].....	498
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:AVERage?.....	497
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:HREReference:DISPlay:ANNotation[:STATe].....	498
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:HREReference?.....	497
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:LREFerence:DISPlay:ANNotation[:STATe].....	498
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:LREFerence?.....	497
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:MAXimum:DISPlay:ANNotation[:STATe].....	498
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:MAXimum?.....	497
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:MINimum:DISPlay:ANNotation[:STATe].....	498
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:MINimum?.....	497
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:PULSe:BASE:DISPlay:ANNotation[:STATe].....	498
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:PULSe:BASE?.....	497
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:PULSe:TOP:DISPlay:ANNotation[:STATe].....	498
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:PULSe:TOP?.....	497
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:REFerence:DISPlay:ANNotation[:STATe].....	498
:TRACe<ch>[:POWer]:SWEep:MEASurement:POWer:REFerence?.....	497
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:ALL:DISPlay:ANNotation[:STATe].....	499
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:DCYClE:DISPlay:ANNotation[:STATe].....	498

:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:DCYClE?	497
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:DURation:DISPlay:ANNotation[:STATe]	498
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:DURation?	497
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:PERiod:DISPlay:ANNotation[:STATe]	498
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:PERiod?	497
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:SEPARation:DISPlay:ANNotation[:STATe]	498
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:SEPARation?	497
:TRACe<ch>[:POWer]:SWEep:MEASurement:PULSe:STATe?	497
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:DURation:DISPlay: ANNotation[:STATe]	498
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:DURation?	497
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:OCCurrence:DISPlay: ANNotation[:STATe]	498
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:OCCurrence?	497
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:OVERshoot:DISPlay: ANNotation[:STATe]	498
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:NEGative:OVERshoot?	497
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:DURation:DISPlay: ANNotation[:STATe]	498
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:DURation?	497
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:OCCurrence:DISPlay: ANNotation[:STATe]	499
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:OCCurrence?	497
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:OVERshoot:DISPlay: ANNotation[:STATe]	499
:TRACe<ch>[:POWer]:SWEep:MEASurement:TRANSition:POSitive:OVERshoot?	497
:TRACe<ch>[:POWer]:SWEep:PULSe:THReshold:BASE?	499
:TRACe<ch>[:POWer]:SWEep:PULSe:THReshold:POWer:HREFerence	500
:TRACe<ch>[:POWer]:SWEep:PULSe:THReshold:POWer:LREFerence	500
:TRACe<ch>[:POWer]:SWEep:PULSe:THReshold:POWer:REFerence	500
:TRACe<ch>[:POWer]:SWEep:STATe	501
:TRIGger<hw>:FSWEEP:SOURce	688
:TRIGger<hw>:FSWEEP[:IMMEDIATE]	689
:TRIGger<hw>:LFFSWEEP	689
:TRIGger<hw>:LFFSWEEP:IMMEDIATE	689
:TRIGger<hw>:LFFSWEEP:SOURce	688
:TRIGger<hw>:PSWEEP:SOURce	688
:TRIGger<hw>:PSWEEP[:IMMEDIATE]	689
:TRIGger<hw>[:SWEep]:SOURce	688
:TRIGger<hw>[:SWEep][:IMMEDIATE]	689
:UNIT:ANGLE	690
:UNIT:POWer	690
[:SOURce]:CORRection:CSET:CATalog?	591
[:SOURce]:CORRection:CSET:DELeTe	592
[:SOURce]:INPut:TRIGger:SLOPe	603
[:SOURce]:LFOutput:OFFSet	609
[:SOURce]:LFOutput:VOLTagE	610
[:SOURce]:LFOutput<ch>:BANDwidth?	606
[:SOURce]:LFOutput<ch>:FREQuency	606
[:SOURce]:LFOutput<ch>:INTErnal:VOLTagE	608

[[:SOURce]:LFOutput<ch>:SOURce.....	609
[[:SOURce]:LFOutput<ch>:SOURce:PATH.....	609
[[:SOURce]:LFOutput<ch>[:STATe].....	608
[[:SOURce]:PM<ch>[:DEVIation].....	533
[[:SOURce]:POWer:WIGNore.....	641
[[:SOURce]:PULM[:INTErnal][:TRAIIn]:TRIGger:IMMEdiate.....	536
[[:SOURce]:ROSCillator:EXTErnal:FREQUency.....	644
[[:SOURce]:ROSCillator:EXTErnal:FREQUency:VARiable.....	644
[[:SOURce]:ROSCillator:EXTErnal:MLRange?.....	645
[[:SOURce]:ROSCillator:EXTErnal:NSBandwidth?.....	645
[[:SOURce]:ROSCillator:EXTErnal:RFOF[:STATe].....	644
[[:SOURce]:ROSCillator:EXTErnal:SBANDwidth.....	645
[[:SOURce]:ROSCillator:INTErnal:TUNing:SLOPe.....	643
[[:SOURce]:ROSCillator:INTErnal:TUNing[:STATe].....	643
[[:SOURce]:ROSCillator:OUTPut:ALTErnate:FREQUency:MODE.....	646
[[:SOURce]:ROSCillator:OUTPut:FREQUency:MODE.....	645
[[:SOURce]:ROSCillator:PRESet.....	643
[[:SOURce]:ROSCillator:SOURce.....	643
[[:SOURce]:ROSCillator[:INTErnal]:ADJJust:VALue.....	646
[[:SOURce]:ROSCillator[:INTErnal]:ADJJust[:STATe].....	647
[[:SOURce<hw>]:ADF:COMid:CODE.....	552
[[:SOURce<hw>]:ADF:COMid:DASH.....	552
[[:SOURce<hw>]:ADF:COMid:DEPTH.....	553
[[:SOURce<hw>]:ADF:COMid:DOT.....	553
[[:SOURce<hw>]:ADF:COMid:FREQUency.....	553
[[:SOURce<hw>]:ADF:COMid:LETTEr.....	554
[[:SOURce<hw>]:ADF:COMid:PERiod.....	554
[[:SOURce<hw>]:ADF:COMid:SYMBol.....	554
[[:SOURce<hw>]:ADF:COMid:TSCHEMA.....	555
[[:SOURce<hw>]:ADF:COMid[:STATe].....	555
[[:SOURce<hw>]:ADF:PRESet.....	550
[[:SOURce<hw>]:ADF:SETTING:CATalog.....	550
[[:SOURce<hw>]:ADF:SETTING:DELEte.....	550
[[:SOURce<hw>]:ADF:SETTING:LOAD.....	550
[[:SOURce<hw>]:ADF:SETTING:STORe.....	551
[[:SOURce<hw>]:ADF:STATe.....	551
[[:SOURce<hw>]:AM:DEPTH:SUM.....	522
[[:SOURce<hw>]:AM:DEVIation:MODE.....	523
[[:SOURce<hw>]:AM:MODE.....	522
[[:SOURce<hw>]:AM:RATIo.....	523
[[:SOURce<hw>]:AM:TYPE.....	524
[[:SOURce<hw>]:AM<ch>:DEPTH:EXPOntial.....	522
[[:SOURce<hw>]:AM<ch>:DEPTH:LINear.....	521
[[:SOURce<hw>]:AM<ch>:SENSitivity:EXPOntial.....	523
[[:SOURce<hw>]:AM<ch>:SENSitivity[:LINear].....	524
[[:SOURce<hw>]:AM<ch>:SOURce.....	520
[[:SOURce<hw>]:AM<ch>:STATe.....	520
[[:SOURce<hw>]:AM<ch>[:DEPTH].....	521
[[:SOURce<hw>]:CORRection:CSET:DATA:FREQUency.....	589
[[:SOURce<hw>]:CORRection:CSET:DATA:FREQUency:POINts?.....	590

[:SOURce<hw>]:CORRection:CSET:DATA:POWer.....	589
[:SOURce<hw>]:CORRection:CSET:DATA:POWer:POINts?.....	590
[:SOURce<hw>]:CORRection:CSET:DATA[:SENSor<ch>][:POWer]:SONCe.....	590
[:SOURce<hw>]:CORRection:CSET:DATA[:SENSor<ch>][:POWer]:SONCe.....	591
[:SOURce<hw>]:CORRection:CSET[:SELEct].....	590
[:SOURce<hw>]:CORRection:DEXChange:AFILe:CATALog?.....	592
[:SOURce<hw>]:CORRection:DEXChange:AFILe:EXTension.....	592
[:SOURce<hw>]:CORRection:DEXChange:AFILe:SELEct.....	593
[:SOURce<hw>]:CORRection:DEXChange:AFILe:SEParator:COLumn.....	593
[:SOURce<hw>]:CORRection:DEXChange:AFILe:SEParator:DECimal.....	593
[:SOURce<hw>]:CORRection:DEXChange:EXECute.....	593
[:SOURce<hw>]:CORRection:DEXChange:MODE.....	594
[:SOURce<hw>]:CORRection:DEXChange:SELEct.....	594
[:SOURce<hw>]:CORRection:VALue?.....	590
[:SOURce<hw>]:CORRection:ZERoing:STATe.....	591
[:SOURce<hw>]:CORRection[:STATe].....	591
[:SOURce<hw>]:FM:DEViation:MODE.....	527
[:SOURce<hw>]:FM:DEViation:SUM.....	528
[:SOURce<hw>]:FM:MODE.....	528
[:SOURce<hw>]:FM:RATio.....	528
[:SOURce<hw>]:FM:SENSitivity?.....	529
[:SOURce<hw>]:FM<ch>:SOURce.....	527
[:SOURce<hw>]:FM<ch>:STATe.....	526
[:SOURce<hw>]:FM<ch>[:DEViation].....	526
[:SOURce<hw>]:FREQuency:CENTer.....	598
[:SOURce<hw>]:FREQuency:MANual.....	597
[:SOURce<hw>]:FREQuency:MODE.....	595
[:SOURce<hw>]:FREQuency:MULTIplier.....	598
[:SOURce<hw>]:FREQuency:OFFSet.....	598
[:SOURce<hw>]:FREQuency:PHASe:CONTinuous:HIGH?.....	601
[:SOURce<hw>]:FREQuency:PHASe:CONTinuous:LOW?.....	601
[:SOURce<hw>]:FREQuency:PHASe:CONTinuous:MODE.....	601
[:SOURce<hw>]:FREQuency:PHASe:CONTinuous:STATe.....	602
[:SOURce<hw>]:FREQuency:PLL:MODE.....	601
[:SOURce<hw>]:FREQuency:SPAN.....	599
[:SOURce<hw>]:FREQuency:STARt.....	599
[:SOURce<hw>]:FREQuency:STEP:MODE.....	600
[:SOURce<hw>]:FREQuency:STEP[:INCRement].....	600
[:SOURce<hw>]:FREQuency:STOP.....	599
[:SOURce<hw>]:FREQuency[:CW FIXed].....	596
[:SOURce<hw>]:FREQuency[:CW FIXed]:RCL.....	597
[:SOURce<hw>]:ILS:GS[GSLope:PRESet.....	562
[:SOURce<hw>]:ILS:LOCalizer:COMid:CODE.....	563
[:SOURce<hw>]:ILS:LOCalizer:COMid:DASH.....	564
[:SOURce<hw>]:ILS:LOCalizer:COMid:DEPTH.....	564
[:SOURce<hw>]:ILS:LOCalizer:COMid:DOT.....	564
[:SOURce<hw>]:ILS:LOCalizer:COMid:FREQuency.....	565
[:SOURce<hw>]:ILS:LOCalizer:COMid:LETTer.....	565
[:SOURce<hw>]:ILS:LOCalizer:COMid:PERiod.....	565
[:SOURce<hw>]:ILS:LOCalizer:COMid:SYMBOL.....	565

[:SOURce<hw>]:ILS:LOCAlizer:COMid:TSCHema.....	566
[:SOURce<hw>]:ILS:LOCAlizer:COMid[:STATe].....	566
[:SOURce<hw>]:ILS:LOCAlizer:DDM:COUPling.....	566
[:SOURce<hw>]:ILS:LOCAlizer:DDM:CURRent.....	567
[:SOURce<hw>]:ILS:LOCAlizer:DDM:DIRection.....	567
[:SOURce<hw>]:ILS:LOCAlizer:DDM:LOGarithmic.....	568
[:SOURce<hw>]:ILS:LOCAlizer:DDM:PCT.....	568
[:SOURce<hw>]:ILS:LOCAlizer:DDM:POLarity.....	568
[:SOURce<hw>]:ILS:LOCAlizer:DDM:STEP.....	569
[:SOURce<hw>]:ILS:LOCAlizer:DDM[:DEPTh].....	569
[:SOURce<hw>]:ILS:LOCAlizer:FREQuency.....	569
[:SOURce<hw>]:ILS:LOCAlizer:FREQuency:MODE.....	570
[:SOURce<hw>]:ILS:LOCAlizer:FREQuency:SYNChronize[:STATe].....	551
[:SOURce<hw>]:ILS:LOCAlizer:FREQuency:SYNChronize[:STATe].....	570
[:SOURce<hw>]:ILS:LOCAlizer:ICAO:CHANnel.....	570
[:SOURce<hw>]:ILS:LOCAlizer:LLOBe[:FREQuency].....	571
[:SOURce<hw>]:ILS:LOCAlizer:MODE.....	571
[:SOURce<hw>]:ILS:LOCAlizer:PHASe.....	571
[:SOURce<hw>]:ILS:LOCAlizer:PRESet.....	572
[:SOURce<hw>]:ILS:LOCAlizer:RLOBe[:FREQuency].....	572
[:SOURce<hw>]:ILS:LOCAlizer:SDM.....	572
[:SOURce<hw>]:ILS:LOCAlizer:SOURce.....	573
[:SOURce<hw>]:ILS:PRESet.....	550
[:SOURce<hw>]:ILS:SETTing:CATalog?.....	550
[:SOURce<hw>]:ILS:SETTing:DELeTe.....	550
[:SOURce<hw>]:ILS:SETTing:LOAD.....	551
[:SOURce<hw>]:ILS:SETTing:STORe.....	551
[:SOURce<hw>]:ILS:STATe.....	551
[:SOURce<hw>]:ILS:TYPE.....	557
[:SOURce<hw>]:ILS[:GS GSLope]:DDM:COUPling.....	557
[:SOURce<hw>]:ILS[:GS GSLope]:DDM:CURRent.....	557
[:SOURce<hw>]:ILS[:GS GSLope]:DDM:DIRection.....	558
[:SOURce<hw>]:ILS[:GS GSLope]:DDM:LOGarithmic.....	558
[:SOURce<hw>]:ILS[:GS GSLope]:DDM:PCT.....	558
[:SOURce<hw>]:ILS[:GS GSLope]:DDM:POLarity.....	559
[:SOURce<hw>]:ILS[:GS GSLope]:DDM:STEP.....	559
[:SOURce<hw>]:ILS[:GS GSLope]:DDM[:DEPTh].....	559
[:SOURce<hw>]:ILS[:GS GSLope]:FREQuency.....	560
[:SOURce<hw>]:ILS[:GS GSLope]:FREQuency:MODE.....	560
[:SOURce<hw>]:ILS[:GS GSLope]:FREQuency:SYNChronize[:STATe].....	551
[:SOURce<hw>]:ILS[:GS GSLope]:FREQuency:SYNChronize[:STATe].....	560
[:SOURce<hw>]:ILS[:GS GSLope]:ICAO:CHANnel.....	561
[:SOURce<hw>]:ILS[:GS GSLope]:LLOBe[:FREQuency].....	561
[:SOURce<hw>]:ILS[:GS GSLope]:MODE.....	561
[:SOURce<hw>]:ILS[:GS GSLope]:PHASe.....	562
[:SOURce<hw>]:ILS[:GS GSLope]:SDM.....	562
[:SOURce<hw>]:ILS[:GS GSLope]:SOURce.....	563
[:SOURce<hw>]:ILS[:GS GSLope]:ULOBe[:FREQuency].....	563
[:SOURce<hw>]:INPut:MODext:COUPling<ch>.....	602
[:SOURce<hw>]:INPut:MODext:IMPedance<ch>.....	603

[:SOURce<hw>]:LFOutput:FREQuency:MANual.....	607
[:SOURce<hw>]:LFOutput:FREQuency:MODE.....	607
[:SOURce<hw>]:LFOutput:FREQuency:STARt.....	608
[:SOURce<hw>]:LFOutput:FREQuency:STOP.....	608
[:SOURce<hw>]:LFOutput:SWEep[:FREQuency]:DWEll.....	613
[:SOURce<hw>]:LFOutput:SWEep[:FREQuency]:EXECute.....	613
[:SOURce<hw>]:LFOutput:SWEep[:FREQuency]:MODE.....	613
[:SOURce<hw>]:LFOutput:SWEep[:FREQuency]:POINts.....	614
[:SOURce<hw>]:LFOutput:SWEep[:FREQuency]:RETRace.....	614
[:SOURce<hw>]:LFOutput:SWEep[:FREQuency]:RUNNing?.....	615
[:SOURce<hw>]:LFOutput:SWEep[:FREQuency]:SHAPE.....	615
[:SOURce<hw>]:LFOutput:SWEep[:FREQuency]:SPACing.....	615
[:SOURce<hw>]:LFOutput:SWEep[:FREQuency]:STEP:LOGarithmic.....	615
[:SOURce<hw>]:LFOutput:SWEep[:FREQuency]:STEP[LINear].....	616
[:SOURce<hw>]:LFOutput<ch>:PERiod?.....	606
[:SOURce<hw>]:LFOutput<ch>:SHAPE.....	610
[:SOURce<hw>]:LFOutput<ch>:SHAPE:PULSe:DCYClE.....	610
[:SOURce<hw>]:LFOutput<ch>:SHAPE:PULSe:PERiod.....	610
[:SOURce<hw>]:LFOutput<ch>:SHAPE:PULSe:WIDTh.....	611
[:SOURce<hw>]:LFOutput<ch>:SHAPE:TRAPEze:FALL.....	611
[:SOURce<hw>]:LFOutput<ch>:SHAPE:TRAPEze:HIGH.....	611
[:SOURce<hw>]:LFOutput<ch>:SHAPE:TRAPEze:PERiod.....	611
[:SOURce<hw>]:LFOutput<ch>:SHAPE:TRAPEze:RISE.....	612
[:SOURce<hw>]:LFOutput<ch>:SHAPE:TRlangle:PERiod.....	612
[:SOURce<hw>]:LFOutput<ch>:SHAPE:TRlangle:RISE.....	612
[:SOURce<hw>]:LIST:CATAlog?.....	624
[:SOURce<hw>]:LIST:DELete.....	625
[:SOURce<hw>]:LIST:DELete:ALL.....	625
[:SOURce<hw>]:LIST:DEXChange:AFILe:CATAlog?.....	627
[:SOURce<hw>]:LIST:DEXChange:AFILe:EXTEnsion.....	627
[:SOURce<hw>]:LIST:DEXChange:AFILe:SELect.....	627
[:SOURce<hw>]:LIST:DEXChange:AFILe:SEPArator:COLumn.....	628
[:SOURce<hw>]:LIST:DEXChange:AFILe:SEPArator:DECimal.....	628
[:SOURce<hw>]:LIST:DEXChange:EXECute.....	627
[:SOURce<hw>]:LIST:DEXChange:MODE.....	628
[:SOURce<hw>]:LIST:DEXChange:SELect.....	628
[:SOURce<hw>]:LIST:DWEll.....	619
[:SOURce<hw>]:LIST:DWEll:LIST.....	620
[:SOURce<hw>]:LIST:DWEll:LIST:POINts?.....	620
[:SOURce<hw>]:LIST:DWEll:MODE.....	619
[:SOURce<hw>]:LIST:FREE?.....	625
[:SOURce<hw>]:LIST:FREQuency.....	620
[:SOURce<hw>]:LIST:FREQuency:POINts?.....	621
[:SOURce<hw>]:LIST:INDEx.....	621
[:SOURce<hw>]:LIST:INDEx:STARt.....	621
[:SOURce<hw>]:LIST:INDEx:STOP.....	621
[:SOURce<hw>]:LIST:MODE.....	622
[:SOURce<hw>]:LIST:POWEr.....	622
[:SOURce<hw>]:LIST:POWEr:POINts?.....	623
[:SOURce<hw>]:LIST:RESet.....	626

[[:SOURce<hw>]:LIST:RUNNING?.....	624
[[:SOURce<hw>]:LIST:SElect.....	626
[[:SOURce<hw>]:LIST:TRIGger:EXECute.....	623
[[:SOURce<hw>]:LIST:TRIGger:SOURce.....	623
[[:SOURce<hw>]:MODulation[:ALL][::STATe].....	517
[[:SOURce<hw>]:NOISe:BANDwidth BWIDth.....	629
[[:SOURce<hw>]:NOISe:BWIDth:STATe.....	629
[[:SOURce<hw>]:NOISe:DISTRibution.....	630
[[:SOURce<hw>]:NOISe:LEVel:RELative?.....	630
[[:SOURce<hw>]:NOISe:LEVel[:ABSolute]?.....	630
[[:SOURce<hw>]:PGENerator:OUTPut:POLarity.....	631
[[:SOURce<hw>]:PGENerator:OUTPut[::STATe].....	631
[[:SOURce<hw>]:PGENerator:STATe.....	632
[[:SOURce<hw>]:PHASe.....	632
[[:SOURce<hw>]:PHASe:REFerence.....	632
[[:SOURce<hw>]:PM:DEVIation:MODE.....	532
[[:SOURce<hw>]:PM:DEVIation:SUM.....	532
[[:SOURce<hw>]:PM:MODE.....	532
[[:SOURce<hw>]:PM:RATio.....	533
[[:SOURce<hw>]:PM:SENSitivity?.....	533
[[:SOURce<hw>]:PM<ch>:SOURce.....	531
[[:SOURce<hw>]:PM<ch>:STATe.....	531
[[:SOURce<hw>]:POWER:ALC:DSensitivity.....	634
[[:SOURce<hw>]:POWER:ALC:SONCe.....	634
[[:SOURce<hw>]:POWER:ALC[::STATe].....	633
[[:SOURce<hw>]:POWER:ATTenuation:PATTenuator.....	635
[[:SOURce<hw>]:POWER:ATTenuation:RFOff:MODE.....	635
[[:SOURce<hw>]:POWER:EMF:STATe.....	635
[[:SOURce<hw>]:POWER:LBEHaviour.....	636
[[:SOURce<hw>]:POWER:LIMit[::AMPLitude].....	636
[[:SOURce<hw>]:POWER:LMODe.....	636
[[:SOURce<hw>]:POWER:MANual.....	637
[[:SOURce<hw>]:POWER:MODE.....	637
[[:SOURce<hw>]:POWER:POWER.....	638
[[:SOURce<hw>]:POWER:RANGe:LOWer?.....	641
[[:SOURce<hw>]:POWER:RANGe:UPPer?.....	641
[[:SOURce<hw>]:POWER:START.....	638
[[:SOURce<hw>]:POWER:STEP:MODE.....	639
[[:SOURce<hw>]:POWER:STEP[::INCRement].....	639
[[:SOURce<hw>]:POWER:STOP.....	638
[[:SOURce<hw>]:POWER[::LEVel][::IMMediate]:OFFSet.....	639
[[:SOURce<hw>]:POWER[::LEVel][::IMMediate]:RCL.....	640
[[:SOURce<hw>]:POWER[::LEVel][::IMMediate][::AMPLitude].....	640
[[:SOURce<hw>]:PULM:DELay.....	536
[[:SOURce<hw>]:PULM:DOUBle:DELay.....	537
[[:SOURce<hw>]:PULM:DOUBle:STATe.....	537
[[:SOURce<hw>]:PULM:DOUBle:WIDTh.....	537
[[:SOURce<hw>]:PULM:IMPedance.....	538
[[:SOURce<hw>]:PULM:MODE.....	535
[[:SOURce<hw>]:PULM:PERiod.....	536

[:SOURce<hw>]:PULM:POLarity.....	538
[:SOURce<hw>]:PULM:SOURce.....	537
[:SOURce<hw>]:PULM:STATe.....	537
[:SOURce<hw>]:PULM:THReshold.....	539
[:SOURce<hw>]:PULM:TRAIin:CATalog?.....	540
[:SOURce<hw>]:PULM:TRAIin:DELeTe.....	540
[:SOURce<hw>]:PULM:TRAIin:DEXChange:AFILe:CATalog?.....	543
[:SOURce<hw>]:PULM:TRAIin:DEXChange:AFILe:EXTension.....	543
[:SOURce<hw>]:PULM:TRAIin:DEXChange:AFILe:SElect.....	544
[:SOURce<hw>]:PULM:TRAIin:DEXChange:AFILe:SEParator:COLumn.....	543
[:SOURce<hw>]:PULM:TRAIin:DEXChange:AFILe:SEParator:DECimal.....	543
[:SOURce<hw>]:PULM:TRAIin:DEXChange:EXECute.....	544
[:SOURce<hw>]:PULM:TRAIin:DEXChange:MODE.....	542
[:SOURce<hw>]:PULM:TRAIin:DEXChange:SElect.....	544
[:SOURce<hw>]:PULM:TRAIin:OFFTime.....	541
[:SOURce<hw>]:PULM:TRAIin:OFFTime:POINts?.....	541
[:SOURce<hw>]:PULM:TRAIin:ONTime.....	541
[:SOURce<hw>]:PULM:TRAIin:ONTime:POINts?.....	541
[:SOURce<hw>]:PULM:TRAIin:REPetition.....	541
[:SOURce<hw>]:PULM:TRAIin:REPetition:POINts?.....	541
[:SOURce<hw>]:PULM:TRAIin:SElect.....	542
[:SOURce<hw>]:PULM:TRIGger:MODE.....	535
[:SOURce<hw>]:PULM:TTYPe.....	538
[:SOURce<hw>]:PULM:WIDTh.....	536
[:SOURce<hw>]:SWEep:GENeration.....	650
[:SOURce<hw>]:SWEep:MARKer:OUTPut:POLarity.....	656
[:SOURce<hw>]:SWEep:POWer:DWELI.....	649
[:SOURce<hw>]:SWEep:POWer:DWELI.....	650
[:SOURce<hw>]:SWEep:POWer:EXECute.....	654
[:SOURce<hw>]:SWEep:POWer:MODE.....	650
[:SOURce<hw>]:SWEep:POWer:POINts.....	651
[:SOURce<hw>]:SWEep:POWer:RETRace.....	654
[:SOURce<hw>]:SWEep:POWer:RUNNing?.....	654
[:SOURce<hw>]:SWEep:POWer:SHAPE.....	653
[:SOURce<hw>]:SWEep:POWer:SPACing:MODE?.....	651
[:SOURce<hw>]:SWEep:POWer:STEP[:LOGarithmic].....	651
[:SOURce<hw>]:SWEep:RESet[:ALL].....	655
[:SOURce<hw>]:SWEep[:FREQuency]:DWELI.....	652
[:SOURce<hw>]:SWEep[:FREQuency]:EXECute.....	654
[:SOURce<hw>]:SWEep[:FREQuency]:MARKer:ACTive.....	656
[:SOURce<hw>]:SWEep[:FREQuency]:MARKer<ch>:FREQuency.....	656
[:SOURce<hw>]:SWEep[:FREQuency]:MARKer<ch>:FState.....	657
[:SOURce<hw>]:SWEep[:FREQuency]:MODE.....	652
[:SOURce<hw>]:SWEep[:FREQuency]:POINts.....	653
[:SOURce<hw>]:SWEep[:FREQuency]:RETRace.....	654
[:SOURce<hw>]:SWEep[:FREQuency]:RUNNing?.....	654
[:SOURce<hw>]:SWEep[:FREQuency]:SHAPE.....	653
[:SOURce<hw>]:SWEep[:FREQuency]:SPACing.....	653
[:SOURce<hw>]:SWEep[:FREQuency]:STEP:LOGarithmic.....	655
[:SOURce<hw>]:SWEep[:FREQuency]:STEP[:LINear].....	655

[[:SOURce<hw>]:SWEep[:FREQUency]:TIME.....	655
[[:SOURce<hw>]:VOR:COMid:CODE.....	580
[[:SOURce<hw>]:VOR:COMid:DASH.....	580
[[:SOURce<hw>]:VOR:COMid:DEPTh.....	580
[[:SOURce<hw>]:VOR:COMid:DOT.....	580
[[:SOURce<hw>]:VOR:COMid:FREQUency.....	581
[[:SOURce<hw>]:VOR:COMid:LETTer.....	581
[[:SOURce<hw>]:VOR:COMid:PERiod.....	581
[[:SOURce<hw>]:VOR:COMid:SYMBol.....	582
[[:SOURce<hw>]:VOR:COMid:TSCHEMA.....	582
[[:SOURce<hw>]:VOR:COMid[:STATe].....	582
[[:SOURce<hw>]:VOR:FREQUency.....	583
[[:SOURce<hw>]:VOR:FREQUency:MODE.....	583
[[:SOURce<hw>]:VOR:ICAO:CHANnel.....	583
[[:SOURce<hw>]:VOR:MODE.....	584
[[:SOURce<hw>]:VOR:PRESet.....	550
[[:SOURce<hw>]:VOR:REFerence[:DEViation].....	585
[[:SOURce<hw>]:VOR:SETTing:CATalog?.....	550
[[:SOURce<hw>]:VOR:SETTing:DELeTe.....	550
[[:SOURce<hw>]:VOR:SETTing:LOAD.....	551
[[:SOURce<hw>]:VOR:SETTing:STORe.....	551
[[:SOURce<hw>]:VOR:SOURce.....	578
[[:SOURce<hw>]:VOR:STATe.....	551
[[:SOURce<hw>]:VOR:SUBCarrier:DEPTh.....	585
[[:SOURce<hw>]:VOR:SUBCarrier[:FREQUency].....	585
[[:SOURce<hw>]:VOR:VAR:FREQUency.....	586
[[:SOURce<hw>]:VOR:VAR[:DEPTh].....	586
[[:SOURce<hw>]:VOR[:BANGLE].....	579
[[:SOURce<hw>]:VOR[:BANGLE]:DIRection.....	579
[[:SOURce<hw>][:ILS]:MBEacon:COMid:CODE.....	573
[[:SOURce<hw>][:ILS]:MBEacon:COMid:DASH.....	573
[[:SOURce<hw>][:ILS]:MBEacon:COMid:DEPTh.....	574
[[:SOURce<hw>][:ILS]:MBEacon:COMid:DOT.....	574
[[:SOURce<hw>][:ILS]:MBEacon:COMid:FREQUency.....	574
[[:SOURce<hw>][:ILS]:MBEacon:COMid:LETTer.....	575
[[:SOURce<hw>][:ILS]:MBEacon:COMid:PERiod.....	575
[[:SOURce<hw>][:ILS]:MBEacon:COMid:SYMBol.....	575
[[:SOURce<hw>][:ILS]:MBEacon:COMid:TSCHEMA.....	576
[[:SOURce<hw>][:ILS]:MBEacon:COMid[:STATe].....	576
[[:SOURce<hw>][:ILS]:MBEacon:FREQUency.....	576
[[:SOURce<hw>][:ILS]:MBEacon:FREQUency:MODE.....	576
[[:SOURce<hw>][:ILS]:MBEacon:MARKer:FREQUency.....	577
[[:SOURce<hw>][:ILS]:MBEacon:PRESet.....	577
[[:SOURce<hw>][:ILS]:MBEacon[:MARKer]:DEPTh.....	577
[[:SOURce<hw>][:ILS]:MBEacon[:MARKer]:PULSed.....	577
*CLS.....	413
*ESE.....	413
*ESR?.....	413
*IDN?.....	413
*IST?.....	414

*OPC.....	414
*OPT?.....	414
*PRE.....	414
*PSC.....	414
*RCL.....	415
*RST.....	415
*SAV.....	415
*SRE.....	416
*STB?.....	416
*TRG.....	416
*TST?.....	416
*WAI.....	416
<subsystem>:FREQuency:SYNChronize:STATe.....	551
<subsystem>:PRESet.....	550
<subsystem>:SETTing:CATalog.....	550
<subsystem>:SETTing:DELeTe.....	550
<subsystem>:SETTing:LOAD.....	550
<subsystem>:SETTing:STORe.....	551
<subsystem>:STATe.....	551

Index

Symbols

*OPC	725
*OPC?	725
*RST	736
*WAI	725
/var/user directory	418
/var/volatile directory	418
>L	390
&LLO	390
&NREN	390
9.91E37	
Remote control	724
50 - Extern reference out of range or disconnected	709
140 - This modulation forces other modulations off	709
180 - Adjustment failed	709
182 - Adjustment data missing	709
183 - Adjustment data invalid	709
200 - Cannot access hardware	709
201 - Hardware revision out of date	709
202 - Cannot access the EEPROM	709
203 - Invalid EEPROM data	709
204 - river initialization failed	709
241 - No current list	709
242 - Unknown list type specified	709
460 - Cannot open the file	709
461 - Cannot write file	710
462 - Cannot read file	710
463 - Filename missing	710
464 - Invalid filename extension	710
465 - File contains invalid data	710

A

About	
Attenuator	197
Internal adjustments	692
Power-On/EMF	325
Reference oscillator	273
Selftests	692
UCOR	202, 203
AC supply	25
Accept	
Security settings	346
Active connections	
Remote access	369
Active elements	55
Add, change, delete	
User key action	331
Adjust	
Display and keyboard	323
Display settings	322
Keyboard settings	322
Adjustment frequency	
Reference oscillator	281
Adjustments	
All	700
Continue	701
Information	701
Last full adjustment	701
Settings	699
Advanced configuration	
LXI	376

ALC	
Detector sensitivity	202
Settings	201
State	201
All packages	
Secure update policy	340
Alphanumeric parameters	58
AM	74
Deviation mode	84
Overview	110
Ratio	85
Subsystem	518
Total deviation	85
Amplitude	
ILS glide slope	134
ILS localizer	141
Amplitude modulation	83
Depth	84
Deviation mode	84
Mode	84
Ratio	85
Sensitivity	84
Subsystem	518
Type	84
Analog modulation	
Options	74
Overview	108
Signal source	74
Annotation	
Disable amplitude display	343
Disable frequency display	342
Disable level	343
Aperture time	
Power sensors	224
Application cards	20
Application notes	20
ATN	742
Attention	742
Attenuator	
About	197
RF signal	197
Settings	198
Attenuator settings	
Level range	199
Mode	199
RF OFF mode	199
Step Attenuator below 20 GHz	199
Auto once	
Power sensors	223
Power viewer	223
Auto-negotiation	
see Autonegotiation	30
Automatic level control	
Detector sensitivity	202
Readjust internal switch position	72
Settings	201
State	201
Automation	351
Autonegotiation	
Failed	712
Failure	30
Avahi	
LAN services	345

- Average
 - Power analysis 237
- Average level
 - Power viewer 221
- Avionics standards
 - Overview 113
- B**
- Bandwidth
 - Modulation input 105
 - Noise generator 105
- Basics
 - Editor 93, 193, 208
 - Export list files 94, 211
 - Fill with sensor list files 210
 - Import list files 94, 211
- Baud rate
 - RS232 interface 367
- Bearing angle
 - VOR 124
- Block data 721
- Boolean parameters 720
- Brackets 721
- Brochures 19
- Browser settings
 - LXI 374
- Bytes order
 - Definition 443
- C**
- CALibration subsystem 428
- Carrier frequency
 - ILS glide slope 131
 - ILS localizer 138
 - ILS marker beacons 147
 - VOR 121
- Carrier frequency mode
 - ILS glide slope 131
 - ILS localizer 138
 - ILS marker beacons 147
 - VOR 121
- Case-sensitivity
 - SCPI 718
- Central storage
 - Accessing 315
- Change
 - GPIB address 380, 388
- Change password
 - Setup (security) 349
- Change user password
 - Setup (security) 348
- Check front panel
 - Key panel test 697
 - Performing 697
 - Settings 696
- Check touch panel
 - Touchscreen test 698
- Cleaning 691
- Clear
 - RF output protection 200
- Clear history
 - Undo/Redo 350
- Clear status
 - Remote 413
- Clk Syn connector 40, 43
- Clock
 - Amplitude 285
 - DC offset 286
 - Frequency 285
 - Phase, reset 286
 - Phase, set 286
 - Shape 284
- Clock synthesis 431
- Clock synthesis inverted output 283
- Clock synthesis output 283
- Close
 - Show SCPI command 393
- Colon 721
- Color
 - Power analysis 231
- COM/ID
 - ILS localizer 144
 - ILS marker beacons 149
 - VOR 125
- COM/ID code
 - ADF 154
 - ILS localizer 145
 - ILS marker beacons 150
 - VOR 126
- COM/ID dash length
 - ADF 155
 - ILS localizer 146
 - ILS marker beacons 151
 - VOR 126
- COM/ID depth
 - ADF 155
 - ILS localizer 145
 - ILS marker beacons 150
 - VOR 126
- COM/ID dot length
 - ADF 155
 - ILS localizer 146
 - ILS marker beacons 151
 - VOR 126
- COM/ID frequency
 - ADF 155
 - ILS localizer 145
 - ILS marker beacons 150
 - VOR 126
- COM/ID letter space
 - ADF 156
 - ILS localizer 146
 - VOR 127
- COM/ID letterspace
 - ILS marker beacons 151
- COM/ID period
 - ILS localizer 145, 155
 - ILS marker beacons 150
 - VOR 126
- COM/ID settings
 - ADF 154
- COM/ID state
 - ADF 154
 - ILS localizer 145
 - ILS marker beacons 150
 - VOR 125
- COM/ID symbol space
 - ADF 155
 - ILS localizer 146
 - ILS marker beacons 151
 - VOR 127

- COM/ID time schema
 - ADF 155
 - ILS localizer 146
 - ILS marker beacons 150
 - VOR 126
- Comma 721
- Command sequence
 - recommendation 736
 - Remote 416
- Commands 715
 - Brackets 721
 - Colon 721
 - Comma 721
 - Command line structure 723
 - Common 715
 - Double dagger 721
 - Instrument control 715
 - Overlapping 724
 - Question mark 721
 - Quotation mark 721
 - SCPI confirmed 715
 - Sequential 724
 - Syntax elements 721
 - Vertical stroke 721
 - White space 721
- Commands of all settings
 - SCPI list 298
- Common commands
 - Syntax 717
- Component
 - ILS 129
- Computer name
 - Changing 30
 - Syntax 30
 - Use instead of IP address 30, 32
- CONDition 730
- Configuration
 - Restoring 299
 - Restoring instrument settings 296
- Configure
 - Power analysis 229
- Configure diagram
 - Power analysis 242
- Configure gate mode
 - Power analysis 253
- Configure measurement
 - Power analysis 234
- Configure sensor
 - Power analysis 238
- Configure time mode
 - Power analysis 243
- Configuring LAN services 345
- Confirm unsigned
 - Secure update policy 340
- Confirm user password
 - Setup (security) 348, 349
- Connection fault
 - 169.254.*.* 712
- Connector
 - AC power supply 44
 - Clk Syn N 40, 43
 - EFC 43
 - Ext 40, 44
 - GPIB 42
 - IEC/IEEE 42
 - Inst Trig 43
 - LAN 42
 - LF 40, 43
 - Marker User1 43
 - Pulse Ext 40, 43
 - Pulse Sync 40, 43
 - Pulse Video 40, 43
 - Ref In 43
 - Ref Out 43
 - RF 39, 44
 - Sensor 38
 - Signal Valid 43
 - Stop 42
 - USB 38, 42
 - USB In 42
 - V/GHz X-Axis 42
 - Z-Axis 42
- Context-sensitive menu 55
- Continue
 - Internal adjustments 701
- Control bus 742
- Copy
 - Instrument settings 305
 - Several files 303, 312, 313
 - Show SCPI command 393
- Counter 704
- Coupling mode
 - AM, FM, PhiM 104
 - External modulation input 104
- Create
 - New directory 305
- Current frequency
 - Sweep 175
- Current index
 - List mode 186
- Current level
 - Sweep 175
- Cut
 - Instrument settings 305
- CW
 - Frequency 66
- CW mode
 - Output level 69
- CW signal
 - Settings 63
- D**
- Data entry 57
- Data format
 - Definition 444
- Data list
 - Access 300
 - How to access 420
 - Select, edit, new 302
- Data sheets 19
- Data valid 742
- Datasheet
 - LXI 378
- Date 695
- DAV 742
- DDM - SDM coupling
 - ILS glide slope 137
 - ILS localizer 143
- DDM current
 - ILS glide slope 136
 - ILS localizer 143

- DDM depth
 - ILS glide slope 136
 - ILS localizer 143
- DDM logarithmic
 - ILS glide slope 136
 - ILS localizer 144
- DDM percent
 - ILS glide slope 136
 - ILS localizer 144
- DDM polarity
 - ILS localizer 141
- DDM step
 - ILS glide slope 136
 - ILS localizer 143
- Deactivate RF output 278
- Deactivated licenses 335
- DEF 720
- Default directory
 - Mass memory 418
 - User data 288, 418
- Default settings 120, 129, 153
- Default values
 - Remote 415
- Define
 - User key action 331
- Delay
 - Double pulse (PULM) 90
 - PULM 90
- Delete
 - Instrument settings 305
 - List mode file 188
- Delete instrument settings 426
- Delta phase
 - RF frequency 73
- Depth of modulation polarity
 - ILS glide slope 134
- Detector sensitivity
 - Automatic level control 202
- Deviation
 - Fixed total deviation 81, 82
 - PhiM 82
- Deviation mode
 - AM 84
 - Amplitude modulation 84
 - FM 81
 - Frequency modulation 81
 - Phase modulation 82
 - PhiM 82
- Device ID 334, 681
- Device reset 417
- Device-specific commands 715
- Device-specific error messages 708
- DHCP 31
- Dialog boxes 56
- Direction
 - VOR 124
- Directory
 - Temporary data 418
 - User data 418
- Disable
 - Frequency display 342
 - Level display 343
- Display
 - Active elements 55
 - Brightness 324
 - Context-sensitive menu 55
 - Info line 55
 - Information 53
 - Keyboard layout 324
 - Lock 343
 - On-screen keypad 55
 - Overview 34
 - Power sensors 221
 - SCPI list 394
 - Screen saver 324
 - Settings 323
 - Setup 323
 - Status bar 53
 - Tab labels 55
 - Taskbar 54
 - Tile diagram 53
 - Wait time (screen saver) 324
- Display correction value
 - UCOR 206
- DISPlay subsystem 438
- Distribution
 - Noise generator 105
- DNS server 365
- DNS suffix 365
- Documentation overview 18
- Double dagger 721
- Double pulse delay
 - PULM 90
- Double pulse width
 - PULM 90
- DOWN 720
- Down frequency
 - ILS glide slope 134
- Downgrade information 705
- Factory version 705
- Min. version 705
- Dwell time
 - Sweep 177
- Dwell time mode
 - List mode 187
- E**
- Edit
 - Editor 93, 194, 209
 - List mode data 189
 - UCOR data 206
- Editor
 - Basics 93, 193, 208
 - Edit 93, 194, 209
 - Fill with sensor 194, 209
 - Goto 93, 193, 208
 - Save 93, 194, 209
 - Save as 93, 194, 209
- EFC
 - Activate 279
 - Sensitivity 280
- Electrostatic discharge 22
- EMF display
 - RF level 325
- EMI suppression 23
- Emulating front panel keys 61
- Emulation
 - IDN string 369
 - Language 368
 - Mode 369
 - Set IDN and OPT to default 369
- Enable
 - LAN interface 345

ENABLE	730	F	
Enable registers		Factory	
Remote	414	Preset	292
Enter license key	334	Factory preset	
Enter password		Change GPIB address	380
Setup (security)	346	GPIB address	388
EOI	742	Factory version	
Error log	713	Firmware	705
Error messages	710	Failure	
Adjustment data invalid (183)	709	Network connection	30
Adjustment data missing (182)	709	File	
Adjustment failed (180)	709	SCPI export	395
Cannot access hardware (200)	709	File catalog	
Cannot access the EEPROM (202)	709	List mode	188
Cannot open file (460)	709	File handling	289
Cannot read file (462)	710	File list	423
Cannot write file (461)	710	File manager	303
Driver initialization failed (204)	709	File name	317
Extern reference out of range or disconnected (50) ..	709	File select	
File contains invalid data (465)	710	Dialog	300
Filename missing (463)	710	File server	
Hardware revision out of date (201)	709	Data exchange	315
Invalid EEPROM data (203)	709	File sharing	310
Invalid filename extension (464)	710	File storage location	418
No current list (241)	709	File system	287
This modulation forces other modulations off (140) ..	709	Accessing	310
Unknown list type specified (242)	709	File transfer	289
Error Messages	707	From file server	315
device-specific	708	FTP/SAMBA	351
SCPI	708	How to	310
Error queue	731	File type selection	305
Error queue query	661, 662	Filename	
Error queues		Pulse graph	97
recommendations	736	Files	
ESD	22	User data	287
ESE (event status enable register)	732	Fill	
ESR	729	User correction data	93, 194, 209
ESR (event status register)	732	Fill table	
EVENT	730	Automatically	93, 194, 209
Event status enable register (ESE)	732	UCOR	206
Remote	413	Fill with sensor	
Event status register (ESR)	732	Basics	210
Remote	413	Editor	194, 209
Exclude frequency	298	Filter	
Exclude level	299	Power sensors	222
Execute		Filter length	
Single sweep	178	Auto	223
Trigger (list mode)	188	User-defiend	223
Expiration date of option	706	Finding out the default directory	288, 418
Export		Firmware	
Execute	96, 191, 213	Factory version	705
SCPI	302	Min. version	705
SCPI export	395	Version	705
SCPI list	394	Fixed	
SCPI settings	394	Frequency	66
Export deactivation response	334	Floating licenses	706
Export license key	335	Fly	
Export list files		ILS glide slope	135
Basics	94, 211	ILS localizer	142
Express level in		FM	74
Volts	633	Deviation	80
Ext AM		Deviation mode	81
ILS glide slope	132	Ratio	81
ILS localizer	139	Subsystem	524
VOR	122	Total deviation	81
External frequency			
Reference oscillator	278		

- Format
 - SCPI Export 395
- FORMat subsystem 443
- FPGA/μC
 - Check for updates 702
 - Shut down after update internal 703
 - Update installation internal assembly 702
 - Update table 702
- Frequency
 - Annotation disable 342
 - CW, fixed 66
 - LF generator 102
 - LF sweep 102
 - Multiplier 66
 - Offset 66
 - Power sensors 222
 - RF signal 65
 - UCOR 206
- Frequency marker
 - Activate 184
 - Boost marker x 185
 - Duration 185
 - Polarity 185
 - State 184
- Frequency modulation 80
 - Deviation mode 81
 - Ratio 81
 - Subsystem 524
- Frequency sweep
 - Sweep type 174, 183
 - V/GHz 182
 - X-Axis 182
- Frequency, internal
 - AM 102
 - FM 102
- Front panel
 - Checking 696
- Front panel test
 - Performing 697
- Front panel tour 33
- ftp
 - How to access the instrument 310
- FTP
 - LAN services 345
- Function check 27
- Function keys
 - Overview 35
- G**
- Gateway 365
- General
 - ILS glide slope 130
 - ILS localizer 137
 - ILS marker beacons 147
 - VOR 119
- General configuration of instrument 322
- General instrument settings 322
- General settings
 - ADF 152
 - ILS 127
- Generating an unmodulated signal 63
- Getting started 19
- Global dwell time
 - List mode 187
- Goto
 - Editor 93, 193, 208
- GPIO
 - Bus address 367
 - Change address 380, 388
 - Characteristics 358
 - Set up remote control 388
- GPIO address 367
 - Factory preset 388
- GUI
 - Setting 326
- GUI update
 - Setup 322
- H**
- Hard copy
 - Create, how to 320
 - File format 317, 318
 - Print, how to 320
- Hardcopy 316
 - Options 317
- Help 19, 59
- HiSLIP
 - Protocol 356
 - Resource string 354
- History
 - Undo/Redo 350
- Host name
 - see computer name 30, 32
- Hostname 364
 - LXI 373
 - see computer name 30, 32
- How to
 - Change the default directory 420
 - Use an absolute file path 420
- HTTP
 - LAN services 345
- I**
- ICAO channel
 - ILS 132
 - ILS localizer 139
 - VOR 121
- Identification
 - Emulation mode 369
 - Remote 413
- IDN string
 - Emulation mode 369
- IFC 742
- ILS
 - Glide Slope 130
 - Localizer 137
 - Marker beacons 146
- ILS component 129
- Impedance
 - External modulation source 104
- Import
 - Execute 96, 191, 213
- Import license key 334
- Import list files
 - Basics 94, 211
- Import/Export
 - Lists 189
 - Select file 96, 190, 191, 213
- Inactive licenses 335
- Index
 - List mode 186

- INF 720
- Info line 55, 710
- Information
 - Internal adjustments 701
- Input
 - Impedance external modulations 104
 - Pulse polarity 98
 - Pulse threshold 99
 - Trigger impedance 98
- Input connector 40, 43, 44
- Input connectors
 - Stop 42
- Installed assembly 704
- Instrument control 51
- Instrument emulations 362, 368
- Instrument help 19
- Instrument messages 715
- Instrument security procedures 19
- Instrument settings
 - Recall 415, 426
 - Save 415, 427
- Instrument tour 32
- Interface
 - functions (GPIB bus) 743
- Interface clear 742
- Interface messages 715, 716
- Interfaces
 - GPIB 358
 - USB 357
- Internal adjustments
 - About 692
- Interrupt 734
- Invalid results
 - Remote control 724
- IP address 354
 - Changing 31
 - Dynamic 365
 - LXI 373
 - Not recognized 712
 - Zeroconf 365
- IP address Mode 364
- IP configuration
 - LXI 375
- IST 729
- IST flag
 - Remote 414
- K**
- Key
 - ★ (User) 37, 296
 - Access on a remote computer 61
 - Arrow 37
 - Backspace 36
 - Down 37
 - Emulation 61
 - Enter 36
 - Esc 36
 - Freq 36
 - Help 35
 - Home 37
 - Left 37
 - Level 36
 - Local 35
 - Mod on/off 36, 76
 - Next window 37
 - On/Off 37
 - On/Standby 35
 - Preset 35
 - Resize window 37
 - RF on/off 36
 - Right 37
 - Setup 35
 - Up 37
- Key panel test
 - Check front panel 697
- Keyboard
 - On-screen 57
 - Setting 326
 - Settings 323
 - Setup 323
 - Subsystem 449
 - Usage 52
- Keypad
 - On-screen 57
 - Overview 36
- Keywords
 - see Mnemonics 716
- L**
- LAN
 - Interface 354
 - IP address 354
 - Reset 373
 - Services 345
 - VXI protocol 356
- LAN configuration 29
 - LXI 375
- LAN connection
 - Not working 30
- LAN interface
 - Avahi 345
 - Enable 345
 - FTP 345
 - HTTP 345
 - LAN over SCPI 345
 - SMB (Samba) 345
 - SSH 345
 - VNC 345
- LAN status
 - LXI 373
- Landing systems
 - Overview 113
- Language
 - Emulation 368
- Last factory calibration 704
- Last full adjustment
 - Internal adjustments 701
- Layout
 - Keyboard 324
- Left frequency
 - ILS localizer 141
- Left/Right phase
 - ILS localizer 141
- Level
 - Annotation disable 343
 - Behavior (RF) 70, 181
 - Noise generator 108
- Level default unit
 - Change 633
- Level in SCPI in V 633
- Level limit 70

- Level offset
 - Power sensors 222
 - RF level 70
 - State (power sensors) 222
- Level range
 - Attenuator settings 199
- Level settings
 - On start-up 325
- LF frequency sweep
 - State 100, 174
- LF generator
 - Shape 101
- LF Out
 - Overview 109
- LF output 106
 - Load impedance 107
 - Offset 107
 - Period 102
 - Pulse duty cycle 103
 - Pulse width 102
 - Shape 101
 - Source 107, 110
 - Sweep reset 178
 - Trapezoid high 103
 - Trapezoid rise, fall 103
 - Triangle rise 103
 - Voltage 107
- LF sweep
 - Frequency 102
- License for software option 706
 - Infos 706
- Limit
 - RF level 70
- List
 - Define 189
 - Range 189
 - State 186
 - Values, defining 193, 208
- List file
 - Catalog 188
- List mode
 - Create list automatically 93, 194, 209
 - Current index 186
 - Dwell time mode 187
 - Edit 189
 - Execute trigger 188
 - Export user data 96, 191, 213
 - File settings, import/export 95, 190, 212
 - Global dwell time 187
 - Import/export 95, 189, 190, 212
 - Load from file 96, 190, 213
 - Load user data 189
 - Reset 188
 - Select file 188
 - Settings 185
 - State 186
 - Trigger execute 188
 - Trigger source 187
- Load
 - Impedance 107
 - See recall 296
- Load instrument settings 415, 426
- Loading
 - Trying out 49
- Local to remote switch over 390
- Lock
 - Display 343
- LSB/MSB order
 - Definition 443
- LXI
 - Advanced configuration 376
 - Browser settings 374
 - Configuration 407
 - Datasheet 378
 - Hostname 373
 - IP address 373
 - IP configuration 375
 - LAN configuration 375
 - LAN status 373
 - MAC address 373
 - Ping 376
 - Remote trace (SCPI) 377
 - Reset (LCI) 373
 - Status settings 372
- LXI settings 372
- M**
 - Mac address 366
 - MAC address
 - LXI 373
 - Maintenance 692
 - Malfunctions
 - reacting 736
 - Manual interaction 52
 - Map network share
 - Settings 305
 - Mapping network drives/folders
 - How to 307
 - Mark frequency
 - Sweep 184
 - Marker
 - Power analysis 229
 - Marker depth
 - ILS marker beacons 148
 - Marker frequency
 - ILS marker beacons 148
 - Marker User1 43
 - Mass storage location 418
 - MAX 720
 - Maximal deviation
 - Frequency modulation 80
 - PhiM 82
 - Measurement window
 - Power analysis 228
 - Messages
 - Commands 715
 - Instrument 715
 - Instrument responses 716
 - Interface 715
 - MIN 720
 - Min. version
 - Firmware 705
 - Min/max Y scale
 - Power analysis 242
 - Minimum locking range 279
 - Mnemonics 716
 - Optional 718
 - Mode
 - AM 84
 - Attenuator settings 199
 - Emulation 369
 - Frequency modulation 81
 - IP address 364

- List 187
- PhiM 83
- PULM 87
- Pulse modulation 87
- RF level 71
- Sweep 175
- User variation 67, 72
- VOR 123
- Modulation
 - AM 77
 - Analog 74
 - Bandwidth, external input 105
 - External coupling 104
 - FM 77
 - Input impedance 104
 - Overview 108
 - Phase 77
 - PhiM 77
 - PM 77
 - Pulse 77
 - Source 80
 - State 80
- Modulation depth
 - AM 84
- Modulation sensitivity
 - AM 84
- Modulations state
 - Toggle 76
- Mount network drive
 - How to 307
- Mounting
 - Rack 25
- Mouse
 - Usage 52
- Multiple files
 - Copy 303, 312, 313
- Multiplier
 - Frequency 66
- N**
- Naming conventions
 - Allowed file names 287
- NAN 720
- NAN (not a number)
 - Remote control 724
- Navigation
 - Keys 37
- Navigation controls
 - Overview 36
- NDAC 742
- Network
 - Connection fails 712
 - Settings 363
- Network connection
 - Error 30
- Network share
 - Mapping 305
 - Mapping, how to 307
- Network status 363
- New password
 - Setup (security) 348
- New user password
 - Setup (security) 348
- NINF 720
- Noise
 - Distribution 105
 - Noise bandwidth limitation
 - System bandwidth 105
 - Noise generator
 - Bandwidth 105
 - Noise level
 - Absolute system bandwidth 108
 - Relative system bandwidth 108
 - Noise ratio
 - Power sensors 223
- NRFD 742
- NRP
 - see Power analysis 225
- NRP power viewer
 - Settings 219
 - Use S-Parameter 224
- NRP sensor mapping
 - Connector 216
 - Protocol 216
 - Scan 217
 - Sensor name 216
 - Settings 216
- NTP
 - Address 696
- NTRansition 730
- Number of licenses 706
- Numeric data entry 57
- Numeric parameters 58, 719
- Numeric values
 - Special 720
- O**
- Offset
 - Frequency 66
- Old password
 - Setup (security) 348
- Old user password
 - Setup 348
- On-screen keyboard 58
- On-screen keypad 55
- Open source acknowledgment (OSA) 20
- Open source acknowledgments 705
- Operating mode
 - ILS glide slope 133
 - ILS localizer 140
- Operation
 - Manual 52
- Operation complete
 - Remote 414
- Operation hours 704
- Operation mode 296
- Option
 - Expiration date 706
- Option: expiration date 706
- Options
 - Analog modulation 74
 - Identification (remote) 414
- Oscillator
 - Reference 273
- Output
 - Clk Syn 283
 - LF 107
 - SCPI list (select file) 395
 - Source (LF output) 110
- OUTPut
 - Subsystem 450
- Output connector 40, 43

Output connectors		
Clk Syn	40, 43	
Marker User1	43	
Pulse Sync	40, 43	
RF	39, 44	
Stop	42	
V/GHz X-Axis	42	
Z-Axis	42	
Output queue	729	
Output, LF		
Offset	107	
Voltage	107	
Overlapping commands	724	
Preventing	725	
Overview		
AM	110	
LF Out	109	
P		
Packing	692	
Parallel poll register enable		
Remote	414	
Parameters		
Block data	721	
Boolean	720	
Entering	58	
Numeric values	719	
SCPI	719	
Special numeric values	720	
String	721	
Text	721	
Parity		
RS232 interface	368	
Password		
Change (security password)	349	
Change (user password (security))	348	
Confirm (security password)	349	
Confirm (user password (security))	348	
Enter (security password)	346	
New (security password)	348	
New (user password (security))	348	
Old (security password)	348	
Old user password	348	
Protection level	338	
Password management		
Security	347	
Paste		
Instrument settings	305	
PCI bus	704	
Phase		
Subsystem	632	
Phase modulation	82	
Deviation	82	
Deviation mode	82	
Mode	83	
Ratio	82	
Subsystem	529	
Phase reference	73	
PhiM		
Deviation mode	82	
Mode	83	
Ratio	82	
Settings	82	
Total deviation	82	
Ping		
LXI	376	
PLL bandwidth	66	
PM	74	
Subsystem	529	
Polarity		
Pulse generator output	90	
Pulse modulation	98	
Position		
VOR	124	
Power		
UCOR	206	
Power analysis	225	
Access	227	
Example	229	
Options	229	
Trace settings	230	
Power Analysis Diagram		
Power analysis	228	
Power On	35	
Power sensors		
Activation	221	
Aperture time	224	
Auto once	223	
Filter	222	
Filter length	223	
Frequency	222	
Level (average)	221	
Level (peak)	221	
Level offset	222	
Noise ratio	223	
Serial number	221	
Source	222	
State	221	
State (level offset)	222	
Timeout	223	
Unit	221	
Update	219	
Use default aperture time	224	
Zero	221	
Power Sensors		
Display	221	
Power supply		
Connector	44	
Power switch	26	
Power viewer		
Auto once	223	
Power-On		
Settings	325	
Power-On count	704	
Power-On state		
RF level	325	
Power-On/EMF		
About	325	
RF signal	325	
PPE	729	
Prefix, year, month, Day	319	
Preset		
Factory preset	292	
Print		
Hard copy	320	
Protection		
Settings	338	
Setup	337	
Protection level		
1	337	
2	337	
3, 4, 5	337	
Adjustments	337	

- Calibration 337
- Factory only 337
- Protection level 338
- Service department 337
- Protocol
 - VXI 356
- PTRansition 730
- PULM
 - Delay 90
 - Double pulse delay 90
 - Double pulse width 90
 - Impedance (trigger input) 98
 - Mode 87
 - Period 89
 - Pulse polarity (input) 98
 - see PM 77
 - Source 78
 - State 78
 - Subsystem 533
 - Threshold (pulse input) 99
 - Transition type 78
 - Width 89
- Pulse
 - Duty cycle 103
 - Length (PULM) 89
 - Period 102
 - Width 102
 - Width (PULM) 89
- Pulse generator
 - Delay 90
 - Output polarity 90
 - Output state 90
 - Single Trigger 90
 - Subsystem 630
 - Width 89
- Pulse graph
 - Filename 97
 - Zoom In/Out 97
 - Zoom position 97
 - Zooming 97
- Pulse modulation 77
 - Double pulse delay 90
 - Double pulse width 90
 - Mode 87
 - Period 89
 - Pulse input threshold 99
 - Pulse polarity (input) 98
 - Repetition frequency 89
 - see PM 77
 - Select pulse train file 92
 - Source 78
 - State 78
 - Subsystem 533
 - Trigger input impedance 98
 - Trigger mode 87
- Pulse Sync connector 40, 43
- Pulse train
 - File catalog 92
 - Import/export 95, 190, 212
 - On/off time 93
 - Repetition 93
 - Select 92
- Pulsed marker
 - ILS marker beacons 148
- Q**
 - QR code 371
 - Queries 715, 723
 - Status 734
 - Question mark 721, 723
 - Questionable status register 733
 - Quotation mark 721
- R**
 - R&S signed packages
 - Secure update policy 340
 - Rack
 - Mounting 25
 - Rack installation 44
 - Radar systems
 - Overview 113
 - Radio navigation systems
 - Overview 113
 - Ratio
 - AM 85
 - Amplitude modulation 85
 - FM 81
 - Frequency modulation 81
 - Phase modulation 82
 - PhiM 82
 - Readjust
 - Automatic level control 72
 - Ready state 26
 - Recall
 - Instrument settings 299
 - Recall instrument settings 415, 426
 - Recall intermediate 299, 415
 - Recommendations
 - remote control programming 736
 - Recorded SCPI commands
 - SCPI list 394
 - Redo 349
 - Clear history 350
 - History 350
 - Settings 349
 - State 350
 - REF deviation
 - VOR 124
 - Reference frequency output
 - 1 GHz 280
 - 10 MHz, 100 MHz 280
 - Loop through 280
 - Reference oscillator 273
 - Adjustment 281
 - Adjustment frequency 281
 - External frequency 278
 - Output frequency 280
 - Preset 278
 - Reference frequency, variable 279
 - RF off state 278
 - Source 278
 - Synchronization bandwidth 279
 - Use external tuning 279
 - Registers 729
 - Release notes 20
 - Reload
 - SCPI list 395
 - Remote access 351
 - Active connections 369
 - DNS server 365

- DNS suffix 365
- GPIB address 367
- GPIB resource (Visa resource string) 366
- HILSLIP resource (Visa resource string) 366
- Identification 369
- IDN string 369
- Instrument emulations 368
- IP address mode 364
- Language 368
- Network gateway 365
- Network hostname 364
- Network IP address 365
- Network Mac address 366
- Network resource (Ethernet resource string) 366
- Network settings 363
- Network status 363
- OPT string 369
- QR code 371
- RS232 367
- see Remote operation from a computer 52
- Serial 366
- Set IDN and OPT to default 369
- Settings 362
- Socket resource (Visa resource string) 366
- Subnet mask 365
- USB Visa resource string 366
- Visa resource strings 366
- Workgroup name 364
- Remote connection
 - Not working 30
- Remote control 60
 - Basics 715
 - GPIB 388
 - Programming examples 412
 - SCPI 351
 - Source subsystem 516
- Remote operation 61
 - VNC 351
- Remote trace
 - LXI 377
- Removing sensitive data 713
- REN 742
- Rename
 - File 427
 - Instrument settings 305
- Reset
 - List mode 188
 - RF frequency (delta phase) 73
 - Sweep 178
- Reset device parameters 417
- Reset values
 - Remote 415
- Resource string
 - VISA 354
- Restoring configuration 292
- Resulting file name 319
- Retrace
 - Sweep 176
- RF connector 39, 44
- RF frequency
 - Configuring 63
- RF frequency sweep
 - State 174
- RF level
 - Configuring 63
 - EMF display 325
 - Mode 71
 - Offset 70
 - Power-On state 325
 - Setting characteristics 70, 181
 - Settings 67
- RF level sweep
 - State 174
- RF OFF mode
 - Attenuator settings 199
- RF off state
 - Reference oscillator 278
- RF ON, RF OFF, RF ON/OFF 63
- RF output
 - Amplitude 69
 - Harmonic filter 71
 - Impedance 63
 - Protection 200
 - State 63
- RF Output
 - Level range 71
- RF output signal
 - Phase 73
 - Phase reference 73
- RF phase
 - Configuring 63
- RF signal
 - Analog modulation 74
 - Attenuator 197
 - Frequency 65
 - Power-On/EMF 325
 - User correction 202
- Right frequency
 - ILS localizer 141
- Rotary knob
 - User step 286
 - User variation 67, 72
- RS232
 - Baud rate 367
 - Parity 368
 - Serial interface 367
 - Stop bits 368
- S**
 - S-Parameter
 - Activate corrections 224
 - Safety instructions 19
 - SAMBA/SMB
 - How to access the instrument 310
 - Sanitize 342
 - Save
 - Editor 93, 194, 209
 - Instrument settings 298
 - Power analysis 259
 - Save and load 296
 - Save as
 - Editor 93, 194, 209
 - Save hard copy as
 - bmp, jpg, png 317, 318
 - Save immediate 298
 - Save instrument settings 415, 427
 - Save intermediate 415
 - Save to Ref
 - Power analysis 231
 - Save/Recall 296
 - ADF 121, 129, 153
 - Dialog 296
 - How to 299

- ILS 121, 129, 153
- SCPI-Export 398
- VOR 121, 129, 153
- Saving 49
- Scan
 - NRP sensor mapping 217
- SCPI
 - Error messages 708
 - Export 302
 - Export settings 394
 - LAN services 345
 - Output file 395
 - Parameters 719
 - Syntax 717
 - Version 354
- SCPI confirmed commands 715
- SCPI export 395
 - Select file 395
 - Show file content 396
- SCPI Export
 - Format 395
- SCPI list
 - Commands of all settings 298
 - Display 394
 - Export 394
 - Recorded SCPI commands 394
 - Show all commands 298
- SCPI remote trace
 - LXI 377
- SCPI script
 - Select 331
- SCPI-Export
 - Save/Recall 398
- Screen saver
 - Activate 326
 - State 324
 - Wait time 324
- SD card slot 38
- Secure update policy
 - All packages 340
 - Confirm unsigned 340
 - R&S signed packages 340
- Security
 - Accept settings 346
 - Change password (setup) 349
 - Change user password (setup) 348
 - Confirm password (setup) 349
 - Confirm user password (setup) 348
 - Display lock 343
 - Enter password (setup) 346
 - New password (setup) 348
 - New user password (setup) 348
 - Old password (setup) 348
 - Old user password 348
 - Password management 347
 - Sanitize 342
 - Secure update policy 340
 - Security password 348
 - Settings 339
 - Setup 337
 - USB storage (setup) 341
 - User name (setup) 348
 - User password 348
 - Volatile memory 341
- Security password
 - Security 348
 - Setup 348
- Security settings 337
- Select
 - List mode data file 188
 - Setup file 331
 - User correction data file 206
- Select file 302
- Self-test
 - Remote 416
- Selftests
 - About 692
- Sensitive information
 - Protecting 288, 295
- Sequential commands 724
- Serial bus 704
- Serial interface
 - RS232 367
- Serial number 31
 - Power sensors 221
- Service manual 19
- Service request (SRQ) 731, 734
- Service request enable register (SRE) 731
 - Remote 416
- Services
 - LAN 345
- Set IDN and OPT to default
 - Emulation mode 369
- Set to default 120, 129, 153
- Set up remote control
 - GPIB 388
- Setting commands 715
- Settings
 - Active connections 369
 - ALC 201
 - AM 83
 - Attenuator 198
 - Automatic level control 201
 - Check front panel 696
 - Display 323
 - Instrument emulations 368
 - Internal adjustments 699
 - Keyboard 323
 - List mode 185
 - Managing 287
 - NRP power viewer 219
 - NRP sensor mapping 216
 - On power-on 325
 - Protection 338
 - Remote access 362
 - RF level 67
 - SCPI export 394
 - Security 339
 - UCOR 205
 - Undo/Redo 349
- Setup
 - Accept security settings 346
 - Adjusting display 322
 - Adjusting keyboard 322
 - Annotation frequency 342
 - Annotation level 343
 - Change password 348
 - Change password (security) 349
 - Confirm password 348
 - Confirm password (security) 349
 - Display lock 343
 - Enter password (security) 346
 - GUI update 322
 - Keyboard settings 323

- Layout (keyboard) 324
- New password 348
- New password (security) 348
- Old password (security) 348
- Password (protection) 338
- Performing the front panel test 697
- Protection level 338
- Screen saver 324
- Secure update policy 340
- Security password 348
- USB storage (security) 341
- User name (security) 348
- User password 348
- Wait time 324
- Setup files
 - Data exchange 315
- Setup key 322
- Shape
 - LF generator 101
 - LF output 101
 - Period 102
 - Pulse duty cycle 103
 - Pulse width 102
 - Sweep 176
 - Trapeze high 103
 - Trapezoid rise, fall 103
 - Triangle rise 103
- Shortcut to a network drives
 - How to 307
- Show
 - SCPI list 298
- Show file content
 - SCPI export 396
- Show SCPI command 393
 - Close 393
 - Copy 393
- Shutting down 27
- Signal
 - ILS glide slope 133
 - ILS localizer 139
 - ILS marker beacons 148
 - VOR 122
- Signal output
 - LF 106
- Signal source
 - Analog modulation 74
- Single
 - Execute (list mode) 188
- SMB (Samba)
 - LAN services 345
- Softkey bar
 - see Taskbar 54
- Source
 - AM, FM, Φ M 80
 - Analog modulation 74
 - LF output 107, 110
 - Power sensors 222
 - Pulse modulation 78
 - Reference oscillator 278
 - Sweep trigger 175
- Source subsystem
 - Remote control commands 516
- Spacing
 - Frequency sweep 177, 179
 - RF level sweep 181
- Span
 - Frequency sweep 179
- SRE 729
- SRE (service request enable register) 731
- SRQ 742
- SRQ (service request) 731, 734
- SSH
 - LAN services 345
- Standard settings 120, 129, 153
- Standby 26, 35
- Start
 - Frequency sweep 179
 - Power analysis 229
 - RF level sweep 181
- Starting 26
- State
 - ADF 120, 129, 153
 - Adjustment (reference oscillator) 281
 - AM, FM, Φ M 80
 - Automatic level control 201
 - Clock synthesis 284
 - DC offset 285
 - ILS 120, 129, 153
 - LF frequency sweep 100, 174
 - List mode 186
 - Power sensors 221
 - Pulse generator output 90
 - Pulse modulation 78
 - RF frequency sweep 174
 - RF level sweep 174
 - RF output 63
 - RF output protection 200
 - Screen saver 324
 - UCOR 206
 - Undo/Redo 350
 - VOR 120, 129, 153
- Status
 - Queries 734
- Status bar
 - Display 53
- Status byte
 - Remote 413, 416
- Status byte (STB) 731
- Status information 334
- Status register
 - Response format definition 443
- Status registers 729
 - CONDition 730
 - ENABLE 730
 - EVENT 730
 - model 730
 - NTRansition 730
 - parts 730
 - PTRansition 730
- Status reporting system 727
 - Application 734
 - Common commands 412
- Status settings
 - LXI 372
- STB 729
- Step
 - Frequency sweep 180
 - Linear (frequency sweep) 180
 - Logarithmic (frequency sweep) 180
 - RF level sweep 181
- Step Attenuator below 20 GHz
 - Attenuator settings 199
- Step width
 - User variation 67, 72, 286

- Stop
 - Frequency sweep 179
 - Power analysis 229
 - RF level sweep 181
- Stop bits
 - RS232 interface 368
- Stop connector 42
- Storage location
 - /usb/ 287
 - /var/user 287
 - /var/volatile 287
 - Mass memory 418
- Store
 - Save 296
- Storing 692
- Storing files 420
- String in remote commands 721
- Subcarrier depth
 - VOR 123
- Subcarrier frequency
 - VOR 123
- Subnet mask 365
- Subsystem
 - AM 518
 - FM 524
 - Keyboard 449
 - Phase 632
 - PM 529
 - Power 633
 - PULM 533
 - Pulse generator 630
- Suffixes 718
- Sum of depth
 - ILS glide slope 135
 - ILS localizer 142
- Support 713
- Sweep
 - Center frequency 179
 - Current frequency 175
 - Current level 175
 - Dwell time 177
 - Execute single 178
 - Frequency span 179
 - Mode 175
 - Reset 178
 - Retrace 176
 - Shape 176
 - Spacing 177, 179, 181
 - Start/stop frequency 179
 - Start/stop level 181
 - State (LF frequency) 100, 174
 - State (RF frequency) 174
 - State (RF level) 174
 - Step 180, 181
 - Trigger manually 178
- Sweep time
 - RF sweep 177
- Sweep type
 - Frequency sweep 174, 183
- Sync with glide slope
 - ILS 132, 139
- Sync with localizer
 - ILS 132, 139
- Synchronization bandwidth
 - Reference oscillator 279
- Syntax elements
 - SCPI 721
- Synthesizer
 - PLL bandwidth 66
- System
 - Factory preset 292
- System bandwidth
 - Noise level (absolute) 108
 - Noise level (relative) 108
- T**
- Tab labels 55
- Temperature offset
 - Internal adjustments 701
- Temporary files 288, 295
- Test
 - Check front panel 697
- Text entry 57
- Text paramters in remote commands 721
- Threshold
 - Pulse modulation 99
- Tile diagram
 - Display 53
- Time
 - UTC 695
- Timeout
 - Filter (power sensors) 223
- Tooltips
 - Show 59
- Touchscreen
 - Compared with mouse 52
 - Usage 52
- Touchscreen test
 - Perform 698
- Trace
 - Power analysis 229
- Trace indication
 - Power analysis 231
- Trace settings
 - Power analysis 244
- Traces
 - Power analysis 230
- Transition
 - PULM 78
 - Pulse modulation 78
- Trapezoid
 - High (LF generator) 103
 - Rise, fall 103
- Triangle
 - Rise 103
- Trigger
 - Event (remote) 416
 - Execute (list mode) 188
 - Power Sensors 251
 - Sweep, manually 178
- Trigger source
 - List mode 187
 - Sweep 175
- Tripped
 - RF output protection 200
- TS-USB1
 - USB adapter 367
- Turn on 26
- Type
 - AM 84

U

UCOR	
About	203
Data	206
Display correction value	206
Edit data	206
Export user data	96, 191, 213
File catalog	206
File settings, import/export	95, 190, 212
Fill with sensor	210
Import/export	95, 189, 190, 212
Load from file	96, 190, 213
RF signal	202
Select file	206
Settings	205
State	206
Values, defining	193, 208
Undo	349
Clear history	350
History	350
Settings	349
State	350
UP	720
Up frequency	
ILS glide slope	134
Up/Down phase	
ILS glide slope	134
USB	
Adapter TS-USB1	367
Interfaces	357
Storage (security)	341
Use default aperture time	
Power sensors	224
User correction	
see UCOR	202
User data	
Access	300
Load from a specific directory	420
User files	287
User interface	
Lock	343
User key	
Action name	330
Add, change, delete action	331
Define action	330, 331
SCPI command	331
Select dialog ID	331
Toggle between define and execute mode	331
User manual	19
User name	
Setup (security)	348
User password	
Security	348
Setup	348
User preset	292
User variation	
Activating	67, 72, 286
Clock synthesis	286
Level	67, 72
RF	67, 72
User-definable preset	
Recall	328
Utility keys	
Overview	35

V

V/GHz	
Frequency sweep	182
V/GHz X-Axis connector	42
VAR depth	
VOR	123
VAR/REF frequency	
VOR	123
Variable reference frequency	279
Varying	
RF frequency and level	67, 72
Version	
Firmware	705
Vertical stroke	721
VISA	354
Libraries	359
Resource string	354
Visa resource string	
Ethernet	366
GPIB	366
HISLIP	366
Serial	366
Socket	366
USB	366
Visa resource strings	366
VNC	
LAN services	345
Using in a LAN	61
Volatile memory	288, 295
Volatile mode	
Activate	341
VXI protocol	356

W

Wait	
Remote	416
Wait time	
Screen saver	324
Warnings	707, 710
White papers	20
White space	721
Wi-Fi	
WLAN	404
Width	
Double pulse (PULM)	90
PULM	89
Pulse modulation	89
Workgroup name	364

X

X-Axis	
Frequency sweep	182

Y

y-axis	
Power analysis	242

Z

Z-Axis connector	42
Zero	
Power Sensors	221
Zero - Power Sensors	470

Zeroconf	
IP address	712
Zeroconf (APIPA) protocol	31
Zoom In/Out	
Pulse graph	97
Zoom position	
Pulse graph	97
Zooming	
Pulse graph	97